
U8903B
Performance Audio Analyzer

Notices

Copyright Notice

© Keysight Technologies 2014–2024
No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies as governed by United States and international copyright laws.

Trademark

Bluetooth and the *Bluetooth* logos are trademarks owned by Bluetooth SIG, Inc., U.S.A. and licensed to Keysight Technologies.

Manual Part Number

U8903-90045

Edition

Edition 9, January 2024

Printed in:

Printed in Malaysia

Published by:

Keysight Technologies
Bayan Lepas Free Industrial Zone,
11900 Penang, Malaysia

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Declaration of Conformity

Declarations of Conformity for this product and for other Keysight products may be downloaded from the Web. Go to <http://www.keysight.com/go/conformity>. You can then search by product number to find the latest Declaration of Conformity.

U.S. Government Rights

The Software is “commercial computer software,” as defined by Federal Acquisition Regulation (“FAR”) 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement (“DFARS”) 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at <http://www.keysight.com/find/sweula>. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED “AS IS,” AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR FOR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT SHALL CONTROL.

Safety Information

CAUTION

A CAUTION notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

Safety Symbols

The following symbols on the instrument and in the documentation indicate precautions which must be taken to maintain safe operation of the instrument.

| | |
|--|--|
|  Direct current (DC) |  Alternating current (AC) |
|  Off (mains supply) |  On (mains supply) |
|  Caution, risk of electric shock |  Caution, risk of danger (refer to this manual for specific Warning or Caution information) |
|  Earth (ground) terminal |  Frame or chassis (ground) terminal |
|  Protective earth (ground) terminal |  Equipment protected throughout by double insulation or reinforced insulation |

Safety Considerations

Read the information below before using this instrument.

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards for design, manufacture, and intended use of the instrument. Keysight Technologies assumes no liability for the customer's failure to comply with these requirements.

WARNING

- Do not use the device if it is damaged. Before you use the device, inspect the casing. Look for cracks or missing plastic. Do not operate the device around explosive gas, vapor, or dust.
- Always use the device with the cables provided.
- Observe all markings on the device before establishing any connection.
- Turn off the device and application system power before connecting to the I/O terminals.
- When servicing the device, use only the specified replacement parts.
- Do not operate the device with the cover removed or loosened.
- Use only the power adapter provided by the manufacturer to avoid any unexpected hazards.
- This equipment is under measurement category as below:
DO NOT CONNECT THE CABLE TO MAINS.



Maximum working voltage: 200 Vp for altitude up to 3000 m
Maximum transient voltage: 1210 V

- Do not measure more than the rated voltage (as marked on the device).
-

CAUTION

- If the device is used in a manner not specified by the manufacturer, the device protection may be impaired.
 - Always use dry cloth to clean the device. Do not use ethyl alcohol or any other volatile liquid to clean the device.
 - Clean the case with a soft, lint-free, slightly dampened cloth. Do not use detergent, volatile liquids, or chemical solvents.
 - Do not permit any blockage of the ventilation holes of the device.
-

Environmental Conditions

The U8903B is designed for indoor use and in an area with low condensation. The table below shows the general environmental requirements for this instrument.

| Environmental condition | Requirement |
|-------------------------|---|
| Temperature | Operating condition - 0 °C to 55 °C |
| | Storage condition - -40 °C to 70 °C |
| Humidity | Operating condition - 95% RH up to 40 °C, decreases linearly to 45% RH at 55 °C (non-condensing) ^[a] |
| | Storage condition - Up to 95% RH at 40 °C (non-condensing) |
| Altitude | Up to 3000 m |
| Pollution degree | 2 |
| Installation category | II |
| Measurement category | CAT (none) 200 Vpk max |
| Overvoltage protection | II |

[a] From 40 °C to 55 °C, the maximum % Relative Humidity follows the line of constant dew point.

WARNING

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE OR WET ENVIRONMENTS
Do not operate the instrument around flammable gases or fumes, vapor, or wet environments.

Regulatory Information

The U8903B complies with the following safety and Electromagnetic Compatibility (EMC) standard:

Safety compliance

- IEC 61010-1/EN 61010-1
- Canada: CAN/CSA-C22.2 No. 61010-1-12
- USA: ANSI/UL Std. No. 61010-1

EMC compliance

- IEC 61326-1/EN61326-1
- Canada: ICES/NMB-001
- Australia/New Zealand: AS/NZS CISPR11

NOTE

Refer to Declaration of Conformity for current revisions. Go to <http://www.keysight.com/go/conformity> for more information.

Regulatory Markings

| | |
|--|---|
|  <p>The CE mark is a registered trademark of the European Community. This CE mark shows that the product complies with all the relevant European Legal Directives.</p> <p>ICES/NMB-001 indicates that this ISM device complies with the Canadian ICES-001.</p> <p>Cet appareil ISM est conforme a la norme NMB-001 du Canada.</p> |  <p>The CSA mark is a registered trademark of the Canadian Standards Association.</p> |
|  <p>This instrument complies with the WEEE Directive (2002/96/EC) marking requirement. This affixed product label indicates that you must not discard this electrical or electronic product in domestic household waste.</p> |  <p>The RCM mark is a registered trademark of the Australian Communications and Media Authority.</p> |
|  <p>This symbol is a South Korean Class A EMC Declaration. This is a Class A instrument suitable for professional use and in electromagnetic environment outside of the home.</p> |  <p>This symbol indicates the time period during which no hazardous or toxic substance elements are expected to leak or deteriorate during normal use. Forty years is the expected useful life of the product.</p> |

Waste Electrical and Electronic Equipment (WEEE) Directive 2002/96/EC

This instrument complies with the WEEE Directive (2002/96/EC) marking requirement. This affixed product label indicates that you must not discard this electrical or electronic product in domestic household waste.

Product category:

With reference to the equipment types in the WEEE directive Annex 1, this instrument is classified as a “Monitoring and Control Instrument” product.

The affixed product label is as shown below.



Do not dispose in domestic household waste.

To return this unwanted instrument, contact your nearest Keysight Service Center, or visit www.keysight.com/environment/product for more information.

Sales and Technical Support

To contact Keysight for sales and technical support, refer to the support links on the following Keysight websites:

- www.keysight.com/find/U8903B
(product-specific information and support, software and documentation updates)
- www.keysight.com/find/assist
(worldwide contact information for repair and service)

Table of Contents

| | |
|---|----|
| Safety Symbols | 3 |
| Safety Considerations | 4 |
| Environmental Conditions | 5 |
| Regulatory Information | 6 |
| Safety compliance | 6 |
| EMC compliance | 6 |
| Regulatory Markings | 7 |
| Waste Electrical and Electronic Equipment (WEEE) Directive 2002/96/EC | 8 |
| Product category: | 8 |
| Sales and Technical Support | 8 |
| 1 Getting Started | |
| Introduction | 34 |
| LXI Standard 1.4 Compliant Audio Analyzer | 34 |
| Installation and Configuration | 35 |
| Initial inspection | 35 |
| Ventilation | 35 |
| Rack mounting | 35 |
| Standard Shipped Items | 36 |
| Optional Accessories | 36 |
| U8903B Options | 37 |
| Product at a Glance | 38 |
| Front panel | 38 |
| Rear panel | 40 |
| LCD display | 42 |
| Getting Started | 44 |
| Power on the U8903B | 44 |
| Preset the U8903B | 44 |
| Access the help mode | 45 |
| Update the U8903B | 46 |
| Perform self-test | 48 |
| Add or remove U8903B options | 49 |
| 2 Operation and Features | |
| Test Capabilities | 52 |
| U8903B Block Diagram | 53 |

| | |
|--|----|
| Analog audio interface | 53 |
| Digital audio interface | 55 |
| <i>Bluetooth</i> audio interface | 56 |
| <i>Bluetooth</i> audio connection examples | 57 |
| Navigation and CHANNEL/DATA Panels | 58 |
| Menu Key | 60 |
| Standard View | 61 |
| Test Sequence Application (Test Seq App) | 62 |
| HP8903B | 62 |
| FUNCTION Panel | 63 |
| Full screen | 64 |
| Display mode | 65 |
| GRAPH Panel | 67 |
| Peak Search | 68 |
| Marker | 70 |
| Scale | 74 |
| Zoom | 75 |
| Edit zoom | 76 |
| SYSTEM Panel | 77 |
| Preset | 78 |
| Utility | 79 |
| System | 82 |
| RUN CONTROL Panel | 93 |
| Save and Recall | 94 |
| Save | 94 |
| Recall | 95 |

3 Audio Generator Functions

| | |
|---|-----|
| Audio Generator | 99 |
| Waveform Configuration | 102 |
| Sine waveform | 102 |
| Variable phase waveform | 104 |
| Dual waveform | 106 |
| SMPTE IMD waveforms (1:1/4:1/10:1) | 108 |
| DFD IEC waveforms (IEC 60118/IEC 60268) | 110 |
| Gaussian noise | 114 |
| Rectangular noise | 116 |
| Triangular noise | 118 |
| Pink noise | 119 |
| Square waveform | 121 |
| DC signal | 123 |
| Sine burst waveform | 124 |

| | |
|---|-----|
| Stereo waveform | 126 |
| Monotonicity | 127 |
| Constant value waveform | 128 |
| Walking zero | 130 |
| Walking one | 131 |
| Arbitrary waveform | 132 |
| Multitone waveform | 134 |
| Dual-Tone Multi-Frequency (DTMF) | 138 |
| Output Configuration (Analog Generator) | 141 |
| Output Configuration (Digital Generator) | 143 |
| Reference clock | 144 |
| Sync clock | 145 |
| Link Configuration (<i>Bluetooth</i> Generator) | 147 |
| Device scan | 148 |
| Device action | 149 |
| Common settings | 151 |
| A2DP settings | 154 |
| HFP settings | 155 |
| AVRCP log view | 157 |
| DSI Output Configuration (Digital Generator) | 158 |
| AES3/SPDIF Output Configuration (Digital Generator) | 160 |
| Edit Bits (Consumer format) | 161 |
| Edit Bits (Professional format) | 166 |
| References (Analog Generator) | 172 |
| References (Digital and <i>Bluetooth</i> Generator) | 173 |

4 Audio Analyzer Measurement Functions

| | |
|--|-----|
| Audio Analyzer | 177 |
| Measurement mode (Digital Analyzer) | 181 |
| Functions | 184 |
| Measurement Functions | 186 |
| Frequency measurement | 186 |
| AC voltage level measurement | 189 |
| DC voltage level measurement | 193 |
| THD+N ratio and THD+N level measurements | 196 |
| SINAD measurement | 202 |
| THD ratio and THD level measurements | 205 |
| SMPTE IMD measurements | 212 |
| DFD measurements | 215 |
| SNR measurement | 217 |
| SNR (fast mode) measurement | 219 |
| J-test measurement | 222 |

| | |
|--|-----|
| Positive peak measurement | 223 |
| Negative peak measurement | 225 |
| Phase Measurement | 227 |
| Crosstalk Measurement | 230 |
| Filters Configuration (Analog Analyzer) | 233 |
| Notch Filter | 235 |
| Filters Configuration (Digital Analyzer) | 236 |
| Filters Configuration (<i>Bluetooth</i> Analyzer) | 238 |
| Notch Filter | 239 |
| Measurement Configuration (Analog Analyzer) | 240 |
| Measurement Configuration (Digital Analyzer) | 242 |
| Measurement Configuration (<i>Bluetooth</i> Analyzer) | 244 |
| Trigger (Analog, Digital, and <i>Bluetooth</i> Analyzer) | 246 |
| Input Configuration (Analog Analyzer) | 248 |
| Input Configuration (Digital Analyzer) | 250 |
| Link Configuration (<i>Bluetooth</i> Analyzer) | 252 |
| DSI Input Configuration (Digital Analyzer) | 253 |
| AES/SPDIF Input Configuration (Digital Analyzer) | 255 |
| Bits Analysis (Digital Analyzer) | 256 |
| Wave File (Analog, Digital, and <i>Bluetooth</i> Analyzer) | 257 |
| Statistics | 259 |

5 Graph Analysis

| | |
|-----------------------------|-----|
| Graph Analysis | 262 |
| Graph Settings | 264 |
| Axis Settings | 266 |
| Trace Settings | 268 |
| Memory | 270 |
| Math | 271 |
| Persistence | 272 |
| Display Options | 273 |
| Graph | 273 |
| Data table | 274 |
| Marker table | 274 |
| Statistics | 275 |
| Harmonics | 275 |
| Signal analysis | 277 |
| Measurement Settings | 278 |
| Measurement 1/Measurement 2 | 279 |

6 Sweep Function

| | |
|-----------------|------|
| Sweep Parameter | .282 |
| Group Delay | .284 |
| Points settings | .285 |
| Sweep channels | .286 |
| Plot View | .287 |
| Axis settings | .288 |
| Plot settings | .289 |
| Edit Points | .291 |

7 Test Sequence Application

| | |
|-----------------------------|------|
| Test Sequence Application | .295 |
| Project | .297 |
| Properties | .298 |
| Test Sequence | .299 |
| IO Configuration | .300 |
| Settings | .301 |
| Properties | .308 |
| Sub-steps | .309 |
| Prompt sub-step settings | .310 |
| Send SCPI sub-step settings | .311 |
| Measurements | .312 |
| Properties | .314 |
| AC level | .315 |
| Frequency | .318 |
| Phase | .321 |
| SNR | .324 |
| THD+N | .329 |
| DC level | .333 |
| Crosstalk | .336 |
| SMPTE IMD | .339 |
| DFD IMD | .342 |
| Multitone analyzer | .345 |
| Stepped frequency sweep | .348 |
| SMPTE frequency sweep | .353 |
| DFD frequency sweep | .356 |
| External frequency sweep | .360 |
| Stepped level sweep | .365 |
| SMPTE level sweep | .370 |
| DFD level sweep | .374 |
| DC level sweep | .378 |

| | |
|----------------------|-----|
| Receiver sensitivity | 382 |
| External level sweep | 387 |
| Measurement recorder | 392 |
| Voice quality | 397 |
| Measurement Results | 401 |
| Report | 405 |
| Properties | 406 |

8 HP8903B

| | |
|----------------------------|-----|
| HP8903B | 410 |
| Measurement | 412 |
| Generator | 414 |
| Sweep | 415 |
| Special function code list | 416 |
| SPCL | 418 |
| Floating input | 418 |

9 Characteristics and Specifications

A Appendixes

| | |
|--|-----|
| Appendix 1: FUNCTION panel | 423 |
| Appendix 2: Graph Panel Menu Tree | 424 |
| Appendix 3: System Panel Menu Tree | 426 |
| Appendix 4: Analog Generator Menu Tree | 430 |
| Appendix 5: Digital Generator Menu Tree | 434 |
| Appendix 6: <i>Bluetooth</i> Generator Menu Tree | 445 |
| Appendix 7: Analog Analyzer Menu Tree | 452 |
| Appendix 8: Digital Analyzer Menu Tree | 464 |
| Appendix 9: <i>Bluetooth</i> Analyzer Menu Tree | 476 |
| Appendix 10: Graph Analysis Menu Tree | 488 |
| Appendix 11: Sweep Function Menu Tree | 492 |
| Appendix 12: Save Menu Tree | 495 |
| Appendix 13: Recall Menu Tree | 496 |
| Appendix 14: Test Sequence Menu Tree | 497 |
| Measurement settings | 505 |
| Measurement results | 550 |
| Appendix 15: HP8903B Menu Tree | 554 |
| Appendix 16: Units of the Measurement Function Returned Values | 556 |
| Analog analyzer | 556 |
| Digital analyzer | 557 |

| | |
|---|------|
| <i>Bluetooth</i> analyzer | .558 |
| Units for digital audio measurements | .560 |
| Appendix 17: Arbitrary File Format | .561 |
| Appendix 18: User-defined Filter File Format | .563 |
| Appendix 19: DSI Input and Output Interface | .566 |
| Appendix 20: Digital System Clock Distribution Block Diagram | .567 |
| Appendix 21: Typical DSI Test Configurations | .568 |
| Configuration 1 | .568 |
| Configuration 2 | .569 |
| Configuration 3 | .570 |
| Configuration 4 | .571 |
| Configuration 5 | .572 |
| Appendix 22: U8903B Configuration Examples | .573 |
| Example 1: Generating a sine waveform with the digital generator and measuring its voltage with the digital analyzer | .573 |
| Example 2: Establishing a connection to a <i>Bluetooth</i> device and generating a sine waveform with the <i>Bluetooth</i> generator. | .575 |
| Example 3: Generating a multitone waveform with the analog generator and viewing the multitone spectrum in the graph | .577 |
| Example 4: Running the Test Sequence App for the multitone analyzer measurement | 579 |
| Example 5: Configuring the system clock reference settings | .581 |
| Example 6: Configuring the digital generator DSI output settings | .582 |
| Appendix 23: Relationship between Digital Waveform Parameters and Channels | .583 |
| Appendix 24: Word Length, Sampling Rate, and Multiplier for DSI | .585 |
| Appendix 25: Word Length, Sampling Rate, and Multiplier for Master Clock In | .591 |
| Appendix 26: U8903B Default Settings | .597 |
| Analog generator | .597 |
| Analog analyzer | .598 |
| Sweep | .601 |
| HP8903B | .602 |
| System | .602 |
| Appendix 27: Procedure to Rename, Copy, Move, and Delete Files | .603 |
| Renaming a file | .603 |
| Copying a file | .603 |
| Moving a file | .603 |
| Deleting a file | .603 |
| Appendix 28: POLQA Recording Duration Analysis | .604 |
| Appendix 29: Audio Measurement Ranging | .605 |
| Manual ranging | .605 |
| Auto ranging | .605 |
| Using manual ranging for continuous sweep and frequency response measurements | 606 |

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

List of Figures

| | | |
|-------------|--|-----|
| Figure 1-1 | U8903B front panel | .38 |
| Figure 1-2 | U8903B rear panel | .40 |
| Figure 1-3 | Connect the TOSLINK cable straight into the connector | .41 |
| Figure 1-4 | U8903B LCD display | .42 |
| Figure 1-5 | Help mode | .45 |
| Figure 1-6 | System > Update menu page | .46 |
| Figure 1-7 | Recall menu page | .47 |
| Figure 1-8 | System > Service > Self-Test menu page | .48 |
| Figure 1-9 | System > Service > Options menu page | .49 |
| Figure 1-10 | Recall menu page | .50 |
| Figure 2-1 | U8903B analog generator block diagram | .53 |
| Figure 2-2 | U8903B analog analyzer block diagram | .54 |
| Figure 2-3 | U8903B digital generator and analyzer block diagram | .55 |
| Figure 2-4 | U8903B <i>Bluetooth</i> generator and analyzer block diagram | .56 |
| Figure 2-5 | Direct U8903B Bluetooth audio connection to DUT example | .57 |
| Figure 2-6 | Wireless U8903B Bluetooth audio connection to DUT example | .57 |
| Figure 2-7 | Navigation and CHANNEL/DATA panels | .58 |
| Figure 2-8 | U8903B mode selection | .60 |
| Figure 2-9 | Full screen graph display | .64 |
| Figure 2-10 | 4-panel view | .65 |
| Figure 2-11 | 10-panel view | .65 |
| Figure 2-12 | Graph analysis mode 2-panel view | .66 |
| Figure 2-13 | Peak Search menu page | .68 |
| Figure 2-14 | Peak Search > Threshold menu page | .69 |
| Figure 2-15 | Marker menu page 1 | .70 |
| Figure 2-16 | Marker > Marker - menu page | .72 |
| Figure 2-17 | Marker > Harmonics menu page | .73 |
| Figure 2-18 | Scale menu page | .74 |
| Figure 2-19 | Magnified graph display | .75 |
| Figure 2-20 | Edit zoom mode display | .76 |
| Figure 2-21 | Preset menu page | .78 |
| Figure 2-22 | Utility menu page (generator and analyzer mode) | .79 |
| Figure 2-23 | Utility menu page (graph analysis mode) | .80 |
| Figure 2-24 | File Explorer menu page | .81 |
| Figure 2-25 | System menu page 1 | .82 |
| Figure 2-26 | System > Error Info menu page (Error) | .83 |
| Figure 2-27 | System > I/O menu page | .84 |
| Figure 2-28 | System > I/O > Lan Settings menu page 1 | .85 |
| Figure 2-29 | System > Service menu page | .86 |
| Figure 2-30 | System > Settings menu page 1 | .87 |
| Figure 2-31 | System > HP8903B Config menu page | .89 |
| Figure 2-32 | System > Fan & Temperature menu page | .90 |

| | | |
|-------------|--|-----|
| Figure 2-33 | System > Aux Output menu page | 91 |
| Figure 2-34 | System > Board Info menu page | 92 |
| Figure 2-35 | RUN CONTROL panel | 93 |
| Figure 2-36 | Save menu page | 94 |
| Figure 2-37 | Recall menu page | 95 |
| Figure 3-1 | Analog Generator menu page | 99 |
| Figure 3-2 | Digital Generator menu page | 100 |
| Figure 3-3 | <i>Bluetooth</i> Generator menu page | 101 |
| Figure 3-4 | Analog Generator > Waveform Config menu page (sine waveform) | 102 |
| Figure 3-5 | Digital Generator > Waveform Config menu page (sine waveform) | 102 |
| Figure 3-6 | <i>Bluetooth</i> Generator > Waveform Config menu page (sine waveform) | 103 |
| Figure 3-7 | Analog Generator > Waveform Config menu page (variable phase waveform) | 104 |
| Figure 3-8 | Digital Generator > Waveform Config menu page (variable phase waveform) | 104 |
| Figure 3-9 | <i>Bluetooth</i> Generator > Waveform Config menu page (variable phase waveform) | 105 |
| Figure 3-10 | Analog Generator > Waveform Config menu page (dual waveform) | 106 |
| Figure 3-11 | Digital Generator > Waveform Config menu page (dual waveform) | 106 |
| Figure 3-12 | <i>Bluetooth</i> Generator > Waveform Config menu page (dual waveform) | 107 |
| Figure 3-13 | Analog Generator > Waveform Config menu page (SMPTE 1:1 waveform) | 108 |
| Figure 3-14 | Digital Generator > Waveform Config menu page (SMPTE 1:1 waveform) | 108 |
| Figure 3-15 | <i>Bluetooth</i> Generator > Waveform Config menu page (SMPTE 1:1 waveform) | 109 |
| Figure 3-16 | Analog Generator > Waveform Config menu page (IEC 60118 waveform) | 110 |
| Figure 3-17 | Digital Generator > Waveform Config menu page (IEC 60118 waveform) | 110 |
| Figure 3-18 | <i>Bluetooth</i> Generator > Waveform Config menu page (IEC 60118 waveform) | 111 |
| Figure 3-19 | Analog Generator > Waveform Config menu page (IEC 60268 waveform) | 112 |
| Figure 3-20 | Digital Generator > Waveform Config menu page (IEC 60268 waveform) | 112 |
| Figure 3-21 | <i>Bluetooth</i> Generator > Waveform Config menu page (IEC 60268 waveform) | 113 |
| Figure 3-22 | Analog Generator > Waveform Config menu page (Gaussian noise) | 114 |
| Figure 3-23 | Digital Generator > Waveform Config menu page (Gaussian noise) | 114 |
| Figure 3-24 | <i>Bluetooth</i> Generator > Waveform Config menu page (Gaussian noise) | 115 |
| Figure 3-25 | Analog Generator > Waveform Config menu page (Rectangular noise) | 116 |
| Figure 3-26 | Digital Generator > Waveform Config menu page (Rectangular noise) | 116 |
| Figure 3-27 | <i>Bluetooth</i> Generator > Waveform Config menu page (Rectangular noise) | 117 |
| Figure 3-28 | Digital Generator > Waveform Config menu page (Triangular noise) | 118 |

| | | |
|-------------|--|-----|
| Figure 3-29 | Analog Generator > Waveform Config menu page (Pink noise) | 119 |
| Figure 3-30 | Digital Generator > Waveform Config menu page (Pink noise) | 119 |
| Figure 3-31 | <i>Bluetooth</i> Generator > Waveform Config menu page (Pink noise) | 120 |
| Figure 3-32 | Analog Generator > Waveform Config menu page (square waveform) | 121 |
| Figure 3-33 | Digital Generator > Waveform Config menu page (square waveform) | 121 |
| Figure 3-34 | <i>Bluetooth</i> Generator > Waveform Config menu page (square waveform) | 122 |
| Figure 3-35 | Analog Generator > Waveform Config menu page (DC signal) | 123 |
| Figure 3-36 | Analog Generator > Waveform Config menu page (sine burst) | 124 |
| Figure 3-37 | Digital Generator > Waveform Config menu page (sine burst) | 124 |
| Figure 3-38 | <i>Bluetooth</i> Generator > Waveform Config menu page (sine burst) | 125 |
| Figure 3-39 | Digital Generator > Waveform Config menu page (stereo) | 126 |
| Figure 3-40 | Digital Generator > Waveform Config menu page (monotonicity) | 127 |
| Figure 3-41 | Digital Generator > Waveform Config menu page (constant) | 128 |
| Figure 3-42 | <i>Bluetooth</i> Generator > Waveform Config menu page (constant) | 128 |
| Figure 3-43 | Digital Generator > Waveform Config menu page (walking zero) | 130 |
| Figure 3-44 | Digital Generator > Waveform Config menu page (walking one) | 131 |
| Figure 3-45 | Analog Generator > Waveform Config menu page (arbitrary waveform) | 132 |
| Figure 3-46 | Digital Generator > Waveform Config menu page (arbitrary waveform) | 132 |
| Figure 3-47 | <i>Bluetooth</i> Generator > Waveform Config menu page (arbitrary waveform) | 133 |
| Figure 3-48 | Analog Generator > Waveform Config menu page 1 (multitone waveform) | 134 |
| Figure 3-49 | Digital Generator > Waveform Config menu page 1 (multitone waveform) | 134 |
| Figure 3-50 | <i>Bluetooth</i> Generator > Waveform Config menu page 1 (multitone waveform) | 135 |
| Figure 3-51 | Analog Generator > Waveform Config > Custom menu page 1 (multitone waveform) | 136 |
| Figure 3-52 | Digital Generator > Waveform Config > Custom menu page 1 (multitone waveform) | 136 |
| Figure 3-53 | <i>Bluetooth</i> Generator > Waveform Config > Custom menu page 1 (multitone waveform) | 137 |
| Figure 3-54 | Analog Generator > Waveform Config menu page 1 (DTMF) | 138 |
| Figure 3-55 | Dial menu page | 139 |
| Figure 3-56 | Analog Generator > Output Config menu page | 141 |
| Figure 3-57 | Digital Generator > Output Config menu page | 143 |
| Figure 3-58 | Digital Generator > Clock Config > Ref Clock menu page | 144 |
| Figure 3-59 | Digital Generator > Clock Config > Sync Clock menu page | 145 |
| Figure 3-60 | Digital Generator > Clock Config > External Clock menu page | 146 |
| Figure 3-61 | <i>Bluetooth</i> Generator > Link Config menu page | 147 |
| Figure 3-62 | <i>Bluetooth</i> Analyzer > Link Config > Device Scan menu page | 148 |
| Figure 3-63 | <i>Bluetooth</i> Analyzer > Link Config > Device Action menu page | 149 |
| Figure 3-64 | <i>Bluetooth</i> Analyzer > Link Config > Common Settings menu page 1 | 151 |
| Figure 3-65 | <i>Bluetooth</i> Analyzer > Link Config > Common Settings menu page 2 | 151 |

| | | |
|-------------|---|-----|
| Figure 3-66 | <i>Bluetooth</i> Analyzer > Link Config > Common Settings menu page 3 | 152 |
| Figure 3-67 | <i>Bluetooth</i> Analyzer > Link Config > A2DP Settings menu page | 154 |
| Figure 3-68 | <i>Bluetooth</i> Analyzer > Link Config > HFP Settings menu page | 155 |
| Figure 3-69 | <i>Bluetooth</i> Analyzer > Link Config > AVRCP log view menu page | 157 |
| Figure 3-70 | Digital Generator > DSI Config menu page 1 | 158 |
| Figure 3-71 | Digital Generator > AES Config menu page 1 | 160 |
| Figure 3-72 | Digital Generator > AES Config > Edit Bits (Consumer format) menu page 1 161 | |
| Figure 3-73 | Digital Generator > AES Config > Edit Bits (Consumer format) menu page 1 166 | |
| Figure 3-74 | Analog Generator > References menu page | 172 |
| Figure 3-75 | Digital Generator > References menu page | 173 |
| Figure 3-76 | <i>Bluetooth</i> Generator > References menu page | 173 |
| Figure 4-1 | Analog Analyzer menu page | 177 |
| Figure 4-2 | Digital Analyzer menu page (standard measurement mode) | 178 |
| Figure 4-3 | <i>Bluetooth</i> Analyzer menu page | 180 |
| Figure 4-4 | Digital Analyzer menu page (process delay measurement mode) | 181 |
| Figure 4-5 | Digital Analyzer menu page (BERT measurement mode) | 182 |
| Figure 4-6 | Analog Analyzer > Functions menu page 1 | 184 |
| Figure 4-7 | Digital Analyzer > Functions menu page 1 | 184 |
| Figure 4-8 | <i>Bluetooth</i> Analyzer > Functions menu page 1 | 185 |
| Figure 4-9 | Analog Analyzer > Functions > Frequency menu page 1 | 186 |
| Figure 4-10 | Digital Analyzer > Functions > Frequency menu page 1 | 187 |
| Figure 4-11 | <i>Bluetooth</i> Analyzer > Functions > Frequency menu page 1 | 187 |
| Figure 4-12 | Analog Analyzer > Functions > AC Voltage menu page 1 | 189 |
| Figure 4-13 | Digital Analyzer > Functions > AC Voltage menu page 1 | 190 |
| Figure 4-14 | <i>Bluetooth</i> Analyzer > Functions > AC Voltage menu page 1 | 190 |
| Figure 4-15 | Analog Analyzer > Functions > DC Voltage menu page 1 | 193 |
| Figure 4-16 | Digital Analyzer > Functions > DC Voltage menu page 1 | 194 |
| Figure 4-17 | <i>Bluetooth</i> Analyzer > Functions > DC Voltage menu page 1 | 194 |
| Figure 4-18 | Analog Analyzer > Functions > THD+N Ratio menu page 1 | 196 |
| Figure 4-19 | Digital Analyzer > Functions > THD+N Ratio menu page 1 | 197 |
| Figure 4-20 | <i>Bluetooth</i> Analyzer > Functions > THD+N Ratio menu page 1 | 197 |
| Figure 4-21 | Analog Analyzer > Functions > THD+N Level menu page 1 | 199 |
| Figure 4-22 | Digital Analyzer > Functions > THD+N Level menu page 1 | 199 |
| Figure 4-23 | <i>Bluetooth</i> Analyzer > Functions > THD+N Level menu page 1 | 200 |
| Figure 4-24 | Analog Analyzer > Functions > SINAD menu page 1 | 202 |
| Figure 4-25 | Digital Analyzer > Functions > SINAD menu page 1 | 202 |
| Figure 4-26 | <i>Bluetooth</i> Analyzer > Functions > SINAD menu page 1 | 203 |
| Figure 4-27 | Analog Analyzer > Functions > THD Ratio menu page 1 | 205 |
| Figure 4-28 | Digital Analyzer > Functions > THD Ratio menu page 1 | 206 |
| Figure 4-29 | <i>Bluetooth</i> Analyzer > Functions > THD Ratio menu page 1 | 206 |
| Figure 4-30 | Analog Analyzer > Functions > THD level menu page 1 | 208 |
| Figure 4-31 | Digital Analyzer > Functions > THD level menu page 1 | 208 |
| Figure 4-32 | <i>Bluetooth</i> Analyzer > Functions > THD level menu page 1 | 209 |
| Figure 4-33 | Analog Analyzer > Functions > SMPTE IMD menu page 1 | 212 |

| | | |
|-------------|--|------|
| Figure 4-34 | Digital Analyzer > Functions > SMPTE IMD menu page 1 | .213 |
| Figure 4-35 | <i>Bluetooth</i> Analyzer > Functions > SMPTE IMD menu page 1 | .213 |
| Figure 4-36 | Analog Analyzer > Functions > DFD 60268 2nd menu page 1 | .215 |
| Figure 4-37 | Digital Analyzer > Functions > DFD 60268 2nd menu page 1 | .215 |
| Figure 4-38 | <i>Bluetooth</i> Analyzer > Functions > DFD 60268 2nd menu page 1 | .216 |
| Figure 4-39 | Analog Analyzer > Functions > SNR menu page 1 | .217 |
| Figure 4-40 | Analog Analyzer > Functions > SNR (Fast) menu page 1 | .219 |
| Figure 4-41 | <i>Bluetooth</i> Analyzer > Functions > SNR (Fast) menu page 1 | .220 |
| Figure 4-42 | Analog Analyzer > Functions > J-Test menu page | .222 |
| Figure 4-43 | Digital Analyzer > Functions > Positive Peak menu page | .223 |
| Figure 4-44 | Digital Analyzer > Functions > Negative Peak menu page | .225 |
| Figure 4-45 | Analog Analyzer > Functions > Phase menu page | .228 |
| Figure 4-46 | Digital Analyzer > Functions > Phase menu page | .228 |
| Figure 4-47 | <i>Bluetooth</i> Analyzer > Functions > Phase menu page | .229 |
| Figure 4-48 | Analog Analyzer > Functions > X-Talk menu page 1 | .230 |
| Figure 4-49 | Digital Analyzer > Functions > X-Talk menu page 1 | .231 |
| Figure 4-50 | <i>Bluetooth</i> Analyzer > Functions > X-Talk menu page 1 | .231 |
| Figure 4-51 | Analog Analyzer > Filter Config menu page | .233 |
| Figure 4-52 | Analog Analyzer > Filter Config > Notch Filter menu page | .235 |
| Figure 4-53 | Digital Analyzer > Filter Config menu page | .236 |
| Figure 4-54 | <i>Bluetooth</i> Analyzer > Filter Config menu page | .238 |
| Figure 4-55 | <i>Bluetooth</i> Analyzer > Filter Config > Notch Filter menu page | .239 |
| Figure 4-56 | Analog Analyzer > Meas Config menu page 1 | .240 |
| Figure 4-57 | Digital Analyzer > Meas Config menu page | .242 |
| Figure 4-58 | <i>Bluetooth</i> Analyzer > Meas Config menu page | .244 |
| Figure 4-59 | Analog Analyzer > Meas Config > Trigger menu page | .246 |
| Figure 4-60 | Digital Analyzer > Meas Config > Trigger menu page | .246 |
| Figure 4-61 | <i>Bluetooth</i> Analyzer > Meas Config > Trigger menu page | .247 |
| Figure 4-62 | Analog Analyzer > Input Config menu page | .248 |
| Figure 4-63 | Digital Analyzer > Input Config menu page | .250 |
| Figure 4-64 | Digital Analyzer > DSI Config menu page 1 | .253 |
| Figure 4-65 | Digital Analyzer > AES Config menu page 1 | .255 |
| Figure 4-66 | Digital Analyzer > Bits Analysis menu page 1 | .256 |
| Figure 4-67 | Analog Analyzer > Wave File menu page | .257 |
| Figure 4-68 | Digital Analyzer > Wave File menu page | .257 |
| Figure 4-69 | <i>Bluetooth</i> Analyzer > Wave File menu page | .258 |
| Figure 4-70 | Analog Analyzer > Statistics menu page | .259 |
| Figure 4-71 | Digital Analyzer > Statistics menu page | .259 |
| Figure 4-72 | <i>Bluetooth</i> Analyzer > Statistics menu page | .260 |
| Figure 5-1 | Graph Analysis menu page | .262 |
| Figure 5-2 | Graph Analysis > Graph Settings menu page | .264 |
| Figure 5-3 | Graph Analysis > Axis Settings menu page 1 | .266 |
| Figure 5-4 | Graph Analysis > Trace Settings menu page 1 | .268 |
| Figure 5-5 | Graph Analysis > Trace Settings > Memory menu page | .270 |
| Figure 5-6 | Graph Analysis > Trace Settings > Math menu page | .271 |
| Figure 5-7 | Graph Analysis > Trace Settings > Persistence menu page | .272 |

| | | |
|-------------|--|-----|
| Figure 5-8 | Graph Analysis > Display Option > Graph menu page | 273 |
| Figure 5-9 | Graph Analysis > Display Option > DataTable menu page | 274 |
| Figure 5-10 | Graph Analysis > Display Option > Marker Table menu page | 274 |
| Figure 5-11 | Graph Analysis > Display Option > Statistics menu page | 275 |
| Figure 5-12 | Graph Analysis > Display Option > Harmonics menu page | 275 |
| Figure 5-13 | Graph Analysis > Harm Settings menu page (Harmonics display) | 276 |
| Figure 5-14 | Graph Analysis > Display Option > Signal Analysis menu page | 277 |
| Figure 5-15 | Graph Analysis > Measurement menu page | 278 |
| Figure 5-16 | Graph Analysis > Measurement > Measurement 1 menu page | 279 |
| Figure 6-1 | Sweep Parameter menu page | 282 |
| Figure 6-2 | Sweep Parameter > App. Type > Group Delay menu page | 284 |
| Figure 6-3 | Sweep Parameter > Points Settings menu page 1 | 285 |
| Figure 6-4 | Sweep Parameter > Channels menu page | 286 |
| Figure 6-5 | Sweep > Plot View menu page | 287 |
| Figure 6-6 | Sweep > Plot View > Axis Settings menu page | 288 |
| Figure 6-7 | Sweep > Plot View > Plot Settings menu page | 289 |
| Figure 6-8 | Sweep > Edit Points menu page 1 | 291 |
| Figure 7-1 | TSA > Project menu page | 295 |
| Figure 7-2 | Test Application menu page | 296 |
| Figure 7-3 | TSA > Project menu page | 297 |
| Figure 7-4 | TSA > Project > Properties menu page | 298 |
| Figure 7-5 | TSA > Project > Test menu page | 299 |
| Figure 7-6 | TSA > Project > Test > IO Configuration menu page | 300 |
| Figure 7-7 | TSA > Project > Test > IO Configuration > Output Configuration menu page (Analog) | 301 |
| Figure 7-8 | TSA > Project > Test > IO Configuration > Output Configuration menu page (Bluetooth) | 303 |
| Figure 7-9 | TSA > Project > Test > IO Configuration > Input Configuration menu page (Analog) | 304 |
| Figure 7-10 | TSA > Project > Test > IO Configuration > Input Configuration menu page (Bluetooth) | 306 |
| Figure 7-11 | Test > IO Configuration > Properties menu page | 308 |
| Figure 7-12 | Delay sub-step menu page | 309 |
| Figure 7-13 | Prompt sub-step settings menu page | 310 |
| Figure 7-14 | Send SCPI sub-step settings menu page | 311 |
| Figure 7-15 | TSA > Project > Test > AC Level menu page | 312 |
| Figure 7-16 | TSA > Project > Test > AC Level > Properties menu page | 314 |
| Figure 7-17 | TSA > Project > Test > AC Level > Settings > Signal Generation menu page | 315 |
| Figure 7-18 | TSA > Project > Test > AC Level > Settings > Signal Analysis menu page | 316 |
| Figure 7-19 | Frequency > Signal Generation settings menu page | 318 |
| Figure 7-20 | Frequency > Signal Analysis settings menu page | 320 |
| Figure 7-21 | Phase > Signal Generation settings menu page | 321 |
| Figure 7-22 | Phase > Signal Analysis settings menu page | 323 |
| Figure 7-23 | SNR > Signal Generation settings menu page | 324 |

| | | |
|-------------|---|-----|
| Figure 7-24 | SNR > Signal Analysis settings menu page | 326 |
| Figure 7-25 | THD+N > Signal Generation settings menu page | 329 |
| Figure 7-26 | THD+N > Signal Analysis settings menu page | 330 |
| Figure 7-27 | DC Level > Signal Generation settings menu page | 333 |
| Figure 7-28 | DC Level > Signal Analysis settings menu page | 335 |
| Figure 7-29 | Crosstalk > Signal Generation settings menu page | 336 |
| Figure 7-30 | Crosstalk > Signal Analysis settings menu page | 337 |
| Figure 7-31 | SMPTE IMD > Signal Generation settings menu page | 339 |
| Figure 7-32 | SMPTE IMD > Signal Analysis settings menu page | 340 |
| Figure 7-33 | DFD IMD > Signal Generation settings menu page | 342 |
| Figure 7-34 | DFD IMD > Signal Analysis settings menu page | 343 |
| Figure 7-35 | Multitone Analyzer > Signal Generation settings menu page | 345 |
| Figure 7-36 | Multitone Analyzer > Signal Analysis settings menu page | 347 |
| Figure 7-37 | Stepped Frequency Sweep > Signal Generation settings menu page | 348 |
| Figure 7-38 | Stepped Frequency Sweep > Signal Analysis settings menu page | 350 |
| Figure 7-39 | SMPTE Frequency Sweep > Signal Generation settings menu page | 353 |
| Figure 7-40 | SMPTE Frequency Sweep > Signal Analysis settings menu page | 355 |
| Figure 7-41 | DFD Frequency Sweep > Signal Generation settings menu page | 356 |
| Figure 7-42 | DFD Frequency Sweep > Signal Analysis settings menu page | 358 |
| Figure 7-43 | External Frequency Sweep > Signal Generation settings menu page | 360 |
| Figure 7-44 | External Frequency Sweep > Signal Analysis settings menu page | 362 |
| Figure 7-45 | Stepped Level Sweep > Signal Generation settings menu page | 365 |
| Figure 7-46 | Stepped Level Sweep > Signal Analysis settings menu page | 367 |
| Figure 7-47 | SMPTE Level Sweep > Signal Generation settings menu page | 370 |
| Figure 7-48 | SMPTE Level Sweep > Signal Analysis settings menu page | 372 |
| Figure 7-49 | DFD Level Sweep > Signal Generation settings menu page | 374 |
| Figure 7-50 | DFD Level Sweep > Signal Analysis settings menu page | 376 |
| Figure 7-51 | DC Level Sweep > Signal Generation settings menu page | 378 |
| Figure 7-52 | DC Level Sweep > Signal Analysis settings menu page | 379 |
| Figure 7-53 | General setup for the receiver sensitivity measurement | 382 |
| Figure 7-54 | Receiver Sensitivity > Signal Generation settings menu page | 383 |
| Figure 7-55 | Receiver Sensitivity > Signal Analysis settings menu page | 384 |
| Figure 7-56 | External Level Sweep > Signal Generation settings menu page | 387 |
| Figure 7-57 | External Level Sweep > Signal Analysis settings menu page | 389 |
| Figure 7-58 | Measurement Recorder > Signal Generation settings menu page | 393 |
| Figure 7-59 | Measurement Recorder > Signal Analysis settings menu page | 394 |
| Figure 7-60 | Voice Quality > Signal Generation and Analysis settings menu page | 398 |
| Figure 7-61 | AC Level > Settings > Result (AC level) menu page | 401 |
| Figure 7-62 | Multitone Analyzer > Settings > Result (Spectrum) menu page | 402 |
| Figure 7-63 | TSA > Report menu page | 405 |
| Figure 7-64 | TSA > Report > Properties menu page | 406 |
| Figure 7-65 | Select Path menu page | 407 |
| Figure 8-1 | HP8903B menu page | 410 |
| Figure 8-2 | HP8903B > Measurement menu page | 412 |
| Figure 8-3 | HP8903B > Generator menu page | 414 |
| Figure 8-4 | HP8903B > Sweep menu page | 415 |

| | | |
|-------------|--|-----|
| Figure 8-5 | HP8903B > Code List menu page (Input Level Range (except DC Level)) | 416 |
| Figure A-1 | Analog Generator > Waveform Config > Info menu page (arbitrary waveform) | 561 |
| Figure A-2 | 25-pin female D-SUB connector | 566 |
| Figure A-3 | Digital system clock distribution block diagram | 567 |
| Figure A-4 | DSI test configuration 1 | 568 |
| Figure A-5 | DSI test configuration 2 | 569 |
| Figure A-6 | DSI test configuration 3 | 570 |
| Figure A-7 | DSI test configuration 4 | 571 |
| Figure A-8 | DSI test configuration 5 | 572 |
| Figure A-9 | Digital generator sine waveform generation | 573 |
| Figure A-10 | Digital analyzer voltage measurement | 574 |
| Figure A-11 | <i>Bluetooth</i> generator sine waveform generation | 576 |
| Figure A-12 | Analog analyzer multitone waveform measurement | 578 |
| Figure A-13 | Graph analysis for multitone spectrum | 578 |
| Figure A-14 | Test Sequence App result for multitone analyzer | 579 |
| Figure A-15 | Test Sequence App report for multitone analyzer | 580 |

List of Tables

| | | |
|------------|---|------|
| Table 1-1 | U8903B optional accessories | .36 |
| Table 1-2 | U8903B options | .37 |
| Table 1-3 | U8903B front panel description | .38 |
| Table 1-4 | U8903B rear panel description | .40 |
| Table 1-5 | U8903B LCD display description | .43 |
| Table 1-6 | System > Update menu page | .46 |
| Table 1-7 | System > Service > Self-Test menu page | .48 |
| Table 1-8 | System > Service > Options menu page | .49 |
| Table 2-1 | Navigation and CHANNEL/DATA panels description | .58 |
| Table 2-2 | U8903B modes description | .60 |
| Table 2-3 | FUNCTION panel description | .63 |
| Table 2-4 | GRAPH panel description | .67 |
| Table 2-5 | Peak Search menu description | .68 |
| Table 2-6 | Peak Search > Threshold menu description | .69 |
| Table 2-7 | Marker menu description | .70 |
| Table 2-8 | Marker > Marker - menu description | .72 |
| Table 2-9 | Marker > Harmonics menu description | .73 |
| Table 2-10 | Scale menu description | .74 |
| Table 2-11 | SYSTEM panel description | .77 |
| Table 2-12 | Preset menu description | .78 |
| Table 2-13 | Utility menu description (generator and analyzer mode) | .79 |
| Table 2-14 | Utility menu description (graph analysis mode) | .80 |
| Table 2-15 | File Explorer menu description | .81 |
| Table 2-16 | Error Info menu description | .83 |
| Table 2-17 | I/O menu description | .84 |
| Table 2-18 | System > I/O > Lan Settings menu description | .85 |
| Table 2-19 | System > Service menu description | .86 |
| Table 2-20 | System > Settings menu description | .87 |
| Table 2-21 | System > HP8903B Config menu description | .89 |
| Table 2-22 | System > Aux Output menu description | .91 |
| Table 2-23 | Navigation and CHANNEL/DATA panels description | .93 |
| Table 2-24 | Save menu description | .94 |
| Table 2-25 | Recall menu description | .95 |
| Table 3-1 | Analog Generator menu description | .99 |
| Table 3-2 | Digital Generator menu description | .100 |
| Table 3-3 | <i>Bluetooth</i> Generator menu description | .101 |
| Table 3-4 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (sine waveform) | .103 |
| Table 3-5 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (variable phase waveform) | .105 |
| Table 3-6 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (dual waveform) | .107 |

| | | |
|------------|---|-----|
| Table 3-7 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (SMPTE IMD waveforms) | 109 |
| Table 3-8 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (IEC 60118 waveform) | 111 |
| Table 3-9 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (IEC 60268 waveform) | 113 |
| Table 3-10 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (Gaussian noise) | 115 |
| Table 3-11 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (Rectangular noise) | 117 |
| Table 3-12 | Digital Generator > Waveform Config menu description (Triangular noise) | 118 |
| Table 3-13 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (Pink noise) | 120 |
| Table 3-14 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (square waveform) | 122 |
| Table 3-15 | Analog Generator > Waveform Config menu description (DC signal) | 123 |
| Table 3-16 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (sine burst) | 125 |
| Table 3-17 | Digital Generator > Waveform Config menu description (stereo) | 126 |
| Table 3-18 | Digital Generator > Waveform Config menu description (monotonicity) | 127 |
| Table 3-19 | Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (constant) | 129 |
| Table 3-20 | Digital Generator > Waveform Config menu description (walking zero) | 130 |
| Table 3-21 | Digital Generator > Waveform Config menu description (walking one) | 131 |
| Table 3-22 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (arbitrary waveform) | 133 |
| Table 3-23 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config menu description (multitone waveform) | 135 |
| Table 3-24 | Analog/Digital/ <i>Bluetooth</i> Generator > Waveform Config > Custom menu description (multitone waveform) | 137 |
| Table 3-25 | Analog Generator > Waveform Config menu description (DTMF) | 139 |
| Table 3-26 | Dial menu page description | 140 |
| Table 3-27 | DTMF tone mapping | 140 |
| Table 3-28 | Analog Generator > Output Config menu description | 141 |
| Table 3-29 | Digital Generator > Output Config menu description | 143 |
| Table 3-30 | Digital Generator > Clock Config > Ref Clock menu description | 144 |
| Table 3-31 | Digital Generator > Clock Config > Sync Clock menu description | 145 |
| Table 3-32 | Digital Generator > Clock Config > External Clock menu description | 146 |
| Table 3-33 | <i>Bluetooth</i> Generator > Link Config menu description | 147 |
| Table 3-34 | <i>Bluetooth</i> Analyzer > Link Config > Device Scan menu description | 148 |
| Table 3-35 | | 149 |
| Table 3-36 | <i>Bluetooth</i> Analyzer > Link Config > Common Settings menu description | 152 |
| Table 3-37 | <i>Bluetooth</i> Analyzer > Link Config > A2DP Settings menu description | 154 |

| | | |
|------------|---|-----|
| Table 3-38 | <i>Bluetooth</i> Analyzer > Link Config > HFP Settings menu description | 155 |
| Table 3-39 | <i>Bluetooth</i> Analyzer > Link Config > AVRCP log view menu description | 157 |
| Table 3-40 | Digital Generator > DSI Output Config menu description | 158 |
| Table 3-41 | Digital Generator > AES Config menu description | 160 |
| Table 3-42 | Digital Generator > AES Config > Edit Bits (Consumer format) menu description | 161 |
| Table 3-43 | AES3/SPDIF Consumer mode bit description | 164 |
| Table 3-44 | Digital Generator > AES Config > Edit Bits (Professional format) menu description | 166 |
| Table 3-45 | AES3/SPDIF Professional mode bit description | 169 |
| Table 3-46 | Analog Generator > References menu description | 172 |
| Table 3-47 | Digital/ <i>Bluetooth</i> Generator > References menu description | 173 |
| Table 4-1 | Analog Analyzer menu description | 178 |
| Table 4-2 | Digital Analyzer menu description | 179 |
| Table 4-3 | <i>Bluetooth</i> Analyzer menu description | 180 |
| Table 4-4 | Digital Analyzer > Meas Mode > BERT menu description | 183 |
| Table 4-5 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions menu description | 185 |
| Table 4-6 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > Frequency menu description | 187 |
| Table 4-7 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > AC Voltage menu description | 191 |
| Table 4-8 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > DC Voltage menu description | 195 |
| Table 4-9 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > THD+N Ratio menu description | 198 |
| Table 4-10 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > THD+N Level menu description | 200 |
| Table 4-11 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > SINAD menu description | 203 |
| Table 4-12 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > THD Ratio menu description | 206 |
| Table 4-13 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > THD Level menu description | 209 |
| Table 4-14 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > SMPTE IMD menu description | 214 |
| Table 4-15 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > DFD measurements menu description | 216 |
| Table 4-16 | Analog Analyzer > Functions > SNR menu description | 218 |
| Table 4-17 | Analog/ <i>Bluetooth</i> Analyzer > Functions > SNR (Fast) menu description | 220 |
| Table 4-18 | Digital Analyzer > Functions > Positive Peak menu description | 223 |
| Table 4-19 | Digital Analyzer > Functions > Negative Peak menu description | 225 |
| Table 4-20 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > Phase menu description | 229 |
| Table 4-21 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Functions > X-Talk menu description | 231 |

| | | |
|------------|--|-----|
| Table 4-22 | Analog Analyzer > Filter Config menu description | 233 |
| Table 4-23 | Analog Analyzer > Filter Config > Notch Filter menu description | 235 |
| Table 4-24 | Digital Analyzer > Filter Config menu description | 236 |
| Table 4-25 | <i>Bluetooth</i> Analyzer > Filter Config menu description | 238 |
| Table 4-26 | <i>Bluetooth</i> Analyzer > Filter Config > Notch Filter menu description | 239 |
| Table 4-27 | Analog Analyzer > Meas Config menu description | 240 |
| Table 4-28 | Digital Analyzer > Meas Config menu description | 242 |
| Table 4-29 | <i>Bluetooth</i> Analyzer > Meas Config menu description | 244 |
| Table 4-30 | Digital Analyzer > Meas Config > Trigger menu description | 247 |
| Table 4-31 | Analog Analyzer > Input Config menu description | 248 |
| Table 4-32 | Digital Analyzer > Input Config menu description | 250 |
| Table 4-33 | Digital Analyzer > DSI Config menu description | 253 |
| Table 4-34 | Digital Analyzer > AES Config menu description | 255 |
| Table 4-35 | Digital Analyzer > Bits Analysis menu description | 256 |
| Table 4-36 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Wave File menu description | 258 |
| Table 4-37 | Analog/Digital/ <i>Bluetooth</i> Analyzer > Statistics menu description | 260 |
| Table 5-1 | Graph Analysis menu description | 263 |
| Table 5-2 | Graph Analysis > Graph Settings menu description | 264 |
| Table 5-3 | Graph Analysis > Axis Settings menu description | 266 |
| Table 5-4 | Graph Analysis > Trace Settings menu description | 268 |
| Table 5-5 | Graph Analysis > Trace Settings > Memory menu description | 270 |
| Table 5-6 | Graph Analysis > Trace Settings > Math menu description | 271 |
| Table 5-7 | Graph Analysis > Trace Settings > Persistence menu description | 272 |
| Table 5-8 | Graph Analysis > Harm Settings menu description (Harmonics display) | 276 |
| Table 5-9 | Graph Analysis > Measurement menu description | 278 |
| Table 5-10 | Graph Analysis > Measurement > Measurement 1/Measurement 2 menu description | 279 |
| Table 6-1 | Sweep Parameter menu description | 283 |
| Table 6-2 | Sweep Parameter > Points Settings menu description | 285 |
| Table 6-3 | Sweep Parameter > Channels menu description | 286 |
| Table 6-4 | Sweep > Plot View menu description | 287 |
| Table 6-5 | Sweep > Plot View > Axis Settings menu description | 288 |
| Table 6-6 | Sweep > Plot View > Plot Settings menu description | 289 |
| Table 6-7 | Sweep > Edit Points menu description | 291 |
| Table 7-1 | Test Application menu description | 296 |
| Table 7-2 | TSA > Project menu description | 297 |
| Table 7-3 | TSA > Project > Properties menu description | 298 |
| Table 7-4 | TSA > Project > Test menu description | 299 |
| Table 7-5 | TSA > Project > Test > IO Configuration menu description | 300 |
| Table 7-6 | TSA > Project > Test > IO Configuration > Output Configuration menu description (Analog) | 302 |
| Table 7-7 | TSA > Project > Test > IO Configuration > Output Configuration menu description (<i>Bluetooth</i>) | 303 |
| Table 7-8 | TSA > Project > Test > IO Configuration > Input Configuration menu description (Analog) | 304 |

| | | |
|------------|---|-----|
| Table 7-9 | TSA > Project > Test > IO Configuration > Input Configuration menu description (<i>Bluetooth</i>) | 306 |
| Table 7-10 | TSA > Project > Test > IO Configuration > Properties menu description | 308 |
| Table 7-11 | Sub-step menu description | 309 |
| Table 7-12 | Prompt sub-step settings menu description | 310 |
| Table 7-13 | Send SCPI sub-step settings menu description | 311 |
| Table 7-14 | TSA > Project > Test > Measurement menu description | 312 |
| Table 7-15 | TSA > Project > Test > Measurement > Properties menu description | 314 |
| Table 7-16 | TSA > Project > Test > AC Level > Settings > Signal Generation menu description | 316 |
| Table 7-17 | TSA > Project > Test > AC Level > Settings > Signal Analysis menu description | 317 |
| Table 7-18 | Frequency > Signal Generation settings menu description | 319 |
| Table 7-19 | Frequency > Signal Analysis settings menu description | 320 |
| Table 7-20 | Phase > Signal Generation settings menu description | 322 |
| Table 7-21 | Phase > Signal Analysis settings menu description | 323 |
| Table 7-22 | SNR > Signal Generation settings menu description | 325 |
| Table 7-23 | SNR > Signal Analysis settings menu description | 326 |
| Table 7-24 | THD+N > Signal Generation settings menu description | 330 |
| Table 7-25 | THD+N > Signal Analysis settings menu description | 331 |
| Table 7-26 | DC Level > Signal Generation settings menu description | 334 |
| Table 7-27 | DC Level > Signal Analysis settings menu description | 335 |
| Table 7-28 | Crosstalk > Signal Generation settings menu description | 337 |
| Table 7-29 | Crosstalk > Signal Analysis settings menu description | 338 |
| Table 7-30 | SMPTE IMD > Signal Generation settings menu description | 340 |
| Table 7-31 | SMPTE IMD > Signal Analysis settings menu description | 341 |
| Table 7-32 | DFD IMD > Signal Generation settings menu description | 343 |
| Table 7-33 | DFD IMD > Signal Analysis settings menu description | 344 |
| Table 7-34 | Multitone Analyzer > Signal Generation settings menu description | 346 |
| Table 7-35 | Multitone Analyzer > Signal Analysis settings menu description | 347 |
| Table 7-36 | Stepped Frequency Sweep > Signal Generation settings menu description | 349 |
| Table 7-37 | Stepped Frequency Sweep > Signal Analysis settings menu description | 350 |
| Table 7-38 | SMPTE Frequency Sweep > Signal Generation settings menu description | 354 |
| Table 7-39 | SMPTE Frequency Sweep > Signal Analysis settings menu description | 355 |
| Table 7-40 | DFD Frequency Sweep > Signal Generation settings menu description | 357 |
| Table 7-41 | DFD Frequency Sweep > Signal Analysis settings menu description | 358 |
| Table 7-42 | External Frequency Sweep > Signal Generation settings menu description | 360 |
| Table 7-43 | External Frequency Sweep > Signal Analysis settings menu description | 362 |
| Table 7-44 | Stepped Level Sweep > Signal Generation settings menu description | 366 |
| Table 7-45 | Stepped Level Sweep > Signal Analysis settings menu description | 367 |
| Table 7-46 | SMPTE Level Sweep > Signal Generation settings menu description | 371 |

| | | |
|------------|---|-----|
| Table 7-47 | SMPT E Level Sweep > Signal Analysis settings menu description | 372 |
| Table 7-48 | DFD Level Sweep > Signal Generation settings menu description | 375 |
| Table 7-49 | DFD Level Sweep > Signal Analysis settings menu description | 376 |
| Table 7-50 | DC Level Sweep > Signal Generation settings menu description | 379 |
| Table 7-51 | DC Level Sweep > Signal Analysis settings menu description | 380 |
| Table 7-52 | Receiver Sensitivity > Signal Generation settings menu description . . | 383 |
| Table 7-53 | Receiver Sensitivity > Signal Analysis settings menu description | 384 |
| Table 7-54 | External Level Sweep > Signal Generation settings menu description . | 387 |
| Table 7-55 | Stepped Level Sweep > Signal Analysis settings menu description . . . | 389 |
| Table 7-56 | Measurement Recorder > Signal Generation settings menu description . . | 393 |
| Table 7-57 | Measurement Recorder > Signal Analysis settings menu description . | 394 |
| Table 7-58 | Voice Quality > Signal Generation and Analysis settings menu description | 398 |
| Table 7-59 | TSA > Project > Test > Measurement > Settings > Result (bar chart) menu description | 401 |
| Table 7-60 | TSA > Project > Test > Measurement > Settings > Result (graph) menu description | 403 |
| Table 7-61 | TSA > Report menu description | 405 |
| Table 7-62 | TSA > Report > Properties menu description | 406 |
| Table 8-1 | U8903B LCD display description | 411 |
| Table 8-2 | HP8903B > Measurement menu description | 412 |
| Table 8-3 | HP8903B unit charts | 413 |
| Table 8-4 | HP8903B > Generator menu description | 414 |
| Table 8-5 | HP8903B > Sweep menu description | 415 |
| Table 8-6 | HP8903B special function code list description | 416 |
| Table 8-7 | Floating input settings | 418 |
| Table 8-8 | Floating output settings | 418 |
| Table 8-9 | Floating output settings and special functions to change the generator impedance | 418 |
| Table A-1 | FUNCTION panel description | 423 |
| Table A-2 | GRAPH panel menu tree description | 424 |
| Table A-3 | SYSTEM panel menu tree description | 426 |
| Table A-4 | Analog generator menu tree description | 430 |
| Table A-5 | Digital generator menu tree description | 434 |
| Table A-6 | <i>Bluetooth</i> generator menu tree description | 445 |
| Table A-7 | Analog analyzer menu tree description | 452 |
| Table A-8 | Digital analyzer menu tree description | 464 |
| Table A-9 | <i>Bluetooth</i> analyzer menu tree description | 476 |
| Table A-10 | Graph analysis menu tree description | 488 |
| Table A-11 | Sweep function menu tree description | 492 |
| Table A-12 | Save menu tree description | 495 |
| Table A-13 | Recall menu tree description | 496 |
| Table A-14 | Test sequence menu tree description | 497 |
| Table A-15 | Measurement settings > AC Level menu tree description | 505 |
| Table A-16 | Measurement settings > Frequency menu tree description | 507 |

| | | |
|------------|---|-----|
| Table A-17 | Measurement settings > Phase menu tree description | 508 |
| Table A-18 | Measurement settings > SNR menu tree description | 509 |
| Table A-19 | Measurement settings > THD+N menu tree description | 512 |
| Table A-20 | Measurement settings > DC Level menu tree description | 514 |
| Table A-21 | Measurement settings > Crosstalk menu tree description | 515 |
| Table A-22 | Measurement settings > SMPTE IMD menu tree description | 516 |
| Table A-23 | Measurement settings > DFD IMD menu tree description | 517 |
| Table A-24 | Measurement settings > Multitone Analyzer menu tree description | 518 |
| Table A-25 | Measurement settings > Stepped Frequency Sweep menu tree description | 520 |
| Table A-26 | Measurement settings > SMPTE Frequency Sweep menu tree description | 523 |
| Table A-27 | Measurement settings > DFD Frequency Sweep menu tree description | 525 |
| Table A-28 | Measurement settings > External Frequency Sweep menu tree description | 527 |
| Table A-29 | Measurement settings > Stepped Level Sweep menu tree description | 530 |
| Table A-30 | Measurement settings > SMPTE Level Sweep menu tree description | 533 |
| Table A-31 | Measurement settings > DFD Level Sweep menu tree description | 535 |
| Table A-32 | Measurement settings > DC Level Sweep menu tree description | 537 |
| Table A-33 | Measurement settings > Receiver Sensitivity menu tree description | 539 |
| Table A-34 | Measurement settings > External Level Sweep menu tree description | 542 |
| Table A-35 | Measurement settings > Measurement Recorder menu tree description | 545 |
| Table A-36 | Measurement settings > Voice Quality menu tree description | 548 |
| Table A-37 | Measurement Results > Bar chart menu tree description | 550 |
| Table A-38 | Measurement results > Graph menu tree description | 551 |
| Table A-39 | HP8903B menu tree description | 554 |
| Table A-40 | Analog analyzer units of the measurement function returned values | 556 |
| Table A-41 | Digital analyzer units of the measurement function returned values | 557 |
| Table A-42 | Bluetooth analyzer units of the measurement function returned values | 558 |
| Table A-43 | Unit conversion formula | 559 |
| Table A-44 | Units for digital audio measurements | 560 |
| Table A-45 | Allowable range for arbitrary file parameters | 561 |
| Table A-46 | 25-pin female D-SUB connector pins assignment | 566 |
| Table A-47 | Relationship between digital waveform parameters and channels | 583 |
| Table A-48 | Word Length, Sampling Rate, and Multiplier for DSI | 585 |
| Table A-49 | Word Length, Sampling Rate, and Multiplier for Master Clock In | 591 |
| Table A-50 | Analog generator default settings | 597 |
| Table A-51 | Analog analyzer default settings | 598 |
| Table A-52 | Sweep default settings | 601 |
| Table A-53 | HP8903B default settings | 602 |
| Table A-54 | System default settings | 602 |
| Table A-55 | U8903B option configuration | 604 |
| Table A-56 | Maximum wave file recording duration for the POLQA narrowband and super-wideband analysis | 604 |

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

Keysight U8903B
Performance Audio Analyzer
User's Guide

1 Getting Started

| | |
|---|----|
| Introduction | 34 |
| LXI Standard 1.4 Compliant Audio Analyzer | 34 |
| Installation and Configuration | 35 |
| Initial inspection | 35 |
| Ventilation | 35 |
| Rack mounting | 35 |
| Standard Shipped Items | 36 |
| Optional Accessories | 36 |
| U8903B Options | 37 |
| Product at a Glance | 38 |
| Front panel | 38 |
| Rear panel | 40 |
| LCD display | 42 |
| Getting Started | 44 |
| Power on the U8903B | 44 |
| Preset the U8903B | 44 |
| Access the help mode | 45 |
| Update the U8903B | 46 |
| Perform self-test | 48 |
| Add or remove U8903B options | 49 |

This chapter teaches you how to set up the U8903B for the first time. A summary of all the features of the U8903B is also given.

Introduction

The U8903B is a digital signal processing (DSP)-based audio measurement system with a frequency measurement range of 10 Hz to 96 kHz or 1.5 MHz depending on the installed option. The U8903B basic configuration has two channels of analog audio generator and two channels of analog audio analyzer.

The standard option for the U8903B performance audio analyzer is Option STD. The U8903B can be further expanded with additional analog analyzer channels; digital audio interfaces like the AES3, SPDIF, and Digital Serial Interface (DSI); and *Bluetooth*[®] audio option with source and sink interface. Refer to “**U8903B Options**” on page 37 for more information on the available U8903B options.

The U8903B is capable of performing a wide range of audio parameter measurements on the analog, digital, and *Bluetooth* audio interfaces. Up to four measurement functions can be performed simultaneously on the analog audio. Measurement functions can be performed simultaneously on the analog audio and digital audio interfaces such as analog audio + AES3/SPDIF, analog audio + DSI, and AES3/SPDIF + DSI. The *Bluetooth* audio interface provides the U8903B with *Bluetooth* link capabilities with support for different audio profiles and codecs. The U8903B also supports industrial standard instrument connectivity such as GPIB, USB, and LAN. In addition, the U8903B is equipped with frequency, phase, time, and FFT graph analysis, as well as sweep capability for frequency and amplitude.

The U8903B also allows you to create test sequences. Refer to **Chapter 7**, “Test Sequence Application” for more information.

To search for firmware updates for the U8903B, go to the Keysight U8903B firmware update Web site at www.keysight.com/find/audioanalyzer_firmware.

LXI Standard 1.4 Compliant Audio Analyzer



The U8903B performance audio analyzer is a LAN eXtension for Instrumentation (LXI) Standard 1.4 compliant (Standard Core) instrument, developed using LXI Technology. LXI is an instrument standard for devices that use the Ethernet (LAN) as their primary communication interface.

Hence, it is an easy-to-use instrument especially with the usage of an integrated Web browser that provides a convenient way to configure the instrument's functionality.

Installation and Configuration

Initial inspection

When you receive your U8903B, inspect the unit for any obvious damage such as broken terminals or cracks, dents, and scratches on the chassis that may occur during shipment. If any damage is found, notify the nearest Keysight Sales Office immediately.

Keep the original packaging in case the U8903B has to be returned to Keysight in the future. If you return the U8903B for service, attach a tag identifying the owner and model number. Also, include a brief description of the problem.

Ventilation

The U8903B can operate within the temperature range of 0 °C to 55 °C. The U8903B is cooled by drawing air through the sides and bottom at the front of the U8903B, and exhausting it through the ventilation holes on the sides and top at the rear of the U8903B. The U8903B must be installed in a location that allows sufficient space at the top, sides, and rear for adequate air circulation.

Rack mounting

The U8903B can be mounted in a standard 19-inch rack. Rackmount kits are available as Option 908. Support rails are also required for rack mounting. These are normally supplied with the rack and are not included with the rackmount options.

If you are installing an instrument on top of the U8903B, ensure that the instrument does not obstruct the ventilation holes at the top of the U8903B. If required, use a filler panel above the U8903B to ensure adequate space for air circulation.

Standard Shipped Items

Verify that you have received the following items. If anything is missing or damaged, please contact the nearest Keysight Sales Office.

- U8903B Performance Audio Analyzer
- Power cord
- USB cable
- Certificate of Calibration
- Safety Notices

Optional Accessories

The following accessories are available for purchase separately.

Table 1-1 U8903B optional accessories

| Option | Description |
|------------|---|
| 11500A | Cable assembly, Type-N (male) to Type-N (male), DC to 6.0 GHZ |
| U8903A-101 | Male BNC to male BNC cable (1.2 m) |
| U8903A-102 | Male BNC to male RCA cable (2 m) |
| U8903A-103 | Male XLR to female XLR cable (2 m) |
| U8903A-908 | Rackmount kit |
| U8903B-105 | Cable, digital serial interface for DSI input and output connection |
| U8903A-107 | Cable, accessory – Male XLR-2 male BNC analyzer, 0.26 m |
| U8903A-108 | Cable, accessory – Female XLR-2 male BNC generator, 0.26 m |
| U8903A-109 | BNC accessory kit |

U8903B Options

Table 1-2 U8903B options

| Option | Description |
|------------|---|
| U8903B-STD | <ul style="list-style-type: none"> - 2 channels (analog generator) - 2 channels (analog analyzer) |
| U8903B-AN4 | <ul style="list-style-type: none"> - 2 channels (analog generator) - 4 channels (analog analyzer) |
| U8903B-AN8 | <ul style="list-style-type: none"> - 2 channels (analog generator) - 8 channels (analog analyzer) |
| U8903B-DGT | Digital audio card |
| U8903B-BLU | <i>Bluetooth</i> card with 2 RF connectors. |
| U8903B-BL2 | <i>Bluetooth</i> card with 2 RF connectors at a secondary option slot. This is only applicable when U8903B-AN8 is selected. |
| N3431A | Wide bandwidth option - 1.5 MHz (fixed perpetual license). This is only available for channel 1 and channel 2 analog analyzer. |
| N3432A | Perceptual Objective Listening Quality Analysis (POLQA) measurement software (fixed perpetual license). |
| N3434A | AES3, SPDIF, and DSI digital audio interfaces (fixed perpetual license). This option can only be ordered with U8903B-DGT. |

Product at a Glance

Front panel




Figure 1-1 U8903B front panel

Table 1-3 U8903B front panel description

| Item | Description |
|------|--|
| 1 | LCD display Provides information on the current function including status indicators, settings, and error messages. Refer to “ LCD display ” on page 42 for more information. |
| 2 | Softkeys 1 to 7 Activates the functions displayed on the LCD display next to the respective softkeys. |
| 3 | Navigation and CHANNEL/DATA panels The navigation and CHANNEL/DATA panels consist of the arrow keys, Enter key, knob, and channel/data keys. Refer to “ Navigation and CHANNEL/DATA Panels ” on page 58 for more information. |
| 4 | Menu key Displays the available U8903B mode of operation. - Standard View - Test Seq App - HP8903B |
| 5 | FUNCTION panel Enables access to the U8903B main functions. |
| 6 | Run control panel Press On/Off to turn on or off signal generation or measurements for the selected generator or analyzer channel respectively. Press On/Off to start or stop the graph generation. Press On/Off to start or stop the sweep. Press On/Off to start or stop the test sequence. Press Stop All to stop all generator and test sequence operations. Refer to “ RUN CONTROL Panel ” on page 93 for more information. |
| 7 | GRAPH panel Enables access to the U8903B commonly used graph functions. Refer to “ GRAPH Panel ” on page 67 for more information. |

Table 1-3 U8903B front panel description (continued)

| Item | | Description |
|------|-------------------------|--|
| 8 | SYSTEM panel | Enables access to the U8903B system functions. Refer to “ SYSTEM Panel ” on page 77 for more information. |
| 9 | Headphone jack | The headphone jack can be operated in stereo or mono mode. Refer to “ Input Configuration (Analog Analyzer) ” on page 248 for more information. |
| 10 | USB port | Allows an external USB flash storage to be connected to the U8903B. |
| 11 | Analog analyzer input | Receives analog audio signal using a female XLR input connector for balanced signal and a female BNC input connector for unbalanced signal. The input connectors are available for each channel. |
| 12 | Analog generator output | Outputs analog audio signal using a male XLR output connector for balanced signal and a female BNC output connector for unbalanced signal. The output connectors are available for each channel. |
| 13 | Power key | Turns on or off the U8903B. |

Rear panel




Figure 1-2 U8903B rear panel

Table 1-4 U8903B rear panel description


| Item | Description |
|---|--|
| 1 Monitor 1 | Outputs a scaled signal of the analog analyzer channels 1, 3, 5, and 7 input signals. The scaled signal can then be connected to an external amplifier or other measurement instruments. |
| 2 Monitor 2 | Outputs a scaled signal of the analog analyzer channels 2, 4, 6, and 8 input signals. The scaled signal can then be connected to an external amplifier or other measurement instruments. |
| 3 Analog analyzer input (channels 3 and 4) | Expandable up to 6 analog input channels. Refer to “U8903B Options” on page 37. Receives analog audio signal using a female XLR input connector for balanced input and a female BNC input connector for unbalanced input. The input connectors are available for each channel. |
| 4 Bluetooth RF ports | For all applicable <i>Bluetooth</i> options, refer to “U8903B Options” on page 37. Receives and transmits audio signal through the RF1 and RF2 connectors. The RF1 connector is the default port and the RF2 port can be selected in the U8903B’s GUI. Only one RF port can be used at a time. |
| 5 Digital analyzer input and output (AES3) | This is only applicable for option U8903B-DGT. Receives and outputs digital audio signal using a female XLR input connector and a male XLR output connector respectively. |
| 6 Digital analyzer input and output (SPDIF) | This is only applicable for option U8903B-DGT. Receives and outputs digital audio signal using a TOSLINK input connector and a TOSLINK output connector respectively. |
| 7 Sync in | This is only applicable for option U8903B-DGT. Receives an external sync in clock/frame signal using a female BNC input connector (for digital audio only). |
| 8 LAN port | Allows the U8903B to be controlled remotely over the LAN interface. |

Table 1-4 U8903B rear panel description (continued)

| Item | Description |
|------|--|
| 9 | USB port (type B) Allows the U8903B to be controlled remotely over the USB interface. |
| 10 | AC power port Connects to an AC line voltage. |
| 11 | VGA port Allows an external monitor to be connected to the U8903B. |
| 12 | GPIB port Allows the U8903B to be controlled remotely over the GPIB (General Purpose Interface Bus) interface. |
| 13 | USB port Allows an external USB flash storage to be connected to the U8903B. |
| 14 | Digital analyzer input and output (AES3/SPDIF) This is only applicable for option U8903B-DGT. Receives and outputs digital audio signal using a female BNC input connector and a female BNC output connector respectively. |
| 15 | Digital analyzer input and output (DSI) This is only applicable for option U8903B-DGT. Receives and outputs digital audio signals using a 25-pin female D-SUB connector. |
| 16 | AUX port Outputs a variable DC voltage (0.5 V to 5.1 V, up to 100 mA). The AUX port can be used to power test devices, as a trigger, or to control external hardware. |
| 17 | Trigger in Receives an external TTL signal using a female BNC input connector for triggering operation. Triggering can occur on either the positive or negative edge. |

CAUTION

- Connect the TOSLINK cable straight into the TOSLINK connector.
- DO NOT force the cable in or connect at an angle. Failing to do so may cause damage to the TOSLINK connector.

**Figure 1-3** Connect the TOSLINK cable straight into the connector

LCD display




Figure 1-4 U8903B LCD display

Table 1-5 U8903B LCD display description

| Item | Description |
|------------------|---|
| 1 Main display | Displays the available U8903B modes and functions. <ul style="list-style-type: none"> - AG1/AG2: Analog generator channel 1 or 2. - AA#: Analog analyzer channel (1, 2, 3, 4, 5, 6, 7, or 8). - DG1/DG2: Digital generator channel 1 or 2. - DA1/DA2: Digital analyzer channel 1 or 2. - BG1/BG2: <i>Bluetooth</i> generator channel 1 or 2. - BA1/BA2: <i>Bluetooth</i> analyzer channel 1 or 2. |
| 2 Title bar | <ul style="list-style-type: none"> - Displays the name of the current active menu in the main display. - Displays the following icons. <ul style="list-style-type: none"> -  LAN connected -  LAN disconnected -  LAN connected with error -  <i>Bluetooth</i> connected -  <i>Bluetooth</i> disconnected -  LXI front panel turned on -  External USB flash storage connected -  Shift function -  Remote control mode -  Front panel keys locked -  Help mode -  Warning -  Fan(s) malfunctioned -  Memory buffer |
| 3 Softkeys panel | Displays a maximum of 7 softkey menu options for the selected panel. |
| 4 Status bar | Displays the status of an action such as information, warning, or error messages. |

NOTE

Refer to “**Display mode**” on page 65 for more information on the U8903B display layout.

Getting Started

Power on the U8903B

Connect one end of the power cord to the U8903B rear panel AC power inlet and the other end to an AC voltage source. The U8903B will automatically adjust to the correct line voltage in the range of 100 VAC to 240 VAC.

Preset the U8903B

A preset will set the U8903B to a default state. It does not affect the I/O configuration, calibration data, system configurations (time, date, model number, and serial number), and license information. Refer to “**Appendix 19: DSI Input and Output Interface**” on page **566** for more information.

To preset the U8903B, you can perform either one of the following steps.

- Send the *RST, SYSTem:PRESet, SYSTem:PRESet:TYPE, or SYSTem:RESet[:MODE] SCPI command from the PC via the USB, GPIB, or LAN interface.
- Press  on the SYSTEM panel.

NOTE

For more information on preset, refer to “**SYSTEM Panel**” on page **77**.

Access the help mode

The U8903B help mode provides you quick access to the operating information by displaying the description of all the front panel keys and current softkeys.

To activate or deactivate the U8903B help mode, press  on the

CHANNEL/DATA panel and  on the SYSTEM panel.

NOTE

When the U8903B help mode is activated, the front panel keys will not execute their normal functions when pressed.

An example of a help mode is shown in **Figure 1-5**. The help mode icon will appear at the top-right of the title bar. Refer to **Figure 1-5** for more information on the help mode icon. Press the front panel keys or the current menu page softkeys to display the respective information.



Figure 1-5 Help mode

Update the U8903B

The U8903B firmware update file can be obtained from the Keysight U8903B firmware update website at www.keysight.com/find/audioanalyzer_firmware.

Perform the following procedure to update the U8903B firmware.

- 1 Save the firmware update files in an external USB flash storage.
- 2 Connect the external USB flash storage to the U8903B.
- 3 Press  on the SYSTEM panel.
- 4 From the System menu page, press the **Update** softkey. The Update menu page is displayed as shown in **Figure 1-6**.




Figure 1-6 System > Update menu page

Table 1-6 System > Update menu page

| Menu | Description |
|-----------|--|
| Load File | Press the Load File softkey to load the update files. The Recall menu page will be displayed to select the source location. Refer to " Recall " on page 95 for more information on the Recall menu page. |
| EULA | Press the EULA softkey to display the U8903B EULA (End User License Agreement) page. |

- 5 Press the **Load File** softkey and the recall menu page is displayed to enable you to select the source location.
- 6 Select the firmware file to be updated, and press the **Recall** softkey as shown in **Figure 1-7**. Refer to "**Recall**" on page 95 for more information on the Recall menu page.




Figure 1-7 Recall menu page

NOTE

The System menu page is only available in the Standard mode. Refer to “**Menu Key**” on page 60 for more information on the U8903B available modes.

CAUTION

The firmware update process may take 20 minutes to 40 minutes to complete. DO NOT power off the U8903B during the firmware update process.

Perform self-test

Perform the following procedure to run the U8903B self-test.

- 1 Press  on the SYSTEM panel.
- 2 From the System menu page, press the **Service** softkey.
- 3 From the Service menu page, press the **Self-Test** softkey. The Self-Test menu page is displayed as shown in **Figure 1-8**.
- 4 Press the **Customize Test** softkey to select the desired tests.
- 5 Press the **Run Test** softkey to run the selected tests.




Figure 1-8 System > Service > Self-Test menu page

Table 1-7 System > Service > Self-Test menu page

| Menu | Description |
|-----------------------|--|
| Customize Test | Press the Customize softkey to select or deselect the desired tests. - LAN Test - Card Self Test |
| Run Test | Press the Run Test softkey to run the selected tests. |
| Clear Result | Press the Clear Result softkey to clear the previous self-test results. The self-test results are saved in the system memory. |

NOTE

The System menu page is only available in the Standard mode. Refer to “**Menu Key**” on page 60 for more information on the U8903B available modes.

Add or remove U8903B options

Perform the following procedure to add U8903B options.

- 1 Press  on the SYSTEM panel.
- 2 From the System menu page, press the **Service** softkey.
- 3 From the Service menu page, press the **Options** softkey. The Options menu page is displayed as shown in **Figure 1-9**.




Figure 1-9 System > Service > Options menu page

Table 1-8 System > Service > Options menu page

| Menu | Description |
|----------------------|---|
| Add Option | Press the Add Option softkey to load the U8903B option file. The Recall menu page will be displayed to select the source location. |
| Remove Option | Press the Remove Option softkey to remove the selected U8903B option. |

- 4 Press the **Add option** softkey, and the Recall menu page is displayed to enable you to select the U8903B option file.
- 5 Select the U8903B option file to be loaded, and press the **Recall** softkey as shown in **Figure 1-10**.




Figure 1-10 Recall menu page

NOTE

Restart the U8903B after adding a new U8903B option file.

Perform the following procedure to remove U8903B options.

- 1 Select the U8903B option to be removed from the list.
- 2 Press the **Remove Option** softkey to remove the U8903B option as shown in **Figure 1-9**.

NOTE

The System menu page is only available in the Standard mode. Refer to “**Menu Key**” on page 60 for more information on the U8903B available modes.

Keysight U8903B
Performance Audio Analyzer
User's Guide

2 Operation and Features

| | |
|--|----|
| Test Capabilities | 52 |
| U8903B Block Diagram | 53 |
| Analog audio interface | 53 |
| Digital audio interface | 55 |
| Bluetooth audio interface | 56 |
| Bluetooth audio connection examples | 57 |
| Navigation and CHANNEL/DATA Panels | 58 |
| Menu Key | 60 |
| Standard View | 61 |
| Test Sequence Application (Test Seq App) | 62 |
| HP8903B | 62 |
| FUNCTION Panel | 63 |
| Full screen | 64 |
| Display mode | 65 |
| GRAPH Panel | 67 |
| Peak Search | 68 |
| Marker | 70 |
| Scale | 74 |
| Zoom | 75 |
| Edit zoom | 76 |
| SYSTEM Panel | 77 |
| Preset | 78 |
| Utility | 79 |
| System | 82 |
| RUN CONTROL Panel | 93 |
| Save and Recall | 94 |
| Save | 94 |
| Recall | 95 |

This chapter describes the test capabilities, key features, and the front panel operation of the U8903B.

Test Capabilities

The U8903B is capable of testing a broad range of audio-related devices and components for research and development, manufacturing, and quality assurance applications.

Examples of the products that can be tested are listed follows.

- Multichannel home theater systems
- Audio amplifiers, as a complete product or at the component level
- Portable audio playback devices such as MP3 players
- Speakers (require third-party accessories such as microphones and power amplifiers)
- PC audio cards
- Audio components
- *Bluetooth* audio devices

The U8903B performs the following two basic functions.

- Audio signal generation
- Audio signal analysis

The U8903B basic configuration has two channels of analog generator and two channels of analog analyzer which enables the U8903B to test devices with stereo capability. The U8903B is also able to generate and analyze digital and *Bluetooth* audio interfaces with the available options as listed in “**U8903B Options**” on page 37.

U8903B Block Diagram

Analog audio interface

Signal generation

A simplified U8903B analog generator block diagram is shown as follows.




Figure 2-1 U8903B analog generator block diagram

The digital signal processing (DSP) generates all the required waveforms, except for square wave, digitally. The digital waveform data is streamed realtime into the 24-bit digital-to-analog converter (DAC) where it is converted to voltage and sent to the output conditioning block to be amplified or attenuated to the required amplitude. Finally, the waveform is routed through either the balanced (XLR) or unbalanced (BNC) output signal connectors to the unit-under-test (UUT). The output can also be fully floating or have the output grounded to the instrument ground. There is also a loopback facility where the analog generator can be connected onto the systems internal analog bus and routed to the analog analyzer.

Measurement

A simplified U8903B analog analyzer block diagram is shown as follows.




Figure 2-2 U8903B analog analyzer block diagram

An audio signal can enter the analog analyzer through either the balanced (XLR) or unbalanced (BNC) input signal connector. There is also a loopback facility where the analog generator can be connected onto the systems internal analog bus and routed to the analog analyzer.

From the input connector, the signal passes through the AC/DC coupling circuit. If AC coupling is selected, the DC component is blocked and only the AC component of the signal passes through. However, if DC coupling is selected, the entire signal passes through.

The attenuators, buffer, gain, and common mode rejection (CMR) conditions the signal to as close to the full scale of the analog-to-digital converter (ADC) as possible, optimizing the measurement dynamic range.

There are two separate ADCs in the analog analyzer. The low bandwidth ADC is designed for best performance in the audio bandwidth and beyond. The high bandwidth ADC is designed to give high resolution measurements up to 1.5 MHz.

The default input impedance is 100 k Ω for unbalanced signals or 200 k Ω for balanced signals. Terminations of 600 Ω or 300 Ω can also be applied. The 600 Ω termination can tolerate up to 1.5 W and the 300 Ω termination can tolerate up to 3 W.

Digital audio interface

A simplified U8903B digital audio interface block diagram is shown as follows.




Figure 2-3 U8903B digital generator and analyzer block diagram

Signal generation

The digital generator generates all the required waveforms digitally. The digital waveform data is then streamed to the serial audio transmitter for the DSI output, or to the AES transmitter for the balanced, unbalanced, and optical output. Finally, the waveform is routed through the balanced (XLR), unbalanced (BNC), optical (TOSLINK), or digital serial interface (DSI) output signal connectors to the device under test (DUT).

Measurement

A digital audio signal can enter the digital analyzer through the balanced (XLR), unbalanced (BNC), optical (TOSLINK), or digital serial interface (DSI) input signal connector. For balanced, unbalanced, and optical input, the audio signal then passes through the AES receiver. For DSI input, the audio signal then passes through serial audio receiver. The audio signal is sent to the digital analyzer. Inside the digital analyzer, the digital signal can be optionally passed through a combination of up to five digital filters, one each from the low pass, high pass, weighting, deemphasis, and sample rate filter groups before sending it to the measurement section.

Bluetooth audio interface

A simplified U8903B *Bluetooth* audio interface block diagram is shown as follows.




Figure 2-4 U8903B *Bluetooth* generator and analyzer block diagram

Signal generation

The digital signal processing (DSP) generates all the required waveforms digitally. The digital waveform data is then streamed to the U8903B *Bluetooth* module in which the audio will be encoded and converted to the RF interface. Finally, the waveform is transmitted to the *Bluetooth* audio devices through the RF1 connector. The RF1 connector is the default port and the RF2 port can be selected in the U8903B's GUI.

Measurement

The audio signal enters the *Bluetooth* analyzer through the RF1 connector. The audio signal then passes through the U8903B *Bluetooth* module in which the audio will be decoded and converted to the digital interface and sent to the *Bluetooth* analyzer. Inside the *Bluetooth* analyzer, the digital signal can be optionally passed through a combination of up to five digital filters, one each from the low pass, high pass, weighting, deemphasis, and sample rate filter groups before sending it to the measurement section.

Bluetooth audio connection examples

An example of a direct U8903B *Bluetooth* audio connection to DUT using an RF cable is shown as follows.




Figure 2-5 Direct U8903B Bluetooth audio connection to DUT example

An example of a wireless U8903B *Bluetooth* audio connection using an antenna is shown as follows.




Figure 2-6 Wireless U8903B Bluetooth audio connection to DUT example

CAUTION

Over the air testing shall be conducted in a shielded chamber.

Navigation and CHANNEL/DATA Panels

The navigation and CHANNEL/DATA panels are used to navigate and set or modify the parameter values.




Figure 2-7 Navigation and CHANNEL/DATA panels

Table 2-1 Navigation and CHANNEL/DATA panels description

| Item | Description |
|------|---|
| 1 | Knob Rotate the knob to increase or decrease a numeric value, change a highlighted digit or character, or step through lists or items in a row. |
| 2 | Arrow keys Use the arrow keys to highlight or navigate the editable items on the LCD display for editing. In HP8903B mode, press the up and down arrow keys to increment/decrement the frequency and amplitude values. |
| 3 | Enter key Press  to confirm an entry. |
| 4 | Numeric keys Use the numeric keys to enter alphanumeric data by using the number keys and decimal point, or select the channel number. In DTMF single mode, press  to generate the *# DTMF tone. |

Table 2-1 Navigation and CHANNEL/DATA panels description (continued)

| Item | Description |
|--------------------|---|
| 5 Numeric sign key | <p>Press  to specify a positive or negative value. For a negative value, press  to enter the negative sign before a numeric value.</p> <p>In DTMF single mode, press  to generate the '#' DTMF tone.</p> |
| 6 Shift key | <p>Press  prior to pressing a shifted function key. The shifted functions are printed in Blue on top of the front panel keys. Refer to “GRAPH Panel” on page 67 and “SYSTEM Panel” on page 77 for more information.</p> |
| 7 Escape key | <p>Press  to cancel a selected action.</p> |
| 8 Back space key | <p>Press  to delete the character to the left of the cursor.</p> |

Menu Key

Press  to display the list of available U8903B main modes of operation. Select the desired mode from the drop-down list as shown in **Figure 2-8**.




Figure 2-8 U8903B mode selection

The U8903B modes are listed as follows.

Table 2-2 U8903B modes description

| Mode | Description |
|---------------|---|
| Standard View | The Standard View mode is the default mode for the U8903B. Refer to “ Standard View ” on page 61 for more information. |
| Test Seq App | Refer to “ Test Sequence Application (Test Seq App) ” on page 62 for more information. |
| HP8903B | Refer to “ HP8903B ” on page 62 for more information. |

Standard View

Press  and select **Standard View** to access the standard view menu page. In the standard view, you can perform signal analysis, graph analysis, sweep function, and system configurations. The Standard View mode is the default mode for the U8903B.

Signal analysis

Press  on the FUNCTION panel to switch between audio generator or audio analyzer mode. Refer to **Chapter 3**, “Audio Generator Functions” and **Chapter 4**, “Audio Analyzer Measurement Functions” for more information on the respective configurations.

Graph analysis

Press  on the FUNCTION panel to access the graph analysis mode. Refer to **Chapter 5**, “Graph Analysis” for more information on the graph analysis mode configurations.

Sweep function

Press  on the FUNCTION panel to access the U8903B sweep parameter and the configurations. Refer to **Chapter 6**, “Sweep Function” for more information on the sweep configurations.

System configurations

Press  on the SYSTEM panel to access the U8903B system configurations. You can view the error messages, configure I/O settings, update the U8903B, perform self-tests, configure the U8903B settings, configure the HP8903B mode settings, and others. Refer to “**System**” on page [82](#) for more information on the system configurations.

Test Sequence Application (Test Seq App)

Press  and select **Test Seq App** to access the test sequence application mode. The test sequence application mode allows you to perform a series of automated measurements. Refer to **Chapter 7**, “Test Sequence Application” for more information.


HP8903B

Press  and select HP8903B to access the HP8903B mode. The HP8903B mode emulates the HP8903B audio analyzer behavior. Refer to **Chapter 8**, “HP8903B” for more information.

FUNCTION Panel

The FUNCTION panel provides quick access to the U8903B main functions.

Table 2-3 FUNCTION panel description

| FUNCTION panel | Key | Description |
|---|--------------------|---|
|  | Interface | Press  to switch between the analog, digital, or <i>Bluetooth</i> interface. |
| | Generator/Analyzer | Press  to switch between the generator or analyzer mode. Refer to Chapter 3 , “Audio Generator Functions” and Chapter 4 , “Audio Analyzer Measurement Functions” for more information. |
| | Graph | Press  to access the graph analysis mode. Refer to Chapter 5 , “Graph Analysis” for more information. |
| | Sweep | Press  to access the sweep function mode. Refer to Chapter 6 , “Sweep Function” for more information. |
| | Full Screen | Press  to maximize the graph view to the full display size. This function is only applicable in the graph analysis mode. Refer to “ Full screen ” on page 64 for more information. |
| | Display | Press  to switch among the 2-panel view, 4-panel view, or 10-panel view in the analyzer and generator mode. Press  to switch between the single panel view and 2-panel view in the graph analysis mode. Refer to “ Display mode ” on page 65 for more information. |
| | Shortcut 1 | Customizable shortcut key. Refer to Table 2-20 for more information. |
| | Shortcut 2 | Customizable shortcut key. Refer to Table 2-20 for more information. |

Full screen

NOTE

The full screen function is only available in the graph analysis mode.

The full screen graph display is displayed as shown in **Figure 2-9**. To exit from the full screen graph display, press .




Figure 2-9 Full screen graph display

Display mode

The U8903B allows you to display up to ten panels on the main display in the analyzer and generator mode.



Figure 2-10 4-panel view



Figure 2-11 10-panel view

The U8903B allows you to display up to two panels on the main display in the graph analysis mode.




Figure 2-12 Graph analysis mode 2-panel view


GRAPH Panel

NOTE

Some keys have a shifted function printed above the keys. Press  on the CHANNEL/DATA panel before pressing the desired key with the shifted function.

The graph panel provides quick access to the commonly used graph functions. Refer to **Chapter 5**, “Graph Analysis” for more information on the graph analysis mode.

Table 2-4 GRAPH panel description

| GRAPH panel | Key | Description |
|--|--------------------------|--|
|  | Peak Search | Press  to display the peak search menu page, and place the selected marker on the trace point at the maximum Y-axis value for the marker trace. Refer to “ Peak Search ” on page 68 for more information. |
| | Marker | Press   to access the marker softkeys that select the current and reference markers and turns them on and off. You may also move the markers, display the marker measurement data, and display the section of the graph based on the selected marker position. Refer to “ Marker ” on page 70 for more information. |
| | Print (Shift + Marker) | Press  and   to print the current display to a file. Refer to “ Save ” on page 94 for more information. |
| | Scale | Press  to perform autoscaling to automatically scale the display according to the signal, or to autoscale the X-axis or Y-axis. Refer to “ Scale ” on page 74 for more information. |
| | Zoom | Press   to magnify a section of the graph. Refer to “ Zoom ” on page 75 for more information. |
| | Edit Zoom (Shift + Zoom) | Press  and   to configure the section of the graph to be magnified. Refer to “ Edit zoom ” on page 76 for more information. |

Peak Search

The Peak Search menu page allows you to define a specific threshold to determine which signals can be considered peaks, excluding the unwanted signals from the search. A peak can only qualify as a peak if there is a rising slope before the point and falling slope after the point. A minimum can only qualify as a minimum if there is a falling slope before the point and rising slope after the point.

NOTE

The Peak Search menu page is only available in the graph analysis mode.




Figure 2-13 Peak Search menu page

Table 2-5 Peak Search menu description

| Menu | Description |
|-----------|---|
| Max Peak | Press the Max Peak softkey to search and move the active marker to the highest peak which is higher than the peak threshold value. If the active maker is off, the marker will be turned on before performing the maximum peak operation. |
| Next Peak | Press the Next Peak softkey to search and move the active marker to the next peak which is higher than the peak threshold value. If the active maker is off, the marker will be turned on before performing the next peak operation. |
| Prev Peak | Press the Prev Peak softkey to search and move the active marker to the previous peak which is higher than the peak threshold value. If the active maker is off, the marker will be turned on before performing the previous peak operation. |
| Next Min | Press the Next Min softkey to search and move the active marker to the previous peak which is lower than the minimum threshold value. If the active maker is off, the marker will be turned on before performing the next minimum operation. |
| Prev Min | Press the Prev Min softkey to search and move the active marker to the next peak which is lower than the minimum threshold value. If the active maker is off, the marker will be turned on before performing the previous minimum operation. |
| Threshold | Press the Threshold softkey to configure the peak search setting. Refer to " Threshold " on page 69 for more information. |

Marker

The Marker menu page allows you to place a marker on the graph. A marker can be placed on a trace to allow the value of the trace at the marker point to be determined precisely. A total of up to 8 markers can be placed in the graph. You can also press the numeric keys (1 to 8) once to switch among the active markers, and press the numeric keys (1 to 8) twice to toggle the state of the selected marker.

NOTE

The Marker menu page is only available in the graph analysis mode.




Figure 2-15 Marker menu page 1

Table 2-7 Marker menu description

| Menu | Description |
|---------------|--|
| Active Marker | Press the Active Marker softkey to select the active marker number. The active marker is displayed in green, and the other markers are displayed in white. The active marker reference marker is displayed in red. |
| State | Press the State softkey to enable or disable the active marker. |
| Trace | Press the Trace softkey to select the trace number for the active marker. |
| Ref Mkr | Press the Ref Mkr softkey to select the reference marker number. The reference marker has to be specified to perform the delta marker calculations in the marker table. <ul style="list-style-type: none"> - OFF - M1 to M8 |

Table 2-7 Marker menu description (continued)

| Menu | Description |
|---------------------|--|
| Movement | <p>Press the Movement softkey to select the marker movement type.</p> <ul style="list-style-type: none"> - Single The active marker will move depending on the speed and direction of the knob being turned. - Pair The active marker will move with the reference marker. - Bin The active marker will move to the next/previous bin or pixel regardless of the speed of the knob. - Peak The active marker will move from peak to peak. This behavior is affected by the peak threshold settings. - Harmonic The active marker will move from harmonic to harmonic. This setting is only useful if the display option is changed to Harmonics. |
| Function | <p>Press the Function softkey to select the marker function type.</p> <ul style="list-style-type: none"> - None No marker function type is specified. - Slope The slope of the current marker. The beginning point and end point taken into account for the calculation is from the previous and subsequent point of the marker. - PSD The total power contained in each of the frequency bins in the band, and then dividing the result by the “effective bandwidth”. |
| Marker -> | <p>Press the Marker -> softkey to perform automatic adjustment of the graph left and right values in reference to the current marker location. Refer to “Marker ->” on page 72 for more information.</p> |
| Harmonics | <p>Press the Harmonics softkey to place the markers on the harmonic values. Refer to “Harmonics” on page 73 for more information.</p> |
| Rdg at Mkr | <p>Press the Rdg at Mkr softkey to enable or disable the readings at the marker. You can choose to have the active marker readings to be at the top left corner of the graph, or at the marker location itself. When marker table is enabled, the marker readings at the marker location are automatically hidden.</p> |

Marker ->

The Marker -> menu page allows you to perform automatic adjustment of the graph left and right values in reference to the current marker location.




Figure 2-16 Marker > Marker - menu page

Table 2-8 Marker > Marker - menu description

| Menu | Description |
|--------------|--|
| -> Start | Press the -> Start softkey to set the left value of the graph to the current marker location. The span is retained so the right value of the graph may be changed. |
| -> Stop | Press the -> Stop softkey to set the right value of the graph to the current marker location. The span is retained so the left value of the graph may be changed. |
| -> Center | Press the -> Center softkey to set the center value of the graph to the current marker location. The span is retained so the left and right values of the graph may be changed. |
| -> Delta | Press the -> Delta softkey to set the left and right values of the graph to the current marker and the reference marker location. |
| Move to 3 dB | Press the Move to 3 dB softkey to place the marker on the nearest -3 dB value data point. |
| Move to 6 dB | Press the Move to 6 dB softkey to place the marker on the nearest -6 dB value data point. |

Harmonics

The Harmonics menu page allows you to place the markers on the harmonic values. The graph display option have to be in harmonic display view. All the markers will be used and placed in the selected trace.




Figure 2-17 Marker > Harmonics menu page

Table 2-9 Marker > Harmonics menu description

| Menu | Description |
|---------|---|
| Trace | Press the Trace softkey to set the trace number to place the marker. |
| Enabled | Press the Enabled softkey to show or hide the markers. |

Scale

The Scale menu page allows you to perform autoscaling to automatically scale the display according to the signal, or to autoscale the X-axis or Y-axis.

NOTE

The Scale menu page is only available in the graph analysis mode.




Figure 2-18 Scale menu page

Table 2-10 Scale menu description

| Menu | Description |
|--------------------|--|
| AutoScale | Press the AutoScale softkey to perform autoscaling on the X-axis and Y-axis. |
| AutoScale X | Press the AutoScale X softkey to perform autoscaling on the X-axis by searching for the most optimum scale (left and right values) for the X-axis based on the data being displayed in the graph. |
| AutoScale Y | Press the AutoScale Y softkey to perform autoscaling on the Y-axis by searching for the most optimum scale (top and bottom values) for the Y-axis based on the data being displayed in the graph. |

Zoom

The U8903B screen is split into two windows in the zoom view. The top window is a normal graph window, and the bottom window displays a magnified representation of the traces in the top window. The data in the bottom window will be more detailed due to the screen resolution difference between both windows. The magnified region is indicated by the red border in the top window.

NOTE

The zoom view is only available in the graph analysis mode.

The magnified graph display is displayed as shown in **Figure 2-19**.




Figure 2-19 Magnified graph display

Edit zoom

To display the edit zoom mode in the zoom view, press  on the CHANNEL/DATA panel and  on the GRAPH panel. Press the up or down arrow key to modify the stepping value and use the left and right arrow keys to move the red border region in the top window. To resize the red border region in the top window, rotate the knob.

The edit zoom mode is displayed as shown in **Figure 2-20**.




Figure 2-20 Edit zoom mode display

To exit the edit zoom mode, press  on the CHANNEL/DATA panel and  on the GRAPH panel.

To exit the zoom view, press  on the GRAPH panel.


SYSTEM Panel

NOTE

Some keys have a shifted function printed above the keys. Press  on the CHANNEL/DATA panel before pressing the desired key with the shifted function.

The SYSTEM panel provides access to some useful system functions.

Table 2-11 SYSTEM panel description

| SYSTEM panel | Key | Description |
|--|------------------------|--|
|  | Preset | Press  to display the Preset menu page. Refer to “Preset” on page 78 for more information. |
| | Utility | Press  to display the Utility menu page. Refer to “Utility” on page 79 for more information. |
| | Help (Shift + Utility) | Press  and  to display the help mode page. Refer to “Access the help mode” on page 45 for more information. |
| | System | Press  to display the System menu page. Refer to “System” on page 82 for more information. |
| | Macro (Shift + System) | Reserved for future expansion. |
| | Local | Press  to switch from remote control mode to local mode. The front panel keys are locked in the remote mode. Refer to Table 1-5 for more information on the remote control icon. |
| | Lock/Unlock | Press  to lock or unlock the front panel keys in the local mode. A dialog box will pop-up for confirmation. Refer to Table 1-5 for more information on the front panel keys locked icon. |

Preset

A preset will set the U8903B to a default state. It does not affect the I/O configuration, calibration data, system configurations (time, date, model number, and serial number), and license information.

NOTE

The Preset menu page is only available in the Standard View mode. Refer to “**Menu Key**” on page 60 for more information.



Figure 2-21 Preset menu page

Table 2-12 Preset menu description

| Menu | Description |
|---------------------|---|
| (Current mode) | <p>Press the (Current mode) softkey to reset the current mode to its default settings. For example, resetting the analog generator will only reset all the generator settings while other modes settings remain unchanged.</p> <ul style="list-style-type: none"> - Analog Analyzer Resetting the analog analyzer will also reset the analog generator loopback connector. - Analog Generator Resetting the analog generator will not reset the analog generator loopback connector. - Graph Analysis |
| Save User State | Press the Save User State softkey to save the current user state. |
| Mode | Press the Mode softkey to reset all modes to the default settings without deleting the user-defined files. All running operations such as auto query, sweep, and test sequence will be aborted. |
| To Factory Settings | Press the To Factory Settings softkey to reset the U8903B to the factory default settings, delete all the files saved in the internal flash memory (for example, state file, arbitrary waveform, test sequence project files, and so on), and reset the GUI state to the Standard View mode. If the HP8903B mode is turned on, the GUI state will remain at the HP8903B mode. |
| User State | Press the User State softkey to reset the U8903B to the previously saved user state. |

Utility

The Utility menu page allows you to save the U8903B state to a file, or recall the U8903B state from a file.

NOTE

The Utility menu page is only available in the Standard View mode. Refer to “**Menu Key**” on page 60 for more information.

For the generator and analyzer mode, the Utility menu page is displayed as shown in **Figure 2-22**.



Figure 2-22 Utility menu page (generator and analyzer mode)

Table 2-13 Utility menu description (generator and analyzer mode)

| Menu | Description |
|---|--|
| Save Channel (x) (x) = current channel number | Press the Save Channel (x) softkey to save the current channel state to a file. Refer to “ Save ” on page 94 for more information on the Save menu page. |
| Save (x) (x) = current mode | Press the Save (x) softkey to save the current mode state to a file. Refer to “ Save ” on page 94 for more information on the Save menu page. |
| Recall | Press the Recall softkey to recall a saved U8903B state from a file. Refer to “ Recall ” on page 95 for more information on the Recall menu page. |
| Copy To | Press the Copy To softkey to copy the current channel state to other channel(s). |
| Copy From | Press the Copy From softkey to copy other channel state to the current channel. |
| File Explorer | Press the File Explorer softkey to access the file explorer menu. Refer to “ File Explorer ” on page 81. |

For the graph analysis mode, the Utility menu page is displayed as shown in **Figure 2-23**.




Figure 2-23 Utility menu page (graph analysis mode)

Table 2-14 Utility menu description (graph analysis mode)

| Menu | Description |
|-------------------------------|--|
| Save Graph | Press the Save Graph softkey to save the current graph state to a file. Refer to “ Save ” on page 94 for more information on the Save menu page. |
| Save Channels Settings | Press the Save Channels Settings softkey to save the current channel graph state or all channels graph state to a file. Refer to “ Save ” on page 94 for more information on the Save menu page. |
| Save Traces | Press the Save Traces softkey to save the current trace state, all traces state, axis settings state, all traces and axis settings states, or the current trace data to a file. Refer to “ Save ” on page 94 for more information on the Save menu page. |
| Recall | Press the Recall softkey to load a trace from a CSV file into the active trace. Refer to “ Recall ” on page 95 for more information on the Recall menu page. |
| Copy To | Press the Copy To softkey to copy the current channel graph state to other channel(s). |
| Copy Graph From | Press the Copy Graph From softkey to copy other channel graph state to the current channel. |
| File Explorer | Press the File Explorer softkey to access the file explorer menu. Refer to “ File Explorer ” on page 81. |

File Explorer

File explorer allows you to rename, delete, copy, or move files from the U8903B's internal storage or an external flash drive.




Figure 2-24 File Explorer menu page

Table 2-15 File Explorer menu description

| Menu | Description |
|--------------|--|
| Select | Press the Select softkey to select the folder to browse in the file explorer mode. |
| Type | Press the Type softkey to select the file type to be displayed on the current directory and to be saved into. |
| Rename | Press the Rename softkey to rename the selected file in the current directory. |
| Copy or Move | Press the Copy or Move softkey to copy or move the marked files to the selected folder. |
| Delete | Press the Delete softkey to delete the selected file in the current directory. |
| New Folder | Press the New Folder softkey to create a new folder in the current directory. |

System

The System menu page allows you to view error messages, configure I/O settings, update the U8903B, perform self-tests, configure the U8903B settings, configure the HP8903B mode settings, and others.

NOTE

- The System menu page is only available in the Standard View mode. Refer to “**Menu Key**” on page 60 for more information.
- Pressing  in the System menu page will bring up the File Explorer menu.




Figure 2-25 System menu page 1

Error Info

Press the **Error Info** softkey to display the Error Info menu page. The error messages will be listed in the error log viewing panel. The error messages are displayed in descending order where the latest error message is displayed at the top most of the list.




Figure 2-26 System > Error Info menu page (Error)

Table 2-16 Error Info menu description

| Menu | Description |
|------------------|---|
| Load File | Press the Load File softkey to select the log file to be loaded in the error log viewing panel. The latest log file name is EventLog_CE.xml. The older log files are named as EventLog_CE.<yyyyMMdd>_n.xml, where yyyy = year, MM = month, dd = day, and n = version. The U8903B will keep the log files up to seven days. |

I/O

Press the **I/O** softkey to display the I/O menu page.




Figure 2-27 System > I/O menu page

Table 2-17 I/O menu description

| Menu | Description |
|--------------|---|
| Lan Settings | Press the Lan Settings softkey to configure the LAN settings. Refer to Table 2-18 for more information. |
| GPIB | Press the GPIB softkey to set the desired GPIB address. |
| FTP | Press the FTP softkey to enable or disable the FTP control. |

In the Lan Settings menu page, you can reset the LAN, change the hostname, and switch between automatic or manual configuration mode as shown in **Figure 2-28**.




Figure 2-28 System > I/O > Lan Settings menu page 1

Table 2-18 System > I/O > Lan Settings menu description

| Menu | Description |
|-------------|--|
| Reset | Press the Reset softkey to reset the LAN settings. |
| Hostname | Press the Hostname softkey to set the LAN hostname. |
| Config Mode | Press the Config Mode softkey to select the LAN configuration mode. <ul style="list-style-type: none"> - Auto - Manual |
| IP Address | Press the IP Address softkey to set the LAN IP address. This setting is only available when the LAN configuration mode is set to Manual. |
| Subnet mask | Press the Subnet mask softkey to set the LAN subnet mask address. This setting is only available when the LAN configuration mode is set to Manual. |
| Gateway | Press the Gateway softkey to set the LAN gateway address. This setting is only available when the LAN configuration mode is set to Manual. |
| DNS 1 | Press the DNS 1 softkey to set the LAN DNS 1 address. This setting is only available when the LAN configuration mode is set to Manual. |
| DNS 2 | Press the DNS 2 softkey to set the LAN DNS 2 address. This setting is only available when the LAN configuration mode is set to Manual. |

Update

Refer to “**Update the U8903B**” on page 46.

Service

Press the **Service** softkey to display the Service menu page.




Figure 2-29 System > Service menu page

Table 2-19 System > Service menu description

| Menu | Description |
|-----------------------|---|
| Self-Test | Press the Self-Test softkey to perform self-test. Refer to “ Perform self-test ” on page 48 for more information. |
| Diagnostic | Press the Diagnostic softkey to perform the front panel or display diagnostics test. |
| Secure Erase | Press the Secure Erase softkey to securely erase all the files saved in the internal flash memory (for example, state file, arbitrary waveform, test sequence project files, and so on). It does not affect the U8903B settings and license information. |
| Options | Press the Options softkey to display the installed U8903B options. You may also add or remove the U8903B options from the Options menu page. Refer to “ Add or remove U8903B options ” on page 49 for more information. |
| Residual Noise | Press the Residual Noise softkey to measure the residual noise and get the result. |

Settings

Press the **Settings** softkey to display the Settings menu page.



Figure 2-30 System > Settings menu page 1

Table 2-20 System > Settings menu description

| Menu | Description |
|-----------------------|--|
| Date | Press the Date softkey to edit the date in dd/mm/yyyy format. |
| Time | Press the Time softkey to edit the current time in 24-hour format. |
| Brightness | Press the Brightness softkey to adjust the LCD display brightness value. |
| Key Sound | Press the Key Sound softkey to enable or disable the front panel key sound. |
| Power Up State | Press the Power Up State softkey to select the power up state. <ul style="list-style-type: none"> - Last The U8903B will start up with the last saved settings. - Default The U8903B will start up with the factory default settings. |

Table 2-20 System > Settings menu description (continued)

| Menu | Description |
|-------------------|---|
| Shortcut 1 | <p>Press the Shortcut 1 softkey to select a specific function to map the shortcut 1 key.</p> <ul style="list-style-type: none"> - Error List Display the last 30 errors, warnings, or messages logged. - Auto-Scale Automatically scale the graph display. - File Explorer Launch the file explorer. - Audio Monitor Enable or disable the aux audio monitor. - Audio Volume Adjust the aux audio volume by using the up and down arrow keys or the knob. This is only available if the Audio Monitor is enabled. |
| Shortcut 2 | <p>Press the Shortcut 2 softkey to select a specific function to map the shortcut 2 key.</p> <ul style="list-style-type: none"> - Error List Display the last 30 errors, warnings, or messages logged. - Auto-Scale Automatically scale the graph display. - File Explorer Launch the file explorer. - Audio Monitor Enable or disable the aux audio monitor. - Audio Volume Adjust the aux audio volume by using the up and down arrow keys or the knob. This is only available if the Audio Monitor is enabled. |

HP8903B Config

Press the **HP8903B Config** softkey to display the HP8903B Config menu page.

NOTE

- The HP8903B configuration settings will not be affected by any reset operation.
- Refer to **Chapter 8**, “HP8903B” for more information on the HP8903B mode.




Figure 2-31 System > HP8903B Config menu page

Table 2-21 System > HP8903B Config menu description


| Menu | Description |
|-----------------------|---|
| Active Channel | <p>Press the Active Channel softkey to select the HP8903B active channel.</p> <ul style="list-style-type: none"> - 1 - 2 |
| Left Filter | <p>Press the Left Filter softkey to select the left filter type. The left filter represents the filter on the left side of the HP8903B front panel. The HP8903B filter may be different according to the model and the purchased HP8903B option. The default left filter is None.</p> <ul style="list-style-type: none"> - None - A-Weighing - CCIR 1k wtd - CCIR 2k wtd - C-Message - CCITT - 400 Hz |

Table 2-21 System > HP8903B Config menu description (continued)

| Menu | Description |
|--------------|--|
| Right Filter | <p>Press the Right Filter softkey to select the right filter type. The right filter represents the filter on the right side of the HP8903B front panel. The HP8903B filter may be different according to the model and the purchased HP8903B option. The default right filter is None.</p> <ul style="list-style-type: none"> - None - A-Weighing - CCIR 1k wtd - CCIR 2k wtd - C-Message - CCITT - 400 Hz |
| Default LPF | <p>Press the Default LPF softkey to select the default filter for the HP8903B mode. The default filter is 80 kHz.</p> <ul style="list-style-type: none"> - None - 30 kHz - 80 kHz |

Fan & Temperature

Press the **Fan & Temperature** softkey to display the temperatures of the available cards and the speed of the three 80 mm fans in the U8903B. This menu page is for service usage only. Refer to the *U8903B Service Guide* for more information.

**Figure 2-32** System > Fan & Temperature menu page

Aux Output

Press the **Aux Output** softkey to display the Aux Output menu page.





Figure 2-33 System > Aux Output menu page

Table 2-22 System > Aux Output menu description

| Menu | Description |
|----------------------|--|
| Audio Monitor | Press the Audio Monitor softkey to enable or disable the auxiliary audio monitor. |
| Audio Output | Press the Audio Output softkey to select the aux audio output type. <ul style="list-style-type: none"> - Speaker - Phone |
| Audio Mode | This is only available when Phone is selected as the audio output. Press the Audio Mode softkey to select the aux audio mode type. <ul style="list-style-type: none"> - Stereo - Mono |
| Volume | Press the Volume softkey to select the aux audio volume. |
| DC Output | Press the DC Output softkey to set the aux DC output value. |

Board Info

Press the **Board Info** softkey to display the U8903B available cards information.



The screenshot shows a menu page titled "System Board Info" with a sub-header "Board Information". Below the header is a table with five columns: Name, Part Number, Serial Number, Version, and Slot. The table contains six rows of data. A "Return" button is visible at the bottom right of the screen.

| Name | Part Number | Serial Number | Version | Slot |
|------------------|-------------|---------------|---------|------|
| Analog Analyzer | U8903-68509 | 23-1411-00059 | 1.0.0.0 | 2 |
| Analog Analyzer | U8903-68509 | 23-1409-00002 | 1.0.0.0 | 3 |
| Analog Analyzer | U8903-68509 | 23-1422-00002 | 1.0.0.0 | 4 |
| Analog Analyzer | U8903-68509 | 23-1411-00068 | 1.0.0.0 | 5 |
| Analog Generator | U8903-68510 | 23-1423-00011 | 1.0.0.0 | 6 |

Figure 2-34 System > Board Info menu page

Legacy Sweep

Press the **Legacy Status** softkey to enable or disable the legacy sweep.

When the legacy sweep is enabled, sweep is limited to analog and the sweep channel for the analyzer and generator is paired. For example, analog generator channel 1 is measured by analog analyzer channel 1.

When legacy sweep is disabled, you can select multiple channels to be swept and the channels for generator and analyzer are not required to be paired.

RUN CONTROL Panel

The RUN CONTROL panel is used to start or stop signal generation, measurements, and test sequence operations.





Figure 2-35 RUN CONTROL panel

Table 2-23 Navigation and CHANNEL/DATA panels description

| Key | Description |
|------------|---|
| 1 On/Off | Press  to start or stop the signal generation or measurements for the selected generator or analyzer channel respectively. |
| | Press  to start or stop the graph generation in the graph analysis mode. |
| | Press  to start or stop the sweep in the sweep mode. |
| 2 Stop All | Press  to start or stop the test sequence in the test sequence application mode. |
| | Press  to stop all generator, sweep, and test sequence operations. |

Save and Recall

Save

The Save menu page allows you to save the U8903B state, graph analysis trace settings, sweep function points, or screen capture of the current display into a file.




Figure 2-36 Save menu page

Table 2-24 Save menu description

| Menu | Description |
|---------------------|--|
| Save | Press the Save softkey to save the specific function to a file. |
| Type | Press the Type softkey to select the file type to be displayed on the current directory and to be saved into. |
| Rename | Press the Rename softkey to rename the selected file in the current directory. |
| Copy or Move | Press the Copy or Move softkey to copy or move the marked files to the selected folder. |
| Delete | Press the Delete softkey to delete the selected file in the current directory. |
| New Folder | Press the New Folder softkey to create a new folder in the current directory. |

Select the '..' item at the list and press  to move up a level from the current folder or to another directory. Use the arrow keys to navigate through the files or select the desired folder or file.

NOTE

For the detailed procedure on renaming, copying, moving, and deleting files, please refer to **“Appendix 27: Procedure to Rename, Copy, Move, and Delete Files”** on page **603**.

Recall

The Recall menu page allows you to recall the U8903B state, graph analysis trace settings, or sweep function points from a file.




Figure 2-37 Recall menu page

Table 2-25 Recall menu description

| Menu | Description |
|---------------------|---|
| Recall | Press the Recall softkey to recall the selected file. |
| Type | Press the Type softkey to select the file type to be displayed on the current directory. |
| Rename | Press the Rename softkey to rename the selected file in the current directory. |
| Copy or Move | Press the Copy or Move softkey to copy or move the marked files to the selected folder. |
| Delete | Press the Delete softkey to delete the selected file in the current directory. |
| New Folder | Press the New Folder softkey to create a new folder in the current directory. |

Select the '..' item at the list and press  to move up a level from the current folder or to another directory. Use the arrow keys to navigate through the files or select the desired folder or file.

NOTE

For the detailed procedure on renaming, copying, moving, and deleting files, please refer to **“Appendix 27: Procedure to Rename, Copy, Move, and Delete Files”** on page **603**.

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

Keysight U8903B
Performance Audio Analyzer
User's Guide

3 Audio Generator Functions

| | |
|--|-----|
| Audio Generator | 99 |
| Waveform Configuration | 102 |
| Sine waveform | 102 |
| Variable phase waveform | 104 |
| Dual waveform | 106 |
| SMPTE IMD waveforms (1:1/4:1/10:1) | 108 |
| DFD IEC waveforms (IEC 60118/IEC 60268) | 110 |
| Gaussian noise | 114 |
| Rectangular noise | 116 |
| Triangular noise | 118 |
| Pink noise | 119 |
| Square waveform | 121 |
| DC signal | 123 |
| Sine burst waveform | 124 |
| Stereo waveform | 126 |
| Monotonicity | 127 |
| Constant value waveform | 128 |
| Walking zero | 130 |
| Walking one | 131 |
| Arbitrary waveform | 132 |
| Multitone waveform | 134 |
| Dual-Tone Multi-Frequency (DTMF) | 138 |
| Output Configuration (Analog Generator) | 141 |
| Output Configuration (Digital Generator) | 143 |
| Reference clock | 144 |
| Sync clock | 145 |
| Link Configuration (Bluetooth Generator) | 147 |
| Device scan | 148 |
| Device action | 149 |
| Common settings | 151 |
| A2DP settings | 154 |
| HFP settings | 155 |

| | |
|---|-----|
| AVRCP log view | 157 |
| DSI Output Configuration (Digital Generator) | 158 |
| AES3/SPDIF Output Configuration (Digital Generator) | 160 |
| Edit Bits (Consumer format) | 161 |
| Edit Bits (Professional format) | 166 |
| References (Analog Generator) | 172 |
| References (Digital and Bluetooth Generator) | 173 |

This chapter describes the U8903B audio generator functions and configurations.

Audio Generator

Press  on the FUNCTION panel to switch between audio generator or audio analyzer mode. The Analog Generator menu page, Digital Generator menu page, and *Bluetooth* Generator menu page are displayed as shown in **Figure 3-1**, **Figure 3-2**, and **Figure 3-3** respectively.

Press  on the FUNCTION panel to switch between the analog, digital, and *Bluetooth* interface.

Press  or  on the CHANNEL/DATA panel to switch to channel 1 or channel 2 respectively and start configuring the active channel.

Press  on the RUN CONTROL panel to start or stop the signal generation for the selected generator channel.



Figure 3-1 Analog Generator menu page

Table 3-1 Analog Generator menu description

| Menu | Description |
|------------------------|--|
| Waveform | Press the Waveform softkey to display the list of available analog generator waveform types. Select the desired waveform from the drop-down list. |
| Waveform Config | Press the Waveform Config softkey to set the current active waveform configuration such as frequency, amplitude, and others. Refer to “ Waveform Configuration ” on page 102 for more information. |
| Output Config | Press the Output Config softkey to set the output configurations such as the connector type, impedance, and others. Refer to “ Output Configuration (Analog Generator) ” on page 141 for more information. |
| References | Press the References softkey to configure the output references settings that are used in the unit conversion. Refer to “ References (Analog Generator) ” on page 172 for more information. |




Figure 3-2 Digital Generator menu page

Table 3-2 Digital Generator menu description

| Menu | Description |
|-----------------|--|
| Waveform | Press the Waveform softkey to display the list of available digital generator waveform types. Select the desired waveform from the drop-down list. |
| Waveform Config | Press the Waveform Config softkey to set the current active waveform configuration such as frequency, amplitude, and others. Refer to “ Waveform Configuration ” on page 102 for more information. |
| Output Config | Press the Output Config softkey to set the output configurations such as the connector type, impedance, and others. Refer to “ Output Configuration (Digital Generator) ” on page 143 for more information. |
| DSI Config | Press the DSI Config softkey to set the DSI output configurations such as the format, resolution, and others. Refer to “ DSI Output Configuration (Digital Generator) ” on page 158 for more information. |
| AES3/SPDIF | Press the AES3/SPDIF softkey to set the AES3/SPDIF output configurations such as the level, resolution, and others. Refer to “ AES3/SPDIF Output Configuration (Digital Generator) ” on page 160 for more information. |
| References | Press the References softkey to configure the output references settings that are used in the unit conversion. Refer to “ References (Digital and Bluetooth Generator) ” on page 173 for more information. |
| Clock Config | Press the Clock Config softkey to configure the clock settings. |



Figure 3-3 Bluetooth Generator menu page

Table 3-3 Bluetooth Generator menu description

| Menu | Description |
|-----------------|--|
| Waveform | Press the Waveform softkey to display the list of available <i>Bluetooth</i> generator waveform types. Select the desired waveform from the drop-down list. |
| Waveform Config | Press the Waveform Config softkey to set the current active waveform configuration such as frequency, amplitude, and others. Refer to “ Waveform Configuration ” on page 102 for more information. |
| Link Config | Press the Link Config softkey to set the link configurations such as device scan, A2DP settings, and others. Refer to “ Link Configuration (Bluetooth Generator) ” on page 147 for more information. |
| References | Press the References softkey to configure the output references settings that are used in the unit conversion. Refer to “ References (Digital and Bluetooth Generator) ” on page 173 for more information. |

Waveform Configuration

Sine waveform

Sine waveform is the most basic and commonly used waveform in audio analysis.

Sine waveform mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for sine waveform is displayed as shown in **Figure 3-4**, **Figure 3-5**, and **Figure 3-6** for the analog, digital, and *Bluetooth* generator respectively.



Figure 3-4 Analog Generator > Waveform Config menu page (sine waveform)



Figure 3-5 Digital Generator > Waveform Config menu page (sine waveform)



Figure 3-6 Bluetooth Generator > Waveform Config menu page (sine waveform)

Table 3-4 Analog/Digital/Bluetooth Generator > Waveform Config menu description (sine waveform)

| Menu | Description |
|------------------|--|
| Amplitude | Amplitude can be expressed as V_{rms} , V_{peak} , V_{pp} , dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, V_{pp} is twice V_{peak} and V_{rms} is equivalent to $V_{peak}/\sqrt{2}$. |
| Frequency | Frequency refers to the reciprocal of the period of the signal. |
| DC Offset | DC offset refers to the DC component of the waveform. |

Variable phase waveform

Variable phase waveform outputs a sine waveform on all channels. The waveforms on all channels share the same frequency; however their phase and amplitude can differ. Variable phase waveforms are useful for measuring the phase difference or timing skew between the channels of a multiple channel audio system. Variable phase waveform outputs a sine waveform at the selected frequency at both channel outputs with the channel 2 output phase varies from -180° to $+179.99^\circ$, relative to the channel 1 output.

Variable phase waveform mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for variable phase waveform is displayed as shown in **Figure 3-7**, **Figure 3-8**, and **Figure 3-8** for the analog, digital, and *Bluetooth* generator respectively.



Figure 3-7 Analog Generator > Waveform Config menu page (variable phase waveform)



Figure 3-8 Digital Generator > Waveform Config menu page (variable phase waveform)



Figure 3-9 Bluetooth Generator > Waveform Config menu page (variable phase waveform)

Table 3-5 Analog/Digital/Bluetooth Generator > Waveform Config menu description (variable phase waveform)

| Menu | Description |
|------------|---|
| Amplitude | Amplitude can be expressed as Vrms, Vpeak, Vpp, dBV, dBu, and dBm for analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to Vpeak/ $\sqrt{2}$. |
| Frequency | Frequency refers to the reciprocal of the period of the signal. |
| Phase -> 1 | This is only available when the analog, digital, and <i>Bluetooth</i> generator is in channel 2. Phase -> 1 refers to the phase of the channel 2 sine waveform with reference to channel 1. A positive value will cause the channel 1 output to lead the channel 2 output. A negative value will cause the channel 2 output to lag the channel 1 output. |

Dual waveform

Dual waveform allows you to generate a composite waveform that is the summation of two independent sine waveforms. Dual sine waveforms are useful in testing the intermodulation distortion characteristics of an audio system.

Dual waveform mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for dual waveform is displayed as shown in **Figure 3-10**, **Figure 3-11**, and **Figure 3-12** for the analog, digital, and *Bluetooth* generator respectively.




Figure 3-10 Analog Generator > Waveform Config menu page (dual waveform)



Figure 3-11 Digital Generator > Waveform Config menu page (dual waveform)



Figure 3-12 Bluetooth Generator > Waveform Config menu page (dual waveform)

Table 3-6 Analog/Digital/Bluetooth Generator > Waveform Config menu description (dual waveform)

| Menu | Description |
|--------------------|--|
| Amplitude | Amplitude can be expressed as Vrms, Vpeak, Vpp, dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to Vpeak/ $\sqrt{2}$. |
| Frequency 1 | Frequency 1 refers to the frequency for the first sine component. |
| Frequency 2 | Frequency 2 refers to the frequency for the second sine component. |
| DC Offset | DC Offset refers to the DC component of the waveform. |
| Ratio | Ratio refers to the amplitude ratio of the second sine component over the first sine component. |
| Summation | Summation refers to the method to sum up two levels. <ul style="list-style-type: none"> - RSS The amplitude displayed is the Root Sum Square (RSS) summation result of the two levels. The analyzer will read the same amplitude set at the generator regardless of tone ratio. - Linear The amplitude displayed is the linear summation result of the two levels. The level of each tone can be easily calculated back from the tone ratio. |

SMPTE IMD waveforms (1:1/4:1/10:1)

SMPTE IMD is a signal which is the linear combination of two sine waveforms. The SMPTE IMD waveforms conform to the SMPTE standard RP120-1983 for testing intermodulation distortion. For SMPTE IMD 1:1, the lower frequency sine wave is linearly combined in 1:1 amplitude ratio with the upper frequency sine wave. For SMPTE IMD 4:1, the lower frequency sine wave is linearly combined in 4:1 amplitude ratio with the upper frequency sine wave. For SMPTE IMD 10:1, the lower frequency sine wave is linearly combined in 10:1 amplitude ratio with the upper frequency sine wave.

SMPTE IMD waveform mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for SMPTE 1:1 waveform is displayed as shown in **Figure 3-13**, **Figure 3-14**, and **Figure 3-15** for both the analog, digital, and *Bluetooth* generator respectively.



Figure 3-13 Analog Generator > Waveform Config menu page (SMPTE 1:1 waveform)




Figure 3-14 Digital Generator > Waveform Config menu page (SMPTE 1:1 waveform)



Figure 3-15 Bluetooth Generator > Waveform Config menu page (SMPT 1:1 waveform)

Table 3-7 Analog/Digital/Bluetooth Generator > Waveform Config menu description (SMPT IMD waveforms)

| Menu | Description |
|------------|---|
| Amplitude | Amplitude can be expressed as Vrms, Vpeak, Vpp, dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to Vpeak/ $\sqrt{2}$. |
| Lower Freq | Lower Freq refers to the lower frequency of the waveform. The lower and upper frequencies are differentiated by the amplitude ratio between the frequencies. |
| Upper Freq | Upper Freq refers to the upper frequency of the waveform. The lower and upper frequencies are differentiated by the amplitude ratio between the frequencies. |
| DC Offset | DC Offset refers to the DC component of the waveform. |
| Summation | Summation refers to the method to sum up two levels. <ul style="list-style-type: none"> - RSS The amplitude displayed is the Root Sum Square (RSS) summation result of the two levels. The analyzer will read the same amplitude set at the generator regardless of tone ratio. - Linear The amplitude showed is the linear summation result of the two levels. The level of each tone can be easily calculated back from the tone ratio. |

DFD IEC waveforms (IEC 60118/IEC 60268)

There are two predefined DFD dual tones waveforms comprising DFD IEC 60118 and DFD IEC 60268. The DFD IEC waveforms are similar to SMPTE IMD, except that the two tones have equal amplitude and are spaced closer together.

DFD waveform mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for IEC 60118 waveform is displayed as shown in **Figure 3-16**, **Figure 3-17**, and **Figure 3-18** for the analog, digital, and *Bluetooth* generator respectively.




Figure 3-16 Analog Generator > Waveform Config menu page (IEC 60118 waveform)



Figure 3-17 Digital Generator > Waveform Config menu page (IEC 60118 waveform)



Figure 3-18 Bluetooth Generator > Waveform Config menu page (IEC 60118 waveform)

Table 3-8 Analog/Digital/Bluetooth Generator > Waveform Config menu description (IEC 60118 waveform)

| Menu | Description |
|------------|---|
| Amplitude | Amplitude can be expressed as Vrms, Vpeak, Vpp, dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to $V_{peak}/\sqrt{2}$. |
| Upper Freq | Upper Freq refers to the upper frequency of the waveform. |
| Diff Freq | Diff Freq refers to the difference frequency of the waveform. |
| DC Offset | DC Offset refers to the DC component of the waveform. |
| Summation | Summation refers to the method to sum up two levels. <ul style="list-style-type: none"> - RSS The amplitude displayed is the Root Sum Square (RSS) summation result of the two levels. The analyzer will read the same amplitude set at the generator regardless of the tone ratio. - Linear The amplitude showed is the linear summation result of the two levels. The level of each tone can be easily calculated back from the tone ratio. |

The waveform configuration for IEC 60268 waveform is displayed as shown in **Figure 3-19**, **Figure 3-20**, and **Figure 3-21** for the analog, digital, and *Bluetooth* generator respectively.



Figure 3-19 Analog Generator > Waveform Config menu page (IEC 60268 waveform)



Figure 3-20 Digital Generator > Waveform Config menu page (IEC 60268 waveform)



Figure 3-21 Bluetooth Generator > Waveform Config menu page (IEC 60268 waveform)

Table 3-9 Analog/Digital/Bluetooth Generator > Waveform Config menu description (IEC 60268 waveform)

| Menu | Description |
|-------------|---|
| Amplitude | Amplitude can be expressed as Vrms, Vpeak, Vpp, dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to Vpeak/ $\sqrt{2}$. |
| Center Freq | Center Freq refers to the center frequency of the waveform. |
| Diff Freq | Diff Freq refers to the difference frequency of the waveform. |
| DC Offset | DC Offset refers to the DC component of the waveform. |
| Summation | Summation refers to the method to sum up two levels. <ul style="list-style-type: none"> - RSS The amplitude displayed is the Root Sum Square (RSS) summation result of the two levels. The analyzer will read the same amplitude set at the generator regardless of the tone ratio. - Linear The amplitude showed is the linear summation result of the two levels. The level of each tone can be easily calculated back from the tone ratio. |

Gaussian noise

Gaussian noise is a random noise signal where the frequency components have a Gaussian distribution centered on a predetermined frequency value.

Gaussian noise mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for Gaussian noise is displayed as shown in **Figure 3-22**, **Figure 3-23**, and **Figure 3-24** for the analog, digital, and *Bluetooth* generator respectively.




Figure 3-22 Analog Generator > Waveform Config menu page (Gaussian noise)



Figure 3-23 Digital Generator > Waveform Config menu page (Gaussian noise)



Figure 3-24 Bluetooth Generator > Waveform Config menu page (Gaussian noise)

Table 3-10 Analog/Digital/Bluetooth Generator > Waveform Config menu description (Gaussian noise)

| Menu | Description |
|------------------|--|
| Amplitude | Amplitude can be expressed as V_{rms} , V_{peak} , V_{pp} , dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, V_{pp} is twice V_{peak} and V_{rms} is equivalent to $V_{peak}/\sqrt{2}$. |
| DC Offset | DC Offset refers to the DC component of the waveform. |

Rectangular noise

Rectangular noise is a noise signal based on Rectangular distribution.

Rectangular noise mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for Rectangular noise is displayed as shown in **Figure 3-25**, **Figure 3-26**, and **Figure 3-27** for the analog, digital, and *Bluetooth* generator respectively.




Figure 3-25 Analog Generator > Waveform Config menu page (Rectangular noise)



Figure 3-26 Digital Generator > Waveform Config menu page (Rectangular noise)




Figure 3-27 Bluetooth Generator > Waveform Config menu page (Rectangular noise)

Table 3-11 Analog/Digital/Bluetooth Generator > Waveform Config menu description (Rectangular noise)

| Menu | Description |
|-----------|---|
| Amplitude | Amplitude can be expressed as Vrms, Vpeak, Vpp, dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to $V_{peak}/\sqrt{2}$. |
| DC Offset | DC Offset refers to the DC component of the waveform. |

Triangular noise

Triangular noise mode is only applicable for the digital generator. The waveform configuration for triangular noise is displayed as shown in **Figure 3-28**.




Figure 3-28 Digital Generator > Waveform Config menu page (Triangular noise)

Table 3-12 Digital Generator > Waveform Config menu description (Triangular noise)

| Menu | Description |
|------------------|---|
| Amplitude | Amplitude can be expressed as FFS, dBFS, or %FS for the digital generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to Vpeak/ $\sqrt{2}$. |
| DC Offset | DC Offset refers to the DC component of the waveform. |

Pink noise

Pink noise is a noise signal that contains an equal sound pressure level in each octave band where the energy decreases as frequency increases.

Pink noise mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for Pink noise is displayed as shown in **Figure 3-29**, **Figure 3-30**, and **Figure 3-31** for the analog, digital, and *Bluetooth* generator respectively.




Figure 3-29 Analog Generator > Waveform Config menu page (Pink noise)




Figure 3-30 Digital Generator > Waveform Config menu page (Pink noise)



Figure 3-31 Bluetooth Generator > Waveform Config menu page (Pink noise)

Table 3-13 Analog/Digital/Bluetooth Generator > Waveform Config menu description (Pink noise)

| Menu | Description |
|-----------|---|
| Amplitude | Amplitude can be expressed as V_{rms} , V_{peak} , V_{pp} , dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and Bluetooth generator. For a perfect sine waveform without any DC offset, V_{pp} is twice V_{peak} , while V_{rms} is equivalent to $V_{peak}/\sqrt{2}$. |
| DC Offset | DC Offset refers to the DC component of the waveform. |

Square waveform

Square waveform is a waveform that ideally alternates regularly and instantaneously between two levels.

Square waveform mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for square waveform is displayed as shown in **Figure 3-32**, **Figure 3-33**, and **Figure 3-34** for the analog, digital, and *Bluetooth* generator respectively.




Figure 3-32 Analog Generator > Waveform Config menu page (square waveform)



Figure 3-33 Digital Generator > Waveform Config menu page (square waveform)



Figure 3-34 Bluetooth Generator > Waveform Config menu page (square waveform)

Table 3-14 Analog/Digital/Bluetooth Generator > Waveform Config menu description (square waveform)

| Menu | Description |
|-----------|---|
| Amplitude | Amplitude can be expressed as V_{rms} , V_{peak} , V_{pp} , dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and Bluetooth generator. For a perfect sine waveform without any DC offset, V_{pp} is twice V_{peak} and V_{rms} is equivalent to $V_{peak}/\sqrt{2}$. |
| Frequency | Frequency refers to the frequency of the square waveform. |
| DC Offset | This is only available for the digital generator. DC Offset refers to the DC component of the waveform. |

DC signal

DC signal output is used when a low current DC supply is required. Examples include, biasing amplifiers or other similar circuitry.

DC signal mode is applicable for the analog generator only. The waveform configuration for DC signal is displayed as shown in **Figure 3-35**.




Figure 3-35 Analog Generator > Waveform Config menu page (DC signal)

Table 3-15 Analog Generator > Waveform Config menu description (DC signal)

| Menu | Description |
|---------|--|
| Voltage | Voltage refers to the amplitude of the composite signal. |

Sine burst waveform

Sine burst waveform is usually a sine wave that is switched between two levels. Sine burst waveform mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for sine burst waveform is displayed as shown in **Figure 3-37**, **Figure 3-38**, and **Figure 3-38** for the analog, digital, and *Bluetooth* generator respectively.




Figure 3-36 Analog Generator > Waveform Config menu page (sine burst)



Figure 3-37 Digital Generator > Waveform Config menu page (sine burst)




Figure 3-38 Bluetooth Generator > Waveform Config menu page (sine burst)

Table 3-16 Analog/Digital/Bluetooth Generator > Waveform Config menu description (sine burst)

| Menu | Description |
|-----------|--|
| Amplitude | Amplitude can be expressed as V_{rms} , V_{peak} , V_{pp} , dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, V_{pp} is twice V_{peak} , and V_{rms} is equivalent to $V_{peak}/\sqrt{2}$. |
| Frequency | Frequency refers to the frequency for the first sine component. |
| DC Offset | This is only available for the analog and <i>Bluetooth</i> generator. DC Offset refers to the DC component of the waveform. |
| Burst On | Burst On refers to the number of cycles at which the signal amplitude will be at the higher level. The Burst On value must be less than the period value by one cycle. |
| Period | Period refers to the number of cycles from the beginning of one burst to the beginning of the next burst. The period value must be at least one cycle greater than the burst on. |
| Low Level | Low Level refers to the amplitude ratio of Burst On over Burst Off. |

Stereo waveform

Stereo waveform generates two independent sine waveforms for channel 1 and channel 2. Stereo waveform mode is applicable for the digital generator only. For digital generator, stereo waveform can be generated with a sinewave at two different channels. The waveform configuration for stereo waveform is displayed as shown in **Figure 3-39**.



Figure 3-39 Digital Generator > Waveform Config menu page (stereo)

Table 3-17 Digital Generator > Waveform Config menu description (stereo)

| Menu | Description |
|-----------|---|
| Amplitude | Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, V_{pp} is twice V_{peak} and V_{rms} is equivalent to $V_{peak}/\sqrt{2}$. |
| Frequency | Frequency refers to the frequency for the first sine component. |
| DC Offset | DC Offset refers to the DC component of the waveform. |

Monotonicity

Monotonicity waveform consists of a repeating square-wave staircase signal. The duration for each half cycle of the square wave is determined by the Samples/Step parameter.

Monotonicity waveform mode is applicable for the digital generator only. The waveform configuration for monotonicity waveform is displayed as shown in **Figure 3-40**.



Figure 3-40 Digital Generator > Waveform Config menu page (monotonicity)

Table 3-18 Digital Generator > Waveform Config menu description (monotonicity)

| Menu | Description |
|--------------|---|
| Samples/Step | Samples/Step refers to the duration for each half cycle of the square wave. |

Constant value waveform

Constant value mode outputs a continuous stream of data samples at the same fixed value. This mode helps in the investigation of data-dependent errors in digital systems. In order to repeat a specific error, a fixed value must be used.

Constant value waveform mode is applicable for the digital and *Bluetooth* generator. The waveform configuration for constant value waveform is displayed as shown in **Figure 3-41** and **Figure 3-42** for the digital and *Bluetooth* generator respectively.



Figure 3-41 Digital Generator > Waveform Config menu page (constant)



Figure 3-42 Bluetooth Generator > Waveform Config menu page (constant)

Table 3-19 Digital/*Bluetooth* Generator > Waveform Config menu description (constant)

| Menu | Description |
|----------------|---|
| Voltage | Press the Voltage softkey to select the output voltage or set your desired output voltage. |

Walking zero

In walking zero waveform mode, one bit is set to 0 and the rest of the bits are set to 1. The bit 0 is continuously incremented from the least significant bit (LSB) to the most significant bit (MSB) and loops back to the LSB.

Walking zero waveform mode is applicable for the digital generator only. The waveform configuration for walking zero waveform is displayed as shown in **Figure 3-43**.



Figure 3-43 Digital Generator > Waveform Config menu page (walking zero)

Table 3-20 Digital Generator > Waveform Config menu description (walking zero)

| Menu | Description |
|--------------|---|
| Samples/Step | Samples/Step refers to the speed the single bit 0 is incremented. |

Walking one

In walking one waveform mode, one bit is set to 1 and the rest of the bits are set to 0. The bit 1 is continuously incremented from the least significant bit (LSB) to the most significant bit (MSB) and loops back to the LSB.

Walking one waveform mode is applicable for the digital generator only. The waveform configuration for walking one waveform is displayed as shown in **Figure 3-44**.




Figure 3-44 Digital Generator > Waveform Config menu page (walking one)

Table 3-21 Digital Generator > Waveform Config menu description (walking one)

| Menu | Description |
|--------------|---|
| Samples/Step | Samples/Step refers to the speed the single bit 1 is incremented. |

Arbitrary waveform

You can load a properly formatted waveform file into the U8903B as a sequence of waveform samples. The samples are outputted at the sample rate of the generator. The waveform files must be in the `.arb` or `.wav` file type. For `.wav` file type, mono or stereo audio with 8, 16, or 24 bits per sample are supported.

Arbitrary waveform mode is applicable for the analog, digital, and *Bluetooth* generator. The waveform configuration for arbitrary waveform is displayed as shown in **Figure 3-45**, **Figure 3-46**, and **Figure 3-47** for the analog, digital, and *Bluetooth* generator respectively. Refer to “**Appendix 17: Arbitrary File Format**” on page 561 for more information on the arbitrary waveform file format.




Figure 3-45 Analog Generator > Waveform Config menu page (arbitrary waveform)



Figure 3-46 Digital Generator > Waveform Config menu page (arbitrary waveform)




Figure 3-47 Bluetooth Generator > Waveform Config menu page (arbitrary waveform)

Table 3-22 Analog/Digital/Bluetooth Generator > Waveform Config menu description (arbitrary waveform)

| Menu | Description |
|-----------|---|
| Amplitude | Amplitude can be expressed as Vrms, Vpeak, Vpp, dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to Vpeak/ $\sqrt{2}$. |
| DC Offset | DC Offset refers to the DC component of the waveform. |
| Load File | Press the Load File softkey to load a waveform from a file. Refer to “ Recall ” on page 95 for more information on the Recall menu page. |
| Info | Press the Info softkey to display the loaded waveform information. |

Multitone waveform

Multitone waveform is a composite waveform that is a summation of multiple independent sine waveforms. This feature is useful in measuring different characteristics of audio devices from a single acquisition of audio data.

Multitone waveform mode is applicable for the analog, digital, and *Bluetooth* audio generator. The waveform configuration for multitone waveform is displayed as shown in **Figure 3-48**, **Figure 3-49** and **Figure 3-50** for the analog, digital, and *Bluetooth* generator respectively.




Figure 3-48 Analog Generator > Waveform Config menu page 1 (multitone waveform)



Figure 3-49 Digital Generator > Waveform Config menu page 1 (multitone waveform)



Figure 3-50 Bluetooth Generator > Waveform Config menu page 1 (multitone waveform)

Table 3-23 Analog/Digital/Bluetooth Generator > Waveform Config menu description (multitone waveform)

| Menu | Description |
|--------------|---|
| Amplitude | Amplitude can be expressed as Vrms, Vpeak, Vpp, dBV, dBu, and dBm for the analog generator. Amplitude can be expressed as FFS, dBFS, or %FS for the digital and <i>Bluetooth</i> generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to $V_{peak}/\sqrt{2}$. |
| DC Offset | This is only available for the analog and <i>Bluetooth</i> generator. DC Offset refers to the DC component of the waveform. |
| Start Freq | Start Freq refers to the lowest frequency in the multitone waveform which is usually the frequency for the first tone. |
| Stop Freq | Stop Freq refers to the highest frequency in the multitone waveform which is usually the frequency for the last tone. |
| Freq Spacing | Freq Spacing refers to the frequency spacing between the tones. <ul style="list-style-type: none"> - Linear - Log - Custom |
| Tone Count | Tone Count refers to the number of signal frequency components. For analog generator, the maximum number of tones that can be generated is 60. For digital and <i>Bluetooth</i> generator, the maximum number of tones that can be generated is 64. |
| Length | Length refers to the waveform length that determines the number of samples used to create one iteration of the multitone waveform. Longer waveform length provides higher frequency resolution but will take more time to generate and process. <ul style="list-style-type: none"> - 1024 - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 |
| Custom | Press the Custom softkey to access the custom multitone menu page. You can set the frequency, amplitude, phase, and optimize the crest factor for each tone. Refer to “ Custom multitone ” on page 136 for more information on the custom multitone menu page. |

Custom multitone

The custom multitone waveform configuration is displayed as shown in **Figure 3-51**, **Figure 3-52**, and **Figure 3-53** for both the analog, digital, and *Bluetooth* generator respectively.




Figure 3-51 Analog Generator > Waveform Config > Custom menu page 1 (multitone waveform)




Figure 3-52 Digital Generator > Waveform Config > Custom menu page 1 (multitone waveform)




Figure 3-53 Bluetooth Generator > Waveform Config > Custom menu page 1 (multitone waveform)

Table 3-24 Analog/Digital/Bluetooth Generator > Waveform Config > Custom menu description (multitone waveform)

| Menu | Description |
|------------------|---|
| Apply | Press the Apply softkey to apply the current setting on the selected tone for the custom multitone waveform. |
| Optimize | Press the Optimize softkey to optimize the crest factor for the custom multitone waveform. |
| Frequency | Press the Frequency softkey to set the frequency value for the custom multitone waveform. |
| Amplitude | Press the Amplitude softkey to set the amplitude value for the custom multitone waveform. |
| Phase | Press the Phase softkey to set the phase value for the custom multitone waveform. |
| Add Above | Press the Add Above softkey to add the tone above the selected tone for the custom multitone waveform. |
| Add Below | Press the Add Below softkey to add the tone below the selected tone for the custom multitone waveform. |
| Remove | Press the Remove softkey to remove the selected tone for the custom multitone waveform. |
| Clear | Press the Clear softkey to clear all the tones in the custom multitone waveform list. |

Dual-Tone Multi-Frequency (DTMF)

Dual-Tone Multi-Frequency (DTMF), also known as touch-tone, is a system of signal tones used in telecommunications. Applications include voice mail, help desks, telephone banking, and others. DTMF is only applicable for the analog generator only.

There are 12 DTMF signals where each of the signal is made up of two tones from the following selection:

- 697 Hz
- 770 Hz
- 852 Hz
- 941 Hz
- 1209 Hz
- 1336 Hz
- 1477 Hz

The tones are divided into two groups (low and high), and each DTMF signal uses one from each group. This prevents any harmonics from being misinterpreted as part of the signal. The waveform configuration for DTMF is displayed as shown in **Figure 3-54**.




Figure 3-54 Analog Generator > Waveform Config menu page 1 (DTMF)

Table 3-25 Analog Generator > Waveform Config menu description (DTMF)

| Menu | Description |
|----------------------|---|
| Dial | Press Dial softkey to generate a single DTMF tone or modify the DTMF sequence. Refer to “ Dial ” on page 139 for more information. |
| Amplitude | Amplitude can be expressed as Vrms, Vpeak, Vpp, dBV, dBu, and dBm for the analog generator. For a perfect sine waveform without any DC offset, Vpp is twice Vpeak and Vrms is equivalent to $V_{peak}/\sqrt{2}$. |
| Ratio | Ratio refers to the level difference between the high-frequency tone and low-frequency tone. |
| Tone Duration | Tone Duration refers to the DTMF signal duration. |
| Tone Delay | Tone Delay refers to the delay between two DTMF tones. |
| Pause Time | Pause Time refers to the interval time for the DTMF sequence. |
| Repeat | Press the Repeat softkey to enable or disable repeating the DTMF sequence. |
| Summation | Summation refers to the method to sum up two levels. <ul style="list-style-type: none"> - RSS The amplitude displayed is the Root Sum Square (RSS) summation result of the two levels. The analyzer will read the same amplitude set at generator regardless of tone ratio. - Linear The amplitude showed is the linear summation result of the two levels. The level of each tone can be easily calculated back from the tone ratio. |

Dial

The dial mode allows you to generate a single DTMF tone or to modify the DTMF sequence. Press the **Mode** softkey to switch between Single or Sequence as the dial mode. Press the numeric keys on the CHANNEL/DATA panel to generate the respective DTMF tone as listed in **Table 3-27**. The Dial menu page is displayed as shown in **Figure 3-55**.


**Figure 3-55** Dial menu page

Table 3-26 Dial menu page description

| Menu | Description |
|--------------|--|
| Mode | Mode refers to the mode of operation for the dial mode. Single – You can dial a single DTMF tone using the numeric keys and A to D softkeys. Sequence – You can dial and modify the DTMF sequence. |
| A | Single dial mode |
| B | Press and hold the A , B , C , or D softkey to dial the A, B, C, or D tone respectively. |
| C | Sequence dial mode |
| D | Press the A , B , C , or D softkey to add the A tone to the DTMF sequence. |
| Pause | Pause refers to the pause to be added to the DTMF sequence. Press the Pause softkey to add a pause to the sequence in the form of a comma. |

Table 3-27 DTMF tone mapping

| DTMF tone | Description |
|---------------|--|
| 0 to 9 | Press the numeric keys on the CHANNEL/DATA panel to generate the DTMF 0 to 9 tones respectively. |
| * | Press  on the CHANNEL/DATA panel to generate the '*' DTMF tone. |
| # | Press  on the CHANNEL/DATA panel to generate the '#' DTMF tone. |
| A to D | Press the A to D softkeys to generate the DTMF A to D tones respectively. |

Output Configuration (Analog Generator)

The output configuration for the analog generator is displayed as shown in **Figure 3-56**.



Figure 3-56 Analog Generator > Output Config menu page

Table 3-28 Analog Generator > Output Config menu description

| Menu | Description |
|------------------|---|
| Connector | <p>Press the Connector softkey to select the output connector type.</p> <ul style="list-style-type: none"> - Bal Balanced mode outputs a pair of differential signals which are equal in amplitude but 180 degrees out of phase on the XLR positive and negative pins. - UnBal Unbalanced mode outputs a signal referenced to ground on the BNC output connector. - Com Common mode outputs a pair of equal amplitude and in-phase signals on the XLR positive and negative pins. The common mode test signal is applied to both pins 2 and 3 or the XLR connector, while pin 1 is connected to the return signal. - IEC60268 The common mode test signal is applied to both pins 2 and 3 or the XLR connector, while pin 1 is connected to the return signal. An additional 10 Ω output series resistance is added to pin 2 or 3. |
| Impedance | <p>Press the Impedance softkey to select the output impedance value.</p> <p>For Bal, Com, and IEC60268</p> <ul style="list-style-type: none"> - 600 Ω - 100 Ω - 40 Ω <p>For UnBal</p> <ul style="list-style-type: none"> - 600 Ω - 50 Ω - 20 Ω |

Table 3-28 Analog Generator > Output Config menu description (continued)

| Menu | Description |
|--|---|
| IEC60268 10 Ω | <p>Press the IEC60268 10 Ω softkey to select the additional 10 Ω output series resistance for pin 2 or 3 of the XLR connector in the common IEC60268 configuration. This setting is only available when the output connector type is set to IEC60268.</p> <ul style="list-style-type: none"> - Pin2 Additional 10 Ω is added to pin 2. - Pin3 Additional 10 Ω is added to pin 3. |
| Ground | <p>Press the Ground softkey to select the grounding type.</p> <ul style="list-style-type: none"> - Float In the floating grounding type, the signal return line (XLR pin 1 for balanced output or BNC return for unbalanced output) is not grounded to the chassis earth and is "floating". - Ground In the ground grounding type, the signal return line (XLR pin 1 for balanced output or BNC return for unbalanced output) is connected to the chassis earth. |
| Max Voltage | <p>Press the Max Voltage softkey to set the maximum voltage. The maximum voltage value set will limit the maximum amplitude output from the generator and prevent any excessive high voltage values from damaging the device under test (DUT).</p> |

Output Configuration (Digital Generator)

The output configuration for the digital generator is displayed as shown in **Figure 3-57**.




Figure 3-57 Digital Generator > Output Config menu page

Table 3-29 Digital Generator > Output Config menu description

| Menu | Description |
|-----------------------|--|
| Connector | Press the Connector softkey to select the output connector type. <ul style="list-style-type: none"> - Bal Balanced mode outputs a digital signal on the XLR output connector at the U8903B rear panel. - UnBal Unbalanced mode outputs a digital signal on the BNC output connector at the U8903B rear panel. |
| AES Output | Press the AES Output softkey to enable or disable the AES output. |
| Optical Output | Press the Optical Output softkey to enable or disable the optical output. |
| Sample Rate | Press the Sample Rate softkey to set the sample rate value. |
| Audio Format | Press the Audio Format softkey to select the encoding audio format. <ul style="list-style-type: none"> - Linear PCM - A-Law - μ-Law |
| Dither | Press the Dither softkey to select the dither type. Dither is a noise component that can be superimposed on a signal. <ul style="list-style-type: none"> - Off - Rectangular - Triangular - Shaped |

Reference clock



Figure 3-58 Digital Generator > Clock Config > Ref Clock menu page

Table 3-30 Digital Generator > Clock Config > Ref Clock menu description

| Menu | Description |
|--------|--|
| Source | <p>Press the Source softkey to select the reference clock source. Refer to "Appendix 20: Digital System Clock Distribution Block Diagram" on page 567 for more information on the system clock.</p> <ul style="list-style-type: none"> - Internal - AES RCLK - External |

Sync clock



Figure 3-59 Digital Generator > Clock Config > Sync Clock menu page

Table 3-31 Digital Generator > Clock Config > Sync Clock menu description

| Menu | Description |
|---------|--|
| Output | Press the Output softkey to enable or disable the synchronous clock output. |
| Divider | Press the Divider softkey to select the synchronous clock divider value. When the synchronous clock divider is set to 1, the synchronous clock is locked to 128 × sampling rate (bi-phase clock). When the synchronous clock divider is set to 128, the synchronous clock is divided by 128 which is equal to the sampling rate set at the U8903B. <ul style="list-style-type: none"> - 1 - 128 |
| Source | Press the Source softkey to select the synchronous clock source. Refer to “ Appendix 20: Digital System Clock Distribution Block Diagram ” on page 567 for more information on the system clock. <ul style="list-style-type: none"> - Internal - AES RCLK - External |



Figure 3-60 Digital Generator > Clock Config > External Clock menu page

Table 3-32 Digital Generator > Clock Config > External Clock menu description

| Menu | Description |
|-------------|--|
| Type | <p>Press the Type softkey to select the external reference clock type. Refer to “Appendix 20: Digital System Clock Distribution Block Diagram” on page 567 for more information on the system clock.</p> <ul style="list-style-type: none"> - MClk Sync In - Frame Clk In - DSI Gen FS - DSI Gen Clk |
| Word Length | <ul style="list-style-type: none"> - Press the Word Length softkey to set the external reference clock word length value. - 8 to 32 |
| Multiplier | <ul style="list-style-type: none"> - Press the Multiplier softkey to set the external reference clock multiplier value. The selection available in the external reference clock multiplier depends on the external reference clock word length. |
| Frequency | <ul style="list-style-type: none"> - Press the Frequency softkey to set the external reference clock frequency value. |

Link Configuration (*Bluetooth* Generator)

The link configuration for the *Bluetooth* generator is displayed as shown in **Figure 3-61**.

NOTE

When connecting the U8903B to a PC's *Bluetooth* using A2DP profile where the U8903B acts as source, initiate the connection from the PC (as sink) instead of U8903B. The U8903B does not support the initialization of A2DP source profile connection from the U8903B when connecting to a PC.



Figure 3-61 *Bluetooth* Generator > Link Config menu page

Table 3-33 *Bluetooth* Generator > Link Config menu description

| Menu | Description |
|-----------------|--|
| Device Scan | Press the Device Scan softkey to configure the device scan settings when searching for discoverable <i>Bluetooth</i> devices within range. Refer to " Device scan " on page 148 for more information. |
| Device Action | Press the Device Action softkey to configure the <i>Bluetooth</i> device action settings such as unpair device, profile connection, and others. Refer to " Device action " on page 149 for more information. |
| Common Settings | Press the Common Settings softkey to configure the <i>Bluetooth</i> common settings such as profile, discoverable, and others. Refer to " Common settings " on page 151 for more information. |
| A2DP Settings | Press the A2DP Settings softkey to configure the <i>Bluetooth</i> advanced audio distribution profile settings. Refer to " A2DP settings " on page 154 for more information. |
| HFP Settings | Press the HFP Settings softkey to configure the <i>Bluetooth</i> handsfree/headset profile settings. Refer to " HFP settings " on page 155 for more information. |
| AVRCP Log View | Press the AVRCP Log View softkey to configure the <i>Bluetooth</i> audio/video remote control profile operation log. Refer to " AVRCP log view " on page 157 for more information. |

Device scan




Figure 3-62 Bluetooth Analyzer > Link Config > Device Scan menu page

Table 3-34 Bluetooth Analyzer > Link Config > Device Scan menu description

| Menu | Description |
|----------------|---|
| Device Search | Press the Device Search softkey to begin identifying all the discoverable <i>Bluetooth</i> devices within range. |
| Max Scan | Press the Max Scan softkey to set the maximum number of discoverable <i>Bluetooth</i> devices to be identified during the Device Search procedure. The Device Search procedure will stop when the identified <i>Bluetooth</i> devices reached the set number or if more than 30 s elapsed. - 1 to 16 |
| Filter Class | Press the Filter Class softkey to select the <i>Bluetooth</i> device class to be used during the Device Search procedure. The Device Search procedure identifies all the discoverable <i>Bluetooth</i> device based on the selected class. - All Search for all available <i>Bluetooth</i> device class. - Custom Manually sets the <i>Bluetooth</i> device class using the 6-digit hexadecimal numeric number of the <i>Bluetooth</i> device address such as 60020C for smartphones and 240408 for handsfree/headset devices. |
| Custom | Only available if Filter Class is set to Custom. Press the Custom softkey to manually sets the <i>Bluetooth</i> device class. |
| Refresh Device | Press the Refresh Device softkey to refresh the friendly name of the selected <i>Bluetooth</i> device. |

Device action




Figure 3-63 Bluetooth Analyzer > Link Config > Device Action menu page

Table 3-35

| Menu | Description |
|--------------------|--|
| Pair/Unpair Device | Press the Pair/Unpair Device softkey to pair with the selected discovered <i>Bluetooth</i> device or unpair with the selected paired <i>Bluetooth</i> device respectively. |
| Unpair All Device | Press the Unpair All Device softkey to unpair all the paired <i>Bluetooth</i> devices. |
| Profile Connection | Press the Profile Connection softkey to connect or disconnect the <i>Bluetooth</i> profiles for the connection. <ul style="list-style-type: none"> - Connect/Disconnect All - Connect/Disconnect A2DP - Connect/Disconnect HFP - Connect/Disconnect AVRCP |
| A2DP Operation | Press the A2DP Operation softkey to select the advanced audio distribution profile operation settings. This is only available if the A2DP profile is connected. <ul style="list-style-type: none"> - Open Media Connection Establishes the audio media connection to the connected <i>Bluetooth</i> device via the A2DP profile. - Close Media Connection Disconnects the audio media connection to the connected <i>Bluetooth</i> device via the A2DP profile. - Start Streaming Starts or resumes the audio media connection to the connected <i>Bluetooth</i> device. - Pause Streaming Stops or pauses the audio media connection to the connected <i>Bluetooth</i> device. |

Table 3-35

| Menu | Description |
|--|--|
| HFP Operation (Handsfree/Headset) | <p>Press the HFP Operation softkey to select the HFP (Handsfree/Headset) profile operation settings. This is only available if the HFP profile is connected and the Common Settings > Profile is set to HFP HF.</p> <ul style="list-style-type: none"> - Dial Emulates making an outgoing call from the connected handsfree/headset device. - Answer Call Emulates answering an incoming call from the connected handsfree/headset device. - End Call Emulates terminating a call from the connected handsfree/headset device. - Reject Call Emulates rejecting an incoming call from the connected handsfree/headset device. - Toggle Audio Toggles the audio between RAC and audio gateway of the connected handsfree/headset device. - Button Press Emulates a button press on the connected remote headset device. Only applicable for HFP profile. - Send AT Command Sends the AT command from the U8903B's <i>Bluetooth</i> card to the connected remote device. NOTE: Only support transmitting AT commands. AT command receiving feature is not supported. |
| HFP Operation (Audio Gateway) | <p>Press the HFP Operation softkey to select the HFP (Audio Gateway) profile operation settings. This is only available if the HFP profile is connected and the Common Settings > Profile is set to HFP AG.</p> <ul style="list-style-type: none"> - Connect Establishes an audio connection to the headset device via the connected handsfree/headset device. - Disconnect Disconnects an audio connection to the headset device via the connected handsfree/headset device. - Call Emulates a call alert to the headset device via the connected handsfree/headset device. - Hang Up Emulates ending a call to the headset device via the connected handsfree/headset device. - Send AT Command Sends the AT command from the U8903B's <i>Bluetooth</i> card to the connected remote device. NOTE: Only support transmitting AT commands. AT command receiving feature is not supported. |
| AVRCP Operation | <p>Press the AVRCP Operation softkey to configure the audio/video remote control profile operation settings. This is only available if the AVRCP profile is connected and the Common Settings > Profile is set to AVRCP CTRL.</p> <ul style="list-style-type: none"> - Volume Up - Volume Down - Mute - Play - Stop - Pause - Rewind - Fast Forward - Forward - Backward |

Common settings




Figure 3-64 Bluetooth Analyzer > Link Config > Common Settings menu page 1




Figure 3-65 Bluetooth Analyzer > Link Config > Common Settings menu page 2




Figure 3-66 Bluetooth Analyzer > Link Config > Common Settings menu page 3

Table 3-36 Bluetooth Analyzer > Link Config > Common Settings menu description

| Menu | Description |
|---------------|--|
| Profile | <p>Press the Profile softkey to select the U8903B's <i>Bluetooth</i> card profile. There are two sets of profiles available and the selected profile set will be accessible by the connected <i>Bluetooth</i> device.</p> <ul style="list-style-type: none"> - A2DP SRC, HFP AG, AVRCP TRGT A2DP source, HFP audio gateway, AVRCP target - A2DP SNK, HFP HF, AVRCP CTRL A2DP sink, HFP handsfree/headset, AVRCP controller |
| Friendly Name | Press the Friendly Name softkey to set the friendly name of the U8903B's <i>Bluetooth</i> card. |
| Device PIN | Press the Device PIN softkey to set the passkey for the U8903B's <i>Bluetooth</i> card. |
| Device Class | <p>Press the Device Class softkey to select the device class based on the configured profile.</p> <ul style="list-style-type: none"> - Auto When auto is set and the <i>Bluetooth</i> card is configured as a source profile, device class sets to 60020C (smartphone). When auto is set and the <i>Bluetooth</i> card is configured as a sink profile, device class sets to 240408 (handsfree/headset device). - Custom Manually set the device class. |
| Custom | <p>This is only available if the Device Class is set to Custom.</p> <p>Press the Custom softkey to set the device class.</p> |
| SSP Mode | <p>Press the SSP Mode softkey to select the U8903B's <i>Bluetooth</i> card simple secure pairing (SSP) mode when pairing.</p> <ul style="list-style-type: none"> - Just Works Just works mode is selected when only minimal security is needed. No passkey is required during pairing. - Man-In-The-Middle Man-in-the-middle mode is selected when maximum security is needed. A passkey is required during pairing. |
| Auto Pair | Press the Auto Pair softkey to enable or disable the auto-pairing function of the U8903B's <i>Bluetooth</i> card with a remote device. |

Table 3-36 Bluetooth Analyzer > Link Config > Common Settings menu description (continued)

| Menu | Description |
|---------------|--|
| IO Capability | Press the IO Capability softkey to select the IO capability of the U8903B's Bluetooth card. <ul style="list-style-type: none"> - Display Only - Display Yes No - Keyboard Only - No IO |
| Discoverable | Press the Discoverable softkey to enable or disable the discoverability function of the U8903B's Bluetooth card by a remote device. |
| Connectable | Press the Connectable softkey to enable or disable the connectability function of the U8903B's Bluetooth card by a remote device. |
| Loopback | Press the Loopback softkey to enable or disable the integrated interchip sound (I2S) audio loopback function. This is only available if the HFP profile is connected. |
| Link Status | Press the Link Status softkey to enable or disable the link status of the U8903B's Bluetooth card. This is only available if the HFP profile or A2DP profile is connected. |
| RF Port | Press the RF Port softkey to select the U8903B's Bluetooth card RF port connector. <ul style="list-style-type: none"> - RF1 - RF2 |

A2DP settings




Figure 3-67 Bluetooth Analyzer > Link Config > A2DP Settings menu page

Table 3-37 Bluetooth Analyzer > Link Config > A2DP Settings menu description

| Menu | Description |
|---------------|--|
| Codec | Press the Codec softkey to select the preferred codec for the A2DP profile. - SBC - apt-X |
| Sampling Rate | Press the Sampling Rate softkey to select the preferred audio sampling rate for the A2DP profile. - 16 kHz - 32 kHz - 44.1 kHz - 48 kHz |

HFP settings




Figure 3-68 Bluetooth Analyzer > Link Config > HFP Settings menu page

Table 3-38 Bluetooth Analyzer > Link Config > HFP Settings menu description

| Menu | Description |
|------------|--|
| Wideband | Press the Wideband softkey to enable or disable the wideband speech mode in the HFP profile connection. When the wideband mode is enabled, 16 kHz sampling rate and mSBC codec will be used in the connection. When the wideband mode is disabled (narrowband), 8 kHz sampling rate and CVSD codec will be used in the connection. If the wideband speech mode is enabled, the use of EV3 packet type is mandatory and must be selected together with other optional EDR packet type(s) (EV4, EV5, 2EV3, 3EV3, 2EV5, and 3EV5). The connection will fail if the EV3 packet type is not included. |
| Latency | Press the Latency softkey to set the HFP's codec channel latency in milliseconds. <ul style="list-style-type: none"> - 4 to 65534 |
| Retransmit | Press the Retransmit softkey to select the HFP's codec retransmission effort. <ul style="list-style-type: none"> - No Transmission No retransmission effort. - Power Saving One or more retransmission effort. Optimized for power consumption. - Link Quality One or more retransmission effort. Optimized for link quality. - No Preference No retransmission effort preference. |

Table 3-38 Bluetooth Analyzer > Link Config > HFP Settings menu description (continued)

| Menu | Description |
|---------------------|--|
| Packet Types | <p>Press the Packet Types softkey to select the packet type used in the HFP's codec. Multiple packet types can be selected and the available options are dependent on the supported feature set of the connected <i>Bluetooth</i> device.</p> <ul style="list-style-type: none">- HV1- HV2- HV3- EV3- EV4- EV5- 2EV3- 3EV3- 2EV5- 3EV5 |

AVRCP log view



Figure 3-69 Bluetooth Analyzer > Link Config > AVRCP log view menu page

Table 3-39 Bluetooth Analyzer > Link Config > AVRCP log view menu description

| Menu | Description |
|-------------|--|
| Clear Log | Press the Clear Log softkey to clear the AVRCP operation log history. |
| Refresh Log | Press the Refresh Log softkey to refresh the AVRCP operation log history. |

DSI Output Configuration (Digital Generator)

The DSI output configuration for the digital generator is displayed as shown in **Figure 3-70**.



Figure 3-70 Digital Generator > DSI Config menu page 1

Table 3-40 Digital Generator > DSI Output Config menu description

| Menu | Description |
|-----------------------|--|
| Format | Press the Format softkey to select the DSI output format. <ul style="list-style-type: none"> - Left - Right - I2S - DSP |
| Fsync Polarity | Press the Fsync Polarity softkey to select the sync polarity. <ul style="list-style-type: none"> - Rising - Falling |
| Fsync Width | Press the Fsync Width softkey to select the sync width. <ul style="list-style-type: none"> - One Bit Clock - One Subframe - 50% Duty Cycle |
| Data Shift Cnt | Press the Data Shift Cnt softkey to set the data shift count value. |
| Data Shift Dir | Press the Data Shift Dir softkey to select the data shift direction. <ul style="list-style-type: none"> - Left - Right |
| Word Length | Press the Word Length softkey to set the master clock word length value. The word length cannot be less than the audio resolution. <ul style="list-style-type: none"> - 8 to 32 |
| Resolution | Press the Resolution softkey to set the audio resolution. <ul style="list-style-type: none"> - 8 to 24 |

Table 3-40 Digital Generator > DSI Output Config menu description (continued)

| Menu | Description |
|---------------------|--|
| Sample Rate | Press the Sample Rate softkey to set the sample rate value. |
| Master Clock | Press the Master Clock softkey to enable or disable the master clock output. |
| Multiplier | Press the Multiplier softkey to set the multiplier value. |
| W/BClk Dir | Press the W/BClk Dir softkey to set the word and bit clock direction. |
| Bit Clk Edge | Press the Bit Clk Edge softkey to select the clock edge type. <ul style="list-style-type: none"> - Rising - Falling |
| Voltage | Press the Voltage softkey to select the output voltage or set your desired output voltage. <ul style="list-style-type: none"> - 1.2 Vpp - 1.5 Vpp - 1.8 Vpp - 2.5 Vpp - 3 Vpp - 3.3 Vpp - Custom |

AES3/SPDIF Output Configuration (Digital Generator)

The AES3/SPDIF output configuration for the digital generator is displayed as shown in **Figure 3-71**.



Figure 3-71 Digital Generator > AES Config menu page 1

Table 3-41 Digital Generator > AES Config menu description

| Menu | Description |
|---------------------|---|
| Level | Press the Level softkey to set the output voltage level. |
| Resolution | Press the Resolution softkey to set the audio resolution value. – 8 to 24 |
| Validity Bit | Press the Validity Bit softkey to select the validity bit. – Set – Clear |
| Mode | Press the Mode softkey to select the AES3/SPDIF format. – Consumer – Professional |
| Status Bits | Press the Status Bits softkey to select the status bits type. – Channel – User |
| Edit Bits | Press the Edit Bits softkey to configure the bits according to the format selected. Refer to “ Edit Bits (Consumer format) ” on page 161 and “ Edit Bits (Professional format) ” on page 166 for more information. |
| Clear Bits | Press the Clear Bits softkey to clear all the bits. |
| Save File | Press the Save File softkey to save the bits to a file. Refer to “ Save ” on page 94 for more information on the Save menu page. |
| Load File | Press the Load File softkey to load the bits from a file. Refer to “ Recall ” on page 95 for more information on the Recall menu page. |

Edit Bits (Consumer format)

The AES3/SPDIF bits configuration for the Consumer format is displayed as shown in **Figure 3-72**.




Figure 3-72 Digital Generator > AES Config > Edit Bits (Consumer format) menu page 1

Table 3-42 Digital Generator > AES Config > Edit Bits (Consumer format) menu description

| Menu | Description |
|--------------|--|
| Select Byte | Press the Select Byte softkey to select the byte and edit the byte. |
| Audio Mode | Press the Audio Mode softkey to select the audio mode. <ul style="list-style-type: none"> - Non-Linear PCM - Linear PCM |
| Copyright | Press the Copyright softkey to select the copyright type. <ul style="list-style-type: none"> - Copyright - Non-copyright |
| Emphasis | Press the Emphasis softkey to select the emphasis type. <ul style="list-style-type: none"> - No pre-emphasis - 50/15 μs - Reserved 1 - Reserved 2 |
| Channel Mode | Press the Channel Mode softkey to set the channel mode value. <ul style="list-style-type: none"> - 0 to 3 |

Table 3-42 Digital Generator > AES Config > Edit Bits (Consumer format) menu description (continued)

| Menu | Description |
|---------------------|--|
| Category | <p>Press the Category softkey to select the category code type.</p> <ul style="list-style-type: none"> - General - Laser Optical - D/D Converter - Magnetic - Digital Broadcast 1 - Digital Broadcast 2 - Musical Instrument - ADC Non Copyright - Solid State Memory - ADC Copyright - Experimental - Reserved 1 - Reserved 2 |
| Source Num | <p>Press the Source Num softkey to set the source number.</p> <ul style="list-style-type: none"> - 0 to 15 |
| Channel Num | <p>Press the Channel Num softkey to set the channel number.</p> <ul style="list-style-type: none"> - 0 to 15 |
| Sample Freq | <p>Press the Sample Freq softkey to select the sample frequency value.</p> <ul style="list-style-type: none"> - Not indicated - 22.05 kHz - 24 kHz - 32 kHz - 44.1 kHz - 48 kHz - 88.2 kHz - 96 kHz - 176.4 kHz - 192 kHz - 768 kHz |
| Clk Accuracy | <p>Press the Clk Accuracy softkey to select the clock accuracy type.</p> <ul style="list-style-type: none"> - Level 1 - Level 2 - Level 3 - Reserved |
| Max Word Len | <p>Press the Max Word Len softkey to select the maximum word length.</p> <ul style="list-style-type: none"> - 24 bits - 20 bits |

Table 3-42 Digital Generator > AES Config > Edit Bits (Consumer format) menu description (continued)

| Menu | Description |
|--------------------|---|
| Word Length | Press the Word Length softkey to select the word length. 24 bits maximum word length <ul style="list-style-type: none"> - Not indicated - 20 bits - 21 bits - 22 bits - 23 bits - 24 bits |
| | 20 bits maximum word length <ul style="list-style-type: none"> - Not indicated - 16 bits - 17 bits - 18 bits - 19 bits - 20 bits |
| Orig S.Freq | Press the Orig S.Freq softkey to select the original sample frequency value. <ul style="list-style-type: none"> - Not indicated - 8 kHz - 11.025 kHz - 12 kHz - 16 kHz - 22.05 kHz - 24 kHz - 32 kHz - 44.1 kHz - 48 kHz - 88.2 kHz - 96 kHz - 176.4 kHz - 192 kHz - Reserved 1 - Reserved 2 |
| | Press the CGMA-A softkey to select the CGMA-A type. <ul style="list-style-type: none"> - Copying Permitted - Condition Not Used - One Generation Copy - Copying Denied |

Table 3-43 AES3/SPDIF Consumer mode bit description

| Bits | Label | Description | | |
|---------|--------------------------|--|---------------|---------------|
| 0 | Application mode | 0: Consumer 1: Professional | | |
| 1 | Non-audio | 0: Audio data is linear PCM samples 1: Other than linear PCM samples | | |
| 2 | Copyright | 0: Asserted 1: Not asserted | | |
| 3 – 5 | Emphasis | 000: Emphasis not indicated 100: CD-type emphasis | | |
| 6 – 7 | Channel status mode | 00: Mode zero Other values reserved | | |
| 8 – 15 | Category code | Bit 8 is LSB | | |
| 16 – 19 | Source number | Bit 16 is LSB | | |
| 20 – 23 | Channel number | Bit 20 is LSB | | |
| 24 – 27 | Sampling frequency | 0000: 44.1 kHz 0100: 48 kHz 1100: 32 kHz | | |
| 28 – 29 | Clock accuracy | 10: Level I, ± 50 ppm 00: Level II, ± 1000 ppm 01: Level III, variable pitch shifted | | |
| 30 – 31 | Reserved | | | |
| 32 | Word length (field size) | 0: Maximum length 20 bits 1: Maximum length 24 bits | | |
| 33 – 35 | Word length | | If bit 32 = 1 | If bit 32 = 0 |
| | | 000 | Not indicated | Not indicated |
| | | 101 | 24 bits | 20 bits |
| | | 001 | 23 bits | 19 bits |
| | | 010 | 22 bits | 18 bits |
| | | 011 | 21 bits | 17 bits |
| 100 | 20 bits | 16 bits | | |

Table 3-43 AES3/SPDIF Consumer mode bit description (continued)

| Bits | Label | Description |
|---------------------|-----------------------------|-------------------------|
| 36 – 39 | Original sampling frequency | 1111: 44.1 kHz |
| | | 1110: 88.2 kHz |
| | | 1101: 22.05 kHz |
| | | 1100: 176.4 kHz |
| | | 1011: 48 kHz |
| | | 1010: 96 kHz |
| | | 1001: 24 kHz |
| | | 1000: 192 kHz |
| | | 0111: Reserved |
| | | 0110: 8 kHz |
| | | 0101: 11.025 kHz |
| | | 0100: 12 kHz |
| | | 0011: 32 kHz |
| | | 0010: Reserved |
| 0001: 16 kHz | | |
| 0000: Not indicated | | |
| 40 – 41 | CGMS-A | 00: Copying permitted |
| | | 01: Condition not used |
| | | 10: One generation copy |
| | | 11: Copying denied |
| 42 – 192 | Reserved | |

Edit Bits (Professional format)

The AES3/SPDIF bits configuration for the Professional format is displayed as shown in **Figure 3-72**.




Figure 3-73 Digital Generator > AES Config > Edit Bits (Consumer format) menu page 1

Table 3-44 Digital Generator > AES Config > Edit Bits (Professional format) menu description

| Menu | Description |
|-------------|--|
| Select Byte | Press the Select Byte softkey to select the byte and edit the byte. |
| Audio Mode | Press the Audio Mode softkey to select the audio mode. <ul style="list-style-type: none"> - Non-Linear PCM - Linear PCM |
| Emphasis | Press the Emphasis softkey to select the emphasis type. <ul style="list-style-type: none"> - Not indicated - No pre-emphasis - 50/15 μs - CCITT J.17 |
| Freq Mode | Press the Freq Mode softkey to select the frequency mode. <ul style="list-style-type: none"> - Locked - Unlocked |

Table 3-44 Digital Generator > AES Config > Edit Bits (Professional format) menu description (continued)

| Menu | Description |
|---------------------|--|
| Sample Freq | <p>Press the Sample Freq softkey to select the sample frequency value.</p> <ul style="list-style-type: none"> - Not indicated - 22.05 kHz - 24 kHz - 32 kHz - 44.1 kHz - 48 kHz - 88.2 kHz - 96 kHz - 176.4 kHz - 192 kHz |
| Freq Scaling | <p>Press the Freq Scaling softkey to enable or disable frequency scaling.</p> |
| Chan Mode | <p>Press the Chan Mode softkey to select the channel mode.</p> <ul style="list-style-type: none"> - Not indicated - 2-channel - Single channel - Primary-Secondary - Stereo - Reserved 1 - Reserved 2 - Mono Double Rate - Left Double Rate - Right Double Rate - Multichannel |
| User Bits | <p>Press the User Bits softkey to select the user bits type.</p> <ul style="list-style-type: none"> - Not indicated - 192-bit block - Reserved for AES18 - User defined - Reserved for Metadata - As in IEC60958-3 |
| Aux Bits | <p>Press the Aux Bits softkey to select the auxiliary bits.</p> <ul style="list-style-type: none"> - 20-bit not defined - 24-bit main audio - 20-bit single - Reserved |

Table 3-44 Digital Generator > AES Config > Edit Bits (Professional format) menu description (continued)

| Menu | Description |
|-----------------------|--|
| Word Length | <p>Press the Word Length softkey to select the word length.</p> <p>24 bits maximum word length</p> <ul style="list-style-type: none"> - Not indicated - 20 bits - 21 bits - 22 bits - 23 bits - 24 bits <p>20 bits maximum word length</p> <ul style="list-style-type: none"> - Not indicated - 16 bits - 17 bits - 18 bits - 19 bits - 20 bits |
| Alignment | <p>Press the Alignment softkey to select the alignment level.</p> <ul style="list-style-type: none"> - Not Indicated - -18.06 dBFS - -20 dBFS - Reserved |
| Multi-Channel | <p>Press the Multi-Channel softkey to select the multi-channel status.</p> <ul style="list-style-type: none"> - Defined - Undefined |
| Multi-Ch Mode | <p>This is only available when the multi-channel status is set to Defined.</p> <p>Press the Multi-Ch Mode softkey to select the multi-channel mode.</p> <ul style="list-style-type: none"> - Mode 0 - Mode 1 - Mode 2 - Mode 3 - User Defined |
| Channel Num | <p>Press the Channel Num softkey to set the channel number.</p> <ul style="list-style-type: none"> - 1 to 16 (Defined multi-channel status) - 1 to 128 (Undefined multi-channel status) |
| Ref Signal | <p>Press the Ref Signal softkey to select the reference signal type.</p> <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved |
| Channel Origin | <p>Press the Channel Origin softkey to set the channel origin value (4 alphanumeric digit).</p> |
| Channel Dest | <p>Press the Channel Dest softkey to set the channel destination value (4 alphanumeric digit).</p> |
| Local Addr | <p>Press the Local Addr softkey to set the local address value.</p> <ul style="list-style-type: none"> - 0 to $2^{32}-1$ |

Table 3-44 Digital Generator > AES Config > Edit Bits (Professional format) menu description (continued)

| Menu | Description |
|--------------------|--|
| Time of Day | Press the Time of Day softkey to set the time of day. - 0 to $2^{32}-1$ |
| Rel Flags | Press the Rel Flags softkey to select the reliability flags. - 0-5 - 6-13 - 14-17 - 18-21 |

Table 3-45 AES3/SPDIF Professional mode bit description

| Bits | Label | Description |
|--------|--------------------|--|
| 0 | Application mode | 0: Consumer 1: Professional |
| 1 | Non-audio | 0: Audio data is linear PCM samples 1: Other than linear PCM samples |
| 2 - 4 | Emphasis | 000: Not indicated 100: No emphasis 110: CD-type emphasis 111: J-17 emphasis |
| 5 | Lock | 0: Not indicated 1: Unlocked |
| 6 - 7 | Sampling frequency | 00: Not indicated (or see byte 4) 10: 48 kHz 01: 44.1 kHz 11: 32 kHz |
| 8 - 11 | Channel mode | 0000: Not indicated (default to 2 channels) 0001: 2 channels 0010: 1 channel (monophonic) 0011: Primary/secondary 0100: Stereo 0101: Reserved for user application 0110: Reserved for user application 0111: SCDSR (see byte 3 for ID) 1000: SCDSR (stereo left) 1001: SCDSR (stereo right) 1111: Multichannel (see byte 3 for ID) |
| | | Single Channel Double Sample Rate (SCDSR) |

Table 3-45 AES3/SPDIF Professional mode bit description (continued)

| Bits | Label | Description | | | | | | | | | | | | | | | | | | | | | |
|-----------|---------------------------------------|--|--|----------------------|----------------------|------|---------------|---------------|------|---------|---------|------|---------|---------|------|---------|---------|------|---------|---------|------|---------|---------|
| 12 – 15 | User bit management | 0000: Not indicated 0001: 192-bit block as in channel status 0010: As defined in AES18 0011: User-defined 0100: As in IEC60958-3 (consumer) | | | | | | | | | | | | | | | | | | | | | |
| 16 – 18 | Use of AUX sample word | 0000: Not defined, audio maximum 20 bits 0001: Used for main audio, maximum 24 bits 0010: Used for coordination signal, audio maximum 20 bits 0011: User-defined | | | | | | | | | | | | | | | | | | | | | |
| 19 – 21 | Source word length | <table border="0"> <tr> <td></td> <td>If maximum = 24 bits</td> <td>If maximum = 20 bits</td> </tr> <tr> <td>000:</td> <td>Not indicated</td> <td>Not indicated</td> </tr> <tr> <td>001:</td> <td>23 bits</td> <td>19 bits</td> </tr> <tr> <td>010:</td> <td>22 bits</td> <td>18 bits</td> </tr> <tr> <td>011:</td> <td>21 bits</td> <td>17 bits</td> </tr> <tr> <td>100:</td> <td>20 bits</td> <td>16 bits</td> </tr> <tr> <td>101:</td> <td>24 bits</td> <td>20 bits</td> </tr> </table> | | If maximum = 24 bits | If maximum = 20 bits | 000: | Not indicated | Not indicated | 001: | 23 bits | 19 bits | 010: | 22 bits | 18 bits | 011: | 21 bits | 17 bits | 100: | 20 bits | 16 bits | 101: | 24 bits | 20 bits |
| | If maximum = 24 bits | If maximum = 20 bits | | | | | | | | | | | | | | | | | | | | | |
| 000: | Not indicated | Not indicated | | | | | | | | | | | | | | | | | | | | | |
| 001: | 23 bits | 19 bits | | | | | | | | | | | | | | | | | | | | | |
| 010: | 22 bits | 18 bits | | | | | | | | | | | | | | | | | | | | | |
| 011: | 21 bits | 17 bits | | | | | | | | | | | | | | | | | | | | | |
| 100: | 20 bits | 16 bits | | | | | | | | | | | | | | | | | | | | | |
| 101: | 24 bits | 20 bits | | | | | | | | | | | | | | | | | | | | | |
| 22 – 23 | Alignment level | 00: Not indicated 01: -20 dBFS 10: -18.06 dBFS | | | | | | | | | | | | | | | | | | | | | |
| 24 – 31 | Channel identification | If bit 31 = 0, then channel number is 1 plus the numeric value of bits 24 - 30. If bit 31 = 1, then bits 4 - 6 define a multichannel mode and bits 0 - 3 give the channel number within that mode. | | | | | | | | | | | | | | | | | | | | | |
| 32 – 33 | Digital Audio Reference Signal (DARS) | 00: Not a DARS 01: DARS grade 1 (± 1 ppm) 10: DARS grade 2 (± 10 ppm) | | | | | | | | | | | | | | | | | | | | | |
| 35 – 38 | Sampling frequency | 0000: Not indicated 1000: 24 kHz 0100: 96 kHz 1001: 22.05 kHz 0101: 88.2 kHz 1101: 176.4 kHz 1111: User defined | | | | | | | | | | | | | | | | | | | | | |
| 39 | Sampling frequency scaling | 0: No scaling 1: Apply factor of 1/1.001 to value | | | | | | | | | | | | | | | | | | | | | |
| 48 – 79 | Alphanumeric channel origin | Four-character label using 7-bit ASCII with no parity. Bit 55, 63, 71, 79 = 0 | | | | | | | | | | | | | | | | | | | | | |
| 80 – 111 | Alphanumeric channel destination | Four-character label using 7-bit ASCII with no parity. Bit 87, 95, 103, 111 = 0 | | | | | | | | | | | | | | | | | | | | | |
| 112 – 143 | Local sample address code | 32-bit binary number representing the sample count of the first sample of the channel status block | | | | | | | | | | | | | | | | | | | | | |
| 144 – 175 | Time of day code | 32-bit binary number representing time source encoding in samples since midnight | | | | | | | | | | | | | | | | | | | | | |

Table 3-45 AES3/SPDIF Professional mode bit description (continued)

| Bits | Label | Description |
|-----------|-------------------|--|
| 176 - 183 | Reliability flags | 0: Data in byte range is reliable 1: Data in byte range is unreliable |
| 184 - 191 | CRCC | 00000000: Not implemented nnnnnnnn: Error check code for bits 0 - 183 |

References (Analog Generator)

The output references for the analog generator is displayed as shown in **Figure 3-74**.



Figure 3-74 Analog Generator > References menu page

Table 3-46 Analog Generator > References menu description

| Menu | Description |
|-----------------|---|
| Ref. Imp | Press the Ref. Imp softkey to set the reference impedance for the unit conversion of dBm measurements. |

References (Digital and *Bluetooth* Generator)

The output references for the digital and *Bluetooth* generator is displayed as shown in **Figure 3-75** and **Figure 3-76** respectively.




Figure 3-75 Digital Generator > References menu page



Figure 3-76 *Bluetooth* Generator > References menu page

Table 3-47 Digital/*Bluetooth* Generator > References menu description

| Menu | Description |
|----------|--|
| Volts/FS | Press the Volts/FS softkey to set the volts/FS reference for the analog output voltage (in Volts) of the DAC used when converted to digital full scale (1 FS). This is useful in DAC tests for the conversion of digital units to analog units. |

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

Keysight U8903B
Performance Audio Analyzer
User's Guide

4 Audio Analyzer Measurement Functions

| | |
|---|-----|
| Audio Analyzer | 177 |
| Measurement mode (Digital Analyzer) | 181 |
| Functions | 184 |
| Measurement Functions | 186 |
| Frequency measurement | 186 |
| AC voltage level measurement | 189 |
| DC voltage level measurement | 193 |
| THD+N ratio and THD+N level measurements | 196 |
| SINAD measurement | 202 |
| THD ratio and THD level measurements | 205 |
| SMPTE IMD measurements | 212 |
| DFD measurements | 215 |
| SNR measurement | 217 |
| SNR (fast mode) measurement | 219 |
| J-test measurement | 222 |
| Positive peak measurement | 223 |
| Negative peak measurement | 225 |
| Phase Measurement | 227 |
| Crosstalk Measurement | 230 |
| Filters Configuration (Analog Analyzer) | 233 |
| Notch Filter | 235 |
| Filters Configuration (Digital Analyzer) | 236 |
| Filters Configuration (Bluetooth Analyzer) | 238 |
| Notch Filter | 239 |
| Measurement Configuration (Analog Analyzer) | 240 |
| Measurement Configuration (Digital Analyzer) | 242 |
| Measurement Configuration (Bluetooth Analyzer) | 244 |
| Trigger (Analog, Digital, and Bluetooth Analyzer) | 246 |
| Input Configuration (Analog Analyzer) | 248 |
| Input Configuration (Digital Analyzer) | 250 |
| Link Configuration (Bluetooth Analyzer) | 252 |
| DSI Input Configuration (Digital Analyzer) | 253 |
| AES/SPDIF Input Configuration (Digital Analyzer) | 255 |
| Bits Analysis (Digital Analyzer) | 256 |

4 Audio Analyzer Measurement Functions

Wave File (Analog, Digital, and Bluetooth Analyzer) 257

Statistics 259

This chapter describes the U8903B performance audio analyzer measurement functions and configurations.

Audio Analyzer

Press  on the FUNCTION panel to switch between audio generator or audio analyzer mode. The Analog Analyzer menu page, Digital Analyzer menu page, and *Bluetooth* Analyzer menu page are displayed as shown in **Figure 4-1**, **Figure 4-2**, and **Figure 4-3** respectively.

Press  on the FUNCTION panel to switch between analog and digital interface.

Press  or  on the CHANNEL/DATA panel to switch to channel 1 or channel 2 respectively, and start configuring the active channel.

The U8903B can also be expanded with additional analog analyzer channels. Refer to “**U8903B Options**” on page **37** for more information.

Press  on the RUN CONTROL panel to start or stop the measurements for the selected analyzer channel.




Figure 4-1 Analog Analyzer menu page

Table 4-1 Analog Analyzer menu description

| Menu | Description |
|----------------|---|
| Functions | Press the Functions softkey to configure the analog analyzer functions. Refer to “ Functions ” on page 184 for more information. |
| Filters Config | Press the Filters Config softkey to set the filters configuration. Refer to “ Filters Configuration (Analog Analyzer) ” on page 233 for more information. |
| Meas Config | Press the Meas Config softkey to set the measurement configuration. Refer to “ Measurement Configuration (Analog Analyzer) ” on page 240 for more information. |
| Input Config | Press the Input Config softkey to set the input configuration. Refer to “ Input Configuration (Analog Analyzer) ” on page 248 for more information. |
| Wave File | Press the Wave File softkey to configure the wave file settings. Refer to “ Wave File (Analog, Digital, and Bluetooth Analyzer) ” on page 257 for more information. |
| Statistics | Press the Statistics softkey to configure the statistics settings. Refer to “ Statistics ” on page 259 for more information. |


**Figure 4-2** Digital Analyzer menu page (standard measurement mode)

Table 4-2 Digital Analyzer menu description

| Menu | Description |
|-----------------------|---|
| Meas Mode | <p>Press the Meas Mode softkey to select the measurement mode. Refer to “Measurement mode (Digital Analyzer)” on page 181 for more information.</p> <ul style="list-style-type: none"> – Standard – Process Delay – BERT |
| Unit | <p>This is only available when the measurement mode is BERT.</p> <p>Press the Unit softkey to select the unit for the BERT measurement mode.</p> <ul style="list-style-type: none"> – Hex – Dec |
| Functions | <p>This is only available when the measurement mode is Standard.</p> <p>Press the Functions softkey to configure the analog analyzer functions. Refer to “Functions” on page 184 for more information.</p> |
| Filters Config | <p>This is only available when the measurement mode is Standard.</p> <p>Press the Filters Config softkey to set the filters configuration. Refer to “Filters Configuration (Digital Analyzer)” on page 236 for more information.</p> |
| Meas Config | <p>This is only available when the measurement mode is Standard.</p> <p>Press the Meas Config softkey to set the measurement configuration. Refer to “Measurement Configuration (Digital Analyzer)” on page 242 for more information.</p> |
| Input Config | <p>Press the Input Config softkey to set the input configuration. Refer to “Input Configuration (Digital Analyzer)” on page 250 for more information.</p> |
| DSI Config | <p>Press the DSI Config softkey to set the DSI input configurations such as the format, resolution, and others. Refer to “DSI Input Configuration (Digital Analyzer)” on page 253 for more information.</p> |
| AES/SPDIF | <p>Press the AES/SPDIF softkey to set the AES3/SPDIF input configurations such as the decoding, resolution, and others. Refer to “AES/SPDIF Input Configuration (Digital Analyzer)” on page 255 for more information.</p> |
| Bits Analysis | <p>Press the Bits Analysis softkey to set the bits analysis configuration. Refer to “Bits Analysis (Digital Analyzer)” on page 256 for more information.</p> |
| Statistics | <p>Press the Statistics softkey to configure the statistics settings. Refer to “Statistics” on page 259 for more information.</p> |




Figure 4-3 Bluetooth Analyzer menu page

Table 4-3 Bluetooth Analyzer menu description

| Menu | Description |
|----------------|---|
| Functions | Press the Functions softkey to configure the analog analyzer functions. Refer to “ Functions ” on page 184 for more information. |
| Filters Config | Press the Filters Config softkey to set the filters configuration. Refer to “ Filters Configuration (Analog Analyzer) ” on page 233 for more information. |
| Meas Config | Press the Meas Config softkey to set the measurement configuration. Refer to “ Measurement Configuration (Analog Analyzer) ” on page 240 for more information. |
| Link Config | Press the Link Config softkey to set the input configuration. Refer to “ Link Configuration (Bluetooth Analyzer) ” on page 252 for more information. |
| Wave File | Press the Wave File softkey to configure the wave file settings. Refer to “ Wave File (Analog, Digital, and Bluetooth Analyzer) ” on page 257 for more information. |
| Statistics | Press the Statistics softkey to configure the statistics settings. Refer to “ Statistics ” on page 259 for more information. |

Measurement mode (Digital Analyzer)

Standard

Standard mode is the default mode for the digital analyzer.

Process delay

The process delay measurement calculates the time difference between the output and input frames. A digital audio signal will have delay when the signal is transmitted through a DUT. The process delay measurement calculates the time difference between the first output frame signal and the first input frame signal. Due to the nature of measurements involving frame-to-frame delay, this measurement is only meant for the AES3 signal which has a unique frame pattern. Process delay mode allows you to view the process delay in seconds.

NOTE

When the digital analyzer analysis mode is set to Process Delay, you are not allowed to perform any other types of measurements.



Figure 4-4 Digital Analyzer menu page (process delay measurement mode)

BERT (Bit Error Rate Test)

The BERT mode measurement will provide the total errors, total bits run, and bit error rate. This test will only be meaningful if the selected output and input connectors are the same type.

The U8903B is able to analyze all waveform types generated by the digital generator. In BERT mode except for the following:

- Monotonicity
- Square wave with the frequency setting less than half the sampling rate
- Walking one or walking zero with the Sample per Step setting more than 1

NOTE

If square wave for BERT analysis is needed, set the frequency of the square wave to be equal to half the sampling rate.

If walking one or walking zero for BERT analysis is needed, set the sample per step to be equal to 1.

NOTE

When the digital analyzer measurement mode is set to BERT, you are not allowed to perform any other types of measurements.



Figure 4-5 Digital Analyzer menu page (BERT measurement mode)

Table 4-4 Digital Analyzer > Meas Mode > BERT menu description

| Menu | Description |
|-------------------|---|
| Unit | Press the Unit softkey to select the BERT result in either hex or decimal. <ul style="list-style-type: none">- Hex- Dec |
| Reset BERT | Press the Reset BERT softkey to reset the BERT result. |

Functions

The U8903B supports up to four functions to be measured in one single query. The function configuration for analog, digital, and *Bluetooth* analyzer are displayed as shown in **Figure 4-6**, **Figure 4-7**, and **Figure 4-8**.




Figure 4-6 Analog Analyzer > Functions menu page 1




Figure 4-7 Digital Analyzer > Functions menu page 1



Figure 4-8 Bluetooth Analyzer > Functions menu page 1

Table 4-5 Analog/Digital/Bluetooth Analyzer > Functions menu description

| Menu | Description |
|---------------------|--|
| Multi-Chn | <p>Press the Multi-Chn softkey to select the multichannel measurement mode.</p> <ul style="list-style-type: none"> - Off The measurement functions are set independently across all channels. - Phase Refer to “Phase Measurement” on page 227 for the configuration. - X-Talk Refer to “Crosstalk Measurement” on page 230 for the configuration. |
| Function No. | <p>Press the Function No. softkey to select the active function number to configure the settings.</p> |
| Meas. Func | <p>Press the Meas. Func softkey to display the list of available analyzer measurement function types. Select the desired measurement function from the drop-down list. Refer to “Measurement Functions” on page 186 for the respective measurement functions settings.</p> <p>This setting is only available when the multichannel mode is set to Off.</p> |

Measurement Functions

Frequency measurement

Frequency is a common and basic measurement function which is expressed in hertz (Hz). The U8903B uses software algorithm to detect the period of a repetitive waveform, and the frequency is computed from the reciprocal of the period.

To obtain better accuracy and resolution, auto ranging should be enabled. For low-frequency signals, set a larger sample size to obtain better and more stable readings. Input filters can also be activated to remove unwanted high-frequency noise from the measured signal, allowing more stable readings.

Frequency measurement function mode is applicable for the analog, digital, and *Bluetooth* analyzer. The settings for frequency measurement are displayed as shown in **Figure 4-9**, **Figure 4-10**, and **Figure 4-11** for the analog, digital, and *Bluetooth* analyzer respectively.

NOTE

A limitation in the firmware supplied by the *Bluetooth* chipset vendor causes the *Bluetooth* analyzer frequency measurement for the A2DP profile under SBC codec at 44.1 kHz sampling rate to exhibit a $\pm 0.05\%$ measurement error. Do expect approximately 30 s of settling time for the first frequency measurement in the A2DP profile after the Open Media Connection have been initiated.




Figure 4-9 Analog Analyzer > Functions > Frequency menu page 1



Figure 4-10 Digital Analyzer > Functions > Frequency menu page 1



Figure 4-11 Bluetooth Analyzer > Functions > Frequency menu page 1

Table 4-6 Analog/Digital/Bluetooth Analyzer > Functions > Frequency menu description

| Menu | Description |
|--------|---|
| Unit | Press the Unit softkey to select the measurement unit. <ul style="list-style-type: none"> - Hz - ΔHz |
| Format | Press the Format softkey to select the format of the returned measurement reading. <ul style="list-style-type: none"> - Off - Selecting Off will return the measurement reading without any formatting (raw value). - Delta - Selecting Delta will return the measurement result by deducting the reference frequency from the measured frequency. |

Table 4-6 Analog/Digital/*Bluetooth* Analyzer > Functions > Frequency menu description (continued)

| Menu | Description |
|-------------------------|--|
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference frequency. |
| Ref. Freq | Press the Ref. Freq softkey to set the reference frequency. |

AC voltage level measurement

NOTE

Ensure that the input coupling is set to AC before measuring AC voltage level. Refer to “**Input Configuration (Analog Analyzer)**” on page 248 and “**Measurement Configuration (Digital Analyzer)**” on page 242 for more information.

AC voltage level measurement is the most common measurement function of an AC signal. The U8903B provides two types of AC level detection consisting of rms and peak-to-peak. When the rms detection method is selected, the AC voltage measurement is expressed as an rms value. Likewise, if the peak-to-peak detector is selected, the result is a peak-to-peak value.

As an example, for a 1 Vrms sine input signal, the display will show 1 V if the rms detector is selected. On the other hand, if the peak-to-peak detector is selected, the display will show 2.828 V (1.414×2).

AC voltage level measurement function mode is applicable for the analog, digital, and *Bluetooth* analyzer. The settings for AC voltage level measurement are displayed as shown in **Figure 4-12**, **Figure 4-13** and **Figure 4-14** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-12 Analog Analyzer > Functions > AC Voltage menu page 1



Figure 4-13 Digital Analyzer > Functions > AC Voltage menu page 1



Figure 4-14 Bluetooth Analyzer > Functions > AC Voltage menu page 1

Table 4-7 Analog/Digital/*Bluetooth* Analyzer > Functions > AC Voltage menu description

| Menu | Description |
|--------------------------------|---|
| Unit | Press the Unit softkey to select the measurement unit. Analog Analyzer |
| | <ul style="list-style-type: none"> - dBg - dBm - dBr - dBu - dBV - W - V - ΔV - dBSPL - x |
| Unit | Digital and <i>Bluetooth</i> Analyzer |
| | <ul style="list-style-type: none"> - FFS - dBFS - %FS - V - dBu - dBV - dBr - x - LSB - Hex - Dec - dBSPL |
| Format | Press the Format softkey to select the format of the returned measurement reading. |
| | <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Logarithmic Selecting Logarithmic will return the measurement result by using the following formula: $20 \log_{10} \left(\frac{\text{Measured rms voltage}}{\text{Reference level}} \right)$ The result is returned in unit dBr. - Linear Selecting Linear will return the measurement result by dividing the measured level by the reference level. The result is returned in unit x. - Delta Selecting Delta will return the measurement result by deducting the reference level from the measured level. The result is returned in unit ΔV. This is only available for the analog analyzer. |
| | |
| Set to 0dB | This is only available for analog analyzer. Press the Set to 0dB softkey to store the measured level as the reference level, and set the measurement reading format to Logarithmic. |
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference level. |
| Ref. Level | Press the Ref. Level softkey to set the reference level value. There is only one reference level for each channel. |

Table 4-7 Analog/Digital/*Bluetooth* Analyzer > Functions > AC Voltage menu description (continued)

| Menu | Description |
|-----------------|--|
| Ref. Imp | This is only available for the analog analyzer. Press the Ref. Imp softkey to set the reference impedance value. This setting is only available if the unit is set to W. |
| Volt/FS | This is only available for the digital analyzer. Press the Volt/FS softkey to set the volts/FS reference value. |
| Cal SPL | Press the Cal SPL softkey to set the calibrator level value. This setting is only available when the unit is set to dB SPL. |
| Detector | Press the Detector softkey to select the AC level detection type. <ul style="list-style-type: none"> - RMS - Pk-Pk |

DC voltage level measurement

NOTE

Ensure that the input coupling is set to DC before measuring DC voltage level. Refer to “**Input Configuration (Analog Analyzer)**” on page 248 and “**Measurement Configuration (Digital Analyzer)**” on page 242 for more information.

DC voltage levels are often encountered in audio equipment although they are not part of the audio signal, for example, bias voltages and outputs from AC-to-DC converters. DC voltage is expressed in volts (V). The input coupling must be set to DC for DC voltage level measurement.

DC voltage level measurement function mode is applicable for the analog, digital, and *Bluetooth* analyzer. The settings for DC voltage level measurement are displayed as shown in **Figure 4-15**, **Figure 4-16**, and **Figure 4-17** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-15 Analog Analyzer > Functions > DC Voltage menu page 1




Figure 4-16 Digital Analyzer > Functions > DC Voltage menu page 1




Figure 4-17 Bluetooth Analyzer > Functions > DC Voltage menu page 1

Table 4-8 Analog/Digital/*Bluetooth* Analyzer > Functions > DC Voltage menu description

| Menu | Description |
|--------------------------------|--|
| Unit | Press the Unit softkey to select the measurement unit. Analog Analyzer |
| | <ul style="list-style-type: none"> - V - ΔV - x Digital and <i>Bluetooth</i> Analyzer <ul style="list-style-type: none"> - FFS - V - LSB - Hex - Dec - x |
| Format | Press the Format softkey to select the format of the returned measurement reading. |
| | <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Linear Selecting Linear will return the measurement result by dividing the measured level by the reference level. The result is returned in unit x. - Delta Selecting Delta will return the measurement result by deducting the reference level from the measured level. The result is returned in unit ΔV. This is only available for the analog analyzer. |
| | |
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference level. |
| Ref. Level | Press the Ref. Level softkey to set the reference level value. There is only one reference level for each channel. |

THD+N ratio and THD+N level measurements

Harmonic distortion on a spectrally pure signal is created by nonlinearities in the circuit through which it passes. The nonlinearities can arise in the transfer characteristics of an active device or by running the active device into saturation or cutoff. In most cases, distortion can be reduced by decreasing the signal level, applying filtering, or adding negative feedback.

According to Fourier mathematics, the nonlinear terms in the circuit transfer function give rise to harmonics of the signal. Therefore, the THD+N function provides a quantitative measurement of the quality of an audio signal or in other words, the purity of a signal.

The THD+N ratio is defined as the ratio of the square root of the sum of the squares of all the signal harmonics components and noise amplitude, relative to the total signal amplitude. The THD+N ratio can be computed as follows.

$$\text{THD+N ratio} = 20 \text{ Log}_{10} \left(\frac{\text{rms value of noise and distortion}}{\text{rms value of signal, noise, and distortion}} \right)$$

THD+N ratio measurement function mode is applicable for the analog, digital, and *Bluetooth* analyzer. The settings for THD+N ratio measurement are displayed as shown in **Figure 4-18**, **Figure 4-19**, and **Figure 4-20** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-18 Analog Analyzer > Functions > THD+N Ratio menu page 1



Figure 4-19 Digital Analyzer > Functions > THD+N Ratio menu page 1



Figure 4-20 Bluetooth Analyzer > Functions > THD+N Ratio menu page 1

Table 4-9 Analog/Digital/*Bluetooth* Analyzer > Functions > THD+N Ratio menu description

| Menu | Description |
|--------------------------------|---|
| Unit | Press the Unit softkey to select the measurement unit. <ul style="list-style-type: none"> - dB - ΔdB - % - x |
| Format | Press the Format softkey to select the format of the returned measurement reading. <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Linear Selecting Linear will return the measurement result by dividing the measured ratio by the reference ratio. The result is returned in unit x. - Delta Selecting Delta will return the measurement result by deducting the reference ratio from the measured ratio. The result will be returned in unit ΔdB. |
| Set to 0dB | This is only available for analog analyzer. Press the Set to 0dB softkey to store the measured ratio as the reference ratio, and set the measurement reading format to Delta. |
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference ratio. |
| Ref. Ratio | Press the Ref. Ratio softkey to set the reference ratio value. |
| Precision | This is only available for digital analyzer. Press the Precision softkey to enable or disable the precision mode. |
| Freq Lock | Press the Freq Lock softkey to select the searching method for the fundamental frequency. <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. You can select the generator channel by setting the Src Channel in the Meas. Config. menu page. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. |
| Analog Notch | This is only available for analog analyzer. Press the Analog Notch softkey to enable or disable the analog notch filter. This filter is used to emulate the analog notch filter used in HP8903B. |

THD+N level is defined as the square root of the sum of the squares of all the signal harmonics components and noise amplitude, and it is expressed in Vrms. The THD+N level can be computed as follows.

THD+N Level = rms value of noise and distortion

THD+N level measurement function mode is applicable for the analog, digital, and *Bluetooth* analyzer. The settings for THD+N level measurement are displayed as shown in **Figure 4-21**, **Figure 4-22**, and **Figure 4-23** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-21 Analog Analyzer > Functions > THD+N Level menu page 1



Figure 4-22 Digital Analyzer > Functions > THD+N Level menu page 1




Figure 4-23 Bluetooth Analyzer > Functions > THD+N Level menu page 1

Table 4-10 Analog/Digital/Bluetooth Analyzer > Functions > THD+N Level menu description

| Menu | Description |
|-------------|---|
| | Press the Unit softkey to select the measurement unit. |
| | Analog Analyzer |
| | - dBg |
| | - dBm |
| | - dB |
| | - dBu |
| | - dBV |
| | - W |
| | - V |
| | - ΔV |
| | - dB SPL |
| | - x |
| Unit | Digital and Bluetooth Analyzer |
| | - FFS |
| | - dBFS |
| | - %FS |
| | - V |
| | - dBu |
| | - dBV |
| | - dB |
| | - x |
| | - LSB |
| | - Hex |
| | - Dec |
| | - dB SPL |

Table 4-10 Analog/Digital/*Bluetooth* Analyzer > Functions > THD+N Level menu description (continued)

| Menu | Description |
|--------------------------------|---|
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Logarithmic Selecting Logarithmic will return the measurement result by using the following formula: $20 \log_{10} \left(\frac{\text{Measured rms voltage}}{\text{Reference level}} \right)$ <p>The result is returned in unit dBr.</p> - Linear Selecting Linear will return the measurement result by dividing the measured level by the reference level. The result is returned in unit x. - Delta Selecting Delta will return the measurement result by deducting the reference level from the measured level. The result is returned in unit ΔV. This is only available for the analog analyzer. |
| Set to 0dB | <p>This is only available for analog analyzer.</p> <p>Press the Set to 0dB softkey to store the measured level as the reference level, and set the measurement reading format to Logarithmic.</p> |
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference level. |
| Ref. Level | Press the Ref. Level softkey to set the reference level value. There is only one reference level for each channel. |
| Ref. Imp | <p>This is only available for the analog analyzer.</p> <p>Press the Ref. Imp softkey to set the reference impedance value. This setting is only available if the unit is set to W and dBm.</p> |
| Volt/FS | <p>This is only available for the digital and <i>Bluetooth</i> analyzer.</p> <p>Press the Volt/FS softkey to set the volts/FS reference value.</p> |
| Precision | <p>This is only available for the digital analyzer.</p> <p>Press the Precision softkey to enable or disable the precision mode.</p> |
| Cal SPL | Press the Cal SPL softkey to set the calibrator level value. This setting is only available when the unit is set to dB SPL. |
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. You can select the generator channel by setting the Src Channel in the Meas. Config. menu page. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. |
| Analog Notch | <p>This is only available for analog analyzer.</p> <p>Press the Analog Notch softkey to enable or disable the analog notch filter. This filter is used to emulate the analog notch filter used in HP8903B.</p> |

SINAD measurement

SINAD (Signal, Noise, and Distortion Ratio) is equal to the reciprocal of the distortion measurement. It is mostly used to determine the sensitivity of a communications receiver. The ratio computed in the SINAD measurement is shown as follows.

$$\text{SINAD} = 20 \text{ Log} \left(\frac{\text{rms value of signal, noise, and distortion}}{\text{rms value of noise and distortion}} \right)$$

SINAD measurement function mode is applicable for the analog, digital, and *Bluetooth* audio analyzer. The settings for SINAD measurement are displayed as shown in **Figure 4-24**, **Figure 4-25**, and **Figure 4-26** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-24 Analog Analyzer > Functions > SINAD menu page 1



Figure 4-25 Digital Analyzer > Functions > SINAD menu page 1



Figure 4-26 Bluetooth Analyzer > Functions > SINAD menu page 1

Table 4-11 Analog/Digital/Bluetooth Analyzer > Functions > SINAD menu description

| Menu | Description |
|--------------------------------|--|
| Unit | <p>Press the Unit softkey to select the measurement unit.</p> <ul style="list-style-type: none"> - dB - ΔdB - % - x |
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Linear Selecting Linear will return the measurement result by dividing the measured ratio by the reference ratio. The result is returned in unit x. - Delta Selecting Delta will return the measurement result by deducting the reference ratio from the measured ratio. The result will be returned in unit ΔdB. |
| Set to 0dB | <p>This is only available for the analog analyzer. Press the Set to 0dB softkey to store the measured ratio as the reference ratio, and set the measurement reading format to Delta.</p> |
| Set result as ref. from | <p>Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference ratio.</p> |
| Ref. Ratio | <p>Press the Ref. Ratio softkey to set the reference ratio value.</p> |
| Precision | <p>This is only available for the digital analyzer. Press the Precision softkey to enable or disable the precision mode.</p> |

Table 4-11 Analog/Digital/*Bluetooth* Analyzer > Functions > SINAD menu description (continued)

| Menu | Description |
|------------------|--|
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. You can select the generator channel by setting the Src Channel in the Meas. Config. menu page. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | <p>Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |

THD ratio and THD level measurements

THD (Total Harmonic Distortion) measures the selected harmonics amplitude that are generated due to the nonlinearity of the DUT and adding up the harmonics amplitude. The THD measurement will exclude any noise components that may be present in the DUT.

THD Ratio is defined as the ratio of the THD Level relative to the fundamental signal amplitude, and it is expressed in dB (default) or as a percentage. The THD Ratio can be computed as follows.

$$\text{THD ratio} = 20 \text{ Log}_{10} \left(\frac{\text{rms value of distortion}}{\text{rms value of signal and distortion}} \right)$$

THD+N Ratio measurement function mode is applicable for the analog, digital, and *Bluetooth* analyzer. The settings for THD ratio measurement are displayed as shown in **Figure 4-27**, **Figure 4-28**, and **Figure 4-29** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-27 Analog Analyzer > Functions > THD Ratio menu page 1




Figure 4-28 Digital Analyzer > Functions > THD Ratio menu page 1



Figure 4-29 Bluetooth Analyzer > Functions > THD Ratio menu page 1

Table 4-12 Analog/Digital/Bluetooth Analyzer > Functions > THD Ratio menu description

| Menu | Description |
|------|---|
| Unit | <p>Press the Unit softkey to select the measurement unit.</p> <ul style="list-style-type: none"> - dB - ΔdB - % - x |

Table 4-12 Analog/Digital/*Bluetooth* Analyzer > Functions > THD Ratio menu description (continued)

| Menu | Description |
|--------------------------------|--|
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Delta Selecting Delta will return the measurement result by deducting the reference ratio from the measured ratio. The result will be returned in unit ΔdB. - Linear Selecting Linear will return the measurement result by dividing the measured ratio by the reference ratio. The result is returned in unit x. |
| Set to 0dB | <p>This is only available for analog analyzer.</p> <p>Press the Set to 0dB softkey to store the measured ratio as the reference ratio, and set the measurement reading format to Delta.</p> |
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference ratio. |
| Ref. Ratio | Press the Ref. Ratio softkey to set the reference ratio value. |
| Even Harmonic | <p>Press the Even Harmonic softkey to display the even harmonics order selection. Press the Enter key on the navigation panel to select the desired even harmonics order, and press the Even Harmonic softkey again to confirm the selection.</p> <ul style="list-style-type: none"> - ALL - 2 - 4 - 6 - 8 |
| Odd Harmonic | <p>Press the Odd Harmonic softkey to display the odd harmonics order selection. Press the Enter key on the navigation panel to select the desired odd harmonics order, and press the Odd Harmonic softkey again to confirm the selection.</p> <ul style="list-style-type: none"> - ALL - 3 - 5 - 7 - 9 |
| Freq Lock | <p>This is only available for analog and <i>Bluetooth</i> analyzer.</p> <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. You can select the generator channel by setting the Src Channel in the Meas. Config. menu page. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. |

THD Level is defined as the square root of the sum of the squares of all the signal harmonics components, and it is expressed in Vrms. The THD Level can be computed as follows.

THD Level = rms value of distortion

THD+N Level measurement function mode is applicable for the analog, digital, and *Bluetooth* analyzer. The settings for THD level measurement are displayed as shown in **Figure 4-30**, **Figure 4-31**, and **Figure 4-32** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-30 Analog Analyzer > Functions > THD level menu page 1




Figure 4-31 Digital Analyzer > Functions > THD level menu page 1



Figure 4-32 Bluetooth Analyzer > Functions > THD level menu page 1

Table 4-13 Analog/Digital/Bluetooth Analyzer > Functions > THD Level menu description

| Menu | Description |
|-------------|---|
| | Press the Unit softkey to select the measurement unit. |
| | Analog Analyzer |
| | - dBg |
| | - dBm |
| | - dBr |
| | - dBu |
| | - dBV |
| | - W |
| | - V |
| | - ΔV |
| | - dB SPL |
| | - x |
| Unit | Digital and Bluetooth Analyzer |
| | - FFS |
| | - dBFS |
| | - %FS |
| | - V |
| | - dBu |
| | - dBV |
| | - dBr |
| | - x |
| | - LSB |
| | - Hex |
| | - Dec |
| | - dB SPL |

Table 4-13 Analog/Digital/*Bluetooth* Analyzer > Functions > THD Level menu description (continued)

| Menu | Description |
|--------------------------------|---|
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Logarithmic Selecting Logarithmic will return the measurement result by using the following formula: $20 \log 10 \left(\frac{\text{Measured rms voltage}}{\text{Reference level}} \right)$ The result is returned in unit dBr. - Linear Selecting Linear will return the measurement result by dividing the measured level by the reference level. The result is returned in unit x. - Delta Selecting Delta will return the measurement result by deducting the reference level from the measured level. The result is returned in unit ΔV. This is only available for the analog analyzer. |
| Set to 0dB | <p>This is only available for the analog analyzer. Press the Set to 0dB softkey to store the measured level as the reference level, and set the measurement reading format to Logarithmic.</p> |
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference level. |
| Ref. Level | Press the Ref. Level softkey to set the reference level value. There is only one reference level for each channel. |
| Ref. Imp | <p>This is only available for the analog analyzer. Press the Ref. Imp softkey to set the reference impedance value. This setting is only available if the unit is set to W and dBm.</p> |
| Volt/FS | <p>This is only available for the digital analyzer. Press the Volt/FS softkey to set the volts/FS reference value.</p> |
| Cal SPL | Press the Cal SPL softkey to set the calibrator level value. This setting is only available when the unit is set to dB SPL. |
| Even Harmonic | <p>Press the Even Harmonic softkey to select the even harmonics.</p> <ul style="list-style-type: none"> - ALL - 2 - 4 - 6 - 8 |
| Odd Harmonic | <p>Press the Odd Harmonic softkey to select the odd harmonics.</p> <ul style="list-style-type: none"> - ALL - 3 - 5 - 7 - 9 |

Table 4-13 Analog/Digital/*Bluetooth* Analyzer > Functions > THD Level menu description (continued)

| Menu | Description |
|------------------|--|
| Freq Lock | <p>This is only available for the analog and <i>Bluetooth</i> analyzer.</p> <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. You can select the generator channel by setting the Src Channel in the Meas. Config. menu page. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | <p>Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |

SMPTE IMD measurements

The SMPTE IMD function provides a measure of the second and third order intermodulation distortion introduced by the DUT by injecting two pure tones (tone 1 and tone 2, where tone 1 is at a much lower frequency than tone 2, for example, 60 Hz and 7 kHz respectively) into the DUT. SMPTE IMD is expressed in dB (default) or as a percentage.

If tone 1 = f_1 and tone 2 = f_2 , the following harmonics are considered.

- $f_2 - f_1$
- $f_2 + f_1$
- $f_2 - 2f_1$
- $f_2 + 2f_1$

The SMPTE IMD value is computed as the ratio of the sum of the intermodulation harmonics amplitude to the upper frequency tone amplitude. Refer to “**Dual waveform**” on page 106 for more information on generating dual tones for this measurement.

SMPTE IMD measurement function mode is applicable for the analog, digital, and *Bluetooth* analyzer. The settings for SMPTE IMD measurement are displayed as shown in **Figure 4-33**, **Figure 4-34**, and **Figure 4-35** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-33 Analog Analyzer > Functions > SMPTE IMD menu page 1



Figure 4-34 Digital Analyzer > Functions > SMPTE IMD menu page 1



Figure 4-35 Bluetooth Analyzer > Functions > SMPTE IMD menu page 1

Table 4-14 Analog/Digital/*Bluetooth* Analyzer > Functions > SMPTE IMD menu description

| Menu | Description |
|--------------------------------|--|
| Unit | <p>Press the Unit softkey to select the measurement unit.</p> <ul style="list-style-type: none"> - dB - ΔdB - % - x |
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Delta Selecting Delta will return the measurement result by deducting the reference ratio from the measured ratio. The result will be returned in unit ΔdB. - Linear Selecting Linear will return the measurement result by dividing the measured ratio by the reference ratio. The result is returned in unit x. |
| Set to 0dB | <p>This is only available for the analog analyzer.</p> <p>Press the Set to 0dB softkey to store the measured ratio as the reference ratio, and set the measurement reading format to Delta.</p> |
| Set result as ref. from | <p>Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference ratio.</p> |
| Ref. Ratio | <p>Press the Ref. Ratio softkey to set the reference ratio.</p> |
| Freq Lock | <p>This is only available for the analog and <i>Bluetooth</i> analyzer.</p> <p>Press the Freq Lock softkey to select the searching method for the upper and lower frequencies.</p> <ul style="list-style-type: none"> - Gen Lock Selecting Gen Lock will allow the U8903B to search for the upper and lower frequencies of the input signal based on the upper and lower frequencies of the respective generator channel. You can select the generator channel by setting the Src Channel in the Meas. Config. menu page. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the upper and lower frequency values by setting the searching method to Custom and setting the frequency value in Upper Freq and Lower Freq. |
| Upper Freq | <p>Press the Upper Freq softkey to set the upper frequency value. This setting is only available when Freq Lock is set to Custom.</p> |
| Lower Freq | <p>Press the Lower Freq softkey to set the lower frequency value. This setting is only available when Freq Lock is set to Custom.</p> |

DFD measurements

The DFD measurement is similar to SMPTE IMD, except that the two tones in the stimulus signal are of equal amplitude and are spaced closer to each other (typically 19 kHz and 20 kHz). This measurement also allows you to select either the second or third order intermodulation distortion. The available DFD measurements are DFD 60268 2nd, DFD 60268 3rd, DFD 60118 2nd, or DFD 60118 3rd.

DFD measurement function mode is applicable for the analog, digital, and *Bluetooth* audio analyzer. The settings for DFD measurements are displayed as shown in **Figure 4-36**, **Figure 4-37**, and **Figure 4-38** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-36 Analog Analyzer > Functions > DFD 60268 2nd menu page 1




Figure 4-37 Digital Analyzer > Functions > DFD 60268 2nd menu page 1



Figure 4-38 Bluetooth Analyzer > Functions > DFD 60268 2nd menu page 1

Table 4-15 Analog/Digital/Bluetooth Analyzer > Functions > DFD measurements menu description

| Menu | Description |
|--------------------------------|--|
| Unit | <p>Press the Unit softkey to select the measurement unit.</p> <ul style="list-style-type: none"> - dB - ΔdB - % - x |
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Delta Selecting Delta will return the measurement result by deducting the reference ratio from the measured ratio. The result will be returned in unit ΔdB. - Linear Selecting Linear will return the measurement result by dividing the measured ratio by the reference ratio. The result is returned in unit x. |
| Set to 0dB | <p>This is only available for the analog analyzer. Press the Set to 0dB softkey to store the measured ratio as the reference ratio, and set the measurement reading format to Delta.</p> |
| Set result as ref. from | <p>Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference ratio.</p> |
| Ref. Ratio | <p>Press the Ref. Ratio softkey to set the reference ratio.</p> |

SNR measurement

SNR is defined as the ratio of the signal amplitude to noise amplitude. The U8903B implementation of the SNR measurement is a closed-loop configuration in which both the generator and the analyzer are used in the test setup. For example, channel 1 of the analog generator and analog analyzer must be used together for this measurement.

SNR is further defined by the measurement bandwidth. The measurement bandwidth is specified by the filter selected for the audio analyzer. The SNR measurement is accomplished by an internal routine that alternatively switches the U8903B generator output on and off. When the U8903B output is in the off state, the U8903B output will be terminated at the DUT input.

The SNR result can be expressed in dB (default) or as a percentage. The SNR can be computed as follows.

$$\text{SNR} = 20 \text{ Log}_{10} \left(\frac{\text{rms value of signal}}{\text{rms value of noise}} \right)$$

SNR measurement function mode is applicable for analog analyzer only. The settings for SNR measurement are displayed as shown in **Figure 4-39**.




Figure 4-39 Analog Analyzer > Functions > SNR menu page 1

Table 4-16 Analog Analyzer > Functions > SNR menu description

| Menu | Description |
|--------------------------------|--|
| Unit | <p>Press the Unit softkey to select the measurement unit.</p> <ul style="list-style-type: none"> - dB - ΔdB - % - x |
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Delta Selecting Delta will return the measurement result by deducting the reference ratio from the measured ratio. The result will be returned in unit ΔdB. - Linear Selecting Linear will return the measurement result by dividing the measured ratio by the reference ratio. The result is returned in unit x. |
| Set to 0dB | <p>Press the Set to 0dB softkey to store the measured ratio as the reference ratio, and set the measurement reading format to Delta.</p> |
| Set result as ref. from | <p>Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference ratio.</p> |
| Ref. Ratio | <p>Press the Ref. Ratio softkey to set the reference ratio.</p> |
| SNR Delay | <p>Press the SNR Delay softkey to set the SNR delay.</p> |

SNR (fast mode) measurement

SNR (fast mode) measurement is used to measure the ratio of signal amplitude over noise amplitude. The SNR (fast mode) measurement is a frequency domain calculation. This method is significantly faster than the standard SNR measurement, but it is not suitable for measuring very high SNR. The noise measurement is made by notching out the fundamental and harmonics from the frequency spectrum.

You can set the number of harmonics that will be removed in the computation. For example, if the harmonics count is 1, the fundamental frequency will only be notched. If the harmonics count is 3, the fundamental frequency and the first and second harmonics will be notched for the calculation.

The SNR (fast mode) can be computed as follows.

$$\text{SNR} = 20 \text{ Log}_{10} \left(\frac{\text{rms value of signal}}{\text{rms value of noise}} \right)$$

SNR (fast mode) measurement function mode is applicable for the analog and *Bluetooth* analyzer. The settings for SNR (fast mode) measurement are displayed as shown in **Figure 4-40** and **Figure 4-41** for the analog and *Bluetooth* respectively.




Figure 4-40 Analog Analyzer > Functions > SNR (Fast) menu page 1



Figure 4-41 Bluetooth Analyzer > Functions > SNR (Fast) menu page 1

Table 4-17 Analog/Bluetooth Analyzer > Functions > SNR (Fast) menu description

| Menu | Description |
|-------------------------|--|
| Unit | <p>Press the Unit softkey to select the measurement unit.</p> <ul style="list-style-type: none"> - dB - ΔdB - % - x |
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Delta Selecting Delta will return the measurement result by deducting the reference ratio from the measured ratio. The result will be returned in unit ΔdB. - Linear Selecting Linear will return the measurement result by dividing the measured ratio by the reference ratio. The result is returned in unit x. |
| Set to 0dB | <p>This is only available for the analog analyzer.</p> <p>Press the Set to 0dB softkey to store the measured level or ratio as the reference value, and set the reading to refer to the stored reference value.</p> |
| Set result as ref. from | <p>Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference ratio.</p> |
| Ref. Ratio | <p>Press the Ref. Ratio softkey to set the reference ratio.</p> |

Table 4-17 Analog/Bluetooth Analyzer > Functions > SNR (Fast) menu description (continued)

| Menu | Description |
|------------------|--|
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. You can select the generator channel by setting the Src Channel in the Meas. Config. menu page. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | <p>Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |
| Harmonics | <p>Press the Harmonics softkey to set the number of harmonics order to be removed.</p> |

J-test measurement

Jitter in a digital system is defined as the variation in time between the periodic samples. Jitter may occur during sampling process of the ADC and DAC and clock recovery process. It can also appear in the data pattern of the digital interface link.

J-test is an AES3 test signal that is developed to simulate the worst case data jitter in the digital signal and also to test the jitter susceptibility of the DAC. The J-test signal consists of a test tone with a frequency at 1/4 of the sampling rate (F_s) and a jitter signal with a frequency of 1/192 F_s . The J-test digital pattern to be transmitted is as follows:

```
C00000 C00000 400000 400000  x24
BFFFFFF BFFFFFF BFFFFFF BFFFFFF  x24
```

The digital pattern will cause inter-symbol interference in the digital signal and stress the DAC clock recovery subsystem. You can measure the DAC system jitter performance by observing the analog output of the DAC in the FFT spectrum.

J-test measurement function mode is applicable for the analog analyzer only. The J-test measurement is displayed as shown in **Figure 4-42**.




Figure 4-42 Analog Analyzer > Functions > J-Test menu page

Positive peak measurement

Positive peak measurement function mode is a measurement of the greatest positive voltage level. Positive peak measurement function is applicable for the digital analyzer only. The positive peak measurement is displayed as shown in **Figure 4-43**.




Figure 4-43 Digital Analyzer > Functions > Positive Peak menu page

Table 4-18 Digital Analyzer > Functions > Positive Peak menu description

| Menu | Description |
|-------------|---|
| | Press the Unit softkey to select the measurement unit. |
| | - FFS |
| | - dBFS |
| | - %FS |
| | - V |
| | - dBu |
| Unit | - dBV |
| | - dB |
| | - x |
| | - LSB |
| | - Hex |
| | - Dec |
| | - dB SPL |

Table 4-18 Digital Analyzer > Functions > Positive Peak menu description (continued)

| Menu | Description |
|--------------------------------|--|
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Logarithmic Selecting Logarithmic will return the measurement result by using the following formula: $20 \log 10 \left(\frac{\text{Measured rms voltage}}{\text{Reference level}} \right)$ <p>The result is returned in unit dBr.</p> - Linear Selecting Linear will return the measurement result by dividing the measured level by the reference level. The result is returned in unit x. |
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference level. |
| Ref. Level | Press the Ref. Level softkey to set the reference level value. There is only one reference level for each channel. |
| Volt/FS | Press the Volt/FS softkey to set the volts/FS reference value. |
| Cal SPL | Press the Cal SPL softkey to set the calibrator level value. This setting is only available when the unit is set to dB SPL. |

Negative peak measurement

Negative peak measurement function mode is a measurement of the greatest negative voltage level. Negative peak measurement function is applicable for the digital analyzer only. The negative peak measurement is displayed as shown in **Figure 4-44**.




Figure 4-44 Digital Analyzer > Functions > Negative Peak menu page

Table 4-19 Digital Analyzer > Functions > Negative Peak menu description

| Menu | Description |
|-------------|---|
| | Press the Unit softkey to select the measurement unit. |
| | - FFS |
| | - dBFS |
| | - %FS |
| | - V |
| | - dBu |
| Unit | - dBV |
| | - dB |
| | - x |
| | - LSB |
| | - Hex |
| | - Dec |
| | - dB SPL |

Table 4-19 Digital Analyzer > Functions > Negative Peak menu description (continued)

| Menu | Description |
|--------------------------------|--|
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Logarithmic Selecting Logarithmic will return the measurement result by using the following formula: $20 \log 10 \left(\frac{\text{Measured rms voltage}}{\text{Reference level}} \right)$ The result is returned in unit dBr. - Linear Selecting Linear will return the measurement result by dividing the measured level by the reference level. The result is returned in unit x. |
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference level. |
| Ref. Level | Press the Ref. Level softkey to set the reference level value. There is only one reference level for each channel. |
| Volt/FS | Press the Volt/FS softkey to set the volts/FS reference value. |
| Cal SPL | Press the Cal SPL softkey to set the calibrator level value. This setting is only available when the unit is set to dB SPL. |

Phase Measurement

Phase measurements are used to describe the positive or negative time offset in a periodic waveform cycle (such as a sine waveform), measured from a reference waveform. The reference is usually the same signal at a different point in the system, or a related signal in a different channel of the system. Phase is expressed in degrees (°).

Phase shift varies with frequency, and therefore, it is common to make phase measurements at several frequencies or to plot the phase response of a frequency sweep.

There are generally two types of phase measurements as follows.

- interchannel phase delay
- device phase response

To make an interchannel phase measurement, the signal level must be specified. Phase measurements are generally not level-sensitive, as long as the signal is well above the noise and below distortion.

For example, to test the interchannel phase delay of a stereo system, we inject a 1 V_{rms}, 1 kHz sine waveform using the same analog generator channel. The output of one channel is connected to the analog analyzer channel 1 while the other is connected to channel 2. Set the analog analyzer to measure phase. If channel 1 is set as the reference channel, the channel 2 result is the interchannel phase delay.

A phase response measurement compares the phase of the output signal of a DUT to the phase of the signal at its input. For example, a simple way to make this measurement is to use the analog analyzer channel 1 to measure the input, and use the analog analyzer channel 2 to measure the output.

The U8903B always uses channel 1 of the analog generator as the reference channel, while the selected analog analyzer channel becomes the reference channel for interchannel phase measurements.

Phase measurement function mode is applicable for the analog, digital, and *Bluetooth* audio analyzer. The settings for phase measurement are displayed as shown in

Figure 4-45, **Figure 4-46**, and **Figure 4-47** for both the analog, digital, and *Bluetooth* analyzer respectively.

NOTE

Auto range will be disabled for phase measurement. Refer to “**Measurement Configuration (Analog Analyzer)**” on page 240 to set the input voltage range.



Figure 4-45 Analog Analyzer > Functions > Phase menu page



Figure 4-46 Digital Analyzer > Functions > Phase menu page



Figure 4-47 Bluetooth Analyzer > Functions > Phase menu page

Table 4-20 Analog/Digital/Bluetooth Analyzer > Functions > Phase menu description

| Menu | Description |
|--------------|--|
| Ref. Channel | Press the Ref. Channel softkey to set the reference channel number. |
| Freq Lock | <p>This is only available for the analog and <i>Bluetooth</i> analyzer.</p> <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. You can select the generator channel by setting the Src Channel in the Meas. Config. menu page. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. |

Crosstalk Measurement

In audio systems with more than one channel, it is common for a signal in one channel to appear at the output of another channel at a reduced level. Crosstalk refers to this signal leakage across channels, and it is expressed in dB (default) or as a percentage.

Crosstalk is a measurement of the ratio of the signal amplitude in an unused channel relative to that of a channel driven with a signal. The unused channels should be grounded or set to an appropriate bias point. Crosstalk is largely due to capacitive coupling between the channel conductors in the device and generally varies with frequency. Crosstalk can be computed as follows.

$$\text{Crosstalk} = 20 \text{ Log}_{10} \left(\frac{\text{rms value of signal measured}}{\text{rms value of signal driven}} \right)$$

Phase measurement function mode is applicable for the analog, digital, and *Bluetooth* audio analyzer. The settings for crosstalk measurement are displayed as shown in **Figure 4-48**, **Figure 4-49**, and **Figure 4-50** for the analog, digital, and *Bluetooth* analyzer respectively.




Figure 4-48 Analog Analyzer > Functions > X-Talk menu page 1



Figure 4-49 Digital Analyzer > Functions > X-Talk menu page 1



Figure 4-50 Bluetooth Analyzer > Functions > X-Talk menu page 1

Table 4-21 Analog/Digital/Bluetooth Analyzer > Functions > X-Talk menu description

| Menu | Description |
|--------------|--|
| Ref. Channel | Press the Ref. Channel softkey to set the driven channel. |
| Unit | Press the Unit softkey to select the measurement unit. - dB - ΔdB - % - x |

Table 4-21 Analog/Digital/Bluetooth Analyzer > Functions > X-Talk menu description (continued)

| Menu | Description |
|--------------------------------|--|
| Format | <p>Press the Format softkey to select the format of the returned measurement reading.</p> <ul style="list-style-type: none"> - Off Selecting Off will return the measurement reading without any formatting (raw value). - Delta Selecting Delta will return the measurement result by deducting the reference ratio from the measured ratio. The result will be returned in unit ΔdB. - Linear Selecting Linear will return the measurement result by dividing the measured ratio by the reference ratio. The result is returned in unit x. |
| Set to 0dB | <p>This is only available for the analog analyzer.</p> <p>Press the Set to 0dB softkey to store the measured level or ratio as the reference value, and set the reading to refer to the stored reference value.</p> |
| Set result as ref. from | Press the Set result as ref. from softkey to store the measurement result from the selected channel as the reference ratio. |
| Ref. Ratio | Press the Ref. Ratio softkey to set the reference ratio. |
| Freq Lock | <p>This is only available for the analog and <i>Bluetooth</i> analyzer.</p> <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. You can select the generator channel by setting the Src Channel in the Meas. Config. menu page. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. |

Filters Configuration (Analog Analyzer)

Filters are used to bandwidth limit the input signals before applying a measurement function. The filter configuration for the analog analyzer is displayed as shown in **Figure 4-51**.




Figure 4-51 Analog Analyzer > Filter Config menu page

Table 4-22 Analog Analyzer > Filter Config menu description

| Menu | Description |
|----------------------|--|
| Clear Filters | Press the Clear Filters softkey to clear all the filter settings. |
| LPF | <p>Press the LPF softkey to select the low-pass filter.</p> <ul style="list-style-type: none"> - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom (Refer to "Appendix 18: User-defined Filter File Format" on page 563 for more information.) |

Table 4-22 Analog Analyzer > Filter Config menu description (continued)

| Menu | Description |
|--------------|---|
| HPF | <p>Press the HPF softkey to select the high-pass filter.</p> <ul style="list-style-type: none"> - None - 15 Hz - 20 Hz - 22 Hz - 30 Hz - 50 Hz - 70 Hz - 100 Hz - 200 Hz - 300 Hz - 400 Hz - Custom (Refer to “Appendix 18: User-defined Filter File Format” on page 563 for more information.) |
| Weighting | <p>Press the Weighting softkey to select the weighting filter.</p> <ul style="list-style-type: none"> - None - A - CCIR 1k - CCIR 2k - CCITT - C-Message - Custom (Refer to “Appendix 18: User-defined Filter File Format” on page 563 for more information.) |
| Deemphasis | <p>Press the Deemphasis softkey to select the de-emphasis value.</p> <ul style="list-style-type: none"> - None - 50 μs - 75 μs - Custom |
| Notch Filter | <p>Press the Notch Filter softkey to configure the notch filter settings. Refer to “Notch Filter” on page 235 for more information.</p> |

Notch Filter

Notch filter is used to remove the unwanted frequency component in the input signal. This setting is only applicable for THD+N and SINAD measurements.




Figure 4-52 Analog Analyzer > Filter Config > Notch Filter menu page

Table 4-23 Analog Analyzer > Filter Config > Notch Filter menu description

| Menu | Description |
|-------------|---|
| State | Press the State softkey to enable or disable the notch filter. |
| Center Freq | Press the Center Freq softkey to set the frequency of the component to be removed from the input signal. |
| Bandwidth | Press the Bandwidth softkey to set the bandwidth of the signal component to be removed. |

Filters Configuration (Digital Analyzer)

Filters are used to bandwidth limit the input signals before applying a measurement function. The filter configuration for digital analyzer is displayed as shown in **Figure 4-53**.




Figure 4-53 Digital Analyzer > Filter Config menu page

Table 4-24 Digital Analyzer > Filter Config menu description

| Menu | Description |
|----------------------|---|
| Clear Filters | Press the Clear Filters softkey to clear all the filter settings. |
| LPF | Press the LPF softkey to select the low-pass filter. <ul style="list-style-type: none"> - None - 15 kHz - 20 kHz - 22 kHz - 30 kHz - Custom (Refer to “Appendix 18: User-defined Filter File Format” on page 563 for more information.) |
| HPF | Press the HPF softkey to select the high-pass filter. <ul style="list-style-type: none"> - None - 20 Hz - 100 Hz - 400 Hz - Custom (Refer to “Appendix 18: User-defined Filter File Format” on page 563 for more information.) |

Table 4-24 Digital Analyzer > Filter Config menu description (continued)

| Menu | Description |
|--------------------|--|
| Weighting | <p>Press the Weighting softkey to select the weighting filter.</p> <ul style="list-style-type: none"> - None - A - CCIR 1k - CCIR 2k - CCITT - C-Message - Custom (Refer to “Appendix 18: User-defined Filter File Format” on page 563 for more information.) |
| Deemphasis | <p>Press the Deemphasis softkey to select the de-emphasis value.</p> <ul style="list-style-type: none"> - None - 50 μs - 75 μs - Custom |
| Sample Rate | <p>This is only available for digital analyzer.</p> <p>Press the Sample Rate softkey to select the sample rate.</p> <ul style="list-style-type: none"> - 32 kHz - 44.1 kHz - 48 kHz - 88.2 kHz - 96 kHz - 176.4 kHz - 192 kHz |

Filters Configuration (*Bluetooth Analyzer*)

Filters are used to bandwidth limit the input signals before applying a measurement function. The filter configuration for the *Bluetooth* analyzer is displayed as shown in **Figure 4-54**.



Figure 4-54 *Bluetooth Analyzer* > Filter Config menu page

Table 4-25 *Bluetooth Analyzer* > Filter Config menu description

| Menu | Description |
|----------------------|---|
| Clear Filters | Press the Clear Filters softkey to clear all the filter settings. |
| LPF | Press the LPF softkey to select the low-pass filter. <ul style="list-style-type: none"> - None - 15 kHz - 20 kHz - Custom (Refer to “Appendix 18: User-defined Filter File Format” on page 563 for more information.) |
| HPF | Press the HPF softkey to select the high-pass filter. <ul style="list-style-type: none"> - None - 22 Hz - 100 Hz - 400 Hz - Custom (Refer to “Appendix 18: User-defined Filter File Format” on page 563 for more information.) |
| Weighting | Press the Weighting softkey to select the weighting filter. <ul style="list-style-type: none"> - None - A - CCIR 1k - CCIR 2k - CCITT - C-Message - Custom (Refer to “Appendix 18: User-defined Filter File Format” on page 563 for more information.) |

Table 4-25 Bluetooth Analyzer > Filter Config menu description (continued)

| Menu | Description |
|---------------------|---|
| Deemphasis | Press the Deemphasis softkey to select the de-emphasis value. <ul style="list-style-type: none"> - None - 50 μs - 75 μs - Custom |
| Notch Filter | Press the Notch Filter softkey to configure the notch filter settings. Refer to “ Notch Filter ” on page 239 for more information. |

Notch Filter

Notch filter is used to remove the unwanted frequency component in the input signal. This setting is only applicable for THD+N and SINAD measurements.

**Figure 4-55** Bluetooth Analyzer > Filter Config > Notch Filter menu page**Table 4-26** Bluetooth Analyzer > Filter Config > Notch Filter menu description

| Menu | Description |
|--------------------|---|
| State | Press the State softkey to enable or disable the notch filter. |
| Center Freq | Press the Center Freq softkey to set the frequency of the component to be removed from the input signal. |
| Bandwidth | Press the Bandwidth softkey to set the bandwidth of the signal component to be removed. |

Measurement Configuration (Analog Analyzer)

The measurement configuration for analog analyzer is displayed as shown in **Figure 4-56**.



Figure 4-56 Analog Analyzer > Meas Config menu page 1

Table 4-27 Analog Analyzer > Meas Config menu description

| Menu | Description |
|---------------------|---|
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Mov Average | <p>Press the Mov Average softkey to set the number of measurement readings to be used for the moving average calculation. This is useful for noisy signal. Applying the average points will smooth out the fluctuations introduced by the noise that caused the inconsistencies in the measurement reading.</p> |
| Sync Average | <p>Press the Sync Average softkey to set the number of points for the synchronous averaging in the analyzer meter mode. Synchronous averaging reduces noise levels by averaging the acquired data.</p> <ul style="list-style-type: none"> - 1 to 64 |
| Src Channel | <p>Press the Src Channel to select the internal generator channel as the reference channel used in the following situations.</p> <ul style="list-style-type: none"> - For the result calculation in unit dBg. - For the frequencies searching algorithm when the frequency lock is set to Gen Lock. |
| Trigger | <p>Press the Trigger softkey to configure the trigger settings. Refer to “Trigger (Analog, Digital, and Bluetooth Analyzer)” on page 246 for more information.</p> |

NOTE

For details on audio measurement ranging, please refer to “**Appendix 29: Audio Measurement Ranging**” on page **605** to set the input voltage range.

Measurement Configuration (Digital Analyzer)

The measurement configuration for digital analyzer is displayed as shown in **Figure 4-57**.




Figure 4-57 Digital Analyzer > Meas Config menu page

Table 4-28 Digital Analyzer > Meas Config menu description

| Menu | Description |
|--------------------|---|
| Coupling | <p>Press the Coupling softkey to select the coupling type.</p> <ul style="list-style-type: none"> - DC DC coupling allows both AC and DC input signals to pass through to the digital analyzer and to be measured down to 0 Hz. This setting should be selected when making DC voltage measurements. - AC AC coupling blocks the DC component of the input signal. This setting should be selected when you need to measure only the AC component of a signal. For example, when you are making rms or peak-to-peak voltage measurement. |
| Sample Size | <p>Press the Sample Size softkey to select the sample size. The sample size is the number of data points acquired for the measurement. The higher the sample size, the higher the accuracy of the measurement result.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |

Table 4-28 Digital Analyzer > Meas Config menu description (continued)

| Menu | Description |
|--------------------|---|
| Mov Average | Press the Mov Average softkey to set the average points. Higher number of average points should be used when the analyzed data is noisy. – 1 to 20 points |
| Trigger | Press the Trigger softkey to configure the trigger settings. Refer to “ Trigger (Analog, Digital, and Bluetooth Analyzer) ” on page 246 for more information. |

Measurement Configuration (*Bluetooth Analyzer*)

The measurement configuration for *Bluetooth* analyzer is displayed as shown in **Figure 4-58**.



Figure 4-58 *Bluetooth Analyzer* > Meas Config menu page

Table 4-29 *Bluetooth Analyzer* > Meas Config menu description

| Menu | Description |
|--------------------|--|
| Coupling | <p>Press the Coupling softkey to select the coupling type.</p> <ul style="list-style-type: none"> - DC DC coupling allows both AC and DC input signals to pass through to the <i>Bluetooth</i> analyzer and to be measured down to 0 Hz. This setting should be selected when making DC voltage measurements. - AC AC coupling blocks the DC component of the input signal. This setting should be selected when you need to measure only the AC component of a signal. For example, when you are making rms or peak-to-peak voltage measurement. |
| Sample Size | <p>Press the Sample Size softkey to select the sample size. The sample size is the number of data points acquired for the measurement. The higher the sample size, the higher the accuracy of the measurement result.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 |
| Mov Average | <p>Press the Mov Average softkey to set the average points. Higher number of average points should be used when the analyzed data is noisy.</p> <ul style="list-style-type: none"> - 1 to 20 points |

Table 4-29 Bluetooth Analyzer > Meas Config menu description (continued)

| Menu | Description |
|---------------------|---|
| Sync Average | <ul style="list-style-type: none">– Press the Sync Average softkey to set the number of points for the synchronous averaging in the analyzer meter mode. Synchronous averaging reduces noise levels by averaging the acquired data.– 1 to 64 |
| Src Channel | <p>Press the Src Channel to select the internal generator channel as the reference channel used in the following situations.</p> <ul style="list-style-type: none">– For the result calculation in unit dBg.– For the frequencies searching algorithm when the frequency lock is set to Gen Lock. |
| Trigger | <p>Press the Trigger softkey to configure the trigger settings. Refer to “Trigger (Analog, Digital, and Bluetooth Analyzer)” on page 246 for more information.</p> |

Trigger (Analog, Digital, and *Bluetooth* Analyzer)

The trigger menu page for analog, digital, and *Bluetooth* analyzer is displayed as shown in **Figure 4-59**, **Figure 4-60**, and **Figure 4-61**.



Figure 4-59 Analog Analyzer > Meas Config > Trigger menu page



Figure 4-60 Digital Analyzer > Meas Config > Trigger menu page



Figure 4-61 Bluetooth Analyzer > Meas Config > Trigger menu page

Table 4-30 Digital Analyzer > Meas Config > Trigger menu description

| Menu | Description |
|----------------|--|
| Trigger Source | <p>Press the Trigger Source softkey to select the trigger source. The default trigger is Free Run, where the analyzer triggers immediately after the previous data is acquired. If External trigger is set, the analyzer waits for a trigger pulse on the Trigger In connector at the rear panel before acquiring the measurement data.</p> <ul style="list-style-type: none"> - Free Run - External - Channel |
| Trigger Edge | <p>This is only available when the trigger source is External or Channel.</p> <p>Press the Trigger Edge softkey to select the trigger edge type.</p> <ul style="list-style-type: none"> - Rising - Falling |
| Interface | <p>This is only available when the trigger source is Channel.</p> <p>Press the Interface softkey to select the trigger interface.</p> <ul style="list-style-type: none"> - Analog - Digital - <i>Bluetooth</i> |
| Channel | <p>This is only available when the trigger source is Channel.</p> <p>Press the Channel softkey to set the channel number.</p> |
| Trigger Level | <p>This is only available when the trigger source is Channel.</p> <p>When the Trigger Interface is Analog, the Trigger Level is in Vpeak.</p> <p>When the Trigger Interface is Digital or <i>Bluetooth</i>, the Trigger Level is in Hex.</p> <p>Press the Trigger Level softkey to set the trigger level.</p> |

Input Configuration (Analog Analyzer)

The input configuration for analog analyzer is displayed as shown in **Figure 4-62**.




Figure 4-62 Analog Analyzer > Input Config menu page

Table 4-31 Analog Analyzer > Input Config menu description

| Menu | Description |
|-------------------|---|
| Connector | <p>Press the Connector softkey to select the input connector type.</p> <ul style="list-style-type: none"> - UnBal Unbalanced connector type routes the signal from the BNC input connector. The signal in the inner conductor of the coaxial connector is referenced to the ground for measurement. - Bal Balanced connector type routes the signal from the XLR input connectors in the front panel to the analog analyzer. The signals on the positive and negative pins of the XLR connector enter a differential amplifier where they are subtracted before passing on to the detector. - Loopback Loopback connector type routes the signal from the generator to the analyzer internally. The generator channel 1 signal will be routed to the analyzer odd channels (1, 3, 5, and 7), and the generator channel 2 signal will be routed to the analyzer even channels (2, 4, 6, and 8). For example, if you select Loopback in any of the analyzer odd channels, the output connector type of the generator channel 1 will automatically be set to Loopback. |
| Impedance | <p>Press the Impedance softkey to select the input impedance value. This setting is only available when Connector is set to UnBal or Bal.</p> <ul style="list-style-type: none"> - 100 kΩ (for UnBal) - 200 kΩ (for Bal) - 600 Ω - 300 Ω |
| Auto Range | <p>Press the Auto Range softkey to enable or disable auto range.</p> |

Table 4-31 Analog Analyzer > Input Config menu description (continued)

| Menu | Description |
|------------------|--|
| Range | <p>Press the Range softkey to select the input voltage range. This setting is only available when the auto range is disabled.</p> <ul style="list-style-type: none"> - 140 V - 100 V - 32 V - 10 V - 3.2 V - 1 V - 320 mV |
| Bandwidth | <p>Press the Bandwidth softkey to select the input bandwidth value. This setting is only available with Option N3431A. Refer to “U8903B Options” on page 37 for more information.</p> <ul style="list-style-type: none"> - 90 kHz (This is the default setting with sampling rate of 192 kHz) - 1.5 MHz |
| Coupling | <p>Press the Coupling softkey to select the input coupling type.</p> <ul style="list-style-type: none"> - DC DC coupling allows both the AC and DC analog input signals to pass through to the analog analyzer and to be measured down to 0 Hz. This setting should be selected when making DC voltage measurements. - AC AC coupling blocks the DC component of the analog input signal by switching a capacitor in series to the input path. This setting should be selected when you need to measure only the AC component of a signal. For example, use AC coupling when you are making an rms or peak-to-peak voltage measurement. |
| Ext. Gain | <p>Press the Ext. Gain softkey to set the input external gain value.</p> <p>The external gain can be set in the range of -60 dB to 60 dB. The default external gain is 0 dB. External gain is used to correct the effects of any external gain or loss that may be part of a measurement setup.</p> <p>For example, if an amplifier is part of a measurement setup, the external gain value is used to remove the effects of its gain. However, if an external attenuator is used in a high voltage measurement, the external gain value is used to correct the loss. The external gain value can be set in unit dB or x.</p> |

Input Configuration (Digital Analyzer)

The input configuration for digital analyzer is displayed as shown in **Figure 4-63**.




Figure 4-63 Digital Analyzer > Input Config menu page

Table 4-32 Digital Analyzer > Input Config menu description

| Menu | Description |
|------------------|---|
| Connector | <p>Press the Connector softkey to select the connector type.</p> <ul style="list-style-type: none"> - UnBal Unbalanced connector type routes the digital signal from the BNC input connector at the rear panel to the digital analyzer. - Bal Balanced connector type routes the digital signal from the XLR input connectors in the rear panel to the digital analyzer. - Optical Optical connector type routes the digital signal from the TOSLINK input connector at the rear panel to the digital analyzer. - DSI DSI connector type routes the digital signal from the 25-pin female D-SUB connector at the rear panel to the digital analyzer. |
| Impedance | <p>Press the Impedance softkey to select the input impedance.</p> <p>Unbalanced connector type</p> <ul style="list-style-type: none"> - 75 Ω - HiZ <p>Balanced connector type</p> <ul style="list-style-type: none"> - 110 Ω - HiZ |

Table 4-32 Digital Analyzer > Input Config menu description (continued)

| Menu | Description |
|---------------------|---|
| Freq Scaling | Press the Freq Scaling softkey to select the frequency scaling type. <ul style="list-style-type: none">- MISR The frequency will track the incoming Word Clock and recover the audio at its original frequency.- Custom The audio signal frequency will be translated according to the reference sample rate value set in the Ref SR. |
| Ref SR | This is only available when frequency scaling is Custom. Press the Ref SR softkey to set the reference sample rate value. |

Link Configuration (*Bluetooth* Analyzer)

The link configuration for the *Bluetooth* analyzer is identical to the link configuration for the *Bluetooth* generator. Please refer to “**Link Configuration (Bluetooth Generator)**” on page 147 for more information.

DSI Input Configuration (Digital Analyzer)

The DSI input configuration for digital analyzer is displayed as shown in **Figure 4-64**.




Figure 4-64 Digital Analyzer > DSI Config menu page 1

Table 4-33 Digital Analyzer > DSI Config menu description

| Menu | Description |
|-----------------------|--|
| Format | Press the Format softkey to select the data format. <ul style="list-style-type: none"> – Left – Right – I2S – DSP |
| Fsync Polarity | This is only available when the format is Left or Right. Press the Fsync Polarity softkey to select the frame clock edge synchronization. <ul style="list-style-type: none"> – Rising (indicates the frame clock is high on the left channel of data) – Falling (indicates the frame clock is low on the left channel of data) |
| Fsync Width | This is only available when the format is Left or Right. Press the Fsync Width softkey to select the frame clock synchronization width. <ul style="list-style-type: none"> – One Bit Clock – One Subframe – 50% Duty Cycle |
| Data Shift Cnt | This is only available when the format is Left or Right. Press the Data Shift Cnt softkey to set the number for the data bits to be shifted in relative to the frame clock. |
| Data Shift Dir | This is only available when the format is Left or Right. Press the Data Shift Dir softkey to select the data shift direction. <ul style="list-style-type: none"> – Left – Right |

Table 4-33 Digital Analyzer > DSI Config menu description (continued)

| Menu | Description |
|---------------------|--|
| Word Length | Press the Word Length softkey to set the word length value. The word length value must be greater than or equal to the audio resolution. – 8 to 32 |
| Resolution | Press the Resolution softkey to set the audio resolution value. – 8 to 24 |
| Decoding | Press the Decoding softkey to select the decoding format. – Linear PCM – A-Law – μ -Law |
| W/Bclk Dir | Press the W/Bclk Dir softkey to select the word/bit clock direction. – In – Out |
| Bit Clk Edge | Press the Bit Clk Edge softkey to select the bit clock edge. – Rising – Falling |
| Voltage | Press the Voltage softkey to select the input voltage value. – 1.2 Vpp – 1.5 Vpp – 1.8 Vpp – 2.5 Vpp – 3 Vpp – 3.3 Vpp – Custom |

AES/SPDIF Input Configuration (Digital Analyzer)

The AES/SPDIF input configuration for digital analyzer is displayed as shown in **Figure 4-65**.




Figure 4-65 Digital Analyzer > AES Config menu page 1

Table 4-34 Digital Analyzer > AES Config menu description

| Menu | Description |
|--------------------|--|
| Decoding | Press the Decoding softkey to select the decoding format. <ul style="list-style-type: none"> – Linear PCM – A- Law – μ- Law |
| Resolution | Press the Resolution softkey to set the audio resolution value. <ul style="list-style-type: none"> – 8 to 24 |
| Status Bits | Press the Status Bits softkey to select the status bits type. <ul style="list-style-type: none"> – Channel – User |
| Save in Hex | Press the Save in Hex softkey to save the status bits to a HEX file. Refer to “ Save ” on page 94 for more information on the Save menu page. |
| Save in Xml | Press the Save in Xml softkey to save the status bits to an XML file. Refer to “ Save ” on page 94 for more information on the Save menu page. |

Bits Analysis (Digital Analyzer)

The bits analysis menu page allows you to view the data of every single bit in each word of the embedded audio data in the digital signal. The bits analysis configuration for digital analyzer is displayed as shown in **Figure 4-66**.




Figure 4-66 Digital Analyzer > Bits Analysis menu page 1

Table 4-35 Digital Analyzer > Bits Analysis menu description

| Menu | Description |
|---------------------|---|
| Refresh Rate | Press the Refresh Rate softkey to set the refresh rate. This is only applicable when the Bit Types is set to Active Bit. |
| Bit Types | <p>Press the Bit Types softkey to select the bit type.</p> <ul style="list-style-type: none"> - Data Data bits represent the data in a word of the embedded audio data of the digital signal at the time of the measurement. "1" indicates that the data is 1 at the particular bit, and "0" indicates that the data is 0 at the particular bit. - Active Active bits indicate bits that have changed state during the measurement period. "1" indicates a bit has changed state, and "0" indicates no change. |

Wave File (Analog, Digital, and *Bluetooth* Analyzer)

The U8903B allows you to record and save the input measurement signal into a wave file. The recorded wave file can be used as a test signal. The wave file settings for analog, digital, and *Bluetooth* analyzer is displayed as shown in **Figure 4-67**, **Figure 4-68**, and **Figure 4-69** respectively.

NOTE

It is recommended to use fixed input range for analog wave file saving to ensure that the recorded signal's amplitude is closer to the measured signal. The selected range should be close to the measured signal's amplitude.




Figure 4-67 Analog Analyzer > Wave File menu page

Figure 4-68 Digital Analyzer > Wave File menu page



Figure 4-69 Bluetooth Analyzer > Wave File menu page

Table 4-36 Analog/Digital/Bluetooth Analyzer > Wave File menu description

| Menu | Description |
|-------------|--|
| Channel | <p>Press the Channel softkey to select the wave file channel type.</p> <ul style="list-style-type: none"> - Left Selecting Left will record the present analyzer channel 1 signal into a mono wave file. - Right Selecting Right will record the present analyzer channel 2 signal into a mono wave file. - Stereo Selecting Stereo will record both the present analyzer channel 1 and channel 2 signals into a stereo wave file. |
| Bits/Sample | <p>Press the Bits/Sample softkey to select the wave file bits per sample.</p> <ul style="list-style-type: none"> - 8 - 16 - 24 |
| Duration | <p>Press the Duration softkey to set the recording duration of the wave file.</p> |
| Record | <p>Press the Record softkey to start recording and save the measurement into a wave file. Refer to “Save” on page 94 for more information on the Save menu page.</p> |

Statistics

The statistics settings for analog, digital, and *Bluetooth* analyzer is displayed as shown in **Figure 4-70**, **Figure 4-71**, and **Figure 4-72** respectively.



Figure 4-70 Analog Analyzer > Statistics menu page



Figure 4-71 Digital Analyzer > Statistics menu page




Figure 4-72 Bluetooth Analyzer > Statistics menu page

Table 4-37 Analog/Digital/Bluetooth Analyzer > Statistics menu description

| Menu | Description |
|----------------|--|
| Show Stats | Press the Show Stats softkey to enable or disable the statistics calculation. |
| No. of Reading | Press the No. of Reading softkey to set the number of readings used for the statistics calculation. |
| Stat 1 | Press the respective softkeys to select the statistics calculation type. The U8903B allows you to display three types of statistics data. |
| Stat 2 | <ul style="list-style-type: none"> - Min The minimum value obtained in the measurement. - Max The maximum value obtained in the measurement. |
| Stat 3 | <ul style="list-style-type: none"> - Average The calculated average value on the number of measurement readings captured. - Std Dev The calculated standard deviation value on the number of measurement readings captured. - ΔMinMax The difference between the maximum value and minimum value. |
| Clear | The number of measurement readings is the value set in No. Of Readings . Press the Clear softkey to reset the statistics results of the current analog and <i>Bluetooth</i> analyzer. |

Keysight U8903B
Performance Audio Analyzer
User's Guide

5 Graph Analysis

| | |
|-----------------------------|-----|
| Graph Analysis | 262 |
| Graph Settings | 264 |
| Axis Settings | 266 |
| Trace Settings | 268 |
| Memory | 270 |
| Math | 271 |
| Persistence | 272 |
| Display Options | 273 |
| Graph | 273 |
| Data table | 274 |
| Marker table | 274 |
| Statistics | 275 |
| Harmonics | 275 |
| Signal analysis | 277 |
| Measurement Settings | 278 |
| Measurement 1/Measurement 2 | 279 |

This chapter describes the U8903B graph analysis configurations.

Graph Analysis

NOTE

- The U8903B graph analysis mode is only available in the Standard View mode. Refer to “**Menu Key**” on page 60 for more information.
- When the graph analysis mode is activated, all filters will be turned off.

The U8903B graph analysis mode displays a 2-dimensional graph of the signal. Press



on the FUNCTION panel to access the graph analysis mode. The Graph Analysis menu page is displayed as shown in **Figure 5-1**.



Press on the RUN CONTROL panel to start or stop the graph analysis.

Refer to “**GRAPH Panel**” on page 67 for quick access to the commonly used graph functions.




Figure 5-1 Graph Analysis menu page

Table 5-1 Graph Analysis menu description

| Menu | Description |
|-----------------------|--|
| Analysis Type | <p>Press the Analysis Type softkey to select graph analysis mode to be plotted on the current graph panel.</p> <ul style="list-style-type: none"> - Frequency Frequency domain - Phase Phase magnitude - Time Time domain - PSD The total power contained in each of the frequency bins in the band, and then dividing the result by the “effective bandwidth”. |
| Graph Settings | Press the Graph Settings softkey to configure the graph settings. Refer to “ Graph Settings ” on page 264 for more information. |
| Axis Settings | Press the Axis Settings softkey to configure the axis settings. Refer to “ Axis Settings ” on page 266 for more information. |
| Trace Settings | Press the Trace Settings softkey to configure the trace settings. Refer to “ Trace Settings ” on page 268 for more information. |
| Display Option | <p>Press the Display Option softkey to select the graph analysis display option. Refer to “Display Options” on page 273 for more information.</p> <ul style="list-style-type: none"> - Graph - Data Table - Marker Table - Statistics - Harmonics - Signal Analysis |
| Running Mode | <p>Press the Running Mode softkey to select the graph analysis running mode.</p> <ul style="list-style-type: none"> - Continuous - Single |
| Measurement | Press the Measurement softkey to configure the graph analysis measurement settings. Refer to “ Measurement Settings ” on page 278 for more information. |

Graph Settings

The graph settings for graph analysis is displayed as shown in **Figure 5-2**.




Figure 5-2 Graph Analysis > Graph Settings menu page

Table 5-2 Graph Analysis > Graph Settings menu description

| Menu | Description |
|-----------------------|--|
| Active Channel | Press the Active Channel softkey to select the available active channel. The active channel determines the channel for the graph settings. |
| Sample Size | <p>Press the Sample Size softkey to select the graph sample size value. The sample size affects the performance and quality of the analysis performed. For frequency domain measurements, the data returned is half of the current selected sample size.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M <p>If the sample size of an analyzer card channel is set to 2M, the rest of the analyzer card channels sample size will be set to 2048.</p> <p>If the sample size of an analyzer card channel is set to 1M, the rest of the analyzer card channels sample size will be set to 262144 (if the initial sample size is more than 262144).</p> <p>If the sample size of an analyzer card channel is set to 52428, the rest of the analyzer card channels sample size will be set to 262144 (if the initial sample size is more than 262144).</p> |

Table 5-2 Graph Analysis > Graph Settings menu description (continued)

| Menu | Description |
|-----------------|---|
| Window | <p>Press the Window softkey to select the window function to be applied to the data before the FFT process. The selected window function is dependent on the type of results needed from your measurements. Typically, the window function reduces the effect of spectral leakage that may occur when performing FFT analysis.</p> <ul style="list-style-type: none"> - Rectangular - Hanning - Blackman - Rife-Vincent - Rife-Vincent 3 - Hamming - Flat Top - Kaiser |
| Sync Avg | <p>Press the Sync Avg softkey to set the number of samples to be acquired and averaged before the FFT process is performed.</p> |
| Hold | <p>Press the Hold softkey to select the type of hold to be performed after the FFT process.</p> <ul style="list-style-type: none"> - None If None is selected, the latest data will always be displayed. - Average The Average hold will average both the current and previous data. - Min The Min hold will compare the current data with the previous data and retains whichever value that is lower. - Max The Max hold will compare the current data with the previous data and retain whichever value that is higher. |

Axis Settings

The axis settings for graph analysis is displayed as shown in **Figure 5-3**.




Figure 5-3 Graph Analysis > Axis Settings menu page 1

Table 5-3 Graph Analysis > Axis Settings menu description

| Menu | Description |
|----------------|---|
| Axis | Press the Axis softkey to select the active axis to be configured. <ul style="list-style-type: none"> - Primary - Secondary |
| Enabled | Press the Enabled softkey to enable or disable the axis settings. This setting is only available when the axis type is secondary. If the axis type is primary, this setting is always set to On. |
| Left | Press the Left softkey to set the left axis limit value. If the value entered is more than the right value, the right value will automatically be set to a value of (Left + 10). |
| Right | Press the Right softkey to set the right axis limit value. If the value entered is more than the left value, the left value will automatically be set to a value of (Right - 10). |
| Span | Press the Span softkey to set the total X-axis span or total range to be monitored in the graph. |
| Center | Press the Center softkey to set the X-axis center point in the graph. |
| Top | Press the Top softkey to set the top axis limit value. If the value entered is less than the bottom value, the bottom value will automatically be set to a value of (Top - 10). |
| Bottom | Press the Bottom softkey to set the bottom axis limit value. If the value entered is more than the top value, the top value will automatically be set to a value of (Bottom + 10). |

Table 5-3 Graph Analysis > Axis Settings menu description (continued)

| Menu | Description |
|----------------|---|
| X-Scale | Press the X-Scale softkey to select the X-axis scale type. The left and right values must be more than 0 in order to use the log scale. <ul style="list-style-type: none">- Linear- Log |
| Y-Scale | Press the Y-Scale softkey to select the Y-axis scale type. The bottom and top values must be more than 0 in order to use the log scale. <ul style="list-style-type: none">- Linear- Log |

Trace Settings

The trace settings for graph analysis is displayed as shown in **Figure 5-4**.




Figure 5-4 Graph Analysis > Trace Settings menu page 1

Table 5-4 Graph Analysis > Trace Settings menu description

| Menu | Description |
|---------------------|---|
| Active Trace | Press the Active Trace softkey to select the active trace number. |
| Source | Press the Source softkey to select data source of the active trace from the available channels, traces, files, and memory. |
| Enabled | Press the Enabled softkey to enable or disable the active trace data. You can also access this function by pressing the Shift key and the trace number key on the CHANNEL/DATA panel. |
| Memory | Press the Memory softkey to save or load a trace. Refer to “ Memory ” on page 270 for more information. |
| Math | Press the Math softkey to apply a math function. Refer to “ Math ” on page 271 for more information. |
| Unit | Press the Unit softkey to select the trace unit type. <ul style="list-style-type: none"> - V - dBV - dBu - W - dBm - dBSPL |
| Persistence | Press the Persistence softkey to configure the persistence settings. Refer to “ Persistence ” on page 272 for more information. |

Table 5-4 Graph Analysis > Trace Settings menu description (continued)

| Menu | Description |
|--------------|--|
| Axis | Press the Axis softkey to attach the active trace to the primary or secondary axis. The display of the active trace will reflect on the selected axis. <ul style="list-style-type: none">- Primary- Secondary |
| Color | Press the Color softkey to select the color of the active trace. <ul style="list-style-type: none">- Yellow- Cyan- White- Pink- Green- Orange- Red- Purple |

Memory




Figure 5-5 Graph Analysis > Trace Settings > Memory menu page

Table 5-5 Graph Analysis > Trace Settings > Memory menu description

| Menu | Description |
|-------------------------|---|
| Save To Memory | Press the Save To Memory softkey to save the active trace to the memory buffer ^[a] . The trace in the memory buffer can be loaded into any other traces. The memory buffer icon will be displayed at the top of the display when there is a trace saved in the memory buffer as shown in Table 1-5 . |
| Load From Memory | Press the Load From Memory softkey to load a trace from the memory buffer into the active trace. An error will be displayed if this softkey is pressed when there is no trace in the memory buffer. |
| Clear Memory | Press the Clear Memory softkey to clear the trace from the memory buffer. |

[a] Files saved in the internal volatile memory will be erased after power cycle or reset (refer to “Preset” on page 78).

Math




Figure 5-6 Graph Analysis > Trace Settings > Math menu page

Table 5-6 Graph Analysis > Trace Settings > Math menu description

| Menu | Description |
|------------|---|
| Apply Math | Press the Apply Math softkey to apply the corresponding math function to the trace data or turn off the math function. |
| Function | Press the Function softkey to select the math function to be applied on the active trace. <ul style="list-style-type: none"> - None - $f(\text{Source}) + x$ - $f(\text{Source}) - x$ - $f(\text{Source}) * x$ - $f(\text{Source}) / x$ |
| X | Press the X softkey to set the x value in the selected math function. |

Persistence




Figure 5-7 Graph Analysis > Trace Settings > Persistence menu page

Table 5-7 Graph Analysis > Trace Settings > Persistence menu description

| Menu | Description |
|---------------|--|
| Persist | Press the Persist softkey to enable or disable persistence on the active trace. Persistence allows you to view the previous sets of trace data in the graph before they are removed. The previous trace data will be displayed in a lighter shade color of the active trace to distinguish between the previous and updated trace data. |
| Persist Count | Press the Persist Count softkey to set the number of previous sets of trace data to be displayed in the graph before they are removed. For example, a value of 5 indicates that up to a total of 5 previous sets of trace data will be displayed in the graph before they are removed. This setting is only available when persistence is enabled. |

Display Options

Graph

Graph view is the default display option. In the graph view, the frequency, phase, and time domain analysis are performed. The graph view is displayed as shown in **Figure 5-8**.




Figure 5-8 Graph Analysis > Display Option > Graph menu page

Data table

In the data table view, you can observe the individual data points in a table format with up to a maximum of four different traces without scrolling. The data table view is displayed as shown in **Figure 5-9**. Press the up or down arrow keys to scroll up or down the data points in the table.




Figure 5-9 Graph Analysis > Display Option > DataTable menu page

Marker table

In the marker table view, you can observe the marker and cross-marker calculation information in a table format. The delta marker readings are also listed in the table. The marker table view is displayed as shown in **Figure 5-10**.




Figure 5-10 Graph Analysis > Display Option > Marker Table menu page

Statistics

In the statistics view, the typical statistics calculations are listed down. The available statistics functions are minimum, maximum, standard deviation, and average. The statistics view is displayed as shown in **Figure 5-11**.




Figure 5-11 Graph Analysis > Display Option > Statistics menu page

Harmonics

In the harmonics view, you can view and perform harmonic analysis. Information such as the fundamental frequency amplitude and the respective harmonics can be observed in a bar chart. You can also observe the THD information for the individual channels. The harmonics display is displayed as shown in **Figure 5-12**.




Figure 5-12 Graph Analysis > Display Option > Harmonics menu page

Press the **Harm Settings** softkey to configure the harmonics settings. This setting is only available when the graph analysis display option is Harmonics.




Figure 5-13 Graph Analysis > Harm Settings menu page (Harmonics display)

Table 5-8 Graph Analysis > Harm Settings menu description (Harmonics display)

| Menu | Description |
|----------|--|
| Active | Press the Active softkey to select the active channel. |
| Odd | Press the Odd softkey to select the odd harmonics. <ul style="list-style-type: none"> - ALL - 3 - 5 - 7 - 9 |
| Even | Press the Even to select the even harmonics. <ul style="list-style-type: none"> - ALL - 2 - 4 - 6 - 8 |
| Display | Press the Display softkey to select the type of harmonic analysis data to be displayed. <ul style="list-style-type: none"> - Harmonics - THD |
| THD unit | Press the THD unit softkey to select the unit for THD measurements. <ul style="list-style-type: none"> - dB - % |

Signal analysis

In the signal analysis view, you can view the analyzer and generator channel information. The signal analysis display is displayed as shown in **Figure 5-14**.




Figure 5-14 Graph Analysis > Display Option > Signal Analysis menu page

Measurement 1/Measurement 2




Figure 5-16 Graph Analysis > Measurement > Measurement 1 menu page

Table 5-10 Graph Analysis > Measurement > Measurement 1/Measurement 2 menu description

| Menu | Description |
|-------------|--|
| Interface | <p>Press the Interface softkey to select the measurement interface type.</p> <ul style="list-style-type: none"> - Analog Analyzer - Digital - <i>Bluetooth</i> |
| Channel | <p>Press the Channel softkey to select the desired channel to perform the measurement.</p> |
| Function No | <p>Press the Function No softkey to select the function to be displayed based on the function number (1 to 4). The function number corresponds to the respective measurement functions in the analyzer. The allowable measurement functions are as follows.</p> <ul style="list-style-type: none"> - Frequency - DC voltage - THD ratio - THD level |

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

Keysight U8903B
Performance Audio Analyzer
User's Guide

6 Sweep Function

| | |
|-----------------|-----|
| Sweep Parameter | 282 |
| Group Delay | 284 |
| Points settings | 285 |
| Sweep channels | 286 |
| Plot View | 287 |
| Axis settings | 288 |
| Plot settings | 289 |
| Edit Points | 291 |

This chapter describes the U8903B sweep parameter and the configurations.

Sweep Parameter

NOTE

The U8903B sweep mode is only available in the Standard View mode. Refer to “**Menu Key**” on page 60 for more information.

The U8903B sweep mode allows you to perform sweeps and to display the results in a plot view. Press  on the FUNCTION panel to access the sweep mode. The Sweep Parameter menu page is the default page and is displayed as shown in **Figure 6-1**.

There are three main panels on the Sweep Parameter menu page. The top panel displays the current sweep settings and the bottom panels display the audio generator and audio analyzer settings respectively. Press  on the FUNCTION panel to switch between analog and digital interface. Use the arrow keys to navigate among the panels.

Press  on the RUN CONTROL panel to start or stop the sweep in the sweep mode.



Figure 6-1 Sweep Parameter menu page

Table 6-1 Sweep Parameter menu description

| Menu | Description |
|------------------------|--|
| App. Type | <p>Press the App. Type softkey to select the sweep application type.</p> <ul style="list-style-type: none"> - Sweep - Group Delay <p>This is only applicable for digital interface. Refer to “Group Delay” on page 284 for more information.</p> |
| Parameter | <p>This is only available when the sweep application type is Sweep.</p> <p>Press the Parameter softkey to select the sweep parameter type. The parameter selection depends on the waveform type set at the analog generator.</p> |
| Points Settings | <p>Press the Points Settings softkey to configure the sweep point parameters such as start, stop, step size, point count, and spacing.</p> <p>Refer to “Points settings” on page 285 for more information.</p> |
| Dwell Time | <p>Press the Dwell Time softkey to set the delay in ms for the generator to output the signal.</p> |
| Sweep Mode | <p>Press the Sweep Mode softkey to select the sweep mode.</p> <ul style="list-style-type: none"> - Continuous Sweep all points. - Single Sweep point by point. |
| Channels | <p>Press the Channels softkey to set the sweep channels.</p> <p>Refer to “Sweep channels” on page 286 for more information. This setting is only available when the legacy sweep is disabled.</p> |
| Plot View | <p>Press the Plot View softkey to display the Plot View menu page.</p> <p>Refer to “Plot View” on page 287 for more information.</p> |

Group Delay

Group delay is the difference of phase over the difference of the frequency. All signals are delayed when transiting through a device such as a filter, an amplifier, or a processor. This small delay is usually not a problem, but if the delay is different for different frequencies, and the signal is built up by more than one frequency, then the shape of the signal is distorted. The difference in delay for different frequencies is group delay.

Group delay is a useful measure of phase distortion. The variations in a group delay cause signal distortion, just as deviations from linear phase cause distortion. Group delay is calculated by differentiating the insertion phase response of the DUT versus frequency. Group delay is only meaningful when performing sweep.

The input signal is compared with the output signal to calculate the phase between the input and output signals. The phase for frequency 1 is then recorded. The output frequency is then shifted to frequency 2, and the phase is measured again. The result is a group delay value of $(\text{phase 1} - \text{phase 2}) / (\text{frequency 1} - \text{frequency 2})$. This measurement can be done for a series of frequency points to plot the group delay measurement graph which will show the linearity of the phase versus frequency plot.

Group Delay measurement function mode is only applicable for digital interface.



Figure 6-2 Sweep Parameter > App. Type > Group Delay menu page

Points settings



Figure 6-3 Sweep Parameter > Points Settings menu page 1

Table 6-2 Sweep Parameter > Points Settings menu description

| Menu | Description |
|---------|---|
| Spacing | Press the Spacing softkey to select the spacing type. |
| | <ul style="list-style-type: none"> Log – Geometric series $\text{Step size} = 10^{\frac{\log 10\left(\frac{\text{Stop}}{\text{Start}}\right)}{(\text{Points} - 1)}}$ |
| | <ul style="list-style-type: none"> Linear – Arithmetic series $\text{Step size} = \frac{(\text{Start} - \text{Stop})}{(\text{Points} - 1)}$ <ul style="list-style-type: none"> Custom – Arbitrary spacing |
| Unit | Press the Unit softkey to select the sweep unit. This setting is only available when the sweep parameter is amplitude. |
| | <ul style="list-style-type: none"> Vrms dBV Vp Vpp dBm dBu dB SPL |
| | Press the Start softkey to set the sweep start value. This setting is only available when the sweep spacing is Log or Linear. |
| | Press the Stop softkey to set the sweep stop value. This setting is only available when the sweep spacing is Log or Linear. |
| | Press the Step softkey to set the sweep step value. Adjusting the sweep step value will change the sweep points value. This setting is only available when the sweep spacing is Log or Linear. |
| | |

Table 6-2 Sweep Parameter > Points Settings menu description (continued)

| Menu | Description |
|--------------------|--|
| Points | Press the Points softkey to set the sweep points value. Adjusting the sweep points value will change the sweep step value. This setting is only available when the sweep spacing is Log or Linear. |
| Edit Points | Press the Edit Points softkey to configure the sweep points. Refer to “ Edit Points ” on page 291 for more information. If the sweep points are changed, the sweep spacing mode will be set to Custom. |

Sweep channels

NOTE

This setting is only available when the legacy sweep is disabled.

**Figure 6-4** Sweep Parameter > Channels menu page**Table 6-3** Sweep Parameter > Channels menu description

| Menu | Description |
|----------------|--|
| Source | Press the Source softkey to select the source channel(s). |
| Measure | Press the Measure softkey to select the measure channel(s). The available selection depends on the number of installed analog analyzer cards. |

Plot View

The sweep plot view menu page is displayed as shown in **Figure 6-5**.

Press  on the RUN CONTROL panel to start or stop the sweep in the sweep mode.




Figure 6-5 Sweep > Plot View menu page

Table 6-4 Sweep > Plot View menu description

| Menu | Description |
|---------------|---|
| Axis Settings | Press the Axis Settings softkey to configure the sweep axis settings. Refer to " Axis settings " on page 288 for more information. |
| Plot Settings | Press the Plot Settings softkey to configure the sweep trace settings. Refer to " Plot settings " on page 289 for more information. |
| Edit Points | Press the Edit Points softkey to configure the sweep points. Refer to " Edit Points " on page 291 for more information. |
| Save Pts | Press the Save Pts softkey to save the sweep points to a file. Refer to " Save " on page 94 for the Save menu page. |

Axis settings




Figure 6-6 Sweep > Plot View > Axis Settings menu page

Table 6-5 Sweep > Plot View > Axis Settings menu description

| Menu | Description |
|--------------------|---|
| Active Axis | Press the Active Axis softkey to select the active axis. <ul style="list-style-type: none"> - Primary - Secondary |
| Left | Press the Left softkey to set the left axis value. |
| Right | Press the Right softkey to set the right axis value. |
| Top | Press the Top softkey to set the top axis value. |
| Bottom | Press the Bottom softkey to set the bottom axis value. |
| X-Scale | Press the X-Scale softkey to set the X-axis scale type. <ul style="list-style-type: none"> - Linear - Log |
| Y-Scale | Press the Y-Scale softkey to set the Y-axis scale type. <ul style="list-style-type: none"> - Linear - Log |

Plot settings




Figure 6-7 Sweep > Plot View > Plot Settings menu page

Table 6-6 Sweep > Plot View > Plot Settings menu description

| Menu | Description |
|--------------|--|
| Data Channel | Press the Data Channel softkey to select the trace data channel number to be plotted. This setting is only available when the measured channels are more than one channel. |
| Y Data | Press the Y Data softkey to select the Y-axis trace data source. <ul style="list-style-type: none"> - S: <sweep parameter> - F1: <measurement function 1> - F2: <measurement function 2> - F3: <measurement function 3> - F4: <measurement function 4> |
| Y2 Data | Press the Y2 Data softkey to select the second Y-axis trace data source. <ul style="list-style-type: none"> - S: <sweep parameter> - F1: <measurement function 1> - F2: <measurement function 2> - F3: <measurement function 3> - F4: <measurement function 4> |
| X Data | Press the X Data softkey to select the X-axis trace data source. <ul style="list-style-type: none"> - S: <sweep parameter> - F1: <measurement function 1> - F2: <measurement function 2> - F3: <measurement function 3> - F4: <measurement function 4> |

Table 6-6 Sweep > Plot View > Plot Settings menu description (continued)

| Menu | Description |
|-------------------|---|
| Wrap Phase | <p>Press the Wrap Phase softkey to enable or disable the wrap phase. This is only applicable if Y Data or Y2 Data is set to phase.</p> <ul style="list-style-type: none"> - On The phase result is wrapped so that it falls within the range of $-180^\circ \sim 180^\circ$. - Off The result displayed is the exact value after subtracted from the reference channel. |
| Hold Type | <p>Press the Hold Type softkey to select the data type to be plotted in the graph.</p> <ul style="list-style-type: none"> - None Initial sweep data. - Average Each point is averaged with the corresponding point from the previous result. - Max Always keep the maximum value of each point. - Min Always plot the minimum value of each point. |

Edit Points

| # | Frequency (Hz) | 1.AC Voltage (V) | 2.Frequency (Hz) | 3.Phase (°) |
|----|----------------|------------------|------------------|-------------|
| 1 | 20.000 | 85.055μ | ---- | ---- |
| 2 | 25.380 | 84.964μ | ---- | ---- |
| 3 | 32.207 | 85.467μ | ---- | ---- |
| 4 | 40.871 | 84.702μ | ---- | ---- |
| 5 | 51.885 | 84.843μ | ---- | ---- |
| 6 | 65.817 | 84.547μ | ---- | ---- |
| 7 | 83.522 | 84.672μ | ---- | ---- |
| 8 | 105.99 | 84.862μ | ---- | ---- |
| 9 | 134.50 | 84.511μ | ---- | ---- |
| 10 | 170.68 | 84.736μ | ---- | ---- |
| 11 | 216.59 | 84.442μ | ---- | ---- |
| 12 | 274.86 | 85.310μ | ---- | ---- |
| 13 | 348.79 | 84.789μ | ---- | ---- |
| 14 | 442.62 | 84.816μ | ---- | ---- |
| 15 | 561.68 | 84.671μ | ---- | ---- |
| 16 | 712.78 | 85.636μ | ---- | ---- |
| 17 | 904.52 | 85.620μ | ---- | ---- |
| 18 | 1147.8 | 85.654μ | ---- | ---- |
| 19 | 1456.6 | 84.660μ | ---- | ---- |
| 20 | 1848.4 | 85.094μ | ---- | ---- |

Figure 6-8 Sweep > Edit Points menu page 1

Table 6-7 Sweep > Edit Points menu description

| Menu | Description |
|--------------|--|
| Data Channel | Press the Data Channel softkey to select the trace data channel number to be plotted. This setting is only available when the measured channels are more than one channel. |
| Wrap Phase | Press the Wrap Phase softkey to enable or disable the wrap phase. This is only applicable if Y Data or Y2 Data is set to phase. <ul style="list-style-type: none"> – On The phase result is wrapped so that it falls within the range of $-180^\circ \sim 180^\circ$. – Off The result displayed is the exact value after subtracted from the reference channel. |
| Goto Point | Press the Goto Point softkey to set the sweep point number to go to. The sweep point number will be highlighted. You can also use the arrow keys to select the desired sweep point. |
| Point Value | Press the Point Value softkey to set the currently selected sweep point value. |
| Add Point | Press the Add Point softkey to add a sweep point. |
| Remove Point | Press the Remove Point softkey to remove the selected sweep point. |
| Load Points | Press the Load Points softkey to load the sweep points from a file. Refer to " Recall " on page 95 for the Recall menu page. |
| Save Points | Press the Save Points softkey to save the sweep points to a file. Refer to " Save " on page 94 for the Save menu page. |

NOTE

If the sweep points are changed, the sweep spacing mode will be set to Custom. Refer to **Table 6-2** for more information.

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

Keysight U8903B
Performance Audio Analyzer
User's Guide

7 Test Sequence Application

| | |
|-----------------------------|-----|
| Test Sequence Application | 295 |
| Project | 297 |
| Test Sequence | 299 |
| IO Configuration | 300 |
| Settings | 301 |
| Properties | 308 |
| Sub-steps | 309 |
| Prompt sub-step settings | 310 |
| Send SCPI sub-step settings | 311 |
| Measurements | 312 |
| Properties | 314 |
| AC level | 315 |
| Frequency | 318 |
| Phase | 321 |
| SNR | 324 |
| THD+N | 329 |
| DC level | 333 |
| Crosstalk | 336 |
| SMPTE IMD | 339 |
| DFD IMD | 342 |
| Multitone analyzer | 345 |
| Stepped frequency sweep | 348 |
| SMPTE frequency sweep | 353 |
| DFD frequency sweep | 356 |
| External frequency sweep | 360 |
| Stepped level sweep | 365 |
| SMPTE level sweep | 370 |
| DFD level sweep | 374 |
| DC level sweep | 378 |
| Receiver sensitivity | 382 |
| External level sweep | 387 |
| Measurement recorder | 392 |

- Voice quality 397
- Measurement Results 401
- Report 405
- Properties 406

This chapter describes the various configurations for the U8903B test sequence application.

Test Sequence Application

The U8903B test sequence application (Test Seq App) mode allows you to create a series of automated measurements on a DUT. You can customize the order in which the measurements are performed, edit the pass or fail limits, add sub steps, and create a detailed report of the measurements.

There are two main tabs in the test sequence application mode: Project tab and Report tab.

The Project tab allows you to add up to 20 test sequence and configure the measurements in each test sequence. The Report tab allows you to display all the measurements results and generate a report.

Use the left and right arrow keys to switch between the Project tab or Report tab. Refer to “**Project**” on page 297 and “**Report**” on page 405 for more information.

An example of the Project tab menu page is displayed as shown in **Figure 7-1**.



Figure 7-1 TSA > Project menu page

Press  to start or stop the test sequence. The Test Application menu page will be displayed as shown in **Figure 7-2**.




Figure 7-2 Test Application menu page

Table 7-1 Test Application menu description

| Menu | Description |
|-----------------------------------|---|
| Start Test App | Press the Start Test App softkey to start the test application project. |
| Start Test App From Here | Press the Start Test App From Here softkey to start the test application from the selected test or measurement tab. This setting is only available when the On/Off key is pressed with the test or measurement tab selected. |
| Start Selected Measurement | Press the Start Selected Measurement softkey to start the test for the selected measurement. This setting is only available when the On/Off key is pressed with the measurement tab selected. |

Project

The TSA > Project menu page is displayed as shown in **Figure 7-3**.



Figure 7-3 TSA > Project menu page

Table 7-2 TSA > Project menu description

| Menu | Description |
|---------------------|---|
| New Project | Press the New Project softkey to create a new project. |
| Open Project | Press the Open Project softkey to load a project from a file. Refer to “ Recall ” on page 95 for more information on the Recall menu page. |
| Save Project | Press the Save Project softkey to save the project to a file. Refer to “ Save ” on page 94 for more information on the Save menu page. |
| Properties | Press the Properties softkey to configure the project properties. Refer to “ Properties ” on page 298 for more information on the Properties menu page. |

Press the up or down arrow key to select the test sequence, IO configuration, or measurements tabs. The respective menu page will be displayed. Refer to “**Test Sequence**” on page 299, “**IO Configuration**” on page 300, and “**Measurements**” on page 312 for more information.

Properties

The TSA > Project > Properties menu page is displayed as shown in **Figure 7-4**.



Figure 7-4 TSA > Project > Properties menu page

Table 7-3 TSA > Project > Properties menu description

| Menu | Description |
|----------------------|---|
| Prompt DUT ID | Press the Prompt DUT ID softkey to enable or disable the prompt for device ID (device serial number) at the start of a test sequence. |
| Prompt Msg | Press the Prompt Msg softkey to set the prompt message. This setting is only available when Prompt DUT ID is enabled. |
| Pass/Fail Msg | Press the Pass/Fail Msg softkey to enable or disable the on-screen message dialog box that can be displayed at the end of a test sequence. Press Enter to close the dialog box. |
| Pass Message | Press the Pass Message softkey to edit the pass message. If all the measurements in the test sequence pass, the pass message is displayed. The default message is “Passed”. This setting is only available when Pass/Fail Msg is enabled. |
| Fail Message | Press the Fail Message softkey to edit the fail message. If one or more measurements in the test sequence fails, the fail message is displayed. The default message is “Failed” This setting is only available when Pass/Fail Msg is enabled. |

Test Sequence

The TSA > Project > Test menu page is displayed as shown in **Figure 7-5**.



Figure 7-5 TSA > Project > Test menu page

Table 7-4 TSA > Project > Test menu description

| Menu | Description |
|-----------------------------|---|
| Enable | Press the Enable softkey to enable or disable the selected test sequence. The check boxes for the test and all the measurements in the test will be selected when enabled. |
| Add Test Sequence | Press the Add Test Sequence softkey to add a test sequence. <ul style="list-style-type: none"> - New Add a new test sequence. - Saved Load a saved test sequence file. Refer to "Recall" on page 95 for more information on the Recall menu page. |
| Delete Test Sequence | Press the Delete Test Sequence softkey to delete the selected test sequence. |
| Save | Press the Save softkey to save the test sequence to a file. Refer to " Save " on page 94 for more information on the Save menu page. |
| Edit | Press the Edit softkey to move or copy the selected test sequence, or paste a copied test sequence after the selected test sequence. |
| Properties | Press the Properties softkey to set the test sequence name. |

IO Configuration

The IO Configuration tab allows you to configure the output and input settings. There will be one IO Configuration tab in each test sequence. The settings configured in the IO configuration will be applied to all the measurements in the test sequence. The TSA > Project > Test > IO Configuration menu page is displayed as shown in **Figure 7-6**.



Figure 7-6 TSA > Project > Test > IO Configuration menu page

Table 7-5 TSA > Project > Test > IO Configuration menu description

| Menu | Description |
|------------------------|--|
| Add Measurement | Press the Add Measurement softkey to add measurements to the selected test sequence. Refer to “ Measurements ” on page 312 for more information. |
| Edit | Press the Edit softkey to paste a copied measurement after the IO configuration. The IO Configuration cannot be moved or copied. |
| Settings | Press the Settings softkey to configure the IO settings. Refer to “ Settings ” on page 301 for more information. |
| Properties | Press the Properties softkey to configure the IO configuration properties. Refer to “ Properties ” on page 308 for more information. |

Settings

Press  on the FUNCTION panel to switch between the analog and *Bluetooth* interface. Press the up or down arrow key to select between output configuration or input configuration.

Output configuration (Analog)

The TSA > Project > Test > IO Configuration > Output Configuration menu page is displayed as shown in **Figure 7-7**.




Figure 7-7 TSA > Project > Test > IO Configuration > Output Configuration menu page (Analog)

Table 7-6 TSA > Project > Test > IO Configuration > Output Configuration menu description (Analog)

| Menu | Description |
|--|---|
| Channels | <p>Press the Channels softkey to select the number of output channels in use.</p> <ul style="list-style-type: none"> - None (External) Disable the generator outputs and configure the analyzer for external source (open-loop) measurements. - 1 - 2 |
| Connector | <p>Press the Connector softkey to select the output connector type.</p> <ul style="list-style-type: none"> - Bal Balanced mode outputs a pair of differential signals which are equal in amplitude but 180 degrees out of phase on the XLR positive and negative pins. - UnBal Unbalanced mode outputs a signal referenced to ground on the BNC output connector. - Com Common mode outputs a pair of equal amplitude and in-phase signals on the XLR positive and negative pins. The common mode test signal is applied to both pins 2 and 3 or the XLR connector, while pin 1 is connected to the return signal. - IEC60268 The common mode test signal is applied to both pins 2 and 3 or the XLR connector, while pin 1 is connected to the return signal. An additional 10 Ω output series resistance is added to pin 2 or 3. |
| Impedance | <p>Press the Impedance softkey to select the output impedance value.</p> <p>For Bal, Com, and IEC60268</p> <ul style="list-style-type: none"> - 600 Ω - 100 Ω - 40 Ω <p>For UnBal</p> <ul style="list-style-type: none"> - 600 Ω - 50 Ω - 20 Ω |
| IEC60268 10 Ω | <p>Press the IEC60268 10 Ω softkey to select the additional 10 Ω output series resistance for pin 2 or 3 of the XLR connector in the common IEC60268 configuration. This setting is only available when the output connector type is set to IEC60268.</p> <ul style="list-style-type: none"> - Pin2 Additional 10 Ω is added to pin 2. - Pin3 Additional 10 Ω is added to pin 3. |
| Ground | <p>Press the Ground softkey to select the grounding type.</p> <ul style="list-style-type: none"> - Float In the floating grounding type, the signal return line (XLR pin 1 for balanced output or BNC return for unbalanced output) is not grounded to the chassis earth and is "floating". - Ground In the ground grounding type, the signal return line (XLR pin 1 for balanced output or BNC return for unbalanced output) is connected to the chassis earth. |
| Max Voltage | <p>Press the Max Voltage softkey to set the maximum voltage. The maximum voltage value set will limit the maximum amplitude output from the generator and prevent any excessive high voltage values from damaging the DUT.</p> |
| Reference | <p>Press the Reference softkey to set the output references for generator.</p> <ul style="list-style-type: none"> - Impedance Set the reference impedance for the unit conversion of dBm measurements. |

Output configuration (*Bluetooth*)

The TSA > Project > Test > IO Configuration > Output Configuration menu page is displayed as shown in **Figure 7-8**.




Figure 7-8 TSA > Project > Test > IO Configuration > Output Configuration menu page (*Bluetooth*)

Table 7-7 TSA > Project > Test > IO Configuration > Output Configuration menu description (*Bluetooth*)

| Menu | Description |
|-------------|---|
| Channels | <p>Press the Channels softkey to select the number of output channels in use.</p> <ul style="list-style-type: none"> - None (External) Disable the generator outputs and configure the analyzer for external source (open-loop) measurements. - 1 This is only applicable if the Profiles consist of only HFP, or HFP and AVRCP. - 2 This is only applicable if the Profiles consist of A2DP. |
| Device | <p>Press the Device softkey to select the paired or connected <i>Bluetooth</i> device.</p> |
| Profiles | <p>Press the Profiles softkey to select the profile that will be used in the test. If the connected <i>Bluetooth</i> device is selected in Device, the profile used will be fixed to the connected profile(s).</p> <ul style="list-style-type: none"> - A2DP - HFP - AVRCP |
| Link Config | <p>Press the Link Config softkey to configure the <i>Bluetooth</i> link settings. Refer to “Link Configuration (Bluetooth Generator)” on page 147.</p> |
| References | <p>Press the Reference softkey to set the output references for generator.</p> <ul style="list-style-type: none"> - Volt/FS Set the volts/FS reference value. |

Input configuration (Analog)

The TSA > Project > Test > IO Configuration > Input Configuration menu page is displayed as shown in **Figure 7-9**.




Figure 7-9 TSA > Project > Test > IO Configuration > Input Configuration menu page (Analog)

Table 7-8 TSA > Project > Test > IO Configuration > Input Configuration menu description (Analog)

| Menu | Description |
|------------------|---|
| Channels | Press the Channels softkey to select the number of input channels in use. |
| Connector | <p>Press the Connector softkey to select the input connector type.</p> <ul style="list-style-type: none"> - UnBal Unbalanced connector type routes the signal from the BNC input connector. The signal in the inner conductor of the coaxial connector is referenced to the ground for measurement. - Bal Balanced connector type routes the signal from the XLR input connectors in the front panel to the analog analyzer. The signals on the positive and negative pins of the XLR connector enter a differential amplifier where they are subtracted before passing on to the detector. - Loopback Loopback connector type routes the signal from the generator to the analyzer internally. The generator channel 1 signal will be routed to the analyzer odd channels (1, 3, 5, and 7), and the generator channel 2 signal will be routed to the analyzer even channels (2, 4, 6, and 8). For example, if you select Loopback in any of the analyzer odd channels, the output connector type of the generator channel 1 will automatically be set to Loopback. |
| Impedance | <p>Press the Impedance softkey to select the input impedance value. This setting is only available when Connector is set to UnBal or Bal.</p> <ul style="list-style-type: none"> - 100 kΩ (for Unbalanced) - 200 kΩ (for Balanced) - 600 Ω - 300 Ω |

Table 7-8 TSA > Project > Test > IO Configuration > Input Configuration menu description (continued)(Analog)

| Menu | Description |
|------------------|---|
| Coupling | Press the Coupling softkey to select the input coupling type. <ul style="list-style-type: none"> - DC DC coupling allows both the AC and DC analog input signals to pass through to the analog analyzer and to be measured down to 0 Hz. This setting should be selected when making DC voltage measurements. - AC AC coupling blocks the DC component of the analog input signal by switching a capacitor in series to the input path. This setting should be selected when you need to measure only the AC component of a signal. For example, use AC coupling when you are making an rms or peak-to-peak voltage measurement. |
| Bandwidth | Press the Bandwidth softkey to select the input bandwidth value. <ul style="list-style-type: none"> - 90 kHz (This is the default setting with sampling rate of 192 kHz) - 1.5 MHz - This setting is only available with Option N3431A. Refer to “U8903B Options” on page 37 for more information. |
| Reference | Press the Reference softkey to set the input references for analyzer. <ul style="list-style-type: none"> - Voltage - Ratio - Frequency - Impedance - Sound level - Calibrator level |

Input configuration (*Bluetooth*)

The TSA > Project > Test > IO Configuration > Input Configuration menu page is displayed as shown in **Figure 7-9**.




Figure 7-10 TSA > Project > Test > IO Configuration > Input Configuration menu page (*Bluetooth*)

Table 7-9 TSA > Project > Test > IO Configuration > Input Configuration menu description (*Bluetooth*)

| Menu | Description |
|-------------|---|
| Channels | Displays the number of input channels in use. If the Profiles consist of A2DP, the input channels in use will be fixed to 2 channels. If the Profiles consist of only HFP or HFP and AVRCP, the input channels in use will be fixed to 1 channel. |
| Device | Press the Device softkey to select the paired or connected <i>Bluetooth</i> device. |
| Profiles | Press the Profiles softkey to select the profile that will be used in the test. If the connected <i>Bluetooth</i> device is selected in Device , the profile used will be fixed to the connected profile(s). <ul style="list-style-type: none"> - A2DP - HFP - AVRCP |
| Link Config | Press the Link Config softkey to configure the <i>Bluetooth</i> link settings. Refer to “ Link Configuration (Bluetooth Generator) ” on page 147 . |

Table 7-9 TSA > Project > Test > IO Configuration > Input Configuration menu description (continued)(*Bluetooth*)

| Menu | Description |
|-------------------|--|
| Coupling | <p>Press the Coupling softkey to select the coupling type.</p> <ul style="list-style-type: none"> - DC DC coupling allows both AC and DC input signals to pass through to the <i>Bluetooth</i> analyzer and to be measured down to 0 Hz. This setting should be selected when making DC voltage measurements. - AC AC coupling blocks the DC component of the input signal. This setting should be selected when you need to measure only the AC component of a signal. For example, select this setting when you are making rms or peak-to-peak voltage measurement. |
| References | <p>Press the Reference softkey to set the input references for generator.</p> <ul style="list-style-type: none"> - Voltage Set the reference voltage value. - Ratio Set the reference ratio value. - Frequency Set the reference frequency value. - Sound Lvl Set the sound level value. - Calibrator Lvl Set the calibration level value value. - Volt/FS Set the volts/FS reference value. |

Properties

The TSA > Project > Test > IO Configuration > Properties menu page is displayed as shown in **Figure 7-11**.



Figure 7-11 Test > IO Configuration > Properties menu page

Table 7-10 TSA > Project > Test > IO Configuration > Properties menu description

| Menu | Description |
|------------------|--|
| Name | Press the Name softkey to rename the IO configuration. |
| Sub-Steps | Press the Sub-Steps softkey to configure the sub-steps settings. Refer to “ Sub-steps ” on page 309 for more information on the sub-steps settings. |
| Failure | Press the Failure softkey to edit the failure message. If one or more measurements in the test sequence fails, the failure message is displayed. The default message is “Failed”. This setting is only available when Pass/Fail Msg is enabled. |

Sub-steps

You can add any number of sub-steps to the measurement. The sub-steps can be enabled, disabled, or deleted and moved into any order. You can add delay, prompts, and send SCPI commands to the sub-steps. Press the **Add Sub-Step** softkey to add sub-step and press the up and down arrow keys to select the desired sub-step.

The delay sub-step menu page is displayed as shown in **Figure 7-12**.




Figure 7-12 Delay sub-step menu page

Table 7-11 Sub-step menu description

| Menu | Description |
|------------------------|---|
| Enable | Press the Enable softkey to enable or disable the selected sub-step. The check box of the sub-step will be selected when enabled. |
| Add Sub-Step | Press the Add Sub-Step softkey to add sub-step to the list. <ul style="list-style-type: none"> - Delay - Prompt - Send SCPI |
| Delete Sub-Step | Press the Delete Sub-Step softkey to delete the selected sub-step. |
| Edit | Press the Edit softkey to move or copy the selected sub-step, or paste a copied sub-step after the selected sub-step. |
| Settings | Press the Settings softkey to configure the sub-step settings. <ul style="list-style-type: none"> - Delay Set the delay time in seconds. Minimum: 0 s Maximum: 3600 s (1 hour) - Prompt Refer to “Prompt sub-step settings” on page 310 for more information. - Send SCPI Refer to “Send SCPI sub-step settings” on page 311 for more information. |
| Properties | Press the Properties softkey to rename the sub-step. |

Prompt sub-step settings

The prompt sub-step inserts a prompt message with reply option to the measurement. This provides you the information and opportunity to interact with the sequence. Press OK to close the prompt window and continue the test sequence. The prompt sub-step settings menu page is displayed as shown in **Figure 7-13**.




Figure 7-13 Prompt sub-step settings menu page

Table 7-12 Prompt sub-step settings menu description

| Menu | Description |
|-----------------|---|
| Message | Press the Message softkey to set the prompt message at the lower half of the main display. |
| Prompt Icon | Press the Prompt Icon softkey to select the prompt icon to be displayed. <ul style="list-style-type: none"> - None - Hand - Question - Exclamation - Asterisk |
| Dialog Settings | Press the Dialog Settings softkey to add additional settings to the prompt window. <ul style="list-style-type: none"> - Timeout When selected, the timeout value sets the maximum prompt window display time, in seconds. If the timeout is reached, the current measurement fails. When unselected, the prompt window will remain open until user closes it. - Cancel When selected, a Cancel button will be added to the prompt window. Press the Cancel button to close the prompt window and stop the test sequence. |
| Timeout | Press the Timeout softkey to set the prompt timeout value in seconds. This setting is only available if Timeout is selected in the dialog settings. Minimum: 1 s Maximum: 3600 s (1 hour) |

Send SCPI sub-step settings

The send SCPI sub-step can be inserted into any measurement in the test sequence to issue SCPI command(s) to a connected external instrument and to pause for a specified delay time after the command(s) is issued. This sub-step is useful for setting up an external instrument connected through a USB/GPIB interface before a measurement is performed. The send SCPI sub-step settings menu page is displayed as shown in **Figure 7-14**.




Figure 7-14 Send SCPI sub-step settings menu page

Table 7-13 Send SCPI sub-step settings menu description

| Menu | Description |
|----------------------|--|
| GPIB Address | Press the GPIB Address softkey to select the desired GPIB address. |
| SCPI Commands | Press the SCPI Commands softkey to configure the SCPI commands. <ul style="list-style-type: none"> - Edit Set the SCPI commands at the lower half of the main display. - Import Load the SCPI commands from a file. Refer to “Recall” on page 95 for more information on the Recall menu page. |
| Progress Msg | Press the Progress Msg softkey to set the optional text message that will be displayed on a dialog box for the time length set in Delay . |
| Delay | Press the Delay softkey to set the delay time length after the SCPI command(s) is issued. The SCPI command(s) may start an external event that takes some time to complete. An optional delay time can be set to wait for completion. The next sub-step in the test sequence will not be executed until the delay time has passed. |

Measurements

The U8903B allows up to 20 results in a single measurement. You can move a selected measurement within the same test sequence. An example of the measurement menu page is displayed as shown in **Figure 7-15**.



Figure 7-15 TSA > Project > Test > AC Level menu page

Table 7-14 TSA > Project > Test > Measurement menu description

| Menu | Description |
|---------------------------|---|
| Enable | Press the Enable softkey to enable or disable the selected measurement. The check box for the measurement will be selected when enabled. |
| Add Measurement | Press the Add Measurement softkey to add measurements. |
| Delete Measurement | Press the Delete Measurement softkey to delete the selected measurement. |
| Edit | Press the Edit softkey to move or copy the selected measurement, or paste a copied measurement after the selected measurement. |

Table 7-14 TSA > Project > Test > Measurement menu description (continued)

| Menu | Description |
|-------------------|---|
| Settings | <p>Press the Settings softkey to configure the selected measurement. Refer to the respective measurement settings for more information.</p> <ul style="list-style-type: none"> - AC level - Frequency - Phase - SNR - THD+N - DC level - Crosstalk - SMPTE IMD - DFD IMD - Multitone analyzer - Stepped frequency sweep - SMPTE frequency sweep - DFD frequency sweep - Stepped level sweep - SMPTE level sweep - DFD level sweep - DC level sweep - Receiver sensitivity - Measurement recorder - Voice quality |
| Properties | <p>Press the Properties softkey to configure the measurement properties. Refer to “Properties” on page 314 for more information.</p> |

Properties

An example of the measurement properties menu page is displayed as shown in **Figure 7-16**.



Figure 7-16 TSA > Project > Test > AC Level > Properties menu page

Table 7-15 TSA > Project > Test > Measurement > Properties menu description

| Menu | Description |
|-------------------------|---|
| Name | Press the Name softkey to rename the selected measurement. |
| Sub-Steps | Press the Sub-Steps softkey to configure the sub-steps settings. Refer to “ Sub-steps ” on page 309 for more information on the sub-steps settings. |
| Failure Handling | <p>Press the Failure Handling softkey to select the failure handling type for the selected measurement. When a measurement exceeded its preset limit or faced failure due to improper configuration (for example, calling for a file that does not exist or sending a SCPI sub-step to an unconnected devices), you can direct the application to the following:</p> <ul style="list-style-type: none"> - Cancel Seq. Stop the test sequence. - Allow Retry Display a prompt window with Abort, Retry, and Ignore commands. Abort will immediately stop the test sequence. Retry will rerun the selected measurements. Ignore will flag the measurement as failed and continue with the test sequence. - Continue Seq. Flag the measurement as failed and continue with the test sequence. |

AC level

AC level measurement provides a single value measurement of the output level from each DUT channel, as measured at each of the analyzer input. The AC level measurement settings allows you to configure the signal generation and signal analysis settings. The result for the AC level measurement for all the selected channels are displayed in a bar chart (AC Level and Gain). The gain result is not available if None is selected for the output configuration channels. Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page.

Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The AC level signal generation settings menu page is displayed as shown in **Figure 7-17**.




Figure 7-17 TSA > Project > Test > AC Level > Settings > Signal Generation menu page

Table 7-16 TSA > Project > Test > AC Level > Settings > Signal Generation menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - Sine - Variable Phase - Square - Arbitrary |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration. The available settings depend on the waveform type.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Frequency Set the frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. - Phase->1st Ch Set the phase value. This setting is only available when channel 2 is selected. |

Signal analysis

The AC level signal analysis settings menu page is displayed as shown in **Figure 7-18**.


**Figure 7-18** TSA > Project > Test > AC Level > Settings > Signal Analysis menu page

Table 7-17 TSA > Project > Test > AC Level > Settings > Signal Analysis menu description

| Menu | Description |
|--------------------|--|
| Detector | Press the Detector softkey to select the AC level detector type. <ul style="list-style-type: none"> - RMS AC level measurement is expressed in an rms value. - Pk-Pk AC level measurement is expressed in a Vpp value. |
| LPF | Press the LPF softkey to select the low-pass filter. <ul style="list-style-type: none"> - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom |
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | Press the Input Range softkey to configure the input range settings. <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

Frequency

Frequency measurement provides a single value frequency measurement of the strongest component in the output signal of each DUT channel. The frequency measurement settings allows you to configure the signal generation settings and signal analysis settings.

The result for the frequency measurement for all the selected channels are displayed in a bar chart (Frequency). Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The frequency signal generation settings menu page is displayed as shown in **Figure 7-19**.




Figure 7-19 Frequency > Signal Generation settings menu page

Table 7-18 Frequency > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - Sine - Variable Phase - Square - Arbitrary |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration. The available settings depend on the waveform type.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Frequency Set the frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. - Phase->1st Ch Set the phase value. This setting is only available when channel 2 is selected. |

Signal analysis

The frequency signal analysis settings menu page is displayed as shown in **Figure 7-20**.




Figure 7-20 Frequency > Signal Analysis settings menu page

Table 7-19 Frequency > Signal Analysis settings menu description

| Menu | Description |
|-------------|--|
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. |
| | <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | Press the Input Range softkey to configure the input range settings. |
| | <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

Phase

Phase measurement provides a single value measurement of the relative phase of the DUT channels. One channel is chosen as the phase reference channel and the remaining channels are measured against it. The phase measurement settings allows you to configure the signal generation settings and signal analysis settings.

The result for the phase measurement for all the selected channels are displayed in a bar chart (Phase). Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The phase signal generation settings menu page is displayed as shown in **Figure 7-21**.




Figure 7-21 Phase > Signal Generation settings menu page

Table 7-20 Phase > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - Sine - Variable Phase - Square - Arbitrary |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration. The available settings depend on the waveform type.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Frequency Set the frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. - Phase->1st Ch Set the phase value. This setting is only available when channel 2 is selected. |

Signal analysis

The phase signal analysis settings menu page is displayed as shown in **Figure 7-22**.




Figure 7-22 Phase > Signal Analysis settings menu page

Table 7-21 Phase > Signal Analysis settings menu description

| Menu | Description |
|-------------|---|
| Ref Channel | Press the Ref Channel softkey to set the reference channel number. The phase of each channel is measured against the reference channel. The phase result for the reference channel should always be displayed zero. |
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | Press the Input Range softkey to configure the input range settings. <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

SNR

SNR measurement provides a single value measurement of the signal to noise ratio of the output signal from each DUT channel. SNR is used to evaluate the intelligibility of a signal by expressing the difference between the nominal signal level and the noise. SNR is formed by two measurements where the first measurement is the signal level and the second measurement is the noise level with the signal turned off. These two measurements are expressed as ratio and displayed in decibels. The SNR measurement settings allows you to configure the signal generation settings and signal analysis settings.

The result for the SNR measurement for all the selected channels are displayed in a bar chart (SNR). Refer to **“Measurement Results”** on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The SNR signal generation settings menu page is displayed as shown in **Figure 7-23**.



Figure 7-23 SNR > Signal Generation settings menu page

Table 7-22 SNR > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - Sine - Variable phase - Square - Arbitrary |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration. The available settings depend on the waveform type.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Frequency Set the frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. - Phase->1st Ch Set the phase value. This setting is only available when channel 2 is selected. |

Signal analysis

The SNR signal analysis settings menu page is displayed as shown in **Figure 7-24**.




Figure 7-24 SNR > Signal Analysis settings menu page

Table 7-23 SNR > Signal Analysis settings menu description

| Menu | Description |
|---------------------|--|
| SNR Mode | <p>Press the SNR Mode softkey to select the SNR measurement mode.</p> <ul style="list-style-type: none"> - Fast The SNR measurement is based on the frequency domain computation method. - Standard The SNR measurement is measured by an internal routine that alternatively switches the U8903B generator output on and off. This mode is a closed-loop configuration which requires both the generator and analyzer in the test setup. |
| SNR Delay | <p>Press the SNR Delay softkey to set the SNR delay. This setting is only available when SNR Mode is set to Standard.</p> |
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency. This setting is only available when SNR Mode is set to Fast.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | <p>Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when SNR Mode is set to Fast and Freq Lock is set to Custom.</p> |
| Harmonic Cnt | <p>Press the Harmonic Cnt softkey to set the number of harmonic order to be removed. This setting is only available when SNR Mode is set to Fast.</p> |

Table 7-23 SNR > Signal Analysis settings menu description (continued)

| Menu | Description |
|-------------|---|
| LPF | Press the Filtering softkey to select the low-pass filter. |
| | - None |
| | - 2 kHz |
| | - 3 kHz |
| | - 5 kHz |
| | - 8 kHz |
| | - 10 kHz |
| | - 15 kHz |
| | - 20 kHz |
| | - 22 kHz |
| | - 30 kHz |
| | - 40 kHz |
| | - 50 kHz |
| - 80 kHz | |
| - Custom | |
| HPF | Press the HPF softkey to select the high-pass filter. |
| | - None |
| | - 15 Hz |
| | - 20 Hz |
| | - 22 Hz |
| | - 30 Hz |
| | - 50 Hz |
| | - 70 Hz |
| | - 100 Hz |
| | - 200 Hz |
| - 300 Hz | |
| - 400 Hz | |
| - Custom | |
| Weighting | Press the Weighting softkey to select the weighting filter. |
| | - None |
| | - A |
| | - CCIR 1k |
| | - CCIR 2k |
| | - CCITT |
| - C-Message | |
| - Custom | |
| Deemphasis | Press the Deemphasis softkey to select the de-emphasis filter. |
| | - None |
| | - 50 μ s |
| | - 75 μ s |
| - Custom | |

Table 7-23 SNR > Signal Analysis settings menu description (continued)

| Menu | Description |
|--------------------|--|
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range <ul style="list-style-type: none"> Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch <ul style="list-style-type: none"> If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range <ul style="list-style-type: none"> Set the input voltage range. |

THD+N

THD+N measurement provides a single value measurement of the THD+N (Total Harmonic Distortion with Noise) in the output signal from each DUT channel, as measured at each of the analyzer input. The THD+N measurement settings allows you to configure the signal generation settings and signal analysis settings.

The result for the THD+N measurement for all the selected channels are displayed in a bar chart (SINAD, THD Level, THD Ratio, THD+N Level, and THD+N Ratio). Refer to **“Measurement Results”** on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The THD+N signal generation settings menu page is displayed as shown in **Figure 7-25**.




Figure 7-25 THD+N > Signal Generation settings menu page

Table 7-24 THD+N > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - Sine - Variable phase - Square - Arbitrary |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration. The available settings depend on the waveform type.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Frequency Set the frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. - Phase->1st Ch Set the phase value. This setting is only available when channel 2 is selected. |

Signal analysis

The THD+N signal analysis settings menu page is displayed as shown in **Figure 7-26**.


**Figure 7-26** THD+N > Signal Analysis settings menu page

Table 7-25 THD+N > Signal Analysis settings menu description

| Menu | Description |
|------------------|--|
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | <p>Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |
| Harmonics | <p>Press the Harmonics softkey to select the harmonics count to be used in the THD ratio and THD level results.</p> <ul style="list-style-type: none"> - All - 2 to 9 |
| LPF | <p>Press the LPF softkey to select the low-pass filter.</p> <ul style="list-style-type: none"> - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom |
| HPF | <p>Press the HPF softkey to select the high-pass filter.</p> <ul style="list-style-type: none"> - None - 15 Hz - 20 Hz - 22 Hz - 30 Hz - 50 Hz - 70 Hz - 100 Hz - 200 Hz - 300 Hz - 400 Hz - Custom |

Table 7-25 THD+N > Signal Analysis settings menu description (continued)

| Menu | Description |
|--------------------|---|
| Weighting | <p>Press the Weighting softkey to select the weighting filter.</p> <ul style="list-style-type: none"> - None - A - CCIR 1k - CCIR 2k - CCITT - C-Message - Custom |
| Deemphasis | <p>Press the Deemphasis softkey to select the de-emphasis filter.</p> <ul style="list-style-type: none"> - None - 50 μs - 75 μs - Custom |
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

DC level

DC level measurement provides a single value measurement of the DC voltage present at the output of each DUT channel. If AC coupling is selected in the input configuration settings, it will change to DC coupling when the DC level measurement is being performed. The DC level measurement settings allows you to configure the signal generation settings and signal analysis settings.

The result for the DC level measurement for all the selected channels are displayed in a bar chart (DC Level). Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The DC level signal generation settings menu page is displayed as shown in **Figure 7-27**.




Figure 7-27 DC Level > Signal Generation settings menu page

Table 7-26 DC Level > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - Sine - Arbitrary |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration. The available settings depend on the waveform type.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Frequency Set the frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. |

Signal analysis

The DC level signal analysis settings menu page is displayed as shown in **Figure 7-28**.




Figure 7-28 DC Level > Signal Analysis settings menu page

Table 7-27 DC Level > Signal Analysis settings menu description

| Menu | Description |
|-------------|--|
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. |
| | - 2048 |
| | - 4096 |
| | - 8192 |
| | - 16384 |
| | - 32768 |
| | - 65536 |
| | - 131072 |
| | - 262144 |
| | - 524288 |
| - 1M | |
| - 2M | |
| Input Range | Press the Input Range softkey to configure the input range settings. |
| | - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. |
| | - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. |
| | - Voltage Range Set the input voltage range. |

Crosstalk

Crosstalk is the unwanted leakage or bleed of a signal from one or more channels to other channels in a DUT. Crosstalk measurement provides the measurement of the crosstalk into the unstimulated DUT channel(s) when one channel is stimulated.

The generator will output the test signal to the DUT on the selected driven channel. The crosstalk in each of the remaining channels is then measured. The crosstalk measurement settings allows you to configure the signal generation settings and signal analysis settings.

The crosstalk measured in each channels are displayed in a bar chart (Crosstalk). Refer to **“Measurement Results”** on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The crosstalk signal generation settings menu page is displayed as shown in **Figure 7-29**.




Figure 7-29 Crosstalk > Signal Generation settings menu page

Table 7-28 Crosstalk > Signal Generation settings menu description

| Menu | Description |
|------------------------|---|
| Waveform | Press the Waveform softkey to select the waveform type. <ul style="list-style-type: none"> - Sine - Arbitrary |
| Output | Press the Output softkey to select the output channel. |
| Waveform Config | Press the Waveform Config softkey to set the waveform configuration. The available settings depend on the waveform type. <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Frequency Set the frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. |

Signal analysis

The crosstalk signal analysis settings menu page is displayed as shown in **Figure 7-30**.


**Figure 7-30** Crosstalk > Signal Analysis settings menu page

Table 7-29 Crosstalk > Signal Analysis settings menu description

| Menu | Description |
|--------------------|---|
| Driven Ch | Press the Driven Ch softkey to select the driven channel number from the generator. |
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to use the driven channel frequency value. You can select the generator channel by setting the Driven Ch. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. |
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

SMPTÉ IMD

SMPTÉ IMD measurement provides a single value measurement of the IMD ratio in the output signal from each DUT channel using the SMPTÉ method. The SMPTÉ IMD measurement settings allows you to configure the signal generation settings and signal analysis settings.

The result for the SMPTÉ ratio measurement for all the selected channels are displayed in a bar chart (SMPTÉ Ratio). Refer to **“Measurement Results”** on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

This measurement requires a closed-loop configuration in which both the generator and the analyzer are used in the test setup. If None is selected for the output configuration channel, this measurement is unavailable.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The SMPTÉ IMD signal generation settings menu page is displayed as shown in **Figure 7-31**.




Figure 7-31 SMPTÉ IMD > Signal Generation settings menu page

Table 7-30 SMPTE IMD > Signal Generation settings menu description

| Menu | Description |
|------------------------|---|
| Waveform | Press the Waveform softkey to select the waveform type. <ul style="list-style-type: none"> - SMPTE 1:1 - SMPTE 4:1 - SMPTE 10:1 |
| Output | Press the Output softkey to select the output channel. |
| Waveform Config | Press the Waveform Config softkey to set the waveform configuration. The available settings depend on the waveform type. <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Upper Freq Set the upper frequency value. - Lower Freq Set the lower frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. |

Signal analysis

The SMPTE IMD signal analysis settings menu page is displayed as shown in **Figure 7-32**.


**Figure 7-32** SMPTE IMD > Signal Analysis settings menu page

Table 7-31 SMPTE IMD > Signal Analysis settings menu description

| Menu | Description |
|--------------------|---|
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the upper and lower frequencies.</p> <ul style="list-style-type: none"> - Gen Lock Selecting Gen Lock will allow the U8903B to search for the upper and lower frequencies of the input signal based on the upper and lower frequencies of the respective generator channel. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the upper and lower frequency values by setting the searching method to Custom and setting the frequency value in Upper Freq and Lower Freq. |
| Upper Freq | <p>Press the Upper Freq softkey to set the upper fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |
| Lower Freq | <p>Press the Lower Freq softkey to set the lower fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

DFD IMD

DFD IMD measurement provides a single value measurement of the IMD ratio in the output signal from each DUT channel using the DFD method. The DFD measurement settings allows you to configure the signal generation settings and signal analysis settings.

The result for the DFD ratio measurement for all the selected channels are displayed in a bar chart (DFD Ratio). Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The DFD IMD signal generation settings menu page is displayed as shown in **Figure 7-33**.




Figure 7-33 DFD IMD > Signal Generation settings menu page

Table 7-32 DFD IMD > Signal Generation settings menu description

| Menu | Description |
|------------------------|---|
| Waveform | Press the Waveform softkey to select the waveform type. <ul style="list-style-type: none"> - IEC60118 - IEC60268 |
| Output | Press the Output softkey to select the output channel. |
| Waveform Config | Press the Waveform Config softkey to set the waveform configuration. The available settings depend on the waveform type. <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Upper Freq Set the upper frequency value. - Center Freq Set the center frequency value. - Diff Freq Set the difference frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. |

Signal analysis

The DFD IMD signal analysis settings menu page is displayed as shown in **Figure 7-34**.


**Figure 7-34** DFD IMD > Signal Analysis settings menu page

Table 7-33 DFD IMD > Signal Analysis settings menu description

| Menu | Description |
|--------------------|--|
| DFD order | <p>Press the DFD order softkey to select the distortion order to be measured.</p> <ul style="list-style-type: none"> - 2nd - 3rd |
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

Multitone analyzer

Multitone analyzer measurement uses the FFT analysis with a multitone stimulus waveform. The multitone stimulus signal is the combination of two or more sine waveforms. The multitone signal is applied to the DUT, and the DUT output is acquired for measurement. You can create a multitone from the Tones Config menu page in the signal generation settings.

The result for the multitone analyzer measurement for all the selected channels are displayed in a graph (Spectrum, Waveform, Level, and Gain) and in a bar chart (Max Tone Level, Min Tone Level, TD+N Level, TD+N Ratio, and Tone Level). Refer to **“Measurement Results”** on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

This measurement requires a closed-loop configuration in which both the generator and the analyzer are used in the test setup. If None is selected for the output configuration channel, this measurement is unavailable. This measurement is also unavailable if a different interface is selected for the output and input configuration channel.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The multitone analyzer signal generation settings menu page is displayed as shown in **Figure 7-35**.




Figure 7-35 Multitone Analyzer > Signal Generation settings menu page

Table 7-34 Multitone Analyzer > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Output | Press the Output softkey to select the output channel. |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Amplitude Set the amplitude value. |
| Tones Config | <p>Press the Tones Config softkey to set the tones.</p> <ul style="list-style-type: none"> - Start freq The lowest frequency in the multitone waveform. - Stop freq The highest frequency in the multitone waveform. - Freq Spacing The frequency spacing between the tones. - Tone Count The number of signal frequency components. The maximum number of tones that can be generated is 60 for analog and 64 for digital/<i>Bluetooth</i>. - Length The waveform length that determines the number of samples used to create one iteration of the multitone waveform. Longer waveform length provides higher frequency resolution but will take more time to generate and process. - Apply Apply the multitone after it has been customized. - Optimize Optimize the multitone. - Amplitude Dist: Zero Set the amplitude of all tones to 0 dB. - Phase Dist: Zero Set the phase of all tones to 0 degrees. - Phase Dist: Random Set the phase of all tones to random phase in degrees. - Edit Tones Edit the individual tones frequency, amplitude, and phase. - Active Channel The active channel for the absolute amplitude for each tone to be displayed in a table. |

Signal analysis

The multitone analyzer signal analysis settings menu page is displayed as shown in **Figure 7-36**.




Figure 7-36 Multitone Analyzer > Signal Analysis settings menu page

Table 7-35 Multitone Analyzer > Signal Analysis settings menu description

| Menu | Description |
|--------------------|--|
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

Stepped frequency sweep

Stepped sweep is an audio testing method where one parameter is swept across a range of values while one or more other parameters are measured. The stepped frequency sweep measurement provides a sine wave stimulus signal that is moved across a range of frequencies in a specified number of points. The DUT output is acquired by the analyzer and the results are displayed on an X-Y graph, with the generator frequency on the X-axis and the measured results from the DUT on the Y-axis (AC Level, Gain, Phase, THD Ratio, THD Level, THD+N Ratio, THD+N Level, and SINAD).

Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Auto ranging is not supported for the phase result. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

This measurement requires a closed-loop configuration in which both the generator and the analyzer are used in the test setup. If None is selected for the output configuration channel, this measurement is unavailable.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The stepped frequency sweep signal generation settings menu page is displayed as shown in **Figure 7-37**.



Figure 7-37 Stepped Frequency Sweep > Signal Generation settings menu page

Table 7-36 Stepped Frequency Sweep > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Output | Press the Output softkey to select the output channel. |
| Sweep Config | <p>Press the Sweep Config softkey to set the sweep configuration.</p> <ul style="list-style-type: none"> - Start Set the start value for the sweep parameter. - Stop Set the stop value for the sweep parameter. - Spacing Select Log, Linear, or Custom for the sweep spacing. - Points Set the number of sweep points. - Step Size Set the step size for linear spacing. This setting is only available when spacing is set to Linear. - Dwell Time Set the delay between the sweep points. - Edit Points Edit the individual points value, insert or remove points, load points, and save the points. |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. |

Signal analysis

The stepped frequency sweep signal analysis settings menu page is displayed as shown in **Figure 7-38**.



Figure 7-38 Stepped Frequency Sweep > Signal Analysis settings menu page

Table 7-37 Stepped Frequency Sweep > Signal Analysis settings menu description

| Menu | Description |
|-------------|--|
| Ref Channel | Press the Ref Channel softkey to set the reference channel number. The phase of each channel is measured against the reference channel. The phase result for the reference channel should always be displayed zero. |
| Wrap Phase | Press the Wrap Phase softkey to enable or disable the wrap phase. <ul style="list-style-type: none"> - On The phase result is wrapped so that it falls within the range of -180° ~ 180°. - Off The result displayed is the exact value after subtracted from the reference channel. |
| Harmonics | Press the Harmonics softkey to select the harmonics count to be used in the THD ratio and THD level results. <ul style="list-style-type: none"> - All - 2 to 9 |

Table 7-37 Stepped Frequency Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|-------------------|---|
| LPF | Press the LPF softkey to select the low-pass filter. |
| | - None |
| | - 2 kHz |
| | - 3 kHz |
| | - 5 kHz |
| | - 8 kHz |
| | - 10 kHz |
| | - 15 kHz |
| | - 20 kHz |
| | - 22 kHz |
| | - 30 kHz |
| | - 40 kHz |
| | - 50 kHz |
| - 80 kHz | |
| - Custom | |
| HPF | Press the HPF softkey to select the high-pass filter. |
| | - None |
| | - 15 Hz |
| | - 20 Hz |
| | - 22 Hz |
| | - 30 Hz |
| | - 50 Hz |
| | - 70 Hz |
| | - 100 Hz |
| | - 200 Hz |
| | - 300 Hz |
| - 400 Hz | |
| - Custom | |
| Weighting | Press the Weighting softkey to select the weighting filter. |
| | - None |
| | - A |
| | - CCIR 1k |
| | - CCIR 2k |
| | - CCITT |
| | - C-Message |
| - Custom | |
| Deemphasis | Press the Deemphasis softkey to select the de-emphasis filter. |
| | - None |
| | - 50 μ s |
| | - 75 μ s |
| - Custom | |

Table 7-37 Stepped Frequency Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|--|--|
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. |
| | - 2048 |
| | - 4096 |
| | - 8192 |
| | - 16384 |
| | - 32768 |
| | - 65536 |
| | - 131072 |
| | - 262144 |
| | - 524288 |
| - 1M | |
| - 2M | |
| Input Range | Press the Input Range softkey to configure the input range settings. |
| | - Auto Range |
| | Enable or disable the auto input range. |
| | If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. |
| If auto range is disabled, you can set a fixed input voltage range for each analog input channel. | |
| - Track 1st Ch | |
| If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. | |
| - Voltage Range | |
| Set the input voltage range. | |

SMPT E frequency sweep

SMPT E frequency sweep measurement will hold one of the two tones at a fixed frequency while the other is swept through a range of frequencies. The results are displayed on an X-Y graph, with the swept frequency on the X-axis and the measured SMPT E ratio on the Y-axis.

Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

This measurement requires a closed-loop configuration in which both the generator and the analyzer are used in the test setup. If None is selected for the output configuration channel, this measurement is unavailable.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The SMPT E frequency sweep signal generation settings menu page is displayed as shown in **Figure 7-39**.




Figure 7-39 SMPT E Frequency Sweep > Signal Generation settings menu page

Table 7-38 SMPTE Frequency Sweep > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - SMPTE 1:1 - SMPTE 4:1 - SMPTE 10:1 |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Sweep Config | <p>Press the Sweep Config softkey to set the sweep configuration.</p> <ul style="list-style-type: none"> - Swept Select Upper Freq or Lower Freq as the sweep parameter. - Start Set the start value for the sweep parameter. - Stop Set the stop value for the sweep parameter. - Spacing Select Log, Linear, or Custom for the sweep spacing. - Points Set the number of sweep points. - Step Size Set the step size for linear spacing. This setting is only available when spacing is set to Linear. - Dwell Time Set the delay between the sweep points. - Edit Points Edit the individual points value, insert or remove points, load points, and save the points. |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Upper Freq Set the upper frequency value. This setting is only available if Swept is set to Lower Freq. - Lower Freq Set the lower frequency value. This setting is only available if Swept is set to Upper Freq. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. |

Signal analysis

The SMPTE frequency sweep signal analysis settings menu page is displayed as shown in **Figure 7-40**.



Figure 7-40 SMPTE Frequency Sweep > Signal Analysis settings menu page

Table 7-39 SMPTE Frequency Sweep > Signal Analysis settings menu description

| Menu | Description |
|-------------|--|
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. |
| | <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | Press the Input Range softkey to configure the input range settings. |
| | <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

DFD frequency sweep

DFD frequency sweep measurement will hold one of the two frequencies (IEC60118 upper or difference frequency and IEC60268 center or difference frequency) at a fixed frequency while the other is swept through a range of frequencies. The results are displayed on an X-Y graph, with the swept frequency on the X-axis and the measured DFD ratio on the Y-axis.

Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

This measurement requires a closed-loop configuration in which both the generator and the analyzer are used in the test setup. If None is selected for the output configuration channel, this measurement is unavailable.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The DFD frequency sweep signal generation settings menu page is displayed as shown in **Figure 7-41**.



Figure 7-41 DFD Frequency Sweep > Signal Generation settings menu page

Table 7-40 DFD Frequency Sweep > Signal Generation settings menu description

| Menu | Description |
|------------------------|---|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - IEC60118 - IEC60268 |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Sweep Config | <p>Press the Sweep Config softkey to set the sweep configuration.</p> <ul style="list-style-type: none"> - Swept Select Upper Freq or Diff Freq as the sweep parameter. - Start Set the start value for the sweep parameter. - Stop Set the stop value for the sweep parameter. - Spacing Select Log, Linear, or Custom for the sweep spacing. - Points Set the number of sweep points. - Step Size Set the step size for linear spacing. This setting is only available when spacing is set to Linear. - Dwell Time Set the delay between the sweep points. - Edit Points Edit the individual points value, insert or remove points, load points, and save the points. |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Upper Freq Set the upper frequency value. This setting is only available if Swept is set to Diff Freq. - Diff Freq Set the difference frequency value. This setting is only available if Swept is set to Upper Freq. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. |

Signal analysis

The DFD frequency sweep signal analysis settings menu page is displayed as shown in **Figure 7-42**.



Figure 7-42 DFD Frequency Sweep > Signal Analysis settings menu page

Table 7-41 DFD Frequency Sweep > Signal Analysis settings menu description

| Menu | Description |
|-------------|---|
| DFD order | Press the DFD order softkey to select the distortion product order to be measured. - 2nd - 3rd |
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |

Table 7-41 DFD Frequency Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|--------------------|---|
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

External frequency sweep

Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

The external frequency sweep signal generation settings menu page is displayed as shown in **Figure 7-43**.




Figure 7-43 External Frequency Sweep > Signal Generation settings menu page

Table 7-42 External Frequency Sweep > Signal Generation settings menu description

| Menu | Description |
|-----------------|---|
| Instrument | Press the Instrument softkey to select the instrument model. <ul style="list-style-type: none"> - Keysight 33220A - Keysight 33250A - Keysight 33500A - Keysight 33600A - Other |
| GPIB Address | Press the GPIB Address softkey to select the GPIB address. <ul style="list-style-type: none"> - 0 to 30 |
| Init Instrument | Press the Init Instrument softkey to enable or disable the U8903B to send SCPI commands to initialize the connected signal generator. |
| Init SCPI | Press the Init SCPI softkey to set the SCPI commands that initialize the connected instrument. You can set the SCPI command directly or load from a file. <ul style="list-style-type: none"> - Edit - Import (Refer to “Recall” on page 95 for more information on the Recall menu page.) |

Table 7-42 External Frequency Sweep > Signal Generation settings menu description (continued)

| Menu | Description |
|---------------------|---|
| Sweep SCPI | <p>Press the Sweep SCPI softkey to set the sweep SCPI commands that initialize the connected instrument. You can set the SCPI command directly or load from a file.</p> <ul style="list-style-type: none"> - Edit - Import (Refer to “Recall” on page 95 for more information on the Recall menu page.) |
| Sweep Config | <p>Press the Sweep Config softkey to set the sweep configuration.</p> <ul style="list-style-type: none"> - Start <ul style="list-style-type: none"> Set the start value for the sweep parameter. - Stop <ul style="list-style-type: none"> Set the stop value for the sweep parameter. - Spacing <ul style="list-style-type: none"> Select Log, Linear, or Custom for the sweep spacing. - Points <ul style="list-style-type: none"> Set the number of sweep points. - Step Size <ul style="list-style-type: none"> Set the step size for linear spacing. This setting is only available when spacing is set to Linear. - Dwell Time <ul style="list-style-type: none"> Set the delay between the sweep points. - Edit Points <ul style="list-style-type: none"> Edit the individual points value, insert or remove points, load points, and save the points. |

Signal analysis

The external frequency sweep signal analysis settings menu page is displayed as shown in **Figure 7-44**.



Figure 7-44 External Frequency Sweep > Signal Analysis settings menu page

Table 7-43 External Frequency Sweep > Signal Analysis settings menu description

| Menu | Description |
|-------------|--|
| Ref Channel | Press the Ref Channel softkey to select the reference channel number. The phase of each channel is measured against the reference channel. The phase result for the reference channel should always be displayed zero. |
| Harmonics | Press the Harmonics softkey to select the harmonics count to be used in the THD ratio and THD level results. <ul style="list-style-type: none"> - All - 2 to 9 |
| LPF | Press the LPF softkey to select the low-pass filter. <ul style="list-style-type: none"> - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom |

Table 7-43 External Frequency Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|---------------------|--|
| HPF | Press the HPF softkey to select the high-pass filter. |
| | - None |
| | - 15 Hz |
| | - 20 Hz |
| | - 22 Hz |
| | - 30 Hz |
| | - 50 Hz |
| | - 70 Hz |
| | - 100 Hz |
| | - 200 Hz |
| | - 300 Hz |
| - 400 Hz | |
| - Custom | |
| Weighting | Press the Weighting softkey to select the weighting filter. |
| | - None |
| | - A |
| | - CCIR 1k |
| | - CCIR 2k |
| | - CCITT |
| | - C-Message |
| - Custom | |
| Deemphasis | Press the Deemphasis softkey to select the de-emphasis filter. |
| | - None |
| | - 50 μ s |
| | - 75 μ s |
| - Custom | |
| Notch Filter | Press the Notch Filter softkey to configure the notch filter settings. |
| | - HP8903B Enable or disable the HP8903B mode. |
| | - Custom Notch Enable or disable the custom notch. |
| | - Center Freq Set the center frequency value. This is only applicable when custom notch is enabled. |
| | - Bandwidth Set the bandwidth value. This is only applicable when custom notch is enabled. |
| | |

Table 7-43 External Frequency Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|--------------------|--|
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range <ul style="list-style-type: none"> Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch <ul style="list-style-type: none"> If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range <ul style="list-style-type: none"> Set the input voltage range. |

Stepped level sweep

Stepped sweep is an audio testing method where one parameter is swept across a range of values while one or more other parameters are measured. The stepped level sweep measurement provides a sine wave stimulus signal that is moved across a range of levels in a specified number of points. The DUT output is acquired by the analyzer and the results are displayed on an X-Y graph, with the generator level on the X-axis and the measured results from the DUT on the Y-axis (AC Level, Gain, THD Ratio, THD Level, THD Ratio Vs Measured Amplitude, THD Level Vs Measured Amplitude, THD+N ratio, THD+N Level, THD+N Ratio Vs Measured Amplitude, THD+N Level Vs Measured Amplitude, and SINAD).

Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

This measurement requires a closed-loop configuration in which both the generator and the analyzer are used in the test setup. If None is selected for the output configuration channel, this measurement is unavailable.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The stepped level sweep signal generation settings menu page is displayed as shown in **Figure 7-45**.



Figure 7-45 Stepped Level Sweep > Signal Generation settings menu page

Table 7-44 Stepped Level Sweep > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - Sine - Arbitrary |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Sweep Config | <p>Press the Sweep Config softkey to set the sweep configuration.</p> <ul style="list-style-type: none"> - Start Set the start value for the sweep parameter. - Stop Set the stop value for the sweep parameter. - Spacing Select Log, Linear, or Custom for the sweep spacing. - Points Set the number of sweep points. - Step Size Set the step size for linear spacing. This setting is only available when spacing is set to Linear. - Dwell Time Set the delay between the sweep points. - Edit Points Edit the individual points value, insert or remove points, load points, and save the points. |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Frequency Set the frequency value. - DC Offset Set the DC offset value. |

Signal analysis

The stepped level sweep signal analysis settings menu page is displayed as shown in **Figure 7-46**.




Figure 7-46 Stepped Level Sweep > Signal Analysis settings menu page

Table 7-45 Stepped Level Sweep > Signal Analysis settings menu description

| Menu | Description |
|------------------|--|
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | <p>Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |

Table 7-45 Stepped Level Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|------------|---|
| LPF | Press the LPF softkey to select the low-pass filter. |
| | - None |
| | - 2 kHz |
| | - 3 kHz |
| | - 5 kHz |
| | - 8 kHz |
| | - 10 kHz |
| | - 15 kHz |
| | - 20 kHz |
| | - 22 kHz |
| | - 30 kHz |
| | - 40 kHz |
| | - 50 kHz |
| - 80 kHz | |
| - Custom | |
| HPF | Press the HPF softkey to select the high-pass filter. |
| | - None |
| | - 15 Hz |
| | - 20 Hz |
| | - 22 Hz |
| | - 30 Hz |
| | - 50 Hz |
| | - 70 Hz |
| | - 100 Hz |
| | - 200 Hz |
| | - 300 Hz |
| - 400 Hz | |
| - Custom | |
| Weighting | Press the Weighting softkey to select the weighting filter. |
| | - None |
| | - A |
| | - CCIR 1k |
| | - CCIR 2k |
| | - CCITT |
| | - C-Message |
| - Custom | |
| Deemphasis | Press the Deemphasis softkey to select the de-emphasis filter. |
| | - None |
| | - 50 μ s |
| | - 75 μ s |
| - Custom | |

Table 7-45 Stepped Level Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|--------------------|--|
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range <ul style="list-style-type: none"> Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch <ul style="list-style-type: none"> If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range <ul style="list-style-type: none"> Set the input voltage range. |

SMPTE level sweep

SMPTE level sweep measurement will add two tones of different frequencies into a stimulus signal to sweep through a range of levels. The results are displayed on an X-Y graph, with the swept generator level or measured DUT level on the X-axis and the measured SMPTE ratio on the Y-axis.

Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

This measurement requires a closed-loop configuration in which both the generator and the analyzer are used in the test setup. If None is selected for the output configuration channel, this measurement is unavailable.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The SMPTE level sweep signal generation settings menu page is displayed as shown in **Figure 7-47**.



Figure 7-47 SMPTE Level Sweep > Signal Generation settings menu page

Table 7-46 SMPTE Level Sweep > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - SMPTE 1:1 - SMPTE 4:1 - SMPTE 10:1 |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Sweep Config | <p>Press the Sweep Config softkey to set the sweep configuration.</p> <ul style="list-style-type: none"> - Start Set the start value for the sweep parameter. - Stop Set the stop value for the sweep parameter. - Spacing Select Log, Linear, or Custom for the sweep spacing. - Points Set the number of sweep points. - Step Size Set the step size for linear spacing. This setting is only available when spacing is set to Linear. - Dwell Time Set the delay between the sweep points. - Edit Points Edit the individual points value, insert or remove points, load points, and save the points. |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Upper Freq Set the upper frequency value. - Lower Freq Set the lower frequency value. - DC Offset Set the DC offset value. |

Signal analysis

The SMPTE level sweep signal analysis settings menu page is displayed as shown in **Figure 7-48**.




Figure 7-48 SMPTE Level Sweep > Signal Analysis settings menu page

Table 7-47 SMPTE Level Sweep > Signal Analysis settings menu description

| Menu | Description |
|-------------------|--|
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the upper and lower frequencies.</p> <ul style="list-style-type: none"> - Gen Lock Selecting Gen Lock will allow the U8903B to search for the upper and lower frequencies of the input signal based on the upper and lower frequencies of the respective generator channel. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the upper and lower frequency values by setting the searching method to Custom and setting the frequency value in Upper Freq and Lower Freq. |
| Upper Freq | <p>Press the Upper Freq softkey to set the upper fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |
| Lower Freq | <p>Press the Lower Freq softkey to set the lower fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |

Table 7-47 SMPTE Level Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|--------------------|--|
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. |
| | - 2048 |
| | - 4096 |
| | - 8192 |
| | - 16384 |
| | - 32768 |
| | - 65536 |
| | - 131072 |
| | - 262144 |
| | - 524288 |
| - 1M | |
| - 2M | |
| Input Range | Press the Input Range softkey to configure the input range settings. |
| | - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. |
| | - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. |
| | - Voltage Range Set the input voltage range. |
| | |

DFD level sweep

DFD level sweep measurement will add up two tones of different frequencies into a stimulus signal to sweep through a range of levels. The results are displayed on an X-Y graph, with the swept generator level or measured DUT level on the X-axis and the measured DFD ratio on the Y-axis.

Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

This measurement requires a closed-loop configuration in which both the generator and the analyzer are used in the test setup. If None is selected for the output configuration channel, this measurement is unavailable.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The DFD level sweep signal generation settings menu page is displayed as shown in **Figure 7-49**.



Figure 7-49 DFD Level Sweep > Signal Generation settings menu page

Table 7-48 DFD Level Sweep > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - IEC60118 - IEC60268 |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Sweep Config | <p>Press the Sweep Config softkey to set the sweep configuration.</p> <ul style="list-style-type: none"> - Start Set the start value for the sweep parameter. - Stop Set the stop value for the sweep parameter. - Spacing Select Log, Linear, or Custom for the sweep spacing. - Points Set the number of sweep points. - Step Size Set the step size for linear spacing. This setting is only available when spacing is set to Linear. - Dwell Time Set the delay between the sweep points. - Edit Points Edit the individual points value, insert or remove points, load points, and save the points. |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Upper Freq Set the upper frequency value. - Diff Freq Set the difference frequency value. - DC Offset Set the DC offset value. |

Signal analysis

The DFD level sweep signal analysis settings menu page is displayed as shown in **Figure 7-50**.




Figure 7-50 DFD Level Sweep > Signal Analysis settings menu page

Table 7-49 DFD Level Sweep > Signal Analysis settings menu description

| Menu | Description |
|--------------------|---|
| DFD order | Press the DFD order softkey to select the distortion product order to be measured. - 2nd - 3rd |
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |

Table 7-49 DFD Level Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|--------------------|---|
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none">- Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel.- Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels.- Voltage Range Set the input voltage range. |

DC level sweep

DC level sweep measurement sweeps a DC signal across a range of values in a series of points and the DUT output is acquired by the analyzer. The results are displayed on an X-Y graph, with the generator DC level on the X-axis and the measured result on the Y-axis. If AC coupling is selected in the input configuration settings, it will temporarily be set to DC coupling while the DC level sweep measurement is performed.

Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

This measurement requires a closed-loop configuration in which both the generator and the analyzer are used in the test setup. If None is selected for the output configuration channel, this measurement is unavailable.

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The DC level sweep signal generation settings menu page is displayed as shown in **Figure 7-51**.



Figure 7-51 DC Level Sweep > Signal Generation settings menu page

Table 7-50 DC Level Sweep > Signal Generation settings menu description

| Menu | Description |
|---------------------|--|
| Output | Press the Output softkey to select the output channel. |
| Sweep Config | <p>Press the Sweep Config softkey to set the sweep configuration.</p> <ul style="list-style-type: none"> - Start Set the start value for the sweep parameter. - Stop Set the stop value for the sweep parameter. - Spacing Select Log, Linear, or Custom for the sweep spacing. - Points Set the number of sweep points. - Step Size Set the step size for linear spacing. This setting is only available when spacing is set to Linear. - Dwell Time Set the delay between the sweep points. - Edit Points Edit the individual points value, insert or remove points, load points, and save the points. |

Signal analysis

The DC level sweep signal analysis settings menu page is displayed as shown in **Figure 7-52**.


**Figure 7-52** DC Level Sweep > Signal Analysis settings menu page

Table 7-51 DC Level Sweep > Signal Analysis settings menu description

| Menu | Description |
|------------|---|
| LPF | Press the LPF softkey to select the low-pass filter. |
| | - None |
| | - 2 kHz |
| | - 3 kHz |
| | - 5 kHz |
| | - 8 kHz |
| | - 10 kHz |
| | - 15 kHz |
| | - 20 kHz |
| | - 22 kHz |
| | - 30 kHz |
| | - 40 kHz |
| | - 50 kHz |
| - 80 kHz | |
| - Custom | |
| HPF | Press the HPF softkey to select the high-pass filter. |
| | - None |
| | - 15 Hz |
| | - 20 Hz |
| | - 22 Hz |
| | - 30 Hz |
| | - 50 Hz |
| | - 70 Hz |
| | - 100 Hz |
| | - 200 Hz |
| | - 300 Hz |
| | - 400 Hz |
| | - Custom |
| Weighting | Press the Weighting softkey to select the weighting filter. |
| | - None |
| | - A |
| | - CCIR 1k |
| | - CCIR 2k |
| | - CCITT |
| | - C-Message |
| - Custom | |
| Deemphasis | Press the Deemphasis softkey to select the de-emphasis filter. |
| | - None |
| | - 50 μ s |
| | - 75 μ s |
| - Custom | |

Table 7-51 DC Level Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|--|--|
| Sample Size | Press the Sample Size softkey to select the number of samples to be acquired for the measurement. |
| | - 2048 |
| | - 4096 |
| | - 8192 |
| | - 16384 |
| | - 32768 |
| | - 65536 |
| | - 131072 |
| | - 262144 |
| | - 524288 |
| - 1M | |
| - 2M | |
| Input Range | Press the Input Range softkey to configure the input range settings. |
| | - Auto Range |
| | Enable or disable the auto input range. |
| | If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. |
| If auto range is disabled, you can set a fixed input voltage range for each analog input channel. | |
| - Track 1st Ch | |
| If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. | |
| - Voltage Range | |
| Set the input voltage range. | |

Receiver sensitivity

Receiver sensitivity measurement uses an external RF (radio frequency) signal generator to create a RF stimulus signal that is moved across a range of powers in a specified number of points. The DUT output which is in analog audio is acquired by the analyzer and processed for display.

The receiver sensitivity measurement is typically used for characterizing radio sensitivity by measuring SINAD. SINAD is an audio quality value that is used to specify the RF sensitivity of radio receivers. A higher SINAD value indicates higher quality audio.

Figure 7-53 shows a general setup for the receiver sensitivity measurement. A signal generator provides its own modulation and the U8903B controls the signal generator through Keysight 82357B USB/GPIB interface. A receiver such as a two-way radio is connected to the U8903B either by a direct connection or through an acoustic coupler.




Figure 7-53 General setup for the receiver sensitivity measurement

Set the audio output level of the receiver as required and the signal generator settings to the desired value. The U8903B will automatically adjust the RF power output from the signal generator so that the targeted SINAD is produced at the receiver output. The targeted SINAD value is generally 12 dB for a communications receiver and 23 dB (mono) or 26 dB (stereo) for a broadcast receiver such as a car radio or Hi-Fi tuner.

The results are displayed on an X-Y graph, with the RF power parameter on the X-axis and the measured SINAD results on the Y-axis. Refer to **“Measurement Results”** on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

Receiver sensitivity measurement will be unavailable if the *Bluetooth* interface is selected for the input configuration.

Signal generation

The receiver sensitivity signal generation settings menu page is displayed as shown in **Figure 7-54**.




Figure 7-54 Receiver Sensitivity > Signal Generation settings menu page

Table 7-52 Receiver Sensitivity > Signal Generation settings menu description


| Menu | Description |
|-----------------|---|
| Instrument | Press the Instrument softkey to select the signal generator model. <ul style="list-style-type: none"> - Keysight E4438C - Other |
| GPIB address | Press the GPIB address softkey to set the GPIB address for the connected signal generator. |
| Start Power | Press the Start Power softkey to set the sweep start RF power. |
| Stop Power | Press the Stop Power softkey to set the sweep stop RF power. |
| Step Size | Press the Step Size softkey to set the step size. |
| Dwell Time | Press the Dwell Time softkey to set the delay between each measured SINAD in seconds. |
| Init Instrument | Press the Init Instrument softkey to enable or disable the U8903B to send SCPI commands to initialize the connected signal generator. |
| FM Frequency | Press the FM Frequency softkey to set the RF signal output frequency. This setting is only available if Instrument is set to Keysight E4438C and the Init Instrument is enabled. |
| FM Deviation | Press the FM Deviation softkey to set the RF signal frequency modulation deviation. This setting is only available if Instrument is set to Keysight E4438C and the Init Instrument is enabled. |
| FM Rate | Press the FM Rate softkey to set the RF signal internal frequency modulation rate. This setting is only available if Instrument is set to Keysight E4438C and the Init Instrument is enabled. |

Table 7-52 Receiver Sensitivity > Signal Generation settings menu description (continued)

| Menu | Description |
|--------------------------|--|
| Init SCPI | Press the Init SCPI softkey to set the SCPI commands that initialize the connected signal generator. You can set the SCPI command directly or load from a file. This setting is only available if Instrument is set to Other and the Init Instrument is enabled. |
| Output Power SCPI | Press the Output Power SCPI softkey to edit the SCPI command that adjusts the RF power of the connected signal generator. The command must be in the following pattern. Cmds <val> Cmds is the SCPI command and <val> is the value that will be filled up by the measurement to perform sweep. For example, :POW <val>DBM. This setting is only available if Instrument is set to Other. |

Signal analysis

The receiver sensitivity signal analysis settings menu page is displayed as shown in **Figure 7-55**.

**Figure 7-55** Receiver Sensitivity > Signal Analysis settings menu page**Table 7-53** Receiver Sensitivity > Signal Analysis settings menu description

| Menu | Description |
|-----------------------|---|
| Meas Channel | Press the Meas Channel softkey to set the measured channel number. |
| Target SINAD | Press the Target SINAD softkey to set the target SINAD value measured from the Meas Channel. |
| Min 1st Value | Press the Min 1st Value softkey to set the minimum first value. |
| Stop Condition | Press the Stop Condition softkey to select the stop condition. – Until End – On Target |

Table 7-53 Receiver Sensitivity > Signal Analysis settings menu description (continued)

| Menu | Description |
|------------------|--|
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | <p>Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |
| LPF | <p>Press the LPF softkey to select the low-pass filter.</p> <ul style="list-style-type: none"> - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom |
| HPF | <p>Press the HPF softkey to select the high-pass filter.</p> <ul style="list-style-type: none"> - None - 15 Hz - 20 Hz - 22 Hz - 30 Hz - 50 Hz - 70 Hz - 100 Hz - 200 Hz - 300 Hz - 400 Hz - Custom |
| Weighting | <p>Press the Weighting softkey to select the weighting filter.</p> <ul style="list-style-type: none"> - None - A - CCIR 1k - CCIR 2k - CCITT - C-Message - Custom |

Table 7-53 Receiver Sensitivity > Signal Analysis settings menu description (continued)

| Menu | Description |
|-----------------------|---|
| Deemphasis | <p>Press the Deemphasis softkey to select the de-emphasis filter.</p> <ul style="list-style-type: none"> - None - 50 μs - 75 μs - Custom |
| Notch Filter | <p>Press the Notch Filter softkey to configure the notch filter settings.</p> <ul style="list-style-type: none"> - HP8903B Enable or disable the HP8903B notch filter mode. - Custom Notch Enable or disable custom notch filter. - Center Freq Set the center frequency value. This is only available when the Custom Notch is enabled. - Bandwidth Set the bandwidth value. This is only available when the Custom Notch is enabled. |
| Average Points | <p>Press the Average Points softkey to set the number of measurement readings to be used for the average calculation. This is useful for noisy signals. Applying the average points will smooth out the fluctuations introduced by the noise that causes the inconsistencies in the measurement reading.</p> |
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

External level sweep

Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

Signal generation

The external level sweep signal generation settings menu page is displayed as shown in **Figure 7-56**.




Figure 7-56 External Level Sweep > Signal Generation settings menu page

Table 7-54 External Level Sweep > Signal Generation settings menu description

| Menu | Description |
|-----------------|--|
| Instrument | <p>Press the Instrument softkey to select the instrument model.</p> <ul style="list-style-type: none"> - Keysight 33220A - Keysight 33250A - Keysight 33500A - Keysight 33600A - Other |
| GPIB Address | <p>Press the GPIB Address softkey to select the GPIB address.</p> <ul style="list-style-type: none"> - 0 to 30 |
| Init Instrument | <p>Press the Init Instrument softkey to enable or disable the U8903B to send SCPI commands to initialize the connected signal generator.</p> |
| Init SCPI | <p>Press the Init SCPI softkey to set the SCPI commands that initialize the connected instrument. You can set the SCPI command directly or load from a file.</p> <ul style="list-style-type: none"> - Edit - Import (Refer to “Recall” on page 95 for more information on the Recall menu page.) |

Table 7-54 External Level Sweep > Signal Generation settings menu description (continued)

| Menu | Description |
|---------------------|---|
| Sweep SCPI | <p>Press the Sweep SCPI softkey to set the sweep SCPI commands that initialize the connected instrument. You can set the SCPI command directly or load from a file.</p> <ul style="list-style-type: none"> - Edit - Import (Refer to “Recall” on page 95 for more information on the Recall menu page.) |
| Sweep Config | <p>Press the Sweep Config softkey to set the sweep configuration.</p> <ul style="list-style-type: none"> - Start <ul style="list-style-type: none"> Set the start value for the sweep parameter. - Stop <ul style="list-style-type: none"> Set the stop value for the sweep parameter. - Spacing <ul style="list-style-type: none"> Select Log, Linear, or Custom for the sweep spacing. - Points <ul style="list-style-type: none"> Set the number of sweep points. - Step Size <ul style="list-style-type: none"> Set the step size for linear spacing. This setting is only available when spacing is set to Linear. - Dwell Time <ul style="list-style-type: none"> Set the delay between the sweep points. - Edit Points <ul style="list-style-type: none"> Edit the individual points value, insert or remove points, load points, and save the points. |

Signal analysis

The external frequency sweep signal analysis settings menu page is displayed as shown in **Figure 7-57**.




Figure 7-57 External Level Sweep > Signal Analysis settings menu page

Table 7-55 Stepped Level Sweep > Signal Analysis settings menu description

| Menu | Description |
|------------------|--|
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | <p>Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |

Table 7-55 Stepped Level Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|------------|---|
| LPF | Press the LPF softkey to select the low-pass filter. |
| | - None |
| | - 2 kHz |
| | - 3 kHz |
| | - 5 kHz |
| | - 8 kHz |
| | - 10 kHz |
| | - 15 kHz |
| | - 20 kHz |
| | - 22 kHz |
| | - 30 kHz |
| | - 40 kHz |
| | - 50 kHz |
| - 80 kHz | |
| - Custom | |
| HPF | Press the HPF softkey to select the high-pass filter. |
| | - None |
| | - 15 Hz |
| | - 20 Hz |
| | - 22 Hz |
| | - 30 Hz |
| | - 50 Hz |
| | - 70 Hz |
| | - 100 Hz |
| | - 200 Hz |
| | - 300 Hz |
| - 400 Hz | |
| - Custom | |
| Weighting | Press the Weighting softkey to select the weighting filter. |
| | - None |
| | - A |
| | - CCIR 1k |
| | - CCIR 2k |
| | - CCITT |
| | - C-Message |
| - Custom | |
| Deemphasis | Press the Deemphasis softkey to select the de-emphasis filter. |
| | - None |
| | - 50 μ s |
| | - 75 μ s |
| - Custom | |

Table 7-55 Stepped Level Sweep > Signal Analysis settings menu description (continued)

| Menu | Description |
|---------------------|---|
| Notch Filter | <p>Press the Notch Filter softkey to configure the notch filter settings.</p> <ul style="list-style-type: none"> - HP8903B Enable or disable the HP8903B mode. - Custom Notch Enable or disable the custom notch. - Center Freq Set the center frequency value. - Bandwidth Set the bandwidth value. |
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range Set the input voltage range. |

Measurement recorder

Measurement recorder is a tool that provides a record of a number of measurements versus elapsed time. It is useful to monitor the output of a DUT over an extended period of time. The measurement recorder does not require a specific test signal. It can be used with any audio signal within the input range of the analyzer or with no signal.

The reading rate of the measurement recorder is dependent on the channel count, sample size, and result type. A reading is obtained at the beginning of the measurement and throughout the duration set until the elapsed time.

The results are displayed on an X-Y graph, with the time parameter on the X-axis and the measured results on the Y-axis (AC Level, Gain, Phase, THD+N Ratio, THD+N Level, DC Level, Frequency, and SINAD). Refer to “**Measurement Results**” on page 401 for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

- Auto ranging is not supported for the phase result.
 - DC level result is not available if AC coupling is selected in the output configuration settings.
-

Signal generation

NOTE

The signal generation is disabled if None is selected for the output configuration channel.

The measurement recorder signal generation settings menu page is displayed as shown in **Figure 7-58**.




Figure 7-58 Measurement Recorder > Signal Generation settings menu page

Table 7-56 Measurement Recorder > Signal Generation settings menu description

| Menu | Description |
|------------------------|--|
| Waveform | <p>Press the Waveform softkey to select the waveform type.</p> <ul style="list-style-type: none"> - Sine - Variable Phase - Square - Arbitrary |
| Output | <p>Press the Output softkey to select the output channel.</p> |
| Waveform Config | <p>Press the Waveform Config softkey to set the waveform configuration.</p> <ul style="list-style-type: none"> - Track 1st Ch If Track 1st Ch is enabled, the generator channel 1 waveform configuration settings will be copied to the other channels and the waveform configuration settings for the other channels cannot be edited. Any changes made to channel 1 waveform configuration settings will be reproduced in the other channels waveform configuration settings. Disable the Track 1st Ch to set the individual channels. - Frequency Set the frequency value. - Amplitude Set the amplitude value. - DC Offset Set the DC offset value. |

Signal analysis

The measurement recorder signal analysis settings menu page is displayed as shown in **Figure 7-59**.




Figure 7-59 Measurement Recorder > Signal Analysis settings menu page

Table 7-57 Measurement Recorder > Signal Analysis settings menu description

| Menu | Description |
|--------------------|--|
| Duration | <p>Press the Duration softkey to set the length of the measurement record. The duration is in the following pattern. hh : mm : ss hh is the hours, mm is the minutes, and ss is the seconds. The minimum duration is 0 s, and the maximum duration is 3 days (71 : 59 : 59). When the duration is set to 0 s, a single measurement will be made.</p> |
| Ref Channel | <p>Press the Ref Channel softkey to set the reference channel number. The phase of each channel is measured against the reference channel. The phase result for the reference channel should always be displayed zero.</p> |
| Wrap Phase | <p>Press the Wrap Phase softkey to enable or disable the wrap phase.</p> <ul style="list-style-type: none"> - On The phase result is wrapped so that it falls within the range of -180° ~ 180°. - Off The result displayed is the exact value after subtracted from the reference channel. |
| Freq Lock | <p>Press the Freq Lock softkey to select the searching method for the fundamental frequency.</p> <ul style="list-style-type: none"> - Auto Selecting Auto will allow the U8903B to search for the fundamental frequency automatically. - Gen Lock Selecting Gen Lock will allow the U8903B to search for the fundamental frequency based on the generator frequency value of the respective generator channel. This Gen Lock method is only useful if you use the internal audio generator. - Custom If you have a known input signal, you can define the fundamental frequency value by setting the searching method to Custom and setting the frequency value in Fund Freq. |
| Fund Freq | <p>Press the Fund Freq softkey to set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom.</p> |

Table 7-57 Measurement Recorder > Signal Analysis settings menu description (continued)

| Menu | Description |
|------------|---|
| LPF | Press the LPF softkey to select the low-pass filter. |
| | - None |
| | - 2 kHz |
| | - 3 kHz |
| | - 5 kHz |
| | - 8 kHz |
| | - 10 kHz |
| | - 15 kHz |
| | - 20 kHz |
| | - 22 kHz |
| | - 30 kHz |
| | - 40 kHz |
| | - 50 kHz |
| - 80 kHz | |
| - Custom | |
| HPF | Press the HPF softkey to select the high-pass filter. |
| | - None |
| | - 15 Hz |
| | - 20 Hz |
| | - 22 Hz |
| | - 30 Hz |
| | - 50 Hz |
| | - 70 Hz |
| | - 100 Hz |
| | - 200 Hz |
| | - 300 Hz |
| - 400 Hz | |
| - Custom | |
| Weighting | Press the Weighting softkey to select the weighting filter. |
| | - None |
| | - A |
| | - CCIR 1k |
| | - CCIR 2k |
| | - CCITT |
| | - C-Message |
| - Custom | |
| Deemphasis | Press the Deemphasis softkey to select the de-emphasis filter. |
| | - None |
| | - 50 μ s |
| | - 75 μ s |
| - Custom | |

Table 7-57 Measurement Recorder > Signal Analysis settings menu description (continued)

| Menu | Description |
|--------------------|--|
| Sample Size | <p>Press the Sample Size softkey to select the number of samples to be acquired for the measurement.</p> <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M |
| Input Range | <p>Press the Input Range softkey to configure the input range settings.</p> <ul style="list-style-type: none"> - Auto Range <ul style="list-style-type: none"> Enable or disable the auto input range. If auto range is enabled, each analog channel input range is determined automatically, based on the level of the input signal. If the input signal level changes beyond the ranging threshold, auto range will cause the input ranging circuits to move up or down for a proper ranging. If auto range is disabled, you can set a fixed input voltage range for each analog input channel. - Track 1st Ch <ul style="list-style-type: none"> If Track 1st Ch is enabled, all the other channels will be set to follow the channel 1 range setting. Any changes made to channel 1 range setting will be reproduced in the other channels. Disable the Track 1st Ch to set the individual channels. - Voltage Range <ul style="list-style-type: none"> Set the input voltage range. |

Voice quality

NOTE

POLQA measurement is only available with N3432A. Refer to “**U8903B Options**” on page **37** for more information.

This measurement is unavailable if a different interface is selected for the output and input configuration channel.

Perceptual Objective Listening Quality Assessment (POLQA) is the next-generation voice quality testing technology for fixed, mobile, and IP-based networks. POLQA was standardized by the ITU-T (International Telecommunication Union) as the new Recommendation P.863 and can be applied for voice quality analysis of high definition voice, 3G, and 4G/LTE networks. POLQA is licensed by OPTICOM GmbH.

NOTE

Perceptual Objective Listening Quality Analysis (POLQA) according to ITU-T Recommendation P. 863 included in this product is protected by copyright and by European, US and other International patents and patent applications and is provided under license from OPTICOM Dipl.-Ing. M. Keyhl GmbH, Erlangen, Germany, 2011 - www.opticom.de.

POLQA® is a registered trademark of OPTICOM GmbH. Used by permission.

© 2011 by the POLQA Coalition of OPTICOM GmbH, Germany - SwissQual AG, Switzerland - KPN, The Netherlands - TNO, The Netherlands.

Copying, modifying, translating, reverse engineering or decompiling the POLQA Software is prohibited. Acknowledgement of the rights in the POLQA software shall not be removed from the POLQA software or any installation of it.

For further information please refer to www.polqa.info.

POLQA provides significantly improved benchmark accuracy for 3G and strong support for testing of most recent technologies such as Unified Communications, Next Gen Networks, and 4G/LTE compared to PESQ/P8.862 that was originally released in the year 2001.

POLQA measurement working model is to predict speech quality by analysing digital speech signal. The objective measures should be as close as possible to the subjective quality scores as if it would be obtained from subjective listening tests. Typically, POLQA measurement uses real speech as a test stimulus to assess the quality and performance of telephony networks. POLQA measurement is the successor to PESQ/P8.862 measurement.

The result for the voice quality measurement for all the selected channels are displayed in a bar chart (MOS-LQO and Levels). Refer to “**Measurement Results**” on page **401** for more information on the respective result menu page. Use the arrow keys to navigate through the respective tabs and to display the menu page.

NOTE

POLQA voice quality analysis may have a reduced wave file recording duration compared to the PESQ voice quality analysis based on the different option card configuration and settings in the U8903B. For more information, please refer to “**POLQA Recording Duration Analysis**” on page 604.

Signal generation and analysis

The voice quality signal generation and analysis settings menu page is displayed as shown in **Figure 7-60**.




Figure 7-60 Voice Quality > Signal Generation and Analysis settings menu page

Table 7-58 Voice Quality > Signal Generation and Analysis settings menu description

| Menu | Description |
|-------------|--|
| Test Config | <p>Press the Test Config softkey to set the test configurations.</p> <ul style="list-style-type: none"> - Standard Select POLQA as the test standard. - Bandwidth Select Narrowband or Super Wideband as the bandwidth type for POLQA standard. - Level Align Enable or disable the automatic level alignment. This setting is only applicable for POLQA standard. |

Table 7-58 Voice Quality > Signal Generation and Analysis settings menu description (continued)

| Menu | Description |
|-----------|--|
| Reference | <p>Press the Reference softkey to set the reference source configuration.</p> <ul style="list-style-type: none"> - Source <ul style="list-style-type: none"> Select the reference source. - File <ul style="list-style-type: none"> Use the Reference File as the comparison file. - Generator <ul style="list-style-type: none"> Use the Reference File options to determine the comparison file. - Reference File <ul style="list-style-type: none"> Use the Reference File as the comparison file if the Source is set to File. Use the following Reference File options as the comparison file if the Source is set to Generator: <ul style="list-style-type: none"> - Playback File <ul style="list-style-type: none"> Use the Playback File as the comparison file. - Recorded <ul style="list-style-type: none"> Use the Recorded Playback File as the comparison file. - Custom File <ul style="list-style-type: none"> Use the Custom File as the comparison file. - Playback File <ul style="list-style-type: none"> This setting is only available when the Reference Source is set to Generator. Set the playback file to be used as the comparison file if Reference File is set to Playback File. Set the playback file to be recorded as the comparison file if Reference File is set to Recorded. Set the playback file to be recorded and the Custom File to be used as the comparison file if Reference File is set to Custom. - Custom File <ul style="list-style-type: none"> Set the custom file to be used as the comparison file. This setting is only available when Reference Source is set to Generator and Reference File is set to Custom. - Rec Channel <ul style="list-style-type: none"> Set the channel number to be recorded from. This setting is only available when Source is set to Generator and Reference File is set to Recorded. - Rec Duration <ul style="list-style-type: none"> Set the recording duration to be recorded. This setting is only available when Source is set to Generator and Reference File is set to Recorded. - Rec Step <ul style="list-style-type: none"> Set the start recording type. This setting is only available when Source is set to Generator and Reference File is set to Recorded. <ul style="list-style-type: none"> - Auto <ul style="list-style-type: none"> Start the recording automatically. - Delay <ul style="list-style-type: none"> Start the recording after a delay. - Prompt <ul style="list-style-type: none"> Start the recording after the user presses the Enter key to proceed in the confirmation prompt. - Rec Delay <ul style="list-style-type: none"> Set the delay time before a recording is performed. This setting is only available when Source is set to Generator, Reference File is set to Recorded, and Rec Step is set to Delay. - Rec to File <ul style="list-style-type: none"> Enable or disable exporting the recording function. This setting is only available when Source is set to Generator and Reference File is set to Recorded. <ul style="list-style-type: none"> - Yes <ul style="list-style-type: none"> Export the recording to the file path specified in Rec File. - No <ul style="list-style-type: none"> Do not export the recording. - Rec File <ul style="list-style-type: none"> Set the file path for the exported recording destination. This setting is only available when Source is set to Generator, Reference File is set to Recorded, and Rec To File is set to Yes. |

Table 7-58 Voice Quality > Signal Generation and Analysis settings menu description (continued)

| Menu | Description |
|--------------------------------|--|
| Degraded | <p>Press the Degraded softkey to set the degraded source configuration.</p> <ul style="list-style-type: none"> - Source <ul style="list-style-type: none"> Select the degraded source. <ul style="list-style-type: none"> - File <ul style="list-style-type: none"> Use the Degraded File as the comparison file. - Analyzer <ul style="list-style-type: none"> Use the Analyzer recording as the comparison file. - Degraded File <ul style="list-style-type: none"> Set the degraded file as the comparison file. This setting is only available when Source is set to File. - Rec Channel <ul style="list-style-type: none"> Set the channel number to be recorded from. This setting is only available when Source is set to Analyzer. - Rec Duration <ul style="list-style-type: none"> Set the recording duration to be recorded. This setting is only available when Source is set to Analyzer. - Rec Step <ul style="list-style-type: none"> Set the start recording type. This setting is only available when Source is set to Analyzer. <ul style="list-style-type: none"> - Auto <ul style="list-style-type: none"> Start the recording automatically. - Delay <ul style="list-style-type: none"> Start the recording after a delay. - Prompt <ul style="list-style-type: none"> Start the recording after the user presses the Enter key to proceed in the confirmation prompt. - Rec Delay <ul style="list-style-type: none"> Set the delay time before a recording is performed. This setting is only available when Source is set to Analyzer and Rec Step is set to Delay. - Rec to File <ul style="list-style-type: none"> Enable or disable exporting the recording function. This setting is only available when Source is set to Analyzer. <ul style="list-style-type: none"> - Yes <ul style="list-style-type: none"> Export the recording to the file path specified in Rec File. - No <ul style="list-style-type: none"> Do not export the recording. - Rec File <ul style="list-style-type: none"> Set the file path for the exported recording destination. This setting is only available when Source is set to Analyzer and Rec To File is set to Yes. |
| IO Config | <p>Press the IO Config softkey to set the IO configuration.</p> <ul style="list-style-type: none"> - Output Level <ul style="list-style-type: none"> Set the output level value. |
| Show/Hide POLQA License | <p>Press the Show/Hide POLQA License softkey to show or hide the POLQA license information.</p> |

Measurement Results

The test sequence application allows you to display the measurement results in a bar chart or graph.

Bar chart

An example of the bar chart result menu page is displayed as shown in **Figure 7-61**.




Figure 7-61 AC Level > Settings > Result (AC level) menu page

Table 7-59 TSA > Project > Test > Measurement > Settings > Result (bar chart) menu description

| Menu | Description |
|----------------------|---|
| Enable | Press the Enable softkey to enable or disable the selected result tab. |
| Add Result | Press the Add Result softkey to add a new result tab to the measurement. |
| Delete Result | Press the Delete Result softkey to delete the selected result tab from the measurement. |
| Save Data | Press the Save Data softkey to save the selected result data to a CSV file format in the internal storage or external USB flash storage. Refer to “ Save ” on page 94 for the Save menu page. |

Table 7-59 TSA > Project > Test > Measurement > Settings > Result (bar chart) menu description (continued)

| Menu | Description |
|-------------------------|--|
| Edit Limits | Press the Edit Limits softkey to configure the limits settings. |
| | - Track 1st If Track 1st trace is enabled, the channel 1 limits settings will be copied to the other channels and the limits settings for the other channels cannot be edited. Any changes made to the channel 1 limits settings will be reproduced in the other channels limits settings. Disable the Track 1st trace to set the individual channels limits. |
| | - Lower Limit Enable or disable the lower limit. |
| | - Upper Limit Enable or disable the upper limit. |
| | - Lower Limit Set the lower limit value. |
| | - Upper Limit Set the upper limit value. |
| Graph Properties | Press the Graph Properties softkey to set the graph properties. |
| | - Title Edit the bar chart title. |
| | - X-axis Auto Scale Enable or disable the X-axis autoscale. |
| | - Unit Select the X-axis unit type. |
| | - Left Set the X-axis left edge value. This setting is only available when Auto Scale is disabled. |
| | - Right Set the X-axis right edge value. This setting is only available when Auto Scale is disabled. |

Graph

An example of the graph result menu page is displayed as shown in **Figure 7-62**.


**Figure 7-62** Multitone Analyzer > Settings > Result (Spectrum) menu page

Table 7-60 TSA > Project > Test > Measurement > Settings > Result (graph) menu description

| Menu | Description |
|----------------------|---|
| Enable | Press the Enable softkey to enable or disable the selected result tab. |
| Add Result | Press the Add Result softkey to add a new result tab to the measurement. |
| Delete Result | Press the Delete Result softkey to delete the selected result tab from the measurement. |
| Save Data | Press the Save Data softkey to save the selected result data to a CSV file format in the internal storage or external USB flash storage. Refer to “ Save ” on page 94 for the Save menu page. |
| Edit Limits | <p>Press the Edit Limits softkey to configure the limits settings.</p> <ul style="list-style-type: none"> - Trace Select the trace channel number or the trace type (POLQA measurement) - Limit Type Select Upper or Lower as the limit type. - Track 1st If Track 1st trace is enabled, the channel 1 limits settings will be copied to the other channels and the limits settings for the other channels cannot be edited. Any changes made to the channel 1 limits settings will be reproduced in the other channels limits settings. Disable the Track 1st trace to set the individual channels limits. - Limit Enable or disable the limit. - Points - Point No Set the point number. - X Set the X-axis value for the selected point number. - Y Set the Y-axis value for the selected point number. - Add Point Add a limit point. - Remove Point Remove the selected limit point. - Clear Points Clear all the limit points. - Load Points Load limit points from a file. Refer to “Recall” on page 95 for the Recall menu page. - Save Points Save the selected limit points to a file. Refer to “Save” on page 94 for the Save menu page. |

Table 7-60 TSA > Project > Test > Measurement > Settings > Result (graph) menu description (continued)

| Menu | Description |
|--|---|
| Graph Properties | <p>Press the Graph Properties softkey to set the graph properties.</p> <ul style="list-style-type: none"> - Title Edit the graph title. - X-axis - Auto Scale Enable or disable the X-axis autoscale. - Spacing Select Linear or Log for the spacing. - Unit Select the X-axis unit type. - Left Set the X-axis left edge value. This setting is only available when Auto Scale is disabled. - Right Set the X-axis right edge value. This setting is only available when Auto Scale is disabled. - Center Set the X-axis center value. This setting is only available when Auto Scale is disabled. - Span Set the X-axis span value. This setting is only available when Auto Scale is disabled. - Y-axis - Auto Scale Enable or disable the Y-axis autoscale. - Spacing Select Linear or Log for the spacing. - Unit Select the Y-axis unit type. - Top Set the Y-axis top value. This setting is only available when Auto Scale is disabled. - Bottom Set the Y-axis bottom value. This setting is only available when Auto Scale is disabled. - Traces - Trace Select the analyzer trace channel. - State Enable or disable the trace. - Color Set the trace color. |
| Graph Properties (This is only applicable for POLQA measurement MOS-LQO and Delay results) | <p>Press the Graph Properties softkey to set the graph properties.</p> <ul style="list-style-type: none"> - Title Set the bar chart title. - Auto Scale Enable or disable autoscale. - Left Set the X-axis left edge value. This setting is only available when Auto Scale is disabled. - Right Set the X-axis right edge value. This setting is only available when Auto Scale is disabled. - Top Set the Y-axis top edge value. This setting is only available when Auto Scale is disabled. - Bottom Set the Y-axis bottom edge value. This setting is only available when Auto Scale is disabled. |

Report

The U8903B allows you to generate a report of the test sequence results. The TSA > Report menu page is displayed as shown in **Figure 7-63**.




Figure 7-63 TSA > Report menu page

Table 7-61 TSA > Report menu description

| Menu | Description |
|-------------------|---|
| Clear | Press the Clear softkey to clear all the report data. |
| Save | Press the Save softkey to save the report to a DOCX file format. Refer to " Save " on page 94 for more information on the Save menu page. |
| Properties | Press the Properties softkey to configure the auto save settings. Refer to " Properties " on page 406 for more information. |

Properties




Figure 7-64 TSA > Report > Properties menu page

Table 7-62 TSA > Report > Properties menu description

| Menu | Description |
|--------------------|---|
| Auto Save | Press the Auto Save softkey to enable or disable saving the report automatically at the end of a test sequence. |
| Format | Press the Format softkey to select the report file format to be saved. <ul style="list-style-type: none"> - Docx - Html |
| Name Option | Press the Name Option softkey to select the naming convention of the file name for the automatically saved report. <ul style="list-style-type: none"> - Timestamp Save the report in a time stamp suffix file name. - Numeric Save the report in a numerical suffix file name that increments with each save. - Prompt Prompts for the file name at the end of a test sequence. |
| Prefix | Press the Prefix softkey to set the prefix for the file name. |
| Location | Press the Location softkey to select the folder for the automatically saved report. Refer to " Location " on page 407 for more information. |

Location

Select the '..' item at the list and press  to move up a level from the current folder or to another directory. Use the arrow keys to navigate through the files or select the desired folder or file.

Press the **Select** softkey to select the current folder as the location to be saved to. Press the **New Folder** softkey to create a new folder at the current directory or folder.




Figure 7-65 Select Path menu page

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

Keysight U8903B
Performance Audio Analyzer
User's Guide

8 HP8903B

| | |
|----------------------------|-----|
| HP8903B | 410 |
| Measurement | 412 |
| Generator | 414 |
| Sweep | 415 |
| Special function code list | 416 |
| SPCL | 418 |

This chapter describes the various configurations for the HP8903B mode..

NOTE

The HP8903B mode is only available when GPIB is initialized successfully. Entering or exiting the HP8903B mode will cause the system to reset. Some of the SCPI commands for the active channel of the analog analyzer and analog generator that work in the standard view mode will not work in the HP8903B mode.

HP8903B

Press **Menu** and select **HP8903B** to access the HP8903B menu page. The U8903B allows you to emulate the HP8903B audio analyzer behavior in the HP8903B mode.




Figure 8-1 HP8903B menu page

Table 8-1 U8903B LCD display description

| | Item | Description |
|---|---------------------------|--|
| 1 | SINAD meter | Display the SINAD measurement mode readings. |
| 2 | Analyzer panel | Display the measurement results. The left panel reading shows the frequency result while the right panel reading shows the result of the selected measurement modes. Refer to “Measurement” on page 412 for the available measurement modes. |
| 3 | Generator panel | Display the frequency and amplitude values of the sine waveform. The highlighted generator parameter label in red indicates the current increment parameter. You can use the up or down arrow keys to increment/decrement the current parameter value according to the parameter step value. Refer to “Generator” on page 414 for more information. |
| 4 | Measurement setting panel | Display the current measurement settings in red. |
| 5 | HP8903B settings panel | Display the current setting for input range, detector, impedance, and sweep points. If the auto range is selected, the input range parameter will be highlighted in red. |

Measurement

Select **Measurement** in the HP8903B menu page to configure the HP8903B measurement settings.




Figure 8-2 HP8903B > Measurement menu page

Table 8-2 HP8903B > Measurement menu description

| Menu | Description |
|-------------|---|
| Function | <p>Press the Function softkey to select the HP8903B measurement mode.</p> <ul style="list-style-type: none"> - AC LEVEL - SINAD - DISTN - DC LEVEL - SIG / NOISE - DISTN LEVEL |
| LP Filter | <p>Press the LP Filter softkey to select the HP8903B measurement low-pass filter value. The default low-pass filter can be set at "HP8903B Config" on page 89.</p> <ul style="list-style-type: none"> - None - 30 kHz - 80 kHz |
| HP/W Filter | <p>Press the HP/W Filter softkey to select the HP8903B high-pass or weighting filter value. The filter selection depends on the left and right filters set at "HP8903B Config" on page 89.</p> |
| Reference | <p>Press the Reference softkey to set the reference value to be compared with the measured value in ratio mode. Changing the reference value will enable the measurement ratio mode.</p> |
| Ratio | <p>Press the Ratio softkey to enable or disable the HP8903B measurement ratio mode.</p> |
| Format | <p>Press the Format softkey to select the HP8903B measurement format type.</p> <ul style="list-style-type: none"> - Log - Lin |

Table 8-3 shows the measurement units that are applicable for the individual HP8903B measurement modes.

Table 8-3 HP8903B unit charts

| Measurement | Ratio On | | Ratio Off | |
|-------------|----------|-----|-----------------------|-----|
| | LOG | LIN | LOG | LIN |
| AC LEVEL | dB | % | dBm into 600 Ω | V |
| DC LEVEL | dB | % | dBm into 600 Ω | V |
| SINAD | dB | % | dB | % |
| SIG/NOISE | dB | % | dB | % |
| DSTN | dB | % | dB | % |
| DSTN LEVEL | dB | % | dBm into 600 Ω | V |

Generator

Select **Generator** in the HP8903B menu page to configure the HP8903B generator settings.

NOTE

The generator in the HP8903B generates sine waveform.



Figure 8-3 HP8903B > Generator menu page

Table 8-4 HP8903B > Generator menu description

| Menu | Description |
|------------|---|
| Frequency | Press the Frequency softkey to set the HP8903B generator frequency value. Changing the frequency value will also set the step parameter to frequency. |
| Amplitude | Press the Amplitude softkey to set the HP8903B generator amplitude value. Changing the amplitude value will also set the step parameter to amplitude. |
| Step Param | Press the Step Param softkey to select the HP8903B generator step parameter type. <ul style="list-style-type: none"> - Frequency - Amplitude |
| Freq. Step | Press the Freq. Step softkey to set the HP8903B generator frequency step value. This setting is only available when the step parameter is set to frequency. |
| Amp. Step | Press the Amp. Step softkey to set the HP8903B generator amplitude step value. This setting is only available when the step parameter is set to amplitude. |
| x 10 | Press the x 10 softkey to multiply the current parameter step value by 10. |
| ÷ 10 | Press the ÷ 10 softkey to divide the current parameter step value by 10. |

Sweep

In HP8903B mode, the source frequency is logarithmically swept. The number of frequency points in a sweep is determined by the sweep width (ratio of the stop and start frequencies) and the selected sweep resolution. The maximum number of points allowable in a sweep is 255. The frequency points in a sweep can be computed by using the following formulas:

$$\text{Frequency} = \text{Start frequency} \times 10^{\left(\frac{n}{k}\right)}$$

Where n is the frequency point number (0 is the start frequency) and k is the number of points per decade. Refer to the HP8903B special function codes, 17.0 to 17.9 as listed in **Table 8-6**. The frequency point formula for reverse sweep is as follows:

$$\text{Frequency} = \text{Start frequency} \times 10^{\left(\frac{-n}{k}\right)}$$

Select **Sweep** in the HP8903B menu page to configure the HP8903B sweep settings.




Figure 8-4 HP8903B > Sweep menu page

Table 8-5 HP8903B > Sweep menu description

| Menu | Description |
|--------------|---|
| Freq. Start | Press the Freq. Start softkey to set the HP8903B sweep frequency start value. |
| Freq. Stop | Press the Freq. Stop softkey to set the HP8903B sweep frequency stop value. |
| Sweep Status | Press the Sweep Status softkey to start or abort sweeping in the HP8903B mode. |

Special function code list

Select **Code List** in the HP8903B menu page to display the list of supported HP8903B special function codes. The special function codes will be displayed in the lower main display as shown in **Figure 8-5**. Press the up or down arrow keys to scroll up or down the selected special function code list respectively. The HP8903B special function code are as listed in **Table 8-6**.



Figure 8-5 HP8903B > Code List menu page (Input Level Range (except DC Level))

Table 8-6 HP8903B special function code list description

| Special function | Code | Description |
|--|-------------|--|
| Input Level Range (except DC Level) | 1.0 | Auto range |
| | 1.3 | 140 V range |
| | 1.4 ~ 1.5 | 100 V range |
| | 1.6 ~ 1.8 | 32 V range |
| | 1.9 ~ 1.10 | 10 V range |
| | 1.11 ~ 1.13 | 3.2 V range |
| | 1.14 ~ 1.15 | 1 V range |
| Input Level Range (DC Level only) | 1.16 ~ 1.19 | 0.32 V range |
| | 2.0 | Auto Range |
| | 2.2 | 100 V range |
| | 2.3 | 32 V range |
| Post Notch Detector Response (except in SINAD) | 2.4 | 10 V range |
| | 5.0 ~ 5.1 | RMS Detector |
| Display Source Settings | 10.0 | Activate the generator menu. |
| Re-enter Ratio Mode | 11.0 | Restore last RATIO reference and enter RATIO mode if allowed |
| | 11.1 | Display RATIO reference (measurement menu will be activated) |

Table 8-6 HP8903B special function code list description (continued)

| Special function | Code | Description |
|--|--------|---|
| Signal-to-Noise Measurement Delay | 12.0 | No delay |
| | 12.1 | 200 ms delay |
| | 12.2 | 400 ms delay |
| | 12.3 | 600 ms delay |
| | 12.4 | 800 ms delay |
| | 12.5 | 1.0 s delay |
| | 12.6 | 1.2 s delay |
| | 12.7 | 1.4 s delay |
| | 12.8 | 1.6 s delay |
| | 12.9 | 1.8 s delay |
| SINAD and Signal-to-Noise Display Resolution | 16.0 | 0.01 dB above 25 dB 0.5 dB below 25 dB |
| | 16.1 | 0.01 dB all ranges |
| Sweep Resolution (maximum 255 points/sweep) | 17.0 | 10 points/decade |
| | 17.1 | 1 point/decade |
| | 17.2 | 2 points/decade |
| | 17.3 | 5 points/decade |
| | 17.4 | 10 points/decade |
| | 17.5 | 20 points/decade |
| | 17.6 | 50 points/decade |
| | 17.7 | 100 points/decade |
| | 17.8 | 200 points/decade |
| | 17.9 | 500 points/decade |
| Display Level in Watts | 19.0 | Display level as watts into 8 Ω |
| | 19.NNN | Display level as watts into NNN Ω |
| Read Display to SCPI | 20.0 | Read right display |
| | 20.1 | Read left display (Frequency) |
| GPIB Address (SCPI Only) | 21.1 | Displays GPIB address in decimal |
| GPIB Service Request Condition (SCPI Only) | 22.N | Enable a Condition to cause a service request. N is the sum of any combination of the weighted conditions below: 1 - Data Ready 2 - GPIB error 4 - Instrument Error The instrument powers up in the 22.2 state. |
| Source Output Impedance (Instrument powers up at 600 Ω) | 47.0 | 600 Ω |
| | 47.1 | 50 Ω |

SPCL

Press the **SPCL** softkey to set the HP8903B special function code except those indicated as SCPI only, and execute the special function. The HP8903B special function code are as listed in **Table 8-6**.

Floating input

Table 8-7 Floating input settings

| Floating input | Analog analyzer settings |
|----------------|--|
| Off (default) | Analyzer connector is unbalanced and the analyzer impedance is 100 k Ω (default). |
| On | Analyzer connector is balanced and the analyzer impedance is 200 k Ω . |

Table 8-8 Floating output settings

| Floating output | Analog analyzer settings |
|-----------------|--|
| Off (default) | Generator connector is unbalanced with unbalanced impedance of 600 Ω (default) or 50 Ω . |
| On | Generator connector is balanced with balanced impedance of 600 Ω or 40 Ω . |

Table 8-9 Floating output settings and special functions to change the generator impedance

| Floating output | Special function | Generator impedance |
|-----------------|------------------|--|
| Off | 47.0SP | Change the generator impedance to 600 Ω . |
| Off | 47.1SP | Change the generator impedance to 50 Ω . |
| On | 47.0SP | Change the generator impedance to 600 Ω . |
| On | 47.1SP | Change the generator impedance to 40 Ω . |

9 Characteristics and Specifications

For the characteristics and specifications of the U8903B Performance Audio Analyzer, refer to the data sheet at <http://literature.cdn.keysight.com/litweb/pdf/5991-4551EN.pdf>.

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

Keysight U8903B
Performance Audio Analyzer
User's Guide

Appendixes

| | |
|--|-----|
| Appendix 1: FUNCTION panel | 423 |
| Appendix 2: Graph Panel Menu Tree | 424 |
| Appendix 3: System Panel Menu Tree | 426 |
| Appendix 4: Analog Generator Menu Tree | 430 |
| Appendix 5: Digital Generator Menu Tree | 434 |
| Appendix 6: Bluetooth Generator Menu Tree | 445 |
| Appendix 7: Analog Analyzer Menu Tree | 452 |
| Appendix 8: Digital Analyzer Menu Tree | 464 |
| Appendix 9: Bluetooth Analyzer Menu Tree | 476 |
| Appendix 10: Graph Analysis Menu Tree | 488 |
| Appendix 11: Sweep Function Menu Tree | 492 |
| Appendix 12: Save Menu Tree | 495 |
| Appendix 13: Recall Menu Tree | 496 |
| Appendix 14: Test Sequence Menu Tree | 497 |
| Measurement settings | 505 |
| Measurement results | 550 |
| Appendix 15: HP8903B Menu Tree | 554 |
| Appendix 16: Units of the Measurement Function Returned Values | 556 |
| Analog analyzer | 556 |
| Digital analyzer | 557 |
| Bluetooth analyzer | 558 |
| Units for digital audio measurements | 560 |
| Appendix 17: Arbitrary File Format | 561 |
| Appendix 18: User-defined Filter File Format | 563 |
| Appendix 19: DSI Input and Output Interface | 566 |
| Appendix 20: Digital System Clock Distribution Block Diagram | 567 |
| Appendix 21: Typical DSI Test Configurations | 568 |
| Configuration 1 | 568 |
| Configuration 2 | 569 |
| Configuration 3 | 570 |
| Configuration 4 | 571 |
| Configuration 5 | 572 |

- Appendix 22: U8903B Configuration Examples **573**
 - Example 1: Generating a sine waveform with the digital generator and measuring its voltage with the digital analyzer **573**
 - Example 2: Establishing a connection to a Bluetooth device and generating a sine waveform with the Bluetooth generator. **575**
 - Example 3: Generating a multitone waveform with the analog generator and viewing the multitone spectrum in the graph **577**
 - Example 4: Running the Test Sequence App for the multitone analyzer measurement **579**
 - Example 5: Configuring the system clock reference settings **581**
 - Example 6: Configuring the digital generator DSI output settings **582**
- Appendix 23: Relationship between Digital Waveform Parameters and Channels **583**
- Appendix 24: Word Length, Sampling Rate, and Multiplier for DSI **585**
- Appendix 25: Word Length, Sampling Rate, and Multiplier for Master Clock In **591**
- Appendix 26: U8903B Default Settings **597**
 - Analog generator **597**
 - Analog analyzer **598**
 - Sweep **601**
 - HP8903B **602**
 - System **602**
- Appendix 27: Procedure to Rename, Copy, Move, and Delete Files **603**
- Appendix 28: POLQA Recording Duration Analysis **604**
- Appendix 29: Audio Measurement Ranging **605**
 - Manual ranging **605**
 - Auto ranging **605**
 - Using manual ranging for continuous sweep and frequency response measurements **606**

Appendix 1: FUNCTION panel

Table A-1 FUNCTION panel description

| Key | Description |
|--------------------|--|
| Interface | Switch between the analog, digital, or <i>Bluetooth</i> interface. |
| Generator Analyzer | Switch between the generator or analyzer mode. Refer to “ Appendix 4: Analog Generator Menu Tree ” on page 430 and “ Appendix 7: Analog Analyzer Menu Tree ” on page 452 for the analog generator and analog analyzer menu trees. |
| Graph | Access the graph analysis mode. Refer to “ Appendix 10: Graph Analysis Menu Tree ” on page 488 for the graph analysis menu tree. |
| Sweep | Access the sweep function mode. Refer to “ Appendix 11: Sweep Function Menu Tree ” on page 492 for the sweep function menu tree. |
| Full Screen | Maximize the graph view to the full display size. This function is only applicable in the graph analysis mode. |
| Display | Switch among the 2-panel view, 4-panel view, or 10-panel view in the analyzer and generator mode. Switch between single panel view and 2-panel view in the graph analysis mode. |
| Shortcut 1 | Customizable shortcut key. Refer to “ Appendix 3: System Panel Menu Tree ” on page 426 for more information. |
| Shortcut 2 | Customizable shortcut key. Refer to “ Appendix 3: System Panel Menu Tree ” on page 426 for more information. |

Appendix 2: Graph Panel Menu Tree

Table A-2 GRAPH panel menu tree description

| Key | Level 1 | Level 2 | Description | |
|--------------|--------------|---|---|---|
| Peak Search | Max Peak | | Search and move the active marker to the highest peak which is higher than the peak threshold value. | |
| | Next Peak | | Search and move the active marker to the next peak which is higher than the peak threshold value. | |
| | Prev Peak | | Search and move the active marker to the previous peak which is higher than the peak threshold value. | |
| | Next Min | | Search and move the active marker to the previous peak which is lower than the minimum threshold value. | |
| | Prev Min | | Search and move the active marker to the next peak which is lower than the minimum threshold value. | |
| | Threshold | Line Visible | | Enable or disable the threshold line in the graph. - On - Off |
| | | Peak Thres | | Set the peak threshold value. |
| | | Min Thres | | Set the minimum threshold value. |
| | Marker | Active Marker | M1 to M8 | Select the active marker number. |
| | | State | - On - Off | Enable or disable the active marker. |
| Trace | | 1 to 8 | Select the trace number for the active marker. | |
| Ref Mkr | | - OFF - M1 to M8 | Select the reference marker number. | |
| Movement | | - Single - Pair - Bin - Peak - Harmonic | Select the marker movement type. | |
| Function | | - None - Slope - PSD | Select the marker function type. | |
| Marker -> | | -> Start | | Set the left value of the graph to the current marker location. |
| | | -> Stop | | Set the right value of the graph to the current marker location. |
| | | -> Center | | Set the center value of the graph to the current marker location. |
| | | -> Delta | | Set the left and right values of the graph to the current marker and the reference marker location. |
| | Move to 3 dB | | Place the marker on the nearest -3 dB value data point. | |
| Move to 6 dB | | Place the marker on the nearest -6 dB value data point. | | |

Table A-2 GRAPH panel menu tree description (continued)

| Key | Level 1 | Level 2 | Description |
|-----------------------------------|-------------|---------------|--|
| Marker | Harmonics | Trace | Set the trace number to place the marker. |
| | | Enabled | Show or hide the markers. - On - Off |
| | Rdg at Mkr | - On - Off | Enable or disable the readings at the marker. |
| Print (Shift + Marker) | | | Print the current display to a file. |
| Scale | AutoScale | | Perform autoscaling on the X-axis and Y-axis. |
| | AutoScale X | | Perform autoscaling on the X-axis by searching for the most optimum scale (left and right values) for the X-axis based on the data being displayed in the graph. |
| | AutoScale Y | | Perform autoscaling on the Y-axis by searching for the most optimum scale (top and bottom values) for the Y-axis based on the data being displayed in the graph. |
| Zoom | | | Magnify a section of the graph. |

Appendix 3: System Panel Menu Tree

Table A-3 SYSTEM panel menu tree description

| Key | Level 1 | Level 2 | Level 3 | Description |
|--|--|--------------------------------------|---------|--|
| Preset | (Current mode) | | | Reset the current mode to its default settings. |
| | Save User State | | | Save the current user state. |
| | Mode | | | Reset all modes to the default settings without deleting the user-defined files. |
| | To Factory Settings | | | Reset the U8903B to the factory default settings, delete all the files saved in the internal flash memory (for example, state file, arbitrary waveform, test sequence project files, and so on), and reset the GUI state to the Standard View mode. If the HP8903B mode is turned on, the GUI state will remain at the HP8903B mode. |
| | User State | | | Reset the U8903B to the previously saved user state. |
| Utility (if the mode is in the Analyzer or Generator mode) | Save Channel (x) (x) = current channel number | | | Save the current channel state to a file. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. |
| | Save (x) (x) = current mode | | | Save the current mode state to a file. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. |
| | Recall | | | Recall a saved U8903B state from a file. Refer to “Appendix 13: Recall Menu Tree” on page 496 for the recall menu tree. |
| | Copy To | | | Copy the current channel state to other channel(s). |
| | Copy From | | | Select a channel number to copy the state to the current channel. |
| | File Explorer | | | Rename, delete, copy, or move files. |
| Utility (if the mode is in Graph Analysis mode) | Save Graph | | | Save the current graph state to a file. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. |
| | Save Channels Settings | Channel (x) (x) = current channel | | Save the current channel graph state to a file. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. |
| | | All Channels Settings | | Save all channels graph state to a file. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. |

Table A-3 SYSTEM panel menu tree description (continued)

| Key | Level 1 | Level 2 | Level 3 | Description | |
|---|---------------------------|--|-------------|---|--|
| Utility (if the mode is in Graph Analysis mode) | Save Traces | Trace (x) (x) = current trace number | | Save the active trace to a CSV file format. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. | |
| | | All Traces | | Save all traces state to a file. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. | |
| | | Axis Settings | | Save the axis settings state to a file. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. | |
| | | Traces + Axis | | Save all traces and axis settings states. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. | |
| | | Save Trace (x) Data (x) = current channel | | Save the active trace data to a CSV file format. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. | |
| | Recall | | | Load a trace from a CSV file into the active trace. Refer to “ Appendix 13: Recall Menu Tree ” on page 496 for the recall menu tree. | |
| | Copy To | | | Copy the current channel graph state to other channel(s). | |
| | Copy Graph From | | | Select a channel number to copy the graph state to the current channel. | |
| | File Explorer | | | Rename, delete, copy, or move files. | |
| | Help (Shift + Utility) | | | | Display the help mode. Press Shift + Utility to close the help mode. |
| System | Error Info | Load File | | Select the log file to be loaded in the error log viewing panel. Refer to “ Appendix 13: Recall Menu Tree ” on page 496 for the recall menu tree. | |
| | | | | | |
| | I/O | LAN Settings | Reset | | Reset the LAN settings. |
| | | | Hostname | | Set the LAN hostname. |
| | | | Config Mode | | Select the LAN configuration mode. – Auto – Manual |
| | | | IP Address | | Set the LAN IP address. |
| | | | Subnet mask | | Set the LAN subnet mask address. |
| | | | Gateway | | Set the LAN gateway address. |
| | | | DNS 1 | | Set the LAN DNS 1 address. |
| | | | DNS 2 | | Set the LAN DNS 2 address. |
| | GPIB | 0 to 30 | | Set the desired GPIB address. | |

Table A-3 SYSTEM panel menu tree description (continued)

| Key | Level 1 | Level 2 | Level 3 | Description |
|--------|----------------|---|--|--|
| System | I/O | FTP | <ul style="list-style-type: none"> - Enabled - Disabled | Enable or disable the FTP control. |
| | Firmware | Update | | Load the update files. Refer to “Appendix 13: Recall Menu Tree” on page 496 for the recall menu tree. |
| | | EULA | | Display the Keysight EULA page. |
| | Service | Self-Test | Customize Test | Select all or deselect the desired tests. LAN Test Card Self Test |
| | | | Run Test | Run the selected tests. |
| | | | Clear Result | Clear the previous self-test results. |
| | | Diagnostic | Front Panel | Perform the front panel diagnostics. |
| | | | Display | Perform the display diagnostics. |
| | | Secure Erase | | Securely erase all the files saved in the internal flash memory (for example, state file, arbitrary waveform, test sequence project files, and so on). It does not affect the U8903B settings and license information. |
| | | Options | Add Option | Add a new U8903B option. Refer to “Appendix 13: Recall Menu Tree” on page 496 for the recall menu tree. |
| | | | Remove Option | Remove the selected U8903B option. |
| | | Date | | Edit the date in dd/mm/yyyy format. |
| | | Time | | Edit the current time in 24-hour format. |
| | Brightness | 0 to 6 | Adjust the LCD display brightness value. | |
| | Key Sound | <ul style="list-style-type: none"> - On - Off | Enable or disable the front panel key sound. | |
| | Power Up State | <ul style="list-style-type: none"> - Last - Default | Select the power up state. | |
| | Settings | Shortcut 1 | <ul style="list-style-type: none"> - Error List - Auto-Scale - File Explorer - Audio Monitor - Audio Volume | Select a specific function to map the shortcut 1 key. |
| | | Shortcut 2 | <ul style="list-style-type: none"> - Error List - Auto-Scale - File Explorer - Audio Monitor - Audio Volume | Select a specific function to map the shortcut 2 key. |

Table A-3 SYSTEM panel menu tree description (continued)

| Key | Level 1 | Level 2 | Level 3 | Description |
|---------------|----------------------------------|-------------------|--|--|
| System | HP8903B Config | Active Channel | - 1 - 2 | Select the HP8903B active channel. |
| | | Left Filter | - None - A-Weighing - CCIR 1k wtd - CCIR 2k wtd - C-Message - CCITT - 400 Hz | Select the left filter type. |
| | | Right Filter | - None - A-Weighing - CCIR 1k wtd - CCIR 2k wtd - C-Message - CCITT - 400 Hz | Select the right filter value. |
| | | Default LPF | - None - 30 kHz - 80 kHz | Select the default filter for the HP8903B mode. |
| | | Fan & Temperature | | Display the temperatures of the available cards and the speed of the three 80 mm fans in the U8903B. |
| | | Audio Monitor | - On - Off | Enable or disable the aux audio monitor. |
| | | Audio Output | - Speaker - Phone | Select the aux audio output type. |
| | | Audio Mode | - Stereo - Mono | This is only available when audio output is Phone. Select the aux audio mode type. |
| | | Volume | 0 to 100 | Select the aux audio volume. |
| | DC Output | | Set the aux DC output value. | |
| | Board Info | | Display the U8903B available cards information. | |
| | Legacy Sweep | - On - Off | Enable or disable the legacy sweep. | |
| | Macro (Shift + System) | | | Reserved for future expansion. |
| | Local | | | Switch from remote control mode to local mode. The front panel keys are locked in the remote mode. |
| | Lock/Unlock | | | Lock or unlock the front panel keys in the local mode. A dialog box will pop-up for confirmation. |

Appendix 4: Analog Generator Menu Tree

Table A-4 Analog generator menu tree description

| Level 1 | Level 2 | Level 3 | Description |
|----------------------------|---------------|-------------------|--|
| Waveform | - Sine | | Select the waveform type. |
| | - V. Phase | | |
| | - Dual | | |
| | - SMPTE 1:1 | | |
| | - SMPTE 4:1 | | |
| | - SMPTE 10:1 | | |
| | - IEC 60118 | | |
| | - IEC 60268 | | |
| | - Gaus. Noise | | |
| | - Rect. Noise | | |
| | - Pink Noise | | |
| | - Square | | |
| | - DC | | |
| - Sine Burst | | | |
| - Arbitrary | | | |
| - Multitone | | | |
| - DTMF | | | |
| Waveform Config (Sine) | Amplitude | | Set the signal amplitude value. |
| | Frequency | | Set the signal frequency value. |
| | DC Offset | | Set the signal DC offset value. |
| Waveform Config (V. Phase) | Amplitude | | Set the signal amplitude value. |
| | Frequency | | Set the signal frequency value. |
| | Phase -> 1 | | This is only available when the analog generator is in channel 2. Set the phase of the channel 2 sine waveform with reference to channel 1. |
| Waveform Config (Dual) | Amplitude | | Set the signal amplitude value. |
| | Frequency | | Set the signal frequency value. |
| | Frequency 2 | | Set the second sine wave signal frequency value. This setting is only applicable for the dual waveform. |
| | DC Offset | | Set the signal DC offset value. |
| | Ratio | | Set the ratio of the amplitude of the second sine wave over the first sine wave. |
| | Summation | - RSS - Linear | |

Table A-4 Analog generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|---|-------------|-------------------|--|
| Waveform Config (SMPTE 1:1/4:1/10:1) | Amplitude | | Set the signal amplitude value. |
| | Lower Freq | | Set the lower frequency value. |
| | Upper Freq | | Set the higher frequency value. |
| | DC Offset | | Set the signal DC offset value. |
| | Summation | - RSS - Linear | Summation refers to the method to sum up two levels. |
| Waveform Config (IEC 60118) | Amplitude | | Set the signal amplitude value. |
| | Upper Freq | | Set the higher frequency value. |
| | Diff Freq | | Set the difference frequency of the waveform. |
| | DC Offset | | Set the signal DC offset value. |
| | Summation | - RSS - Linear | Summation refers to the method to sum up two levels. |
| Waveform Config (IEC 60268) | Amplitude | | Set the signal amplitude value. |
| | Center Freq | | Set the center frequency of the waveform. |
| | Diff Freq | | Set the difference frequency of the waveform. |
| | DC Offset | | Set the signal DC offset value. |
| | Summation | - RSS - Linear | Summation refers to the method to sum up two levels. |
| Waveform Config (Gaus. Noise) | Amplitude | | Set the signal amplitude value. |
| | DC Offset | | Set the signal DC offset value. |
| Waveform Config (Rect. Noise) | Amplitude | | Set the signal amplitude value. |
| | DC Offset | | Set the signal DC offset value. |
| Waveform Config (Pink Noise) | Amplitude | | Set the signal amplitude value. |
| | DC Offset | | Set the signal DC offset value. |
| Waveform Config (Square) | Amplitude | | Set the signal amplitude value. |
| | Frequency | | Set the signal frequency value. |
| Waveform Config (DC) | Voltage | | Set the signal voltage value. |
| Waveform Config (Sine Burst) | Amplitude | | Set the signal amplitude value. |
| | Frequency | | Set the signal frequency value. |
| | DC Offset | | Set the signal DC offset value. |
| | Burst On | | Set the number of cycles at which the amplitude is at the highest level. |
| | Period | | Set the number of cycles from the beginning of one burst to the beginning of the next burst. |
| | Low Level | | Set the amplitude ratio of Burst On over Burst Off. |

Table A-4 Analog generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description | | |
|--------------------------------|--------------|---|---|--|---|
| Waveform Config (Arbitrary) | Amplitude | | Set the signal amplitude value. | | |
| | DC Offset | | Set the signal DC offset value. | | |
| | Load File | | Load a waveform from a file. Refer to “ Appendix 13: Recall Menu Tree ” on page 496 for the recall menu tree. | | |
| | Info | | Display the loaded waveform information. | | |
| | Amplitude | | Set the signal amplitude value. | | |
| | DC Offset | | Set the signal DC offset value. | | |
| | Start Freq | | Set the lowest frequency in the multitone waveform which is usually the frequency for the first tone. | | |
| | Stop Freq | | Set the highest frequency in the multitone waveform which is usually the frequency for the last tone. | | |
| Waveform Config (Multitone) | Freq Spacing | <ul style="list-style-type: none"> - Linear - Log - Custom | Select frequency spacing between the tones. Custom is selected when the custom multitone waveform is set. | | |
| | Tones | | Set the number of signal frequency components. | | |
| | Length | | <ul style="list-style-type: none"> - 1024 - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 | Select the waveform length that determines the number of samples used to create one iteration of the multitone waveform. | |
| | | Custom | Apply | | Apply the current setting on the selected tone for the custom multitone waveform. |
| | | | Optimize | | Optimize the crest factor for the custom multitone waveform. |
| | | | Frequency | | Set the frequency value for the custom multitone waveform. |
| | | | Amplitude | | Set the amplitude value for the custom multitone waveform. |
| | | | Phase | | Set the phase value for the custom multitone waveform. |
| | Add Above | | | Add the tone above the selected tone for the custom multitone waveform. | |
| | Add Below | | | Add the tone below the selected tone for the custom multitone waveform. | |
| Remove | | | Remove the selected tone for the custom multitone waveform. | | |
| Clear | | Clear all the tones in the custom multitone waveform list. | | | |

Table A-4 Analog generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|------------------------|----------------|--|---|
| Waveform Config (DTMF) | Dial | Mode | Select the mode of operation for the dial mode. Single Sequence |
| | | A | Single dial mode |
| | | B | - Press and hold the A, B, C, or D softkey to dial the A, B, C, or D tone respectively. |
| | | C | Sequence dial mode |
| | D | - Press the A, B, C, or D softkey to add the A tone to the DTMF sequence. | |
| | Pause | Add a pause to the DTMF sequence in the form of a comma. | |
| Waveform Config (DTMF) | Amplitude | | Set the amplitude level of the DTMF signal. |
| | Ratio | | Set the level difference between the high-frequency tone and low-frequency tone. |
| | Tone Duration | | Set the DTMF signal duration. |
| | Tone Delay | | Set the delay between two DTMF tones. |
| | Pause Time | | Set the interval time for the DTMF sequence. |
| | Repeat | | Enable or disable repeating the DTMF sequence. |
| Output Config | Summation | - RSS | Summation refers to the method to sum up two levels. |
| | | - Linear | |
| | Connector | - Bal | Select the output connector type. |
| | | - UnBal | |
| | | - Com | |
| | | - IEC60268 | |
| | Impedance | For Bal, Com, and IEC60268 | Select the output impedance value. |
| | | - 600 Ω | |
| - 100 Ω | | | |
| - 40 Ω | | | |
| IEC60268 10 Ω | For UnBal | Select the additional 10 Ω output series resistance for pin 2 or 3 of the XLR connector in the common IECIEC 6026860268 configuration. This setting is only available when the output connector type is set to IEC 60268. | |
| | - 600 Ω | | |
| | - 50 Ω | | |
| Ground | - Float | Select the grounding type. | |
| | - Ground | | |
| References | Max Voltage | | Set the maximum voltage value. |
| | Ref Impedance | | Set the reference impedance for the unit conversion of dBm measurements. |

Appendix 5: Digital Generator Menu Tree

Table A-5 Digital generator menu tree description

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------------------|---------------|---------|---------|---|
| Waveform | - Sine | | | Select the waveform type. |
| | - V. Phase | | | |
| | - Dual | | | |
| | - SMPTE 1:1 | | | |
| | - SMPTE 4:1 | | | |
| | - SMPTE 10:1 | | | |
| | - IEC 60118 | | | |
| | - IEC 60268 | | | |
| | - Gaus. Noise | | | |
| | - Rect. Noise | | | |
| | - Tri. Noise | | | |
| | - Pink Noise | | | |
| | - Square | | | |
| | - Sine Burst | | | |
| - Stereo | | | | |
| - Monotonicity | | | | |
| - Constant | | | | |
| - Walking Zero | | | | |
| - Walking One | | | | |
| - Multitone | | | | |
| - Arbitrary | | | | |
| Waveform Config (Sine) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (V. Phase) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| | Phase -> 1 | | | This is only available when the digital generator is in channel 2. Set the phase of the channel 2 sine waveform with reference to channel 1. |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|---|-------------|-------------------|---------|---|
| Waveform Config (Dual) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| | Frequency 2 | | | Set the second sine wave signal frequency value. This setting is only applicable for the dual waveform. |
| | DC Offset | | | Set the signal DC offset value. |
| | Ratio | | | Set the ratio of the amplitude of the second sine wave over the first sine wave. |
| | Summation | - RSS - Linear | | Summation refers to the method to sum up two levels. |
| Waveform Config (SMPTE 1:1/4:1/10:1) | Amplitude | | | Set the signal amplitude value. |
| | Lower Freq | | | Set the lower frequency value. |
| | Upper Freq | | | Set the higher frequency value. |
| | DC Offset | | | Set the signal DC offset value. |
| | Summation | - RSS - Linear | | Summation refers to the method to sum up two levels. |
| Waveform Config (IEC 60118) | Amplitude | | | Set the signal amplitude value. |
| | Upper Freq | | | Set the higher frequency value. |
| | Diff Freq | | | Set the difference frequency of the waveform. |
| | DC Offset | | | Set the signal DC offset value. |
| | Summation | - RSS - Linear | | Summation refers to the method to sum up two levels. |
| Waveform Config (IEC 60268) | Amplitude | | | Set the signal amplitude value. |
| | Center Freq | | | Set the center frequency of the waveform. |
| | Diff Freq | | | Set the difference frequency of the waveform. |
| | DC Offset | | | Set the signal DC offset value. |
| | Summation | - RSS - Linear | | Summation refers to the method to sum up two levels. |
| Waveform Config (Gaus. Noise) | Amplitude | | | Set the signal amplitude value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (Rect. Noise) | Amplitude | | | Set the signal amplitude value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (Triangular Noise) | Amplitude | | | Set the signal amplitude value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (Pink Noise) | Amplitude | | | Set the signal amplitude value. |
| | DC Offset | | | Set the signal DC offset value. |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|--------------------------------|--------------|---|---------|--|
| Waveform Config (Square) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (Sine Burst) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| | Burst On | | | Set the number of cycles at which the signal amplitude will be at the higher level. |
| | Period | | | Set the number of cycles from the beginning of one burst to the beginning of the next burst. |
| | Low Level | | | Set the amplitude ratio of Burst On over Burst Off. |
| Waveform Config (Stereo) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (Monotonicity) | Samples/Step | | | Set the duration for each half cycle of the square wave. |
| Waveform Config (Constant) | Voltage | | | Set the signal voltage value. |
| Waveform Config (Walking Zero) | Samples/Step | | | Set the speed the single bit 0 is incremented. |
| Waveform Config (Walking One) | Samples/Step | | | Set the speed the single bit 1 is incremented. |
| Waveform Config (Multitone) | Amplitude | | | Set the signal amplitude value. |
| | Start Freq | | | Set the lowest frequency in the multitone waveform which is usually the frequency for the first tone. |
| | Stop Freq | | | Set the highest frequency in the multitone waveform which is usually the frequency for the last tone. |
| | Freq Spacing | - Linear - Log - Custom | | Select frequency spacing between the tones. Custom is selected when the custom multitone waveform is set. |
| | Tones | | | Set the number of signal frequency components. |
| | Length | - 1024 - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 | | Select the waveform length that determines the number of samples used to create one iteration of the multitone waveform. |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|--------------------------------|----------------|-----------|-----------------------------------|---|
| Waveform Config (Multitone) | Custom | Apply | | Apply the current setting on the selected tone for the custom multitone waveform. |
| | | Optimize | | Optimize the crest factor for the custom multitone waveform. |
| | | Frequency | | Set the frequency value for the custom multitone waveform. |
| | | Amplitude | | Set the amplitude value for the custom multitone waveform. |
| | | Phase | | Set the phase value for the custom multitone waveform. |
| | | Add Above | | Add the tone above the selected tone for the custom multitone waveform. |
| | | Add Below | | Add the tone below the selected tone for the custom multitone waveform. |
| | | Remove | | Remove the selected tone for the custom multitone waveform. |
| | | Clear | | Clear all the tones in the custom multitone waveform list. |
| Waveform Config (Arbitrary) | | Amplitude | | Set the signal amplitude value. |
| | | DC Offset | | Set the signal DC offset value. |
| | | Load File | | Load a waveform from a file. Refer to “Appendix 13: Recall Menu Tree” on page 496 for the recall menu tree. |
| | | Info | | Display the loaded waveform information. |
| Output Config | Connector | - Bal | | Select the output connector type. |
| | | - UnBal | | |
| | AES Output | - On | | Enable or disable the AES output. |
| | | - Off | | |
| | Optical Output | - On | | Enable or disable the optical output. |
| | | - Off | | |
| | Sample Rate | | | Set the sample rate value. |
| Audio Format | - Linear PCM | | Select the encoding audio format. | |
| | - A-Law | | | |
| Dither | - μ -Law | | Select the dither type. | |
| | - Off | | | |
| | - Rectangular | | | |
| | - Triangular | | | |
| | | - Shaped | | |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-------------|----------------|---|---------------------------------|---|
| DSI Config | Voltage | - 1.2 Vpp | | Select the output voltage or set your desired output voltage. |
| | | - 1.5 Vpp | | |
| | | - 1.8 Vpp | | |
| | | - 2.5 Vpp | | |
| | | - 3 Vpp | | |
| | Channels | - 3.3 Vpp | | Select the number of channels. |
| | | - 2 | | |
| | | - 4 | | |
| | | - 6 | | |
| | | - 8 | | |
| Format | - 10 | | Select the DSI output format. | |
| | - 12 | | | |
| | - 14 | | | |
| | - 16 | | | |
| DSI Config | Resolution | - Left | 8 to 24 | Set the audio resolution. |
| | | - Right | | |
| | | - I2S | | |
| | | - DSP | | |
| | BCLK Edge | - Rising | | Select the clock edge type. |
| | | - Falling | | |
| | Fsync Polarity | - Rising | | Select the sync polarity. |
| | | - Falling | | |
| DSI Config | Fsync Width | - One Bit Clock | | Select the sync width. |
| | | - One Subframe | | |
| | | - 50% Duty Cycle | | |
| | Data Shift Cnt | | Set the data shift count value. | |
| | Data Shift Dir | - Left | | Select the data shift direction. |
| | | - Right | | |
| | Master Output | - On | | Enable or disable the master clock output. |
| | | - Off | | |
| Word Length | | Set the master clock word length value. The word length cannot be less than the audio resolution. | | |
| | | - 8 to 32 | | |
| Multiplier | | Set the multiplier value. | | |
| Sample Rate | | Set the sample rate value. | | |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|------------|-------------------------|------------------------------|---|------------------------------------|
| AES3/SPDIF | Level | | | Set the output voltage level. |
| | Resolution | | 8 to 24 | Set the audio resolution value. |
| | Validity Bit | - Set - Clear | | Select the validity bit. |
| | Mode | - Consumer - Professional | | Select the AES3/SPDIF format. |
| | Status Bits | - Channel - User | | Select the status bits type. |
| | | Select Byte | | Select the byte and edit the byte. |
| | | Audio Mode | - Non-Linear PCM - Linear PCM | Select the audio mode. |
| | | Copyright | - Copyright - Non-copyright | Select the copyright type. |
| | Edit Bits (Consumer) | Emphasis | - No pre-emphasis - 50/15 is - Reserved 1 - Reserved 2 | Select the emphasis type. |
| | | Channel Mode | 0 to 3 | Set the channel mode value. |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------|-------------------------|-----------------|------------------------------------|--------------------------------|
| AES3/SPDIF | Edit Bits (Consumer) | Category | - General | Select the category code type. |
| | | | - Laser Optical | |
| | | | - D/D Converter | |
| | | | - Magnetic | |
| | | | - Digital Broadcast 1 | |
| | | | - Digital Broadcast 2 | |
| | | | - Musical Instrument | |
| | | | - ADC Non Copyright | |
| | | | - Solid State Memory | |
| | | | - ADC Copyright | |
| - Experimental | | | | |
| - Reserved 1 | | | | |
| - Reserved 2 | | | | |
| | Source Num | 0 to 15 | Set the source number. | |
| | Channel Num | 0 to 15 | Set the channel number. | |
| | Sample Freq | - Not indicated | Select the sample frequency value. | |
| | | - 22.05 kHz | | |
| | | - 24 kHz | | |
| | | - 32 kHz | | |
| | | - 44.1 kHz | | |
| | | - 48 kHz | | |
| | | - 88.2 kHz | | |
| | | - 96 kHz | | |
| | | - 176.4 kHz | | |
| | | - 192 kHz | | |
| | - 768 kHz | | | |
| | Clk Accuracy | - Level 1 | Select the clock accuracy type. | |
| | | - Level 2 | | |
| | | - Level 3 | | |
| | | - Reserved | | |
| | Max Word Len | - 24 bits | Select the maximum word length. | |
| | | - 20 bits | | |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-----------------------------|-------------------------|------------------------------------|-----------------------------|---|
| AES3/SPDIF | Edit Bits (Consumer) | Word Length | 24 bits maximum word length | Select the word length. |
| | | | - Not indicated | |
| | | | - 20 bits | |
| | | | - 21 bits | |
| | | | - 22 bits | |
| | | - 23 bits | | |
| | | - 24 bits | | |
| | | Orig S.Freq | 20 bits maximum word length | Select the original sample frequency value. |
| | | | - Not indicated | |
| | | | - 16 bits | |
| - 17 bits | | | | |
| - 18 bits | | | | |
| - 19 bits | | | | |
| - 20 bits | | | | |
| CGMA-A | - Not indicated | Select the CGMA-A type. | | |
| | - 8 kHz | | | |
| | - 11.025 kHz | | | |
| | - 12 kHz | | | |
| | - 16 kHz | | | |
| - 22.05 kHz | | | | |
| - 24 kHz | | | | |
| - 32 kHz | | | | |
| - 44.1 kHz | | | | |
| - 48 kHz | | | | |
| - 88.2 kHz | | | | |
| - 96 kHz | | | | |
| - 176.4 kHz | | | | |
| - 192 kHz | | | | |
| - Reserved 1 | | | | |
| - Reserved 2 | | | | |
| Select Byte | | Select the byte and edit the byte. | | |
| Edit Bits (Professional) | Audio Mode | - Non-Linear PCM | Select the audio mode. | |
| | | - Linear PCM | | |
| | Emphasis | - Not indicated | Select the emphasis type. | |
| - No pre-emphasis | | | | |
| - 50/15 μ s | | | | |
| - CCITT J.17 | | | | |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|------------|-----------------------------|--------------|--|--------------------------------------|
| AES3/SPDIF | Edit Bits (Professional) | Freq Mode | <ul style="list-style-type: none"> - Locked - Unlocked | Select the frequency mode. |
| | | Sample Freq | <ul style="list-style-type: none"> - Not indicated - 22.05 kHz - 24 kHz - 32 kHz - 44.1 kHz - 48 kHz - 88.2 kHz - 96 kHz - 176.4 kHz - 192 kHz | Select the sample frequency value. |
| | | Freq Scaling | <ul style="list-style-type: none"> - On - Off | Enable or disable frequency scaling. |
| | | Chan Mode | <ul style="list-style-type: none"> - Not indicated - 2-channel - Single channel - Primary-Secondary - Stereo - Reserved 1 - Reserved 2 - Mono Double Rate - Left Double Rate - Right Double Rate - Multichannel | Select the channel mode. |
| | | User Bits | <ul style="list-style-type: none"> - Not indicated - 192-bit block - Reserved for AES18 - User defined - Reserved for Metadata - As in IEC60958-3 | Select the user bits type. |
| | | Aux Bits | <ul style="list-style-type: none"> - 20-bit not defined - 24-bit main audio - 20-bit single - Reserved | Select the auxiliary bits. |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------|---|---|--|---|
| AES3/SPDIF | Edit Bits (Professional) | Word Length | 24 bits maximum word length | Select the word length. |
| | | | <ul style="list-style-type: none"> - Not indicated - 20 bits - 21 bits - 22 bits - 23 bits - 24 bits | |
| | | Alignment | 20 bits maximum word length | Select the alignment level. |
| | | | <ul style="list-style-type: none"> - Not indicated - 16 bits - 17 bits - 18 bits - 19 bits - 20 bits | |
| | | Multi-Channel | <ul style="list-style-type: none"> - Not Indicated - -18.06 dBFS - -20 dBFS - Reserved | Select the multi-channel status. |
| | | | <ul style="list-style-type: none"> - Defined - Undefined | |
| | | Multi-Ch Mode | <ul style="list-style-type: none"> - Mode 0 - Mode 1 - Mode 2 - Mode 3 - User Defined | This is only available when the multi-channel status is set to Defined. Select the multi-channel mode. |
| | | | <ul style="list-style-type: none"> - 1 to 16 (Defined multi-channel status) - 1 to 128 (Undefined multi-channel status) | |
| | | Channel Num | <ul style="list-style-type: none"> - 1 to 16 (Defined multi-channel status) - 1 to 128 (Undefined multi-channel status) | Set the channel number. |
| | | | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | |
| Ref Signal | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | Select the reference signal type. | | |
| | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | | | |
| Channel Origin | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | Set the channel origin value (4 alphanumeric digit). | | |
| | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | | | |
| Channel Dest | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | Set the channel destination value (4 alphanumeric digit). | | |
| | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | | | |
| Local Addr | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | Set the local address value. | | |
| | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | | | |
| Time of Day | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | Set the time of day. | | |
| | <ul style="list-style-type: none"> - Not a ref. signal - Grade 1 - Grade 2 - Reserved | | | |

Table A-5 Digital generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | |
|--------------|-----------------------------|-------------|----------------|---|---|
| AES3/SPDIF | Edit Bits (Professional) | Rel Flags | - 0-5 | Select the reliability flags. | |
| | | | - 6-13 | | |
| | | | - 14-17 | | |
| | | | - 18-21 | | |
| | Clear Bits | | | Clear all the bits. | |
| | Save File | | | Save the bits to a file. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. | |
| | Load File | | | Load the bits from a file. Refer to “ Appendix 13: Recall Menu Tree ” on page 496 for the recall menu tree. | |
| References | Volts/FS | | | Set the volts/FS reference for the analog output voltage (in Volts) of the DAC used when converted to digital full scale (1 FS). | |
| Clock Config | Ref Clock | Source | - Internal | Select the reference clock source. | |
| | | | - AES RClk | | |
| | | | | - External | |
| | | Output | | - On | Enable or disable the synchronous clock output. |
| | | | | - Off | |
| | | Sync Clock | Divider | - 1 | Select the synchronous clock divider value. |
| | | | | | |
| | | | Source | - Internal | Select the synchronous clock source. |
| | | | | | |
| | | | | - External | |
| | Ext Clock | Type | - MClk Sync In | Select the external reference clock type. | |
| | | | | | - Frame Clk In |
| | | | | | - DSI Gen FS |
| | | | - DSI Gen Clk | | |
| | | Word Length | | Set the external reference clock word length value. | |
| | | Multiplier | | Set the external reference clock multiplier value. The selection available in the external reference clock multiplier depends on the external reference clock word length | |
| | | Frequency | | Set the external reference clock frequency value. | |

Appendix 6: *Bluetooth* Generator Menu Tree

Table A-6 *Bluetooth* generator menu tree description

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------------------|-------------------|---------|---------|--|
| Waveform | - Sine | | | Select the waveform type. |
| | - V. Phase | | | |
| | - Dual | | | |
| | - SMPTE 1:1 | | | |
| | - SMPTE 4:1 | | | |
| | - SMPTE 10:1 | | | |
| | - IEC 60118 | | | |
| | - IEC 60268 | | | |
| | - Gaus. Noise | | | |
| | - Rect. Noise | | | |
| | - Pink Noise | | | |
| | - Square | | | |
| - Sine Burst | | | | |
| - Constant | | | | |
| - Arbitrary | | | | |
| - Multitone | | | | |
| Waveform Config (Sine) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (V. Phase) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| | Phase -> 1 | | | This is only available when the analog generator is in channel 2. Set the phase of the channel 2 sine waveform with reference to channel 1. |
| Waveform Config (Dual) | Amplitude | | | Set the signal amplitude value. |
| | Frequency 1 | | | Set the signal frequency value. |
| | Frequency 2 | | | Set the second sine wave signal frequency value. This setting is only applicable for the dual waveform. |
| | DC Offset | | | Set the signal DC offset value. |
| | Ratio | | | Set the ratio of the amplitude of the second sine wave over the first sine wave. |
| Summation | - RSS - Linear | | - | Summation refers to the method to sum up two levels. |

Table A-6 Bluetooth generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|---|-------------|-------------------|---------|--|
| Waveform Config (SMPTE 1:1/4:1/ 10:1) | Amplitude | | | Set the signal amplitude value. |
| | Lower Freq | | | Set the lower frequency value. |
| | Upper Freq | | | Set the higher frequency value. |
| | DC Offset | | | Set the signal DC offset value. |
| | Summation | - RSS - Linear | - | Summation refers to the method to sum up two levels. |
| Waveform Config (IEC 60118) | Amplitude | | | Set the signal amplitude value. |
| | Upper Freq | | | Set the higher frequency value. |
| | Diff Freq | | | Set the difference frequency of the waveform. |
| | DC Offset | | | Set the signal DC offset value. |
| | Summation | - RSS - Linear | - | Summation refers to the method to sum up two levels. |
| Waveform Config (IEC 60268) | Amplitude | | | Set the signal amplitude value. |
| | Center Freq | | | Set the center frequency of the waveform. |
| | Diff Freq | | | Set the difference frequency of the waveform. |
| | DC Offset | | | Set the signal DC offset value. |
| | Summation | - RSS - Linear | - | Summation refers to the method to sum up two levels. |
| Waveform Config (Gaus. Noise) | Amplitude | | | Set the signal amplitude value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (Rect. Noise) | Amplitude | | | Set the signal amplitude value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (Pink Noise) | Amplitude | | | Set the signal amplitude value. |
| | DC Offset | | | Set the signal DC offset value. |
| Waveform Config (Square) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| Waveform Config (Sine Burst) | Amplitude | | | Set the signal amplitude value. |
| | Frequency | | | Set the signal frequency value. |
| | DC Offset | | | Set the signal DC offset value. |
| | Burst On | | | Set the number of cycles at which the amplitude is at the highest level. |
| | Period | | | Set the number of cycles from the beginning of one burst to the beginning of the next burst. |
| | Low Level | | | Set the amplitude ratio of Burst On over Burst Off. |

Table A-6 Bluetooth generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | |
|--------------------------------|--------------|----------|---------|---|--|
| Waveform Config (Constant) | Voltage | | | Set the signal voltage value. | |
| | Amplitude | | | Set the signal amplitude value. | |
| | DC Offset | | | Set the signal DC offset value. | |
| Waveform Config (Arbitrary) | Load File | | | Load a waveform from a file. Refer to “ Appendix 13: Recall Menu Tree ” on page 496 for the recall menu tree. | |
| | Info | | | Display the loaded waveform information. | |
| | Amplitude | | | Set the signal amplitude value. | |
| | DC Offset | | | Set the signal DC offset value. | |
| Waveform Config (Multitone) | Start Freq | | | Set the lowest frequency in the multitone waveform which is usually the frequency for the first tone. | |
| | Stop Freq | | | Set the highest frequency in the multitone waveform which is usually the frequency for the last tone. | |
| | Freq Spacing | - Linear | | | Select frequency spacing between the tones. |
| | | - Log | | | Custom is selected when the custom multitone waveform is set. |
| | | - Custom | | | |
| | Tones Count | | | Set the number of signal frequency components. | |
| | Length | - 1024 | | | Select the waveform length that determines the number of samples used to create one iteration of the multitone waveform. |
| | | - 2048 | | | |
| - 4096 | | | | | |
| - 8192 | | | | | |
| - 16384 | | | | | |
| - 32768 | | | | | |
| | - 65536 | | | | |

Table A-6 Bluetooth generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|--------------------------------|---|-------------|-------------|---|
| Waveform Config (Multitone) | Custom | Apply | | Apply the current setting on the selected tone for the custom multitone waveform. |
| | | Optimize | | Optimize the crest factor for the custom multitone waveform. |
| | | Frequency | | Set the frequency value for the custom multitone waveform. |
| | | Amplitude | | Set the amplitude value for the custom multitone waveform. |
| | | Phase | | Set the phase value for the custom multitone waveform. |
| | | Add Above | | Add the tone above the selected tone for the custom multitone waveform. |
| | | Add Below | | Add the tone below the selected tone for the custom multitone waveform. |
| | | Remove | | Remove the selected tone for the custom multitone waveform. |
| | | Clear | | Clear all the tones in the custom multitone waveform list. |
| | | Link Config | Device Scan | Device Search |
| Max Scan | 1 to 16 | | | Set the maximum number of <i>Bluetooth</i> devices to be identified. |
| Filter Class | <ul style="list-style-type: none"> - All - Custom | | | Select the filter class type. |
| Custom | | | | Set the <i>Bluetooth</i> device class. |
| Refresh Device | | | | Refresh the friendly name of the selected <i>Bluetooth</i> device. |

Table A-6 Bluetooth generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-------------|---------------|-----------------------------------|--|---|
| Link Config | Device Action | Pair/Unpair Device | | Pair/Unpair with the selected <i>Bluetooth</i> device. |
| | | Unpair All Device | | Unpair all the paired <i>Bluetooth</i> devices. |
| | | Profile Connection | <ul style="list-style-type: none"> - Connect/Disconnect All - Connect/Disconnect A2DP - Connect/Disconnect HFP - Connect/Disconnect AVRCP | Connect or disconnect the <i>Bluetooth</i> profiles for the connection. |
| | | A2DP Operation | <ul style="list-style-type: none"> - Open Media Connection - Close Media Connection - Start Streaming - Pause Streaming | Select the advanced audio distribution profile operation settings. |
| | | HFP Operation (Handsfree/Headset) | <ul style="list-style-type: none"> - Dial - Answer Call - End Call - Reject Call - Toggle Audio - Button Press - Send AT Command | Select the HFP (Handsfree/Headset) profile operation settings. |
| | | HFP Operation (Audio Gateway) | <ul style="list-style-type: none"> - Connect - Disconnect - Call - Hang Up - Send AT Command | Select the HFP (Audio Gateway) profile operation settings. |
| | | AVRCP Operation | <ul style="list-style-type: none"> - Volume Up - Volume Down - Mute - Play - Stop - Pause - Rewind - Fast Forward - Forward - Backward | Select the audio/video remote control profile operation settings. |

Table A-6 Bluetooth generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | |
|-------------|-----------------|---------------|--|--|--|
| Link Config | Common Settings | Profile | <ul style="list-style-type: none"> - A2DP SRC, HFP AG, AVRCP TRGT - A2DP SNK, HFP HF, AVRCP CTRL | Select the U8903B's <i>Bluetooth</i> card profile. | |
| | | Friendly Name | | Set the friendly name of the U8903B's <i>Bluetooth</i> card. | |
| | | Device PIN | | Set the passkey of the U8903B's <i>Bluetooth</i> card. | |
| | | Device Class | <ul style="list-style-type: none"> - Auto - Custom | Select the device class based on the configured profile. | |
| | | Custom | | Set the device class. | |
| | | SSP Mode | <ul style="list-style-type: none"> - Just Works - Man-In-The-Middle | Select the U8903B's <i>Bluetooth</i> card simple secure pairing mode. | |
| | | Auto Pair | | Enable or disable the auto-pairing function. | |
| | | IO Capability | | Select the IO capability of the U8903B's <i>Bluetooth</i> card. | |
| | | Discoverable | | Enable or disable the discoverability function of the U8903B's <i>Bluetooth</i> card. | |
| | | Connectable | | Enable or disable the connectability function of the U8903B's <i>Bluetooth</i> card. | |
| | | Loopback | | Enable or disable the integrated interchip sound audio loopback function. | |
| | | Link Status | | Enable or disable the link status of the U8903B's <i>Bluetooth</i> card. | |
| | | RF Port | <ul style="list-style-type: none"> - RF1 - RF2 | Select the U8903B's <i>Bluetooth</i> card RF port connector. | |
| | | A2DP Settings | Codec | <ul style="list-style-type: none"> - SBC - apt-X | Select the codec for the A2DP profile. |
| | | | Sampling Rate | <ul style="list-style-type: none"> - 16 kHz - 32 kHz - 44.1 kHz - 48 kHz | Select the audio sampling rate for the A2DP profile. |

Table A-6 Bluetooth generator menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | |
|-------------|--------------|----------------|--|---|--|
| Link Config | HFP Settings | Wideband | | Enable or disable the wideband speech mode in the HFP profile connection. | |
| | | Latency | 4 to 65534 | Set the HFP's codec channel latency in milliseconds. | |
| | | Retransmit | <ul style="list-style-type: none"> - No Transmission - Power Saving - Link Quality - No Preference | Select the HFP's codec retransmission effort. | |
| | | Packet Types | <ul style="list-style-type: none"> - HV1 - HV2 - HV3 - EV3 - EV4 - EV5 - 2EV3 - 3EV3 - 2EV5 - 3EV5 | Select the packet type used in the HFP's codec. | |
| | | AVRCP Log View | Clear Log | | Clear the AVRCP operation log history. |
| | | | Refresh Log | | Refresh the AVRCP operation log history. |
| | | References | Ref Impedance | | Set the reference impedance for the unit conversion of dBm measurements. |

Appendix 7: Analog Analyzer Menu Tree

Table A-7 Analog analyzer menu tree description

| Level 1 | Level 2 | Level 3 | Description |
|-------------------------|-----------------|--|--|
| Functions | Multi-Chn | - Off | Select the multichannel mode. |
| | | - Phase | |
| | Function No. | - X-Talk | Select the active function number to configure the settings. |
| | | - 1 | |
| - 2 | | | |
| - 3 | | | |
| Meas. Func. | | - 4 | Select the measurement function. This setting is only available when the multichannel mode is set to Off. |
| | | - None | |
| | | - Frequency | |
| | | - AC Voltage | |
| | | - DC Voltage | |
| | | - THD+N Ratio | |
| | | - THD+N Level | |
| | | - SINAD | |
| | | - THD Ratio | |
| | | - THD Level | |
| | | - SMPTE IMD | |
| | | - DFD60268 2nd | |
| | | - DFD 60268 3rd | |
| | | - DFD 60118 2nd | |
| - DFD 60118 3rd | | | |
| - SNR | | | |
| - SNR (Fast) | | | |
| - J-Test | | | |
| Functions (Frequency) | Unit | - Hz | Select the unit type. |
| | | - ΔHz | |
| | Format | - Off | Select the reading format of the returned measurement reading. |
| | | - Delta | |
| Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference frequency. | |
| Ref. Freq | | Set the reference frequency value. | |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|---------------------------|-------------------------|---|---|
| Functions (AC Voltage) | Unit | - dBg - dBm - dBr - dBu - dBV - W - V - ΔV - dBSPL - x | Select the unit type. |
| | | Format | - Off - Logarithmic - Linear - Delta Select the reading format of the returned measurement reading. |
| Functions (AC Voltage) | Set to 0dB | | Store the measured level as the reference level, and set the measurement reading format to Logarithmic. |
| | Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference frequency. |
| | Ref. Level | | Set the reference level value. There is only one reference level for each channel. |
| | Ref. Imp | | Set the reference impedance value. This setting is only available when the unit is set to W. |
| | Cal SPL | | Set the calibration level value. This setting is only available when the unit is set to dBSPL. |
| | Detector | - RMS - Pk-Pk - QPK | Select the AC level detection type. |
| Functions (DC Voltage) | Unit | - V - ΔV - x | Select the unit type. |
| | | Format | - Off - Linear - Delta Select the reading format of the returned measurement reading. |
| Functions (DC Voltage) | Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference frequency. |
| | Ref. Level | | Set the reference level value. There is only one reference level for each channel. |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|----------------------------|-----------------|---|---|
| Functions (THD+N Ratio) | Unit | - dB | Select the unit type. |
| | | - ΔdB | |
| | | - % | |
| | | - x | |
| | Format | - Off | Select the reading format of the returned measurement reading. |
| | | - Linear | |
| | - Delta | | |
| | Set to 0dB | | Store the measured ratio as the reference ratio, and set the measurement reading format to Delta. |
| Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference ratio. | |
| Ref. Ratio | | Set the reference ratio value. There is only one reference ratio for each channel. | |
| Freq Lock | - Auto | Select the searching method for the fundamental frequency. | |
| | - Gen Lock | | |
| - Custom | | | |
| Fund Freq | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. | |
| Analog Notch | - Enable | Enable or disable the analog notch filter. This filter is used to emulate the analog notch filter used in the HP8903B. | |
| | - Disable | | |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|----------------------------|-------------------------|--|---|
| Functions (THD+N Level) | Unit | - dBg | Select the unit type. |
| | | - dBm | |
| | | - dBr | |
| | | - dBu | |
| | | - dBV | |
| | | - W | |
| | | - V | |
| | | - ΔV | |
| | | - dBSPL | |
| | | - x | |
| Functions (THD+N Level) | Format | - Off | Select the reading format of the returned measurement reading. |
| | | - Logarithmic | |
| | | - Linear | |
| | - Delta | | |
| | Set to 0dB | | Store the measured level as the reference level, and set the measurement reading format to Logarithmic. |
| | Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference frequency. |
| | Ref. Level | | Set the reference level value. There is only one reference level for each channel. |
| Ref. Imp | | Set the reference impedance value. This setting is only available when the unit is set to W. | |
| Cal SPL | | Set the calibration level value. This setting is only available when the unit is set to dBSPL. | |
| Functions (THD+N Level) | Freq Lock | - Auto | Select the searching method for the fundamental frequency. |
| | | - Gen Lock | |
| | | - Custom | |
| Fund Freq | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. | |
| Analog Notch | Analog Notch | - Enable | Enable or disable the analog notch filter. This filter is used to emulate the analog notch filter used in the HP8903B. |
| | | - Disable | |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|--------------------------|-----------------|--|--|
| Functions (SINAD) | Unit | - dB | Select the unit type. |
| | | - ΔdB | |
| | - % | | |
| | - x | | |
| | Format | - Off | Select the reading format of the returned measurement reading. |
| | | - Linear | |
| | - Delta | | |
| Set to 0dB | | Store the measured ratio as the reference ratio, and set the measurement reading format to Delta. | |
| Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference ratio. | |
| Ref. Ratio | | Set the reference ratio value. There is only one reference ratio for each channel. | |
| Freq Lock | - Auto | Select the searching method for the fundamental frequency. | |
| | - Gen Lock | | |
| - Custom | | | |
| Fund Freq | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. | |
| Functions (THD Ratio) | Unit | - dB | Select the unit type. |
| | | - ΔdB | |
| | - % | | |
| | - x | | |
| | Format | - Off | Select the reading format of the returned measurement reading. |
| | | - Linear | |
| | - Delta | | |
| Set to 0dB | | Store the measured ratio as the reference ratio, and set the measurement reading format to Delta. | |
| Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference ratio. | |
| Ref. Ratio | | Set the reference ratio value. There is only one reference ratio for each channel. | |
| Even Harmonic | - ALL | Display the even harmonics order selection. | |
| | - 2 | | |
| | - 4 | | |
| | - 6 | | |
| | - 8 | | |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|--------------------------|-------------------------|-----------------|--|
| Functions (THD Ratio) | Odd Harmonic | - ALL | Display the odd harmonics order selection. |
| | | - 3 | |
| | | - 5 | |
| Functions (THD Ratio) | Freq Lock | - 7 | Select the searching method for the fundamental frequency. |
| | | - 9 | |
| | | - Auto | |
| Functions (THD Ratio) | Fund Freq | - Gen Lock | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| | | - Custom | |
| | | | |
| Functions (THD Level) | Unit | - dBg | Select the unit type. |
| | | - dBm | |
| | | - dBr | |
| Functions (THD Level) | Format | - dBu | Select the reading format of the returned measurement reading. |
| | | - dBV | |
| | | - W | |
| Functions (THD Level) | Set to 0dB | - V | Store the measured level as the reference level, and set the measurement reading format to Logarithmic. |
| | | - ΔV | |
| | | - dB SPL | |
| Functions (THD Level) | Set result as ref. from | - x | Store the measurement result from the selected channel as the reference frequency. |
| | | Channels 1 to 8 | |
| | | | |
| Functions (THD Level) | Ref. Level | | Set the reference level value. There is only one reference level for each channel. |
| | | | |
| | | | |
| Functions (THD Level) | Ref. Imp | | Set the reference impedance value. This setting is only available when the unit is set to W. |
| | | | |
| | | | |
| Functions (THD Level) | Cal SPL | | Set the calibration level value. This setting is only available when the unit is set to dB SPL. |
| | | | |
| | | | |
| Functions (THD Level) | Even Harmonic | - ALL | Select the even harmonics values. |
| | | - 2 | |
| | | - 4 | |
| Functions (THD Level) | Even Harmonic | - 6 | Select the even harmonics values. |
| | | - 8 | |
| | | | |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description | |
|--------------------------|-------------------------|--|--|--|
| Functions (THD Level) | Odd Harmonic | - ALL | Select the odd harmonics values. | |
| | | - 3 | | |
| | | - 5 | | |
| | | - 7 | | |
| Functions (THD Level) | Fund Freq | - 9 | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. | |
| | | - Auto | | |
| | | - Gen Lock | | |
| | | - Custom | | |
| Functions (THD Level) | Unit | - dB | Select the unit type. | |
| | | - ΔdB | | |
| | | - % | | |
| | | - x | | |
| Functions (SMPTE IMD) | Format | - Off | Select the reading format of the returned measurement reading. | |
| | | - Linear | | |
| | | - Delta | | |
| | | Set to 0dB | | |
| Functions (SMPTE IMD) | Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference ratio. | |
| | | Ref. Ratio | Set the reference ratio value. There is only one reference ratio for each channel. | |
| | | Freq Lock | - Gen Lock | Select the searching method for the upper and lower frequencies. |
| | | | - Custom | |
| Functions (SMPTE IMD) | Upper Freq | Set the upper frequency value. This setting is only available when the frequency lock is set to Custom. | | |
| | Lower Freq | Set the lower frequency value. This setting is only available when the frequency lock is set to Custom. | | |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|---|-----------------|---|--|
| Functions (DFD60268 2nd/ DFD 60268 3rd/ DFD 60118 2nd/ DFD 60118 3rd) | Unit | - dB | Select the unit type. |
| | | - Δ dB | |
| | - % | | |
| | - x | | |
| | Format | - Off | Select the reading format of the returned measurement reading. |
| | | - Linear | |
| - Delta | | | |
| Set to 0dB | | Store the measured ratio as the reference ratio, and set the measurement reading format to Delta. | |
| Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference ratio. | |
| Ref. Ratio | | Set the reference ratio value. There is only one reference ratio for each channel. | |
| Functions (SNR) | Unit | - dB | Select the unit type. |
| | | - Δ dB | |
| | - % | | |
| | - x | | |
| | Format | - Off | Select the reading format of the returned measurement reading. |
| | | - Linear | |
| - Delta | | | |
| Set to 0dB | | Store the measured ratio as the reference ratio, and set the measurement reading format to Delta. | |
| Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference ratio. | |
| Ref. Ratio | | Set the reference ratio value. There is only one reference ratio for each channel. | |
| SNR Delay | | Set the SNR delay value. | |
| Functions (SNR (Fast)) | Unit | - dB | Select the unit type. |
| | | - Δ dB | |
| | - % | | |
| | - x | | |
| | Format | - Off | Select the reading format of the returned measurement reading. |
| | | - Linear | |
| - Delta | | | |
| Set to 0dB | | Store the measured ratio as the reference ratio, and set the measurement reading format to Delta. | |
| Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference frequency. | |
| Ref. Ratio | | Set the reference ratio value. There is only one reference ratio for each channel. | |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|---------------------------|-------------------------|---|--|
| Functions (SNR (Fast)) | Freq Lock | <ul style="list-style-type: none"> - Auto - Gen Lock - Custom | Select the searching method for the fundamental frequency. |
| | Fund Freq | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| | Harmonics | | Set the number of harmonics order to be removed. |
| Functions (Phase) | Ref. Channel | | Set the reference channel number. |
| | Freq Lock | <ul style="list-style-type: none"> - Auto - Gen Lock - Custom | Select the searching method for the fundamental frequency. |
| | Fund Freq | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| Functions (X-Talk) | Ref. Channel | | Set the driven channel. |
| | Unit | <ul style="list-style-type: none"> - dB - ΔdB - % - x | Select the unit type. |
| | Format | <ul style="list-style-type: none"> - Off - Linear - Delta | Select the reading format of the returned measurement reading. |
| | Set to 0dB | | Store the measured ratio as the reference ratio, and set the measurement reading format to Delta. |
| | Set result as ref. from | Channels 1 to 8 | Store the measurement result from the selected channel as the reference ratio. |
| Ref. Ratio | | Set the reference ratio value. There is only one reference ratio for each channel. | |
| Functions (X-Talk) | Freq Lock | <ul style="list-style-type: none"> - Auto - Gen Lock - Custom | Select the searching method for the fundamental frequency. |
| | Fund Freq | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|----------------|---------------|---|--------------------------------|
| Filters Config | Clear Filters | | Clear all the filter settings. |
| | LPF | - None | Select the low-pass filter. |
| | | - 2 kHz | |
| | | - 3 kHz | |
| | | - 5 kHz | |
| | | - 8 kHz | |
| | | - 10 kHz | |
| | | - 15 kHz | |
| | | - 20 kHz | |
| | | - 22 kHz | |
| HPF | - 30 kHz | Select the high-pass filter. | |
| | - 40 kHz | | |
| | - 50 kHz | | |
| | - 80 kHz | | |
| | - Custom | | |
| | - None | | |
| | - 15 Hz | | |
| | - 20 Hz | | |
| | - 22 Hz | | |
| Weighting | - 30 Hz | Select the weighting filter. | |
| | - 50 Hz | | |
| | - 70 Hz | | |
| | - 100 Hz | | |
| | - 200 Hz | | |
| | - 300 Hz | | |
| | - 400 Hz | | |
| | - Custom | | |
| | Deemphasis | | - None |
| - 50 μ s | | | |
| - 75 μ s | | | |
| - Custom | | | |
| Notch Filter | State | Enable or disable the notch filter. | |
| | | - Enable | |
| | | - Disable | |
| | Center Freq | Set the frequency of the component to be removed from the input signal. | |
| | Bandwidth | Set the bandwidth of the signal component to be removed. | |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description | |
|----------------|--------------------------|--|--|--|
| Meas Config | Sample Size | - 2048 | Select the sample size. | |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | | - 262144 | | |
| | Mov Average | 1 to 50 | Set the number of measurement readings to be used for the moving average calculation. | |
| | | Sync Average | 1 to 64 | Set the number of points for the synchronous averaging in the analyzer meter mode. |
| Src Channel | | Select the internal generator channel as the reference channel used in the following situations. For the result calculation in unit dBg. For the frequencies searching algorithm when the frequency lock is set to Gen Lock. | | |
| Trigger Source | - Free Run - External | Select the trigger source | | |
| Trigger Edge | - Rising - Falling | Select the trigger edge type. | | |
| Input Config | Connector | - UnBal - Bal - Loopback | Select the input connector type. | |
| | Impedance | - 100 k Ω (for UnBal) - 200 k Ω (for Bal) - 600 Ω - 300 Ω | Select the input impedance value. This setting is only available when the input connector is set to UnBal or Bal. | |
| | Auto Range | - On - Off | Enable or disable the auto range. | |
| | Range | | - 140 V | Select the input voltage range value. This setting is only available when the auto range is disabled. |
| | | | - 100 V | |
| - 32 V | | | | |
| - 10 V | | | | |
| - 3.2 V | | | | |
| | - 1 V | | | |
| | - 320 mV | | | |

Table A-7 Analog analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|--------------|--------------------------|--|--|
| Input Config | Bandwidth | - 90 kHz | Select the input bandwidth value. |
| | | - 1.5 MHz | This setting is only available with Option N3431A. Refer to “ U8903B Options ” on page 37 for more information. |
| | Coupling | - DC - AC | Select the input coupling type. |
| | Ext. Gain | | Set the input external gain value. |
| Wave File | Channel | - Left | Select the wave file channel type. |
| | | - Right | |
| | | - Stereo | |
| | Bits/Sample | - 8 - 16 - 24 | Select the wave file number of bits per sample. |
| Duration | 1 s to 600 s | Set the recording duration of the wave file. | |
| Record | | Start recording and save the measurement into a wave file. | |
| Statistics | Show Stats | - On | Enable or disable the statistics calculation. |
| | | - Off | |
| | No. of Reading | 2 to 20 | Set the number of readings used for the statistics calculation. |
| | Stat 1 Stat2 Stat3 | - Min | Select the statistics calculation type. |
| | | - Max | |
| - Average | | | |
| - Std Dev | | | |
| | | - Δ MinMax | |
| | Clear | | Reset the statistics results of the current analog analyzer. |

Appendix 8: Digital Analyzer Menu Tree

Table A-8 Digital analyzer menu tree description

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-----------------------|-------------------------|-----------------|---------|--|
| Meas Mode | - Standard | | | Select the analysis mode. |
| | - Process Delay | | | |
| | - BERT | | | |
| Unit | - Hex | | | This is only available when the analysis mode is BERT. |
| | - Dec | | | Select the unit for the BERT analysis mode. |
| | Multi-Chn | - Off | | Select the multichannel mode. |
| | | - Phase | | |
| | | - X-Talk | | |
| | Function No. | - 1 | | Select the active function number to configure the settings. |
| | | - 2 | | |
| | | - 3 | | |
| | | - 4 | | |
| Functions | Meas Func | - None | | Select the measurement function. This setting is only available when the multichannel mode is set to Off. |
| | | - Frequency | | |
| | | - AC Voltage | | |
| | | - DC Voltage | | |
| | | - THD+N Ratio | | |
| | | - THD+N Level | | |
| | | - SINAD | | |
| | | - THD Ratio | | |
| | | - THD Level | | |
| | | - SMPTE IMD | | |
| | | - DFD60268 2nd | | |
| | | - DFD 60268 3rd | | |
| | | - DFD 60118 2nd | | |
| | | - DFD 60118 3rd | | |
| - Positive Peak | | | | |
| - Negative Peak | | | | |
| | Unit | - Hz | | Select the unit type. |
| | | - ΔHz | | |
| Functions (Frequency) | Format | - Off | | Select the reading format of the returned measurement reading. |
| | | - Delta | | |
| | Set result as ref. from | Channels 1 to 8 | | Store the measurement result from the selected channel as the reference frequency. |
| | Ref. Freq | | | Set the reference frequency value. |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | | | |
|---------------------------|-----------------|-------------------------|---|--|----------|--|--|
| Functions (AC Voltage) | Unit | - FFS | | Select the unit type. | | | |
| | | - dBFS | | | | | |
| | | - %FS | | | | | |
| | | - V | | | | | |
| | | - dB | | | | | |
| | | - dBV | | | | | |
| | | - dBr | | | | | |
| Format | Format | - x | | Select the reading format of the returned measurement reading. | | | |
| | | - LSB | | | | | |
| | | - Hex | | | | | |
| | | - Dec | | | | | |
| | | - dB SPL | | | | | |
| | | - Off | | | | | |
| | | - Logarithmic | | | | | |
| - Linear | | | | | | | |
| Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference frequency. | | | | |
| Ref. Level | | | Set the reference level value. There is only one reference level for each channel. | | | | |
| Volt/FS | | | Set the volts/FS reference value. | | | | |
| Detector | Detector | - RMS | | Select the AC level detection type. | | | |
| | | - Pk-Pk | | | | | |
| Functions (DC Voltage) | Unit | - FFS | | Select the unit type. | | | |
| | | - V | | | | | |
| | | - Hex | | | | | |
| | | - x | | | | | |
| | | Format | Format | | - Off | | Select the reading format of the returned measurement reading. |
| | | | | | - Linear | | |
| | | Set result as ref. from | Channels 1 to 2 | | | Store the measurement result from the selected channel as the reference frequency. | |
| Ref. Voltage | | | Set the reference voltage value. There is only one reference level for each channel. | | | | |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------------------|-----------------|----------|--|--|
| Functions (THD+N Ratio) | Unit | - dB | | Select the unit type. |
| | | - ΔdB | | |
| | | - % | | |
| | | - x | | |
| | Format | - Off | | Select the reading format of the returned measurement reading. |
| | | - Linear | | |
| | | - Delta | | |
| Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. | |
| Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. | |
| Precision | - On | | Enable or disable the precision mode. | |
| | - Off | | | |
| Freq Lock | - Auto | | Select the searching method for the fundamental frequency. | |
| | - Gen Lock | | | |
| | - Custom | | | |
| Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. | |
| Functions (THD+N Level) | Unit | - FFS | | Select the unit type. |
| | | - dBFS | | |
| | | - %FS | | |
| | | - V | | |
| | | - dB | | |
| | | - dBV | | |
| | | - dBr | | |
| | | - x | | |
| | | - LSB | | |
| | | - Hex | | |
| | - Dec | | | |
| | - dB SPL | | | |
| Format | - Off | | Select the reading format of the returned measurement reading. | |
| | - Logarithmic | | | |
| | - Linear | | | |
| Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference frequency. | |
| Ref. Level | | | Set the reference level value. There is only one reference level for each channel. | |
| Volt/FS | | | Set the volts/FS reference value. | |
| Precision | - On | | Enable or disable the precision mode. | |
| | - Off | | | |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------------------|-------------------------|-------------------------------------|---------|--|
| Functions (THD+N Level) | Freq Lock | - Auto - Gen Lock - Custom | | Select the searching method for the fundamental frequency. |
| | Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| Functions (SINAD) | Unit | - dB - Δ dB - % - x | | Select the unit type. |
| | Format | - Off - Linear - Delta | | Select the reading format of the returned measurement reading. |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. |
| | Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. |
| | Precision | - On - Off | | Enable or disable the precision mode. |
| | Freq Lock | - Auto - Gen Lock - Custom | | Select the searching method for the fundamental frequency. |
| Functions (THD Ratio) | Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| | Unit | - dB - Δ dB - % - x | | Select the unit type. |
| | Format | - Off - Linear - Delta | | Select the reading format of the returned measurement reading. |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. |
| | Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. |
| | Even Harmonic | - ALL - 2 - 4 - 6 - 8 | | Display the even harmonics order selection. |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | |
|--------------------------|-------------------------|-----------------|---------|---|-----------------------------------|
| Functions (THD Ratio) | Odd Harmonic | - ALL | | Display the odd harmonics order selection. | |
| | | - 3 | | | |
| | | - 5 | | | |
| | | - 7 | | | |
| | | - 9 | | | |
| | | - FFS | | | |
| | | - dBFS | | | |
| | | - %FS | | | |
| | | - V | | | |
| | | - dB | | | |
| | Unit | - dBV | | Select the unit type. | |
| | | - dBr | | | |
| | | - x | | | |
| | | - LSB | | | |
| | | - Hex | | | |
| | | - Dec | | | |
| | | - dB SPL | | | |
| | Format | - Off | | Select the reading format of the returned measurement reading. | |
| | | - Logarithmic | | | |
| | | - Linear | | | |
| Functions (THD Level) | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference frequency. | |
| | Ref. Level | | | Set the reference level value. There is only one reference level for each channel. | |
| | Volt/FS | | | Set the volts/FS reference value. | |
| | | | - ALL | | Select the even harmonics values. |
| | | | - 2 | | |
| Even Harmonic | | - 4 | | | |
| | | - 6 | | | |
| | | - 8 | | | |
| | | - ALL | | Select the odd harmonics values. | |
| | | - 3 | | | |
| Odd Harmonic | | - 5 | | | |
| | | - 7 | | | |
| | | - 9 | | | |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|---|-------------------------|-----------------|---------|---|
| Functions (SMPTE IMD) | Unit | - dB | | Select the unit type. |
| | | - Δ dB | | |
| | | - % | | |
| | | - x | | |
| Functions (SMPTE IMD) | Format | - Off | | Select the reading format of the returned measurement reading. |
| | | - Linear | | |
| | | - Delta | | |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. |
| | Ref. Ratio | | | Set the reference ratio value. |
| Functions (DFD60268 2nd/ DFD 60268 3rd/ DFD 60118 2nd/ DFD 60118 3rd) | Unit | - dB | | Select the unit type. |
| | | - Δ dB | | |
| | | - % | | |
| | | - x | | |
| Functions (DFD60268 2nd/ DFD 60268 3rd/ DFD 60118 2nd/ DFD 60118 3rd) | Format | - Off | | Select the reading format of the returned measurement reading. |
| | | - Linear | | |
| | | - Delta | | |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. |
| | Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. |
| Functions (Positive peak) | Unit | - FFS | | Select the measurement unit type. |
| | | - dBFS | | |
| | | - %FS | | |
| | | - V | | |
| | | - dB | | |
| | | - dBV | | |
| | | - dBr | | |
| | | - x | | |
| | | - LSB | | |
| | | - Hex | | |
| | | - Dec | | |
| | | - dBSPL | | |
| Functions (Positive peak) | Format | - Off | | Select the reading format of the returned measurement reading. |
| | | - Logarithmic | | |
| | | - Linear | | |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference frequency. |
| Functions (Positive peak) | Ref. Level | | | Set the reference level value. There is only one reference level for each channel. |
| | | Volt/FS | | Set the volts/FS reference value. |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|------------------------------|-------------------------|-----------------|-----------------|--|
| Functions (Negative peak) | Unit | - FFS | | Select the measurement unit type. |
| | | - dBFS | | |
| | | - %FS | | |
| | | - V | | |
| | | - dB | | |
| | | - dBV | | |
| Functions (Phase) | Format | - dB | | Select the reading format of the returned measurement reading. |
| | | - dBV | | |
| | | - dBr | | |
| | | - x | | |
| | | - LSB | | |
| Functions (Phase) | Set result as ref. from | - Hex | | Store the measurement result from the selected channel as the reference frequency. |
| | | - Dec | | |
| | | - dB SPL | | |
| | | - Off | Channels 1 to 2 | |
| | | - Logarithmic | | |
| Functions (X-Talk) | Ref. Level | - Linear | | Set the reference level value. There is only one reference level for each channel. |
| | | - Off | | |
| | | - Logarithmic | | |
| | | - Linear | | |
| | | - Linear | | |
| Functions (X-Talk) | Volt/FS | | | Set the volts/FS reference value. |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| Functions (X-Talk) | Ref. Channel | | | Set the reference channel number. |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| Functions (X-Talk) | Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| Functions (X-Talk) | Ref. Channel | | | Set the driven channel. |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| Functions (X-Talk) | Unit | - dB | | Select the unit type. |
| | | - ΔdB | | |
| | | - % | | |
| | | - x | | |
| | | - x | | |
| Functions (X-Talk) | Format | - Off | | Select the reading format of the returned measurement reading. |
| | | - Linear | | |
| | | - Delta | | |
| | | - Off | | |
| | | - Linear | | |
| Functions (X-Talk) | Set result as ref. from | | | Store the measurement result from the selected channel as the reference ratio. |
| | | Channels 1 to 2 | | |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | |
|-----------------------|---------------|--|---------|--|--|
| | Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. | |
| Functions (X-Talk) | Freq Lock | <ul style="list-style-type: none"> - Auto - Gen Lock - Custom | | Select the searching method for the fundamental frequency. | |
| | Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. | |
| | Clear Filters | | | Clear all the filter settings. | |
| Filters Config | LPF | <ul style="list-style-type: none"> - None - 15 kHz - 20 kHz - 22 kHz - 30 kHz - Custom | | Select the low-pass filter. | |
| | HPF | <ul style="list-style-type: none"> - None - 20 Hz - 100 Hz - 400 Hz - Custom | | Select the high-pass filter. | |
| | Weighting | <ul style="list-style-type: none"> - None - A - CCIR 1k - CCIR 2k - C-Message - CCITT - Custom | | Select the weighting filter. | |
| | Deemphasis | <ul style="list-style-type: none"> - None - 50 μs - 75 μs - Custom | | Select the filter de-emphasis value. | |
| | Sample Rate | <ul style="list-style-type: none"> - 32 kHz - 44.1 kHz - 48 kHz - 88.2 kHz - 96 kHz - 176.4 kHz - 192 kHz | | Select the sample rate. | |
| | | | | | |
| | | | | | |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|---------------|----------------|---|--|---|
| Meas Config | Coupling | - DC | | Select the coupling type. |
| | | - AC | | |
| | Sample Size | - 2048 | | Select the sample size. |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | Mov Average | - 262144 | | Set the number of measurement readings to be used for the moving average calculation. |
| - 524288 | | | | |
| Trigger | Trigger Source | - 1M | - Free Run | Select the trigger source. |
| | | - 2M | - External | |
| | | | - Channel | |
| | Trigger Edge | - Rising | This is only available when the trigger source is External or Channel. | |
| | | - Falling | Select the trigger edge type. | |
| | Interface | - Analog | This is only available when the trigger source is Channel. | |
| - Digital | | Select the trigger interface. | | |
| Channel | | This is only available when the trigger source is Channel. Set the channel number. | | |
| Trigger Level | | This is only available when the trigger source is Channel. Set the trigger level. | | |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|--------------|--------------|---------------------------|---------|--|
| Input Config | Connector | - UnBal | | Select the input connector type. |
| | | - Bal | | |
| | Impedance | - Optical | | Select the input impedance value. |
| | | - DSI | | |
| Freq Scaling | Impedance | Unbalanced connector type | | Select the input impedance value. |
| | | - 75 Ω | | |
| Ref SR | Freq Scaling | Balanced connector type | | Select the frequency scaling type. |
| | | - 110 Ω | | |
| | | - HiZ | | |
| | | - MISR | | This is only available when frequency scaling is Custom. |
| | | - Custom | | |
| | | | | Set the reference sample rate value. |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------|----------------|------------------|---|---|
| DSI Config | Format | - Left | | Select the data format |
| | | - Right | | |
| | | - I2S | | |
| | | - DSP | | |
| | Fsync Polarity | - Rising | | This is only available when the format is Left or Right. Select the frame clock edge synchronization. |
| | | - Falling | | |
| | Fsync Width | - One Bit Clock | | This is only available when the format is Left or Right. Select the frame clock synchronization width. |
| | | - One Subframe | | |
| | | - 50% Duty Cycle | | |
| | Data Shift Cnt | | | This is only available when the format is Left or Right. Set the data shift count value. |
| Data Shift Dir | - Left | | This is only available when the format is Left or Right. Select the data shift direction. | |
| | - Right | | | |
| Word Length | 8 to 32 | | Set the word length value. The word length value must be greater than or equal to the audio resolution. | |
| Resolution | 8 to 24 | | Set the audio resolution value. | |
| Decoding | - Linear PCM | | Select the decoding format. | |
| | - A-Law | | | |
| | - μ -Law | | | |
| W/Bclk Dir | - In | | Select the word/bit clock direction. | |
| | - Out | | | |
| Bit Clk Edge | - Rising | | Select the bit clock edge. | |
| | - Falling | | | |
| Voltage | - 1.2 Vpp | | Select the input voltage value. | |
| | - 1.5 Vpp | | | |
| | - 1.8 Vpp | | | |
| | - 2.5 Vpp | | | |
| | - 3 Vpp | | | |
| | - 3.3 Vpp | | | |
| | - Custom | | | |

Table A-8 Digital analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|---------------|--------------------------|---|---------|---|
| AES Config | Decoding | - Linear PCM | | Select the decoding format. |
| | | - A- Law | | |
| | | - μ - Law | | |
| | Resolution | 8 to 24 | | Set the audio resolution value. |
| | Status Bits | - Channel - User | | Select the status bits type. |
| AES Config | Save in Hex | | | Save the status bits to a HEX file. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. |
| | Save in Xml | | | Save the status bits to an XML file. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. |
| Bits Analysis | Refresh Rate | | | Set the refresh rate. |
| | Bit Types | - Data - Active | | Select the bit type. |
| Statistics | Show Stats | - On - Off | | Enable or disable the statistics calculation. |
| | No. of Reading | 2 to 20 | | Set the number of readings used for the statistics calculation. |
| | Stat 1 Stat2 Stat3 | - Min - Max - Average - Std Dev - Δ MinMax | | Select the statistics calculation type. |
| | Clear | | | Reset the statistics results of the current analog analyzer. |

Appendix 9: Bluetooth Analyzer Menu Tree

Table A-9 Bluetooth analyzer menu tree description

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-----------------------|-------------------------|--|---------|--|
| Functions | Multi-Chn | - Off - Phase - X-Talk | | Select the multichannel mode. |
| | Function No. | - 1 - 2 - 3 - 4 | | Select the active function number to configure the settings. |
| | Meas. Func. | - None - Frequency - AC Voltage - DC Voltage - THD+N Ratio - THD+N Level - SINAD - THD Ratio - THD Level - SMPTE IMD - DFD60268 2nd - DFD 60268 3rd - DFD 60118 2nd - DFD 60118 3rd - SNR (Fast) | | Select the measurement function. This setting is only available when the multichannel mode is set to Off. |
| Functions (Frequency) | Unit | - Hz - ΔHz | | Select the unit type. |
| | Format | - Off - Delta | | Select the reading format of the returned measurement reading. |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference frequency. |
| | Ref. Freq | | | Set the reference frequency value. |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | | | |
|---------------------------|-------------------------|---------------------------|-----------------|--|---|--|---|
| Functions (AC Voltage) | Unit | - FFS | | Select the unit type. | | | |
| | | - dBFS | | | | | |
| | | - %FS | | | | | |
| | | - V | | | | | |
| | | - dB | | | | | |
| | | - dBV | | | | | |
| Functions (AC Voltage) | Format | - dBr | | Select the reading format of the returned measurement reading. | | | |
| | | - x | | | | | |
| | | - LSB | | | | | |
| | | - Hex | | | | | |
| | | - Dec | | | | | |
| | | - dB SPL | | | | | |
| Functions (AC Voltage) | Set result as ref. from | - Off | Channels 1 to 2 | Store the measurement result from the selected channel as the reference frequency. | | | |
| | | - Logarithmic | | | | | |
| | | - Linear | | | | | |
| | | Ref. Level | | | Set the reference level value. There is only one reference level for each channel. | | |
| | | | | | | | |
| | | | | | | | |
| Functions (AC Voltage) | Cal SPL | | | Set the calibration level value. This setting is only available when the unit is set to dB SPL. | | | |
| | | | | | | | |
| | | | | | | | |
| Functions (DC Voltage) | Detector | - RMS | | Select the AC level detection type. | | | |
| | | - Pk-Pk | | | | | |
| | | Functions (DC Voltage) | Unit | | - FFS | | Select the unit type. |
| | | | | | - V | | |
| | | | | | - LSB | | |
| | | | | | - Hex | | |
| - Dec | | | | | | | |
| Functions (DC Voltage) | Format | | | - Off | | Select the reading format of the returned measurement reading. | |
| | | - Linear | | | | | |
| | | Set result as ref. from | Channels 1 to 2 | Store the measurement result from the selected channel as the reference frequency. | | | |
| | | | | | | | |
| | | | | | | | |
| | | Functions (DC Voltage) | Ref. Level | | | | Set the reference level value. There is only one reference level for each channel. |
| | | | | | | | |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------------------|-----------------|------------|--|--|
| Functions (THD+N Ratio) | Unit | - dB | | Select the unit type. |
| | | - ΔdB | | |
| | Format | - % | | Select the reading format of the returned measurement reading. |
| | | - x | | |
| | | - Off | | |
| | | - Linear | | |
| Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. | |
| Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. | |
| Freq Lock | | - Auto | | Select the searching method for the fundamental frequency. |
| | | - Gen Lock | | |
| Fund Freq | | - Custom | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| | | | | |
| Functions (THD+N Level) | Unit | - FFS | | Select the unit type. |
| | | - dBFS | | |
| | | - %FS | | |
| | | - V | | |
| | | - dBu | | |
| | | - dBV | | |
| | | - dBr | | |
| | | - x | | |
| | | - LSB | | |
| | | - Hex | | |
| Format | | - Dec | | Select the reading format of the returned measurement reading. |
| | | - dBSP | | |
| Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference frequency. | |
| Ref. Level | | | Set the reference level value. There is only one reference level for each channel. | |
| Cal SPL | | | Set the calibration level value. This setting is only available when the unit is set to dBSP. | |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------------------|-------------------------|---|---------|--|
| Functions (THD+N Level) | Freq Lock | <ul style="list-style-type: none"> - Auto - Gen Lock - Custom | | Select the searching method for the fundamental frequency. |
| | Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| Functions (SINAD) | Unit | <ul style="list-style-type: none"> - dB - ΔdB - % - x | | Select the unit type. |
| | Format | <ul style="list-style-type: none"> - Off - Linear - Delta | | Select the reading format of the returned measurement reading. |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. |
| | Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. |
| | Freq Lock | <ul style="list-style-type: none"> - Auto - Gen Lock - Custom | | Select the searching method for the fundamental frequency. |
| | Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| Functions (THD Ratio) | Unit | <ul style="list-style-type: none"> - dB - ΔdB - % - x | | Select the unit type. |
| | Format | <ul style="list-style-type: none"> - Off - Linear - Delta | | Select the reading format of the returned measurement reading. |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. |
| | Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. |
| | Even Harmonic | <ul style="list-style-type: none"> - ALL - 2 - 4 - 6 - 8 | | Display the even harmonics order selection. |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|--------------------------|-------------------------|-----------------|---------|--|
| Functions (THD Ratio) | Odd Harmonic | - ALL | | Display the odd harmonics order selection. |
| | | - 3 | | |
| | | - 5 | | |
| Functions (THD Ratio) | Freq Lock | - 7 | | Select the searching method for the fundamental frequency. |
| | | - 9 | | |
| | | - Auto | | |
| Functions (THD Ratio) | Fund Freq | - Gen Lock | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| | | - Custom | | |
| | | | | |
| Functions (THD Level) | Unit | - FFS | | Select the unit type. |
| | | - dBFS | | |
| | | - %FS | | |
| | | - V | | |
| | | - dBu | | |
| | | - dBV | | |
| | | - dBr | | |
| | | - x | | |
| | | - LSB | | |
| | | - Hex | | |
| Functions (THD Level) | Format | - Dec | | Select the reading format of the returned measurement reading. |
| | | - dB SPL | | |
| | | - Off | | |
| Functions (THD Level) | Set result as ref. from | - Logarithmic | | Store the measurement result from the selected channel as the reference frequency. |
| | | - Linear | | |
| | | Channels 1 to 2 | | |
| Functions (THD Level) | Ref. Level | | | Set the reference level value. There is only one reference level for each channel. |
| | | | | |
| | | | | |
| Functions (THD Level) | Cal SPL | | | Set the calibration level value. This setting is only available when the unit is set to dB SPL. |
| | | | | |
| | | | | |
| Functions (THD Level) | Even Harmonic | - ALL | | Select the even harmonics values. |
| | | - 2 | | |
| | | - 4 | | |
| | | - 6 | | |
| | | - 8 | | |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|---|-------------------------|-----------------|--|--|
| Functions (THD Level) | Odd Harmonic | - ALL | | Select the odd harmonics values. |
| | | - 3 | | |
| | | - 5 | | |
| | | - 7 | | |
| Functions (THD Level) | Freq Lock | - Auto | | Select the searching method for the fundamental frequency. |
| | | - Gen Lock | | |
| | | - Custom | | |
| | Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. |
| Functions (SMPTE IMD) | Unit | - dB | | Select the unit type. |
| | | - ΔdB | | |
| | | - % | | |
| | | - x | | |
| | Format | - Off | | Select the reading format of the returned measurement reading. |
| | | - Linear | | |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. |
| | Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. |
| Functions (SMPTE IMD) | Freq Lock | - Gen Lock | | Select the searching method for the upper and lower frequencies. |
| | | - Custom | | |
| | Upper Freq | | Set the upper frequency value. This setting is only available when the frequency lock is set to Custom. | |
| | Lower Freq | | Set the lower frequency value. This setting is only available when the frequency lock is set to Custom. | |
| Functions (DFD60268 2nd/ DFD 60268 3rd/ DFD 60118 2nd/ DFD 60118 3rd) | Unit | - dB | | Select the unit type. |
| | | - ΔdB | | |
| | | - % | | |
| | | - x | | |
| | Format | - Off | | Select the reading format of the returned measurement reading. |
| - Linear | | | | |
| | Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. |
| | Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | |
|---------------------------|-----------------|------------|--|--|------------|
| Functions (SNR (Fast)) | Unit | - dB | | Select the unit type. | |
| | | - ΔdB | | | |
| | | | - % | | |
| | | | - x | | |
| | Format | | - Off | Select the reading format of the returned measurement reading. | |
| | | | - Linear | | |
| | | | - Delta | | |
| Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference frequency. | | |
| Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. | | |
| Freq Lock | | - Auto | Select the searching method for the fundamental frequency. | | |
| | | - Gen Lock | | | |
| | | - Custom | | | |
| Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. | | |
| Harmonics | | | Set the number of harmonics order to be removed. | | |
| Functions (Phase) | Ref. Channel | | Set the reference channel number. | | |
| | Freq Lock | | - Auto | Select the searching method for the fundamental frequency. | |
| | | | | | - Gen Lock |
| | | | | | - Custom |
| Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. | | |
| Functions (X-Talk) | Ref. Channel | | Set the driven channel. | | |
| | Unit | | - dB | Select the unit type. | |
| | | | | | - ΔdB |
| | | | | | - % |
| | | | | | - x |
| | Format | | - Off | Select the reading format of the returned measurement reading. | |
| | | | - Linear | | |
| | | - Delta | | | |
| Set result as ref. from | Channels 1 to 2 | | Store the measurement result from the selected channel as the reference ratio. | | |
| Ref. Ratio | | | Set the reference ratio value. There is only one reference ratio for each channel. | | |
| Fund Freq | | | Set the fundamental frequency value. This setting is only available when the frequency lock is set to Custom. | | |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|----------------|---------------|--------------|---------|---|
| | Clear Filters | | | Clear all the filter settings. |
| Filters Config | LPF | - None | - | Select the low-pass filter. |
| | | - 15 kHz | | |
| | - 20 kHz | | | |
| | | - Custom | | |
| | HPF | - None | - | Select the high-pass filter. |
| | | - 22 Hz | | |
| | | - 100 Hz | | |
| | | - 400 Hz | | |
| | | - Custom | | |
| | Weighting | - None | - | Select the weighting filter. |
| | | - A | | |
| | | - CCIR 1k | | |
| | | - CCIR 2k | | |
| | | - C-Message | | |
| | | - Custom | | |
| | Deemphasis | - None | - | Select the filter de-emphasis value. |
| | | - 50 μ s | | |
| | | - 75 μ s | | |
| | | - Custom | | |
| Filters Config | Notch Filter | State | | Enable or disable the notch filter. - Enable - Disable |
| | | Center Freq | | Set the frequency of the component to be removed from the input signal. |
| | | Bandwidth | | Set the bandwidth of the signal component to be removed. |

Table A-9 *Bluetooth* analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-------------|----------------|---------------------------------------|--|--|
| Meas Config | Coupling | - DC | | Select the coupling type. |
| | | - AC | | |
| | Sample Size | - 2048 | | Select the sample size. |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| Mov Average | 1 to 20 | | Set the number of measurement readings to be used for the moving average calculation. | |
| | Sync Average | 1 to 64 | Set the number of points for the synchronous averaging in the analyzer meter mode. | |
| | Src Channel | | Select the internal generator channel as the reference channel used in the following situations. For the result calculation in unit dBg. For the frequencies searching algorithm when the frequency lock is set to Gen Lock. | |
| Trigger | Trigger Source | - Free Run - External - Channel | Select the trigger source | |
| Link Config | Device Scan | Device Search | | Search for the discoverable <i>Bluetooth</i> devices within range. |
| | | Max Scan | 1 to 16 | Set the maximum number of <i>Bluetooth</i> devices to be identified. |
| | | Filter Class | - All - Custom | Select the filter class type. |
| | | Custom | | Set the <i>Bluetooth</i> device class. |
| | | Refresh Device | | Refresh the friendly name of the selected <i>Bluetooth</i> device. |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-------------|---------------|-----------------------------------|--|---|
| Link Config | Device Action | Pair/Unpair Device | | Pair/Unpair with the selected <i>Bluetooth</i> device. |
| | | Unpair All Device | | Unpair all the paired <i>Bluetooth</i> devices. |
| | | Profile Connection | <ul style="list-style-type: none"> - Connect/Disconnect All - Connect/Disconnect A2DP - Connect/Disconnect HFP - Connect/Disconnect AVRCP | Connect or disconnect the <i>Bluetooth</i> profiles for the connection. |
| | | A2DP Operation | <ul style="list-style-type: none"> - Open Media Connection - Close Media Connection - Start Streaming - Pause Streaming | Select the advanced audio distribution profile operation settings. |
| | | HFP Operation (Handsfree/Headset) | <ul style="list-style-type: none"> - Dial - Answer Call - End Call - Reject Call - Toggle Audio - Button Press - Send AT Command | Select the HFP (Handsfree/Headset) profile operation settings. |
| | | HFP Operation (Audio Gateway) | <ul style="list-style-type: none"> - Connect - Disconnect - Call - Hang Up - Send AT Command | Select the HFP (Audio Gateway) profile operation settings. |
| | | AVRCP Operation | <ul style="list-style-type: none"> - Volume Up - Volume Down - Mute - Play - Stop - Pause - Rewind - Fast Forward - Forward - Backward | Select the audio/video remote control profile operation settings. |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | |
|-------------|-----------------|---------------|--|--|--|
| Link Config | Common Settings | Profile | <ul style="list-style-type: none"> - A2DP SRC, HFP AG, AVRCP TRGT - A2DP SNK, HFP HF, AVRCP CTRL | Select the U8903B's <i>Bluetooth</i> card profile. | |
| | | Friendly Name | | Set the friendly name of the U8903B's <i>Bluetooth</i> card. | |
| | | Device PIN | | Set the passkey of the U8903B's <i>Bluetooth</i> card. | |
| | | Device Class | <ul style="list-style-type: none"> - Auto - Custom | Select the device class based on the configured profile. | |
| | | Custom | | Set the device class. | |
| | | SSP Mode | <ul style="list-style-type: none"> - Just Works - Man-In-The-Middle | Select the U8903B's <i>Bluetooth</i> card simple secure pairing mode. | |
| | | Auto Pair | | Enable or disable the auto-pairing function. | |
| | | IO Capability | | Select the IO capability of the U8903B's <i>Bluetooth</i> card. | |
| | | Discoverable | | Enable or disable the discoverability function of the U8903B's <i>Bluetooth</i> card. | |
| | | Connectable | | Enable or disable the connectability function of the U8903B's <i>Bluetooth</i> card. | |
| | | Loopback | | Enable or disable the integrated interchip sound audio loopback function. | |
| | | Link Status | | Enable or disable the link status of the U8903B's <i>Bluetooth</i> card. | |
| | | RF Port | <ul style="list-style-type: none"> - RF1 - RF2 | Select the U8903B's <i>Bluetooth</i> card RF port connector. | |
| | | A2DP Settings | Codec | <ul style="list-style-type: none"> - SBC - apt-X | Select the codec for the A2DP profile. |
| | | | Sampling Rate | <ul style="list-style-type: none"> - 16 kHz - 32 kHz - 44.1 kHz - 48 kHz | Select the audio sampling rate for the A2DP profile. |

Table A-9 Bluetooth analyzer menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description | | |
|-------------|--------------------------|---|--|---|--|--|
| Link Config | HFP Settings | Wideband | | Enable or disable the wideband speech mode in the HFP profile connection. | | |
| | | Latency | 4 to 65534 | Set the HFP's codec channel latency in milliseconds. | | |
| | | Retransmit | <ul style="list-style-type: none"> - No Transmission - Power Saving - Link Quality - No Preference | Select the HFP's codec retransmission effort. | | |
| | | Packet Types | <ul style="list-style-type: none"> - HV1 - HV2 - HV3 - EV3 - EV4 - EV5 - 2EV3 - 3EV3 - 2EV5 - 3EV5 | Select the packet type used in the HFP's codec. | | |
| | | AVRCP Log View | Clear Log | | Clear the AVRCP operation log history. | |
| | | | Refresh Log | | Refresh the AVRCP operation log history. | |
| | | Wave File | Channel | <ul style="list-style-type: none"> - Left - Right - Stereo | - | Select the wave file channel type. |
| | | | Bits/Sample | <ul style="list-style-type: none"> - 8 - 16 | - | Select the wave file number of bits per sample. |
| | | | Duration | 1 s to 600 s | | Set the recording duration of the wave file. |
| | | | Record | | | Start recording and save the measurement into a wave file. |
| Statistics | Show Stats | <ul style="list-style-type: none"> - On - Off | - | Enable or disable the statistics calculation. | | |
| | No. of Reading | 2 to 20 | | Set the number of readings used for the statistics calculation. | | |
| | Stat 1 Stat2 Stat3 | <ul style="list-style-type: none"> - Min - Max - Average - Std Dev - ΔMinMax | - | Select the statistics calculation type. | | |
| | Clear | | | Reset the statistics results of the current analog analyzer. | | |

Appendix 10: Graph Analysis Menu Tree

Table A-10 Graph analysis menu tree description

| Level 1 | Level 2 | Level 3 | Description |
|----------------|---|---|---|
| Analysis Mode | <ul style="list-style-type: none"> - Frequency - Phase - Time - PSD | | Select the graph analysis mode to be plotted on the current graph panel. This setting is not available when the graph analysis display option is Harmonics. |
| | | Active | AA1 to AA8 |
| Harm Settings | Odd | <ul style="list-style-type: none"> - ALL - 3 - 5 - 7 - 9 | Select the odd harmonics values. This setting is only available when the graph analysis display option is Harmonics. |
| | | <ul style="list-style-type: none"> - ALL - 2 - 4 - 6 - 8 | Select the even harmonics values. This setting is only available when the graph analysis display option is Harmonics. |
| | Display | <ul style="list-style-type: none"> - Harmonics - THD | Select the harmonics display option. This setting is only available when the graph analysis display option is Harmonics. |
| | THD Unit | <ul style="list-style-type: none"> - dB - % | Select the unit for THD measurements. This setting is only available when the graph analysis display option is Harmonics. |
| Graph Settings | Active Channel | AA1 to AA8 | Select the available active channel. AA2: Analog Analyzer channel 2 |
| | Sample Size | <ul style="list-style-type: none"> - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M | Select the graph sample size value. |

Table A-10 Graph analysis menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description | |
|------------------|--------------|-------------------------------|--|--|
| Graph Settings | Window | - Rectangular | Select the window function to be applied to the data before the FFT process. | |
| | | - Hanning | | |
| | | - Blackman | | |
| - Rife-Vincent | | | | |
| - Rife-Vincent 3 | | | | |
| - Hamming | | | | |
| - Flat Top | | | | |
| - Kaiser | | | | |
| | Sync Avg | 1 to 64 | Set the number of samples to be acquired and averaged before the FFT process is performed. | |
| | Hold | - None | Select the type of hold to be performed after the FFT process. | |
| | | - Average | | |
| | | - Min | | |
| | | - Max | | |
| Axis Settings | Axis | - Primary | Select the active axis to be configured. | |
| | | - Secondary | | |
| | Enabled | - On | Enable or disable the axis settings. | |
| | | - Off | This setting is only available when the axis type is secondary. If the axis type is primary, this setting is always set to On. | |
| | Left | | Set the left axis limit value. | |
| | Right | | Set the right axis limit value. | |
| | Span | | Set the total X-axis span or total range to be monitored in the graph. | |
| | Center | | Set the X-axis center point in the graph. | |
| | Top | | Set the top axis limit value. | |
| | Bottom | | Set the bottom axis limit value. | |
| X-Scale | - Linear | Select the X-axis scale type. | | |
| | - Log | | | |
| Y-Scale | - Linear | Select the Y-axis scale type. | | |
| | - Log | | | |
| Trace Settings | Active Trace | 1 to 8 | Select the active trace channel. | |
| | Source | | Select data source of the active trace from the available channels, traces, files, and memory. | |
| | Enabled | - On | Enable or disable the active trace data. | |
| | | - Off | | |
| | Memory | Save To Memory | | Save the active trace to the memory buffer. |
| | | Load From Memory | | Load a trace from the memory buffer into the active trace. |
| Clear Memory | | | Clear the trace from the memory buffer. | |

Table A-10 Graph analysis menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|----------------|----------------|---|--|
| Trace Settings | Math | Apply Math | Apply the corresponding math function to the trace data or turn off the math function. - On - Off |
| | | Function | Select the math function to be applied on the active trace. - f(Source) - f(Source) + x - f(Source) - x - f(Source) * x - f(Source) / x |
| | | X | Set the x value in the selected math function. |
| | Unit | <ul style="list-style-type: none"> - V - dBV - dBu - W - dBm - dB SPL | Select the trace unit type. |
| | Persistence | Persist | Enable or disable the persistence on the active trace. |
| | | Persist Count | Set the number of previous sets of trace data to be displayed in the graph before they are removed. This setting is only available when persistence is enabled. |
| | Axis | <ul style="list-style-type: none"> - Primary - Secondary | Attach the active trace to the primary or secondary axis. |
| | Color | <ul style="list-style-type: none"> - Yellow - Cyan - White - Pink - Green - Orange - Red - Purple | Select the color of the active trace. |
| | Display Option | <ul style="list-style-type: none"> - Graph - Data Table - Marker Table - Statistics - Harmonics - Signal Analysis | Select the graph analysis display option. |
| | Running mode | <ul style="list-style-type: none"> Continuous Single | Select the graph analysis running mode. |

Table A-10 Graph analysis menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|-------------|---------------|-------------|--|
| Measurement | Enabled | - On | Enable or disable the measurements in the graph. |
| | | - Off | |
| | Measurement 1 | Interface | Select the measurement interface type. |
| | | Channel | Select the desired channel to perform the measurement. |
| | | Function No | Select the function to be displayed based on the function number (1 to 4). |
| | Measurement 2 | Interface | Select the measurement interface type. |
| | | Channel | Select the desired channel to perform the measurement. |
| | | Function No | Select the function to be displayed based on the function number (1 to 4). |

Appendix 11: Sweep Function Menu Tree

Table A-11 Sweep function menu tree description

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-----------------|--------------------------|--|---------|---|
| App.Type | - Sweep - Group Delay | | | Select the sweep application type. |
| Parameter | | | | This is only available when the sweep application type is Sweep. Select the sweep parameter type. The parameter selection depends on the waveform type set at the analog generator. |
| | Spacing | - Log - Linear - Custom | | Select the spacing type. |
| | Unit | - Vrms - dBV - Vp - Vpp - dBm - dBu - dB SPL | | Select the sweep unit. This setting is only available when the sweep parameter is amplitude. |
| Points Settings | Start | | | Set the sweep start value. This setting is only available when the sweep spacing is Log or Linear. |
| | Stop | | | Set the sweep stop value. This setting is only available when the sweep spacing is Log or Linear. |
| | Step | | | Set the sweep step value. This setting is only available when the sweep spacing is Log or Linear. |
| | Points | | | Set the sweep points value. This setting is only available when the sweep spacing is Log or Linear. |
| | Edit Points | | | Refer to "Edit points" on page 494 for the edit points menu tree. |
| Dwell Time | | | | Set the delay in ms for the generator to output the signal. |
| Sweep Mode | Continuous Single | | | Select the sweep mode. |
| | Source | 1 to 2 | | Select the source channel(s). |
| Channels | Measure | 1 to 8 | | Select the measure channel(s). The available selection depends on the number of installed analog analyzer cards. |

Table A-11 Sweep function menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-----------|---------------|---|--|---|
| Plot View | Axis Settings | Active Axis | <ul style="list-style-type: none"> - Primary - Secondary | Select the active axis. |
| | | Left | | Set the left axis value. |
| | | Right | | Set the right axis value. |
| | | Top | | Set the top axis value. |
| | | Bottom | | Set the bottom axis value. |
| | | X-Scale | <ul style="list-style-type: none"> - Linear - Log | Select the X-axis scale type. |
| | Y-Scale | <ul style="list-style-type: none"> - Linear - Log | Select the Y-axis scale type. | |
| | | Data Channel | | Select the trace data channel number to be plotted. |
| | | Y Data | <ul style="list-style-type: none"> - S: <sweep parameter> - F1: <measurement function 1> - F2: <measurement function 2> - F3: <measurement function 3> - F4: <measurement function 4> | Select the Y-axis trace data source. |
| | | Y2 Data | <ul style="list-style-type: none"> - S: <sweep parameter> - F1: <measurement function 1> - F2: <measurement function 2> - F3: <measurement function 3> - F4: <measurement function 4> | Select the second Y-axis trace data source. |
| | | X Data | <ul style="list-style-type: none"> - S: <sweep parameter> - F1: <measurement function 1> - F2: <measurement function 2> - F3: <measurement function 3> - F4: <measurement function 4> | Select the X-axis trace data source. |
| | | Wrap Phase | <ul style="list-style-type: none"> - On - Off | Enable of disable the wrap phase. |

Table A-11 Sweep function menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Level 4 | Description |
|-----------|---------------|--------------|---|---|
| | Plot Settings | Hold Type | <ul style="list-style-type: none"> - None - Average - Max - Min | Select the data type to be plotted in the graph. |
| | | Data Channel | | Select the trace data channel number to be plotted. |
| | | Wrap Phase | <ul style="list-style-type: none"> - On - Off | Enable or disable the wrap phase. |
| | | Goto Point | | Set the sweep point number to go to. |
| | | Point Value | | Set the currently selected sweep point value. |
| | Edit points | Add Point | | Add a sweep point. |
| | | Remove Point | | Remove the selected sweep point. |
| | | Load Points | | Load the sweep points from a file. Refer to " Appendix 13: Recall Menu Tree " on page 496 for the recall menu tree. |
| | | Save Points | | Save the sweep points to a file. Refer to " Appendix 12: Save Menu Tree " on page 495 for the save menu tree. |
| Plot View | Save Pts | | | Save the sweep points to a file. Refer to " Appendix 12: Save Menu Tree " on page 495 for the save menu tree. |

Appendix 12: Save Menu Tree

Table A-12 Save menu tree description

| Level 1 | Level 2 | Description |
|--------------|-----------------------|--|
| Save | | Save to a file. |
| Type | | Select the file type to be displayed on the current directory. |
| Rename | OK | Set the file name and select OK to rename the file name. |
| | Mark | Mark the selected file. |
| Copy or Move | Copy Marked To Folder | Copy the marked file to the selected folder. |
| | Move Marked To Folder | Move the marked file to the selected folder. |
| Delete | | Delete the selected file. |
| New Folder | OK | Set the new folder name and select OK to create a new folder. |

Appendix 13: Recall Menu Tree

Table A-13 Recall menu tree description

| Level 1 | Level 2 | Description |
|--------------|-----------------------|--|
| Recall | | Recall a saved file. |
| Type | | Select the file type to be displayed on the current directory. |
| Rename | OK | Set the file name and select OK to rename the file name. |
| | Mark | Mark the selected file. |
| Copy or Move | Copy Marked To Folder | Copy the marked file to the selected folder. |
| | Move Marked To Folder | Move the marked file to the selected folder. |
| Delete | | Delete the selected file. |
| New Folder | OK | Set the new folder name and select OK to create a new folder. |

Appendix 14: Test Sequence Menu Tree

Table A-14 Test sequence menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|---------|--------------|-----------------------|--------------------------------------|---|--|
| Project | New Project | | | Create a new project. | |
| | Open Project | | | Load a project from a file. Refer to “ Appendix 13: Recall Menu Tree ” on page 496 for the recall menu tree. | |
| | Save Project | | | Save the project to a file. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. | |
| | Properties | Prompt DUT ID | - On - Off | | Enable or disable the prompt for device ID (device serial number) at the start of a test sequence. |
| | | Prompt Msg | | | Set the prompt message. This setting is only available when Prompt DUT ID is enabled. |
| | Properties | Pass/Fail Msg | - On - Off | | Enable or disable the on-screen message dialog box that can be displayed at the end of a test sequence. Press Enter to close the dialog box. |
| | | Pass Message | | | Edit the pass message. This setting is only available when Pass/Fail Msg is enabled. |
| | | Fail Message | | | Edit the fail message. This setting is only available when Pass/Fail Msg is enabled. |
| | Clear | | | Clear all the report data. | |
| | Save | | | Save the report to a DOCX file format. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. | |
| Report | Auto Save | - Enable - Disable | | Enable or disable saving the report automatically at the end of a test sequence. | |
| | Format | - Docx - Html | | Select the report file format to be saved. | |
| | Properties | Name Option | - Timestamp - Numeric - Prompt | | Select the naming convention of the file name for the automatically saved report. |
| | | Prefix | | | Set the prefix for the file name. |
| | Location | | Select New Folder | Select the folder for the automatically saved report. Create a new folder at the current directory or folder. | |

Table A-14 Test sequence menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|---|----------------------|-----------------|---|--|---|
| Test | Enable | | <ul style="list-style-type: none"> - On - Off | Enable or disable the selected test sequence. | |
| | Add Test Sequence | New Saved | | Add a new test sequence. | |
| | Delete Test Sequence | | | Delete the selected test sequence. | |
| | Save | | | Save the test sequence to a file. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. | |
| | Edit | | Move | | Move the selected test sequence. |
| | | | Copy | | Copy the selected test sequence. |
| | | | Paste | | Paste a copied test sequence after the selected test sequence. |
| | Properties | Name | | Set the test sequence name. | |
| | IO Configuration | Add Measurement | | | Add measurements to the selected test sequence. Refer to “Add Measurement” on page 502 for the list of test measurements. |
| | | Edit | Paste | | Paste a copied measurement after the IO configuration. The IO Configuration cannot be moved or copied. |
| Channels | | | | <ul style="list-style-type: none"> - None (External) - 1 - 2 | Select the number of output channels in use. |
| Settings: Output Configuration (Analog) | | Impedance | Connector | <ul style="list-style-type: none"> - Bal - UnBal - Com - IEC60268 | Select the output connector type. |
| | | | | <ul style="list-style-type: none"> - For Bal, Com, and IEC60268 - 600 Ω - 100 Ω - 40 Ω - For UnBal - 600 Ω - 50 Ω - 20 Ω | Select the output impedance value. |
| | | | IEC60268 | <ul style="list-style-type: none"> - Pin 2 - Pin 3 | Select the additional 10 Ω output series resistance for pin 2 or 3 of the XLR connector in the common IEC 60268 configuration. This setting is only available when the output connector type is set to IEC 60268. |
| | | Ground | <ul style="list-style-type: none"> - Float - Ground | Select the grounding type. | |

Table A-14 Test sequence menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|------------------|--|--|--|--|---|
| IO Configuration | Settings: Output Configuration (Analog) | Max Voltage | | Set the maximum voltage. | |
| | | Reference | Impedance | Set the reference impedance for the unit conversion of dBm measurements. | |
| | | | Channels | <ul style="list-style-type: none"> - None (External) - 2 | Select the number of output channels in use. |
| | Settings: Output Configuration (Bluetooth) | Device | | Select the paired Bluetooth device. | |
| | | Profiles | <ul style="list-style-type: none"> - A2DP - HFP - AVRCP | Select the U8903B's <i>Bluetooth</i> card profile. | |
| | | | Link Config | | Configure the <i>Bluetooth</i> link settings. |
| | | | References | Volt/FS | Set the output references for generator. |
| | | Channels | | Display the number of input channels in use. | |
| | Connector | <ul style="list-style-type: none"> - UnBal - Bal - Loopback | Select the input connector type. | | |
| | | Impedance | <ul style="list-style-type: none"> - 100 kΩ (for Unbalanced) - 200 kΩ (for Balanced) - 600 Ω - 300 Ω | Select the input impedance value. This setting is only available when Connector is set to UnBal or Bal. | |
| | Settings: Input Configuration (Analog) | Coupling | <ul style="list-style-type: none"> - DC - AC | Select the input coupling type. | |
| | | | Bandwidth | <ul style="list-style-type: none"> - 90 kHz - 1.5 MHz | Select the input bandwidth value. This setting is only available with Option N3431A. |
| | | Reference | Voltage | | Set the input voltage value. |
| | | | Ratio | | Set the input ratio value. |
| | | | Frequency | | Set the input frequency value. |
| | | | Impedance | | Set the input impedance value. |
| | | | Sound level | | Set the input sound level value. |
| Calibrator level | | | | Set the input calibrator level value. | |

Table A-14 Test sequence menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|------------------|---|--------------------------------|--|--|---|
| IO Configuration | Settings: Input Configuration (Bluetooth) | Channels | | Select the number of input channels in use. | |
| | | Device | | Select the paired Bluetooth device. | |
| | | Profiles | <ul style="list-style-type: none"> - A2DP - HFP - AVRCP | Select the U8903B's <i>Bluetooth</i> card profile. | |
| | | Link Config | | Configure the <i>Bluetooth</i> link settings. | |
| | | Coupling | <ul style="list-style-type: none"> - DC - AC | Select the input coupling type. | |
| | | Reference | Voltage | | Set the input voltage value. |
| | | | Ratio | | Set the reference ratio value. |
| | | | Frequency | | Set the reference frequency value. |
| | | | Sound Lvl | | Set the sound level value. |
| | | | Calibrator Lvl | | Set the calibration level value value. |
| | | | Volt/FS | Set the volts/FS reference value. | |
| | Properties | Name | | Rename the IO configuration. | |
| | | Sub-Steps: RunIO Configuration | Add Sub-Step | <ul style="list-style-type: none"> - Delay - Prompt - Sent SCPI | Add sub-step to the list. |
| | | | Edit | | Move the RunIO Configuration sub-step in the list. |
| | | Sub-Steps: Delay | Enable | <ul style="list-style-type: none"> - On - Off | Enable or disable the delay sub-step. |
| | | | Add Sub-Step | <ul style="list-style-type: none"> - Delay - Prompt - Sent SCPI | Add sub-step to the list. |
| | | | Delete Sub-Step | | Delete the selected sub-step. |
| | | | Edit | | Move or copy the selected sub-step, or paste a copied sub-step after the selected sub-step. |

Table A-14 Test sequence menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|------------------|------------|-------------------------|-----------------|---|---|
| IO Configuration | Properties | Sub-Steps: Delay | Settings | Configure the delay sub-step settings. – Delay Set the delay time in seconds. | |
| | | | Properties | Rename the delay sub-step name. | |
| | | | Enable | Enable or disable the prompt sub-step. | |
| | | | Add Sub-Step | Add sub-step to the list. – Delay – Prompt – Sent SCPI | |
| | | | Delete Sub-Step | Delete the selected sub-step. | |
| | | | Edit | Move or copy the selected sub-step, or paste a copied sub-step after the selected sub-step. | |
| | | Sub-Steps: Prompt | Settings | | – Message Set the prompt message at the lower half of the main display. |
| | | | | | – Prompt Icon Select the prompt icon to be displayed. – None – Hand – Question – Exclamation – Asterisk |
| | | | | | – Dialog Settings Add additional settings to the prompt window. – Timeout – Cancel Button |
| | | | | | – Timeout Set the prompt timeout value in seconds. |
| | | | | Properties | Set the prompt sub-step name. |
| | | | | Enable | Enable or disable the send SCPI sub-step. |
| | | Sub-Steps: Send SCPI | | Add Sub-Step | Add sub-step to the list. – Delay – Prompt – Sent SCPI |
| | | | | Delete Sub-Step | Delete the selected sub-step. |
| | | | | Edit | Move or copy the selected sub-step, or paste a copied sub-step after the selected sub-step. |

Table A-14 Test sequence menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|------------------|--------------------|--|------------|--|
| IO Configuration | Properties | Sub-Steps: Send SCPI | Settings | <ul style="list-style-type: none"> - GPIB Address Select the desired GPIB address. - SCPI Commands <ul style="list-style-type: none"> - Edit Set the SCPI commands at the lower half of the main display. - Import Load the SCPI commands from a file. Refer to “Appendix 13: Recall Menu Tree” on page 496 for the recall menu tree. - Progress Msg Set the optional text message that will be displayed on a dialog box for the time length set in Delay. - Delay Set the delay time length after the SCPI command(s) is issued. |
| | | | Properties | Set the prompt sub-step name. |
| Measurement | Enable | | | Enable or disable the selected measurement. |
| | Add Measurement | <ul style="list-style-type: none"> - AC level - Frequency - Phase - SNR - THD+N - DC level - Crosstalk - SMPTE IMD - DFD IMD - Multitone analyzer - POLQA - Stepped frequency sweep - SMPTE frequency sweep - DFD frequency sweep - Stepped level sweep - SMPTE level sweep - DFD level sweep - DC level sweep - Receiver Sensitivity - Measurement recorder | | Add measurements. |
| | Delete Measurement | | | Delete the selected test measurement. |
| | Edit | | | Move or copy the selected measurement, or paste a copied measurement after the selected measurement. |
| | Settings | | | Configure the selected test measurement. Refer to “ Measurement settings ” on page 505 for the respective test measurement settings. |

Table A-14 Test sequence menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|-------------|------------|--------------------------------|-----------------|--|
| | | Name | | Rename the selected measurement. |
| | | Sub-Steps: RunIO Configuration | Add Sub-Step | Add sub-step to the list. <ul style="list-style-type: none"> - Delay - Prompt - Sent SCPI |
| | | | Edit | Move the RunIO Configuration sub-step in the list. |
| | | | Enable | Enable or disable the delay sub-step. |
| | | Sub-Steps: Delay | Add Sub-Step | Add sub-step to the list. <ul style="list-style-type: none"> - Delay - Prompt - Sent SCPI |
| | | | Delete Sub-Step | Delete the selected sub-step. |
| | | | Edit | Move or copy the selected sub-step, or paste a copied sub-step after the selected sub-step. |
| | | | Settings | Configure the delay sub-step settings. <ul style="list-style-type: none"> - Delay Set the delay time in seconds. |
| | | | Properties | Rename the delay sub-step name. |
| Measurement | Properties | | Enable | Enable or disable the prompt sub-step. |
| | | | Add Sub-Step | Add sub-step to the list. <ul style="list-style-type: none"> - Delay - Prompt - Sent SCPI |
| | | | Delete Sub-Step | Delete the selected sub-step. |
| | | | Edit | Move or copy the selected sub-step, or paste a copied sub-step after the selected sub-step. |
| | | Sub-Steps: Prompt | | <ul style="list-style-type: none"> - Message Set the prompt message at the lower half of the main display. - Prompt Icon Select the prompt icon to be displayed. <ul style="list-style-type: none"> - None - Hand - Question - Exclamation - Asterisk - Dialog Settings Add additional settings to the prompt window. <ul style="list-style-type: none"> - Timeout - Cancel Button - Timeout Set the prompt timeout value in seconds. |
| | | | Settings | |

Table A-14 Test sequence menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|-------------|------------|-------------------------|---|--|
| | | Sub-Steps: Prompt | Properties | Set the prompt sub-step name. |
| | | | Enable | Enable or disable the send SCPI sub-step. |
| | | | Add Sub-Step | Add sub-step to the list. <ul style="list-style-type: none"> - Delay - Prompt - Sent SCPI |
| | | | Delete Sub-Step | Delete the selected sub-step. |
| | | | Edit | Move or copy the selected sub-step, or paste a copied sub-step after the selected sub-step. |
| Measurement | Properties | Sub-Steps: Send SCPI | Settings | <ul style="list-style-type: none"> - GPIB Address Select the desired GPIB address. - SCPI Commands <ul style="list-style-type: none"> - Edit Set the SCPI commands at the lower half of the main display. - Import Load the SCPI commands from a file. Refer to "Appendix 13: Recall Menu Tree" on page 496 for the recall menu tree. - Progress Msg Set the optional text message that will be displayed on a dialog box for the time length set in Delay. - Delay Set the delay time length after the SCPI command(s) is executed. |
| | | | Properties | Set the prompt sub-step name. |
| | | Failure Handling | <ul style="list-style-type: none"> - Cancel Seq. - Allow Retry - Continue Seq. | Select the failure handling type for the selected measurement. |

Measurement settings

AC level

Table A-15 Measurement settings > AC Level menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|---------------------------------|-----------------|----------------|--|------------------------------------|--|
| AC Level (Signal Generation) | Waveform | Sine | | Select the waveform type. | |
| | | Variable Phase | | | |
| | Output | Square | | Select the output channel. | |
| | | Arbitrary | | | |
| | Waveform Config | Track 1st Ch | | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | | Frequency | | Set the frequency value. |
| | | Amplitude | | Set the amplitude value. | |
| DC Offset | | | Set the DC offset value. | | |
| Phase->1st Ch | | | Set the phase value. This setting is only available when channel 2 is selected. | | |
| AC Level (Signal Analysis) | Detector | | - RMS - Pk-Pk | Select the AC level detector type. | |
| | | | | | |
| | LPF | | - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom | Select the low-pass filter. | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

Table A-15 Measurement settings > AC Level menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|-------------------------------|---------------|----------|-----------------------|--|
| AC Level (Signal Analysis) | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | | - 262144 | | |
| | | - 524288 | | |
| | | - 1M | | |
| - 2M | | | | |
| Input Range | Auto Range | | - On - Off | Enable or disable the auto input range. |
| | Track 1st Ch | | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | Voltage Range | | | Set the input voltage range. |
| | | | | |
| AC Level Gain | | | | Refer to " Bar chart " on page 550 for the bar chart menu tree. |

Frequency

Table A-16 Measurement settings > Frequency menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|----------------------------------|-----------------|------------------|-----------|---|--|
| Frequency (Signal Generation) | Waveform | - Sine | | Select the waveform type. | |
| | | - Variable Phase | | | |
| | - Square | | | | |
| | - Arbitrary | | | | |
| | Output | | | Select the output channel. | |
| | Waveform Config | Track 1st Ch | Enable | Disable | Enable or disable the tracking of the first channel. |
| | | Frequency | | | Set the frequency value. |
| Amplitude | | | | Set the amplitude value. | |
| DC Offset | | | | Set the DC offset value. | |
| Waveform Config | Phase->1st Ch | | | Set the phase value. This setting is only available when channel 2 is selected. | |
| Frequency (Signal Analysis) | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. | |
| | | - 4096 | | | |
| | | - 8192 | | | |
| | | - 16384 | | | |
| | | - 32768 | | | |
| | | - 65536 | | | |
| | | - 131072 | | | |
| - 262144 | | | | | |
| - 524288 | | | | | |
| - 1M | | | | | |
| - 2M | | | | | |
| Input Range | Auto Range | - On | - Off | Enable or disable the auto input range. | |
| | Track 1st Ch | - Enable | - Disable | Enable or disable the tracking of the first channel. | |
| | Voltage Range | | | Set the input voltage range. | |
| Frequency | | | | Refer to " Bar chart " on page 550 for the bar chart menu tree. | |

Phase

Table A-17 Measurement settings > Phase menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|------------------------------|-----------------|-----------------------|---|--|--|
| Phase (Signal Generation) | Waveform | - Sine | | Select the waveform type. | |
| | | - Variable Phase | | | |
| | | | - Square | | |
| | | | - Arbitrary | | |
| | Output | | | Select the output channel. | |
| | Waveform Config | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. | |
| | Waveform Config | Frequency | | Set the frequency value. | |
| Amplitude | | | Set the amplitude value. | | |
| DC Offset | | | Set the DC offset value. | | |
| Phase->1st Ch | | | Set the phase value. This setting is only available when channel 2 is selected. | | |
| Phase (Signal Analysis) | Ref Channel | | | Set the reference channel number. | |
| | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. | |
| | | - 4096 | | | |
| | | - 8192 | | | |
| | | - 16384 | | | |
| | | - 32768 | | | |
| | | - 65536 | | | |
| - 131072 | | | | | |
| - 262144 | | | | | |
| - 524288 | | | | | |
| - 1M | | | | | |
| - 2M | | | | | |
| Input Range | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. | | |
| | Voltage Range | | Set the input voltage range. | | |
| Phase | | | | Refer to “ Bar chart ” on page 550 for the bar chart menu tree. | |

SNR

Table A-18 Measurement settings > SNR menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description |
|----------------------------|-----------------|------------------|---|--|
| SNR (Signal Generation) | Waveform | - Sine | | Select the waveform type. |
| | | - Variable phase | | |
| | - Square | | | |
| | - Arbitrary | | | |
| | Output | | | Select the output channel. |
| | Waveform Config | Track 1st Ch | - Enable | |
| | | - Disable | | |
| Frequency | | | | Set the frequency value. |
| Amplitude | | | | Set the amplitude value. |
| DC Offset | | | | Set the DC offset value. |
| | Phase->1st Ch | | | Set the phase value. This setting is only available when channel 2 is selected. |
| SNR (Signal Analysis) | SNR Mode | - Fast | | Select the SNR measurement mode. |
| | | - Standard | | |
| | SNR Delay | | | Set the SNR delay. This setting is only available when SNR Mode is set to Standard. |
| | Freq Lock | - Auto | | Select the searching method for the fundamental frequency. |
| | | - Gen Lock | | This setting is only available when SNR Mode is set to Fast. |
| | | - Custom | | |
| Fund Freq | | | Set the fundamental frequency value. This setting is only available when SNR Mode is set to Fast and Freq Lock is set to Custom. | |
| Harmonic Cnt | | | Set the number of harmonics order to be removed. This setting is only available when SNR Mode is set to Fast. | |

Table A-18 Measurement settings > SNR menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--------------------------|------------|-------------|---------|--------------------------------|
| SNR (Signal Analysis) | LPF | - None | | Select the low-pass filter. |
| | | - 2 kHz | | |
| | | - 3 kHz | | |
| | | - 5 kHz | | |
| - 8 kHz | | | | |
| - 10 kHz | | | | |
| - 15 kHz | | | | |
| - 20 kHz | | | | |
| - 22 kHz | | | | |
| - 30 kHz | | | | |
| - 40 kHz | | | | |
| - 50 kHz | | | | |
| - 80 kHz | | | | |
| - Custom | | | | |
| | HPF | - None | | Select the high-pass filter. |
| | | - 15 Hz | | |
| | | - 20 Hz | | |
| | | - 22 Hz | | |
| | | - 30 Hz | | |
| | | - 50 Hz | | |
| | | - 70 Hz | | |
| | | - 100 Hz | | |
| | | - 200 Hz | | |
| | | - 300 Hz | | |
| | - 400 Hz | | | |
| | - Custom | | | |
| | Weighting | - None | | Select the weighting filter. |
| | | - A | | |
| | | - CCIR 1k | | |
| | | - CCIR 2k | | |
| | | - CCITT | | |
| | | - C-Message | | |
| | - Custom | | | |
| | Deemphasis | - None | | Select the de-emphasis filter. |
| | | - 50 μs | | |
| | | - 75 μs | | |
| | | - Custom | | |

Table A-18 Measurement settings > SNR menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--------------------------|-------------|---------------|-----------------------|--|
| SNR (Signal Analysis) | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | | - 262144 | | |
| | | - 524288 | | |
| | | - 1M | | |
| - 2M | | | | |
| | | Auto Range | - On - Off | Enable or disable the auto input range. |
| | Input Range | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | Voltage Range | | Set the input voltage range. |
| SNR | | | | Refer to " Bar chart " on page 550 for the bar chart menu tree. |

THD+N

Table A-19 Measurement settings > THD+N menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description |
|------------------------------|----------------------------|---|---|---|
| THD+N (Signal Generation) | Waveform | - Sine | | Select the waveform type. |
| | | - Variable phase | | |
| | Output | - Square | | Select the output channel. |
| | | - Arbitrary | | |
| | Waveform Config | Track 1st Ch | - Enable | Enable or disable the tracking of the first channel. |
| | | Frequency | - Disable | |
| | | Amplitude | | |
| | | DC Offset | | |
| | Waveform Config | Phase->1st Ch | | Set the phase value. This setting is only available when channel 2 is selected. |
| | THD+N (Signal Analysis) | Freq Lock | - Auto | Select the searching method for the fundamental frequency. |
| - Gen Lock | | | | |
| - Custom | | | | |
| Fund Freq | | | Set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. | |
| Harmonics | - All | Select the harmonics count to be used in the THD ratio and THD level results. | | |
| | - 2 to 9 | | | |
| LPF | | - None | Select the low-pass filter. | |
| | | - 2 kHz | | |
| | | - 3 kHz | | |
| | | - 5 kHz | | |
| | | - 8 kHz | | |
| | | - 10 kHz | | |
| | | - 15 kHz | | |
| | | - 20 kHz | | |
| | | - 22 kHz | | |
| | | - 30 kHz | | |
| | | - 40 kHz | | |
| | | - 50 kHz | | |
| | - 80 kHz | | | |
| | - Custom | | | |

Table A-19 Measurement settings > THD+N menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|---|---------|-------------|---------|--|
| THD+N (Signal Analysis) | HPF | - None | | Select the high-pass filter. |
| | | - 15 Hz | | |
| | | - 20 Hz | | |
| | | - 22 Hz | | |
| | | - 30 Hz | | |
| | | - 50 Hz | | |
| | | - 70 Hz | | |
| Weighting | | - 100 Hz | | Select the weighting filter. |
| | | - 200 Hz | | |
| | | - 300 Hz | | |
| | | - 400 Hz | | |
| | | - Custom | | |
| | | - None | | |
| Deemphasis | | - A | | Select the de-emphasis filter. |
| | | - CCIR 1k | | |
| | | - CCIR 2k | | |
| | | - CCITT | | |
| | | - C-Message | | |
| Sample Size | | - Custom | | Select the number of samples to be acquired for the measurement. |
| | | - 2048 | | |
| | | - 4096 | | |
| | | - 8192 | | |
| Input Range | | - 16384 | | Enable or disable the auto input range. |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | | - 262144 | | |
| | | - 524288 | | |
| | | - 1M | | |
| | | - 2M | | |
| | | - On | | |
| | | - Off | | |
| Voltage Range | | - Enable | | Enable or disable the tracking of the first channel. |
| | | - Disable | | |
| | | | | |
| SINAD THD Level THD Ratio THD+N Level THD+N Ratio | | | | Refer to “Bar chart” on page 550 for the bar chart menu tree. |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

DC level

Table A-20 Measurement settings > DC Level menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|---------------------------------|-------------------------------|-----------------------|-----------------------|--|--|
| DC Level (Signal Generation) | Waveform | - Sine - Arbitrary | | Select the waveform type. | |
| | Output | | | Select the output channel. | |
| | Waveform Config | Track 1st Ch | - Enable - Disable | | Enable or disable the tracking of the first channel. |
| | | Frequency | | | Set the frequency value. |
| | | Amplitude | | | Set the amplitude value. |
| | | DC Offset | | | Set the DC offset value. |
| | DC Level (Signal Analysis) | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. |
| - 4096 | | | | | |
| - 8192 | | | | | |
| - 16384 | | | | | |
| - 32768 | | | | | |
| - 65536 | | | | | |
| - 131072 | | | | | |
| - 262144 | | | | | |
| - 524288 | | | | | |
| - 1M | | | | | |
| - 2M | | | | | |
| Input Range | Auto Range | - On - Off | | Enable or disable the auto input range. | |
| | Track 1st Ch | - Enable - Disable | | Enable or disable the tracking of the first channel. | |
| | Voltage Range | | | Set the input voltage range. | |
| DC Level | | | | Refer to “ Bar chart ” on page 550 for the bar chart menu tree. | |

Crosstalk

Table A-21 Measurement settings > Crosstalk menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | | |
|----------------------------------|----------------------------------|---|-----------------------|---|--|--|
| Crosstalk (Signal Generation) | Waveform | - Sine - Arbitrary | | Select the waveform type. | | |
| | Output | | | Select the output channel. | | |
| | Waveform Config | Track 1st Ch | - Enable - Disable | | Enable or disable the tracking of the first channel. | |
| | | Frequency | | | Set the frequency value. | |
| | | Amplitude | | | Set the amplitude value. | |
| | | DC Offset | | | Set the DC offset value. | |
| | Driven Ch | | | | Select the driven channel number from the generator. | |
| Freq Lock | - Auto - Gen Lock - Custom | | | Select the searching method for the fundamental frequency. | | |
| Crosstalk (Signal Analysis) | Fund Freq | | | Set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. | | |
| | Sample Size | - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M | | | Select the number of samples to be acquired for the measurement. | |
| | | Input Range | Auto Range | - On - Off | Enable or disable the auto input range. | |
| | | | Track 1st Ch | - Enable - Disable | | Enable or disable the tracking of the first channel. |
| | | Input Range | Voltage Range | | | Set the input voltage range. |
| | | Crosstalk | | | | Refer to “ Bar chart ” on page 550 for the bar chart menu tree. |

SMPTE IMD

Table A-22 Measurement settings > SMPTE IMD menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|----------------------------------|-----------------|--------------|-----------------------|---|--|
| SMPTE IMD (Signal Generation) | Waveform | - SMPTE 1:1 | | Select the waveform type. | |
| | | - SMPTE 4:1 | | | |
| | | | - SMPTE 10:1 | | |
| | Output | | | Select the output channel. | |
| | Waveform Config | Track 1st Ch | | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | Upper Freq | | | Set the upper frequency value. |
| | | Lower Freq | | | Set the lower frequency value. |
| | | Amplitude | | | Set the amplitude value. |
| | | DC Offset | | | Set the DC offset value. |
| | Freq Lock | Gen Lock | | | Select the searching method for the upper and lower frequencies. |
| Custom | | | | | |
| Upper Freq | | | | Set the upper fundamental frequency value. This setting is only available when Freq Lock is set to Custom. | |
| | Lower Freq | | | Set the lower fundamental frequency value. This setting is only available when Freq Lock is set to Custom. | |
| SMPTE IMD (Signal Analysis) | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. | |
| | | - 4096 | | | |
| | | - 8192 | | | |
| | | - 16384 | | | |
| | | - 32768 | | | |
| | | - 65536 | | | |
| | | - 131072 | | | |
| | | - 262144 | | | |
| | | - 524288 | | | |
| | | - 1M | | | |
| - 2M | | | | | |
| Input Range | Auto Range | | - On - Off | Enable or disable the auto input range. | |
| | Track 1st Ch | | - Enable - Disable | Enable or disable the tracking of the first channel. | |
| | Voltage Range | | | Set the input voltage range. | |
| SMPTE Ratio | | | | Refer to "Bar chart" on page 550 for the bar chart menu tree. | |

DFD IMD

Table A-23 Measurement settings > DFD IMD menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|--------------------------------|-----------------|---|--------------------------|--|--|
| DFD IMD (Signal Generation) | Waveform | - IEC60118 - IEC60268 | | Select the waveform type. | |
| | Output | | | Select the output channel. | |
| | Waveform Config | Track 1st Ch | - Enable - Disable | | Enable or disable the tracking of the first channel. |
| | | Upper Freq | | | Set the upper frequency value. |
| | | Center Freq | | | Set the center frequency value. |
| | | Diff Freq | | | Set the difference frequency value. |
| | | Amplitude | | | Set the amplitude value. |
| DC Offset | | | Set the DC offset value. | | |
| DFD IMD (Signal Analysis) | DFD order | - 2nd - 3rd | | Select the distortion order to be measured. | |
| | Sample Size | - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M | | Select the number of samples to be acquired for the measurement. | |
| | | Input Range | Auto Range | - On - Off | Enable or disable the auto input range. |
| | | | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | | Voltage Range | | Set the input voltage range. |
| | | DFD Ratio | | | Refer to “ Bar chart ” on page 550 for the bar chart menu tree. |

Multitone analyzer

Table A-24 Measurement settings > Multitone Analyzer menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|----------------------------------|-----------------|----------------|---|---|--|
| Multitone (Signal Generation) | Output | | | Select the output channel. | |
| | Waveform Config | Track 1st Ch | <ul style="list-style-type: none"> - Enable - Disable | Enable or disable the tracking of the first channel. | |
| | | Amplitude | | Set the total amplitude value. | |
| | | Start Freq | | Set the lowest frequency in the multitone waveform. | |
| | | Stop Freq | | Set the highest frequency in the multitone waveform. | |
| | | Freq Spacing | <ul style="list-style-type: none"> - Linear - Log - Custom | Select the frequency spacing between the tones. | |
| | | Tone Count | | Set the number of signal frequency components. | |
| | | Length | <ul style="list-style-type: none"> - 1024 - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 | Select the waveform length value. | |
| | | | Apply | | Apply the multitone after it has been customized. |
| | | | Optimize | | Optimize the multitone. |
| | | | Amplitude Dist | <ul style="list-style-type: none"> - Zero | Set the phase of all tones to 0 degrees. |
| | | | Phase Dist | <ul style="list-style-type: none"> - Zero - Random | Select the phase distribution of all tones in degrees. |
| | | Edit Tones | Frequency | | Set the frequency value. |
| | | | Amplitude | | Set the amplitude value. |
| | | | Phase | | Set the phase value. |
| | | | Add Above | | Add a tone above the selected tone. |
| | | | Add Below | | Add a tone below the selected tone. |
| | | | Remove | | Remove the selected tone. |
| | | | Clear All | | Remove all the tones in the list. |
| | | Active Channel | | Set the active channel for the absolute amplitude for each tone to be displayed in a table. | |
| Multitone (Signal Analysis) | Input Range | Track 1st Ch | <ul style="list-style-type: none"> - Enable - Disable | Enable or disable the tracking of the first channel. | |
| | | Voltage Range | | Set the input voltage range. | |

Table A-24 Measurement settings > Multitone Analyzer menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|------------------|---------|---------|---------|--|
| - Spectrum | | | | Refer to “ Graph ” on page 551 for the graph menu tree. |
| - Waveform | | | | |
| - Level | | | | |
| - Gain | | | | |
| - Max Tone Level | | | | Refer to “ Bar chart ” on page 550 for the bar chart menu tree. |
| - Min Tone Level | | | | |
| - TD+N Level | | | | |
| - TD+N Ratio | | | | |
| - Tone Level | | | | |

Stepped frequency sweep

Table A-25 Measurement settings > Stepped Frequency Sweep menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|--|---------|-----------------|--------------------|---|---|
| Stepped Frequency Sweep (Signal Generation) | Output | | | Select the output channel. | |
| | | Start | | Set the start value for the sweep parameter. | |
| | | Stop | | Set the stop value for the sweep parameter. | |
| | | Spacing | | Select Log, Linear, or Custom for the sweep spacing. | |
| | | Points | | Set the number of sweep points. | |
| | | Step Size | | Set the step size for linear spacing. This setting is only available when spacing is set to Linear. | |
| | | Dwell Time | | Set the delay between the sweep points. | |
| | | Sweep Config | Point No | Set the point number. | |
| | | | Point Value | Set the point value. | |
| | | | Insert Point Above | Insert a point above the selected point. | |
| | | | Insert Point Below | Insert a point below the selected point. | |
| | | | Remove Point | Remove the selected point. | |
| | | | Clear | Clear all points. | |
| | | | Edit Points | Reverse Order | Reverse the order of the points. |
| | | | | Sort | Sort the points in ascending order. |
| | | | | Load Points | Load points from a file. Refer to “Appendix 13: Recall Menu Tree” on page 496 for the recall menu tree. |
| | | | | Save Points | Save the points to a file. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. |
| | | Waveform Config | Track 1st Ch | - Enable - Disable Enable or disable the tracking of the first channel. | |
| | | | Amplitude | Set the amplitude value. | |
| | | | DC Offset | Set the DC offset value. | |
| | | Ref Channel | | Set the reference channel number. | |
| | | Harmonics | - All - 2 to 9 | Select the harmonics count to be used in the THD ratio and THD level results. | |

Table A-25 Measurement settings > Stepped Frequency Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--|-------------|---------|------------------------------|---|
| Stepped Frequency Sweep (Signal Analysis) | Ref Channel | - CH1 | | Select the reference channel. |
| | | - CH2 | | |
| | | - CH3 | | |
| | | - CH4 | | |
| | Wrap Phase | - On | | Enable or disable the wrap phase. |
| | | - Off | | |
| | Harmonics | - ALL | | Select the harmonics counts to be used. |
| | | - 2 | | |
| | | - 3 | | |
| | | - 4 | | |
| - 5 | | | | |
| - 6 | | | | |
| - 7 | | | | |
| LPF | - None | | Select the low-pass filter. | |
| | - 2 kHz | | | |
| | - 3 kHz | | | |
| | - 5 kHz | | | |
| | - 8 kHz | | | |
| | - 10 kHz | | | |
| | - 15 kHz | | | |
| | - 20 kHz | | | |
| | - 22 kHz | | | |
| | - 30 kHz | | | |
| | - 40 kHz | | | |
| | - 50 kHz | | | |
| | - 80 kHz | | | |
| | - Custom | | | |
| HPF | - None | | Select the high-pass filter. | |
| | - 15 Hz | | | |
| | - 20 Hz | | | |
| | - 22 Hz | | | |
| | - 30 Hz | | | |
| | - 50 Hz | | | |
| | - 70 Hz | | | |
| | - 100 Hz | | | |
| | - 200 Hz | | | |
| | - 300 Hz | | | |
| | - 400 Hz | | | |
| - Custom | | | | |

Table A-25 Measurement settings > Stepped Frequency Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|---|----------------|-----------------------|--|--------------------------------|
| Stepped Frequency Sweep (Signal Analysis) | Weighting | - None | | Select the weighting filter. |
| | | - A | | |
| | | - CCIR 1k | | |
| | | - CCIR 2k | | |
| | | - CCITT | | |
| | Deemphasis | - C-Message | | Select the de-emphasis filter. |
| | | - Custom | | |
| | | - None | | |
| | | - 50 μ s | | |
| | Notch Filter | - 75 μ s | | Select the notch filter. |
| - Custom | | | | |
| - HP8903B | | | | |
| Sample Size | - Custom Notch | | Select the number of samples to be acquired for the measurement. | |
| | - Center Freq | | | |
| | - Bandwidth | | | |
| | - 2048 | | | |
| | - 4096 | | | |
| | - 8192 | | | |
| | - 16384 | | | |
| | - 32768 | | | |
| | - 65536 | | | |
| | - 131072 | | | |
| Input Range | - 262144 | | Enable or disable the auto input range. | |
| | - 524288 | | | |
| | - 1M | | | |
| Voltage Range | - 2M | | Enable or disable the tracking of the first channel. | |
| | Auto Range | - On - Off | | |
| | Track 1st Ch | - Enable - Disable | | |
| | Voltage Range | | | Set the input voltage range. |
| | - AC Level | | Refer to “ Graph ” on page 551 for the graph menu tree. | |
| | - Gain | | | |
| | - Phase | | | |
| | - THD Ratio | | | |
| | - THD Level | | | |
| | - THD+N Ratio | | | |
| | - THD+N Level | | | |
| - SINAD | | | | |

SMPTE frequency sweep

Table A-26 Measurement settings > SMPTE Frequency Sweep menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|--|----------|--|-----------------------------|----------------------------|---|
| SMPTE Frequency Sweep (Signal Generation) | Waveform | - SMPTE 1:1 - SMPTE 4:1 - SMPTE 10:1 | | Select the waveform type. | |
| | Output | | | Select the output channel. | |
| | | Swept | - Upper Freq - Lowe Freq | | Select the sweep parameter. |
| | | Start | | | Set the start value for the sweep parameter. |
| | | Stop | | | Set the stop value for the sweep parameter. |
| | | Spacing | | | Select Log, Linear, or Custom for the sweep spacing. |
| | | Points | | | Set the number of sweep points. |
| | | Step Size | | | Set the step size for linear spacing. This setting is only available when spacing is set to Linear. |
| | | Dwell Time | | | Set the delay between the sweep points. |
| | | Sweep Config | | Point No | Set the point number. |
| | | | | Point Value | Set the point value. |
| | | | | Insert Point Above | Insert a point above the selected point. |
| | | | | Insert Point Below | Insert a point below the selected point. |
| | | | | Remove Point | Remove the selected point. |
| | | | | Clear | Clear all points. |
| | | | | Reverse Order | Reverse the order of the points. |
| | | | | Sort | Sort the points in ascending order. |
| | | Edit Points | | Load Points | Load points from a file. Refer to " Appendix 13: Recall Menu Tree " on page 496 for the recall menu tree. |
| | | | | Save Points | Save the points to a file. Refer to " Appendix 12: Save Menu Tree " on page 495 for the save menu tree. |
| | | Waveform Config | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | | Upper Freq | | Set the upper frequency value. |
| | | | Lower Freq | | Set the lower frequency value. |
| | | | Amplitude | | Set the amplitude value. |
| | | | DC Offset | | Set the DC offset value. |

Table A-26 Measurement settings > SMPTE Frequency Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--|-------------|---------------|-----------------------|--|
| SMPTE Frequency Sweep (Signal Analysis) | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | | - 262144 | | |
| | | - 524288 | | |
| | | - 1M | | |
| - 2M | | | | |
| | Input Range | Auto Range | - On - Off | Enable or disable the auto input range. |
| | | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | Voltage Range | | Set the input voltage range. |
| SMPTE Ratio | | | | Refer to “Graph” on page 551 for the graph menu tree. |

DFD frequency sweep

Table A-27 Measurement settings > DFD Frequency Sweep menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|--|-----------|--------------------------|------------------------------|---|---|
| DFD Frequency Sweep (Signal Generation) | Waveform | - IEC60118 - IEC60268 | | Select the waveform type. | |
| | Output | | | Select the output channel. | |
| | | Swept | - Upper Freq - Lower Freq | Select the sweep parameter. | |
| | | Start | | Set the start value for the sweep parameter. | |
| | | Stop | | Set the stop value for the sweep parameter. | |
| | | Spacing | | Select Log, Linear, or Custom for the sweep spacing. | |
| | | Points | | Set the number of sweep points. | |
| | | Step Size | | Set the step size for linear spacing. This setting is only available when spacing is set to Linear. | |
| | | Dwell Time | | Set the delay between the sweep points. | |
| | | Sweep Config | Point No | Set the point number. | |
| | | | Point Value | Set the point value. | |
| | | | Insert Point Above | Insert a point above the selected point. | |
| | | | Insert Point Below | Insert a point below the selected point. | |
| | | | Remove Point | Remove the selected point. | |
| | | | Clear | Clear all points. | |
| | | | Reverse Order | Reverse the order of the points. | |
| | | | Sort | Sort the points in ascending order. | |
| | | | Load Points | Load points from a file. Refer to " Appendix 13: Recall Menu Tree " on page 496 for the recall menu tree. | |
| | | Sweep Config | Edit Points | Save Points | Save the points to a file. Refer to " Appendix 12: Save Menu Tree " on page 495 for the save menu tree. |
| | | | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | Waveform Config | Upper Freq | | Set the upper frequency value. |
| | | | Diff Freq | | Set the difference frequency value. |
| | | | Amplitude | | Set the amplitude value. |
| | DC Offset | | | Set the DC offset value. | |

Table A-27 Measurement settings > DFD Frequency Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--|---------------|-----------------------|--|--|
| DFD Frequency Sweep (Signal Analysis) | DFD order | - 2nd | | Select the distortion product order to be measured. |
| | | - 3rd | | |
| | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | | - 262144 | | |
| Input Range | Auto Range | - On - Off | Enable or disable the auto input range. | |
| | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. | |
| | Voltage Range | | Set the input voltage range. | |
| DFD Ratio | | | Refer to “ Graph ” on page 551 for the graph menu tree. | |

External frequency sweep

Table A-28 Measurement settings > External Frequency Sweep menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|---|--------------------|-------------------|---------------|--|---|
| External Frequency Sweep (Signal Generation) | Instrument | - Keysight 33220A | | Select the instrument model. | |
| | | - Keysight 33250A | | | |
| | | - Keysight 33500A | | | |
| | | - Keysight 33600A | | | |
| | | - Other | | | |
| | GPIB Address | - 0 to 30 | | Select the GPIB address. | |
| | Init Instrument | - On | | Enable or disable the U8903B to send SCPI commands to initialize the connected signal generator. | |
| | | - Off | | | |
| | Init SCPI | - Edit | | Set the SCPI commands that initialize the connected instrument. You can set the SCPI command directly or load from a file. | |
| | | - Import | | | |
| | Sweep SCPI | - Edit | | Set the sweep SCPI commands that initialize the connected instrument. You can set the SCPI command directly or load from a file. | |
| | | - Import | | | |
| | | Start | | Set the start value for the sweep parameter. | |
| | | Stop | | Set the stop value for the sweep parameter. | |
| | | Spacing | | Select Log, Linear, or Custom for the sweep spacing. | |
| | | Points | | Set the number of sweep points. | |
| | | Step Size | | Set the step size for linear spacing. This setting is only available when spacing is set to Linear. | |
| | | Dwell Time | | Set the delay between the sweep points. | |
| | | Sweep Config | Point No | | Set the point number. |
| | | | Point Value | | Set the point value. |
| | Insert Point Above | | | Insert a point above the selected point. | |
| | Insert Point Below | | | Insert a point below the selected point. | |
| | Remove Point | | | Remove the selected point. | |
| | Clear | | | Clear all points. | |
| | Edit Points | | Reverse Order | | Reverse the order of the points. |
| | | | Sort | | Sort the points in ascending order. |
| | | | Load Points | | Load points from a file. Refer to "Appendix 13: Recall Menu Tree" on page 496 for the recall menu tree. |
| | | | Save Points | | Save the points to a file. Refer to "Appendix 12: Save Menu Tree" on page 495 for the save menu tree. |

Table A-28 Measurement settings > External Frequency Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|---|-------------|--|---------|---|
| External Frequency Sweep (Signal Analysis) | Ref Channel | - CH1 to CH8 | | Select the reference channel number. The phase of each channel is measured against the reference channel. The phase result for the reference channel should always be displayed zero. |
| | Harmonics | - All - 2 to 9 | | Select the harmonics count to be used in the THD ratio and THD level results. |
| | LPF | - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom | | Select the low-pass filter. |
| | HPF | - None - 15 Hz - 20 Hz - 22 Hz - 30 Hz - 50 Hz - 70 Hz - 100 Hz - 200 Hz - 300 Hz - 400 Hz - Custom | | Select the high-pass filter. |
| | Weighting | - None - A - CCIR 1k - CCIR 2k - CCITT - C-Message - Custom | | Select the weighting filter. |
| | Deemphasis | - None - 50 μ s - 75 μ s - Custom | | Select the de-emphasis filter. |

Table A-28 Measurement settings > External Frequency Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|--|--------------|--------------|---|---|--|
| Stepped Frequency Sweep (Signal Analysis) | Notch Filter | HP8903B | - On - Off | Enable or disable the HP8903B mode. | |
| | | Custom Notch | - On - Off | Enable or disable the custom notch. | |
| | | Center Freq | | Set the center frequency value. This is only applicable when custom notch is enabled. | |
| | | Bandwidth | | Set the bandwidth value. This is only applicable when custom notch is enabled. | |
| | Sample Size | | - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M | | Select the number of samples to be acquired for the measurement. |
| | | Input Range | Auto Range | - On - Off | Enable or disable the auto input range. |
| | | | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | | Voltage Range | | Set the input voltage range. |
| | | | - AC Level - Gain - Phase - THD Ratio - THD Level - THD+N Ratio - THD+N Level - SINAD | | Refer to “ Graph ” on page 551 for the graph menu tree. |

Stepped level sweep

Table A-29 Measurement settings > Stepped Level Sweep menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--|-----------------|-----------------------|-----------------------|---|
| Stepped Level Sweep (Signal Generation) | Waveform | - Sine - Arbitrary | | Select the waveform type. |
| | Output | | | Select the output channel. |
| | | Start | | Set the start value for the sweep parameter. |
| | | Stop | | Set the stop value for the sweep parameter. |
| | | Spacing | | Select Log, Linear, or Custom for the sweep spacing. |
| | | Points | | Set the number of sweep points. |
| | | Step Size | | Set the step size for linear spacing. This setting is only available when spacing is set to Linear. |
| | | Dwell Time | | Set the delay between the sweep points. |
| | Sweep Config | | Point No | Set the point number. |
| | | | Point Value | Set the point value. |
| | | | Insert Point Above | Insert a point above the selected point. |
| | | | Insert Point Below | Insert a point below the selected point. |
| | | | Remove Point | Remove the selected point. |
| | | Edit Points | Clear | Clear all points. |
| | | | Reverse Order | Reverse the order of the points. |
| | | | Sort | Sort the points in ascending order. |
| | | | Load Points | Load points from a file. Refer to “Appendix 13: Recall Menu Tree” on page 496 for the recall menu tree. |
| | Sweep Config | Edit Points | Save Points | Save the points to a file. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. |
| | Waveform Config | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | Frequency | | Set the frequency value. |
| | | DC Offset | | Set the DC offset value. |

Table A-29 Measurement settings > Stepped Level Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--|------------|--|---------|--|
| Stepped Level Sweep (Signal Analysis) | Freq Lock | - Auto - Gen Lock - Custom | | Select the searching method for the fundamental frequency. |
| | Fund Freq | | | Set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. |
| | LPF | - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom | | Select the low-pass filter. |
| | HPF | - None - 15 Hz - 20 Hz - 22 Hz - 30 Hz - 50 Hz - 70 Hz - 100 Hz - 200 Hz - 300 Hz - 400 Hz - Custom | | Select the high-pass filter. |
| | Weighting | - None - A - CCIR 1k - CCIR 2k - CCITT - C-Message - Custom | | Select the weighting filter. |
| | Deemphasis | - None - 50 μ s - 75 μ s - Custom | | Select the de-emphasis filter. |
| | | | | |
| | | | | |

Table A-29 Measurement settings > Stepped Level Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--|-------------|-------------------------------------|-----------------------|--|
| Stepped Level Sweep (Signal Analysis) | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | | - 262144 | | |
| | | - 524288 | | |
| | | | | |
| | | - 2M | | |
| | Input Range | Auto Range | - On - Off | Enable or disable the auto input range. |
| | | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | Voltage Range | | Set the input voltage range. |
| | | - AC Level | | Refer to “ Graph ” on page 551 for the graph menu tree. |
| | | - Gain | | |
| | | - THD Ratio | | |
| | | - THD Level | | |
| | | - THD Ratio Vs Measured Amplitude | | |
| | | - THD Level Vs Measured Amplitude | | |
| | | - THD+N ratio | | |
| | | - THD+N Level | | |
| | | - THD+N Ratio Vs Measured Amplitude | | |
| | | - THD+N Level Vs Measured Amplitude | | |
| | | - SINAD | | |

SMPTE level sweep

Table A-30 Measurement settings > SMPTE Level Sweep menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|--|-----------------|--|-----------------------|----------------------------|---|
| SMPTE Level Sweep (Signal Generation) | Waveform | - SMPTE 1:1 - SMPTE 4:1 - SMPTE 10:1 | | Select the waveform type. | |
| | Output | | | Select the output channel. | |
| | Sweep Config | Start | | | Set the start value for the sweep parameter. |
| | | Stop | | | Set the stop value for the sweep parameter. |
| | | Spacing | | | Select Log, Linear, or Custom for the sweep spacing. |
| | | Points | | | Set the number of sweep points. |
| | | Step Size | | | Set the step size for linear spacing. This setting is only available when spacing is set to Linear. |
| | | Dwell Time | | | Set the delay between the sweep points. |
| | Sweep Config | Edit Points | Point No | | Set the point number. |
| | | | Point Value | | Set the point value. |
| | | | Insert Point Above | | Insert a point above the selected point. |
| | | | Insert Point Below | | Insert a point below the selected point. |
| | | | Remove Point | | Remove the selected point. |
| | | | Clear | | Clear all points. |
| | | | Reverse Order | | Reverse the order of the points. |
| | | | Sort | | Sort the points in ascending order. |
| | | | Load Points | | Load points from a file. Refer to “ Appendix 13: Recall Menu Tree ” on page 496 for the recall menu tree. |
| | | | Save Points | | Save the points to a file. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. |
| | Waveform Config | Track 1st Ch | - Enable - Disable | | Enable or disable the tracking of the first channel. |
| | | Upper Freq | | | Set the upper frequency value. |
| | | Lower Freq | | | Set the lower frequency value. |
| | | DC Offset | | | Set the DC offset value. |

Table A-30 Measurement settings > SMPTE Level Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|--|-------------|---|---------|--|--|
| SMPTE Level Sweep (Signal Analysis) | Freq Lock | - Gen Lock - Custom | | Select the searching method for the upper and lower frequencies. | |
| | Upper Freq | | | Set the upper fundamental frequency value. This setting is only available when Freq Lock is set to Custom. | |
| | Lower Freq | | | Set the lower fundamental frequency value. This setting is only available when Freq Lock is set to Custom. | |
| | Sample Size | - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M | | Select the number of samples to be acquired for the measurement. | |
| | Input Range | Auto Range | | - On - Off | Enable or disable the auto input range. |
| | | Track 1st Ch | | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | Voltage Range | | | Set the input voltage range. |
| | | - SMPTE Ratio - SMPTE Ratio Vs Measured Amplitude | | | Refer to “ Graph ” on page 551 for the graph menu tree. |

DFD level sweep

Table A-31 Measurement settings > DFD Level Sweep menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | | |
|--|-----------------|--------------------------|-----------------------|----------------------------|---|--|
| DFD Level Sweep (Signal Generation) | Waveform | - IEC60118 - IEC60268 | | Select the waveform type. | | |
| | Output | | | Select the output channel. | | |
| | Sweep Config | Start | | | Set the start value for the sweep parameter. | |
| | | | Stop | | Set the stop value for the sweep parameter. | |
| | | Spacing | | | Select Log, Linear, or Custom for the sweep spacing. | |
| | | Points | | | Set the number of sweep points. | |
| | | Step Size | | | Set the step size for linear spacing. This setting is only available when spacing is set to Linear. | |
| | | Dwell Time | | | Set the delay between the sweep points. | |
| | | Sweep Config | Edit Points | Point No | | Set the point number. |
| | | | | Point Value | | Set the point value. |
| | | | | Insert Point Above | | Insert a point above the selected point. |
| | | | | Insert Point Below | | Insert a point below the selected point. |
| | Remove Point | | | | Remove the selected point. | |
| | Clear | | | | Clear all points. | |
| | Reverse Order | | | | Reverse the order of the points. | |
| | Sort | | | | Sort the points in ascending order. | |
| | Sweep Config | Edit Points | Load Points | | Load points from a file. Refer to “ Appendix 13: Recall Menu Tree ” on page 496 for the recall menu tree. | |
| | | | Save Points | | Save the points to a file. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. | |
| | Waveform Config | Track 1st Ch | - Enable - Disable | | Enable or disable the tracking of the first channel. | |
| | | Upper Freq | | | Set the upper frequency value. | |
| | | Diff Freq | | | Set the difference frequency value. | |
| DC Offset | | | | Set the DC offset value. | | |

Table A-31 Measurement settings > DFD Level Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--------------------------------------|---------------|-----------------------|--|--|
| DFD Level Sweep (Signal Analysis) | DFD order | - 2nd | | Select the distortion product order to be measured. |
| | | - 3rd | | |
| | Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | | - 262144 | | |
| Input Range | - 524288 | | | |
| | - 1M | | | |
| | - 2M | | | |
| | Auto Range | - On - Off | Enable or disable the auto input range. | |
| Track 1st Ch | | - Enable - Disable | Enable or disable the tracking of the first channel. | |
| | Voltage Range | | Set the input voltage range. | |
| - DFD Ratio | | | Refer to “ Graph ” on page 551 for the graph menu tree. | |
| - DFD Ratio Vs Measured Amplitude | | | | |

DC level sweep

Table A-32 Measurement settings > DC Level Sweep menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description |
|---------------------------------------|-------------------------------------|-------------|--------------------|---|
| DC Level Sweep (Signal Generation) | Output | | | Select the output channel. |
| | Sweep Config | Start | | Set the start value for the sweep parameter. |
| | | Stop | | Set the stop value for the sweep parameter. |
| | | Spacing | | Select Log, Linear, or Custom for the sweep spacing. |
| | | Points | | Set the number of sweep points. |
| | | Step Size | | Set the step size for linear spacing. This setting is only available when spacing is set to Linear. |
| | | Dwell Time | | Set the delay between the sweep points. |
| | Sweep Config | Edit Points | Point No | Set the point number. |
| | | | Point Value | Set the point value. |
| | | | Insert Point Above | Insert a point above the selected point. |
| | | | Insert Point Below | Insert a point below the selected point. |
| | | | Remove Point | Remove the selected point. |
| | | | Clear | Clear all points. |
| | | | Reverse Order | Reverse the order of the points. |
| | | | Sort | Sort the points in ascending order. |
| | | | Load Points | Load points from a file. Refer to “Appendix 13: Recall Menu Tree” on page 496 for the recall menu tree. |
| | | | Save Points | Save the points to a file. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. |
| | DC Level Sweep (Signal Analysis) | LPF | - None | Select the low-pass filter. |
| | | | - 2 kHz | |
| | | | - 3 kHz | |
| - 5 kHz | | | | |
| - 8 kHz | | | | |
| - 10 kHz | | | | |
| - 15 kHz | | | | |
| - 20 kHz | | | | |
| - 22 kHz | | | | |
| - 30 kHz | | | | |
| - 40 kHz | | | | |
| - 50 kHz | | | | |
| - 80 kHz | | | | |
| - Custom | | | | |

Table A-32 Measurement settings > DC Level Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|-------------------------------------|---------------|-----------------------|--|------------------------------|--------------------------------|
| DC Level Sweep (Signal Analysis) | HPF | - None | | Select the high-pass filter. | |
| | | - 15 Hz | | | |
| | | - 20 Hz | | | |
| | | - 22 Hz | | | |
| | | - 30 Hz | | | |
| | | - 50 Hz | | | |
| | | - 70 Hz | | | |
| | | - 100 Hz | | | |
| - 200 Hz | | | | | |
| - 300 Hz | | | | | |
| - 400 Hz | | | | | |
| - Custom | | | | | |
| Weighting | - None | | Select the weighting filter. | | |
| | - A | | | | |
| | - CCIR 1k | | | | |
| | - CCIR 2k | | | | |
| | - CCITT | | | | |
| | - C-Message | | | | |
| | - Custom | | | | |
| | Deemphasis | - None | | | Select the de-emphasis filter. |
| | | - 50 μ s | | | |
| | | - 75 μ s | | | |
| - Custom | | | | | |
| Sample Size | - 2048 | | Select the number of samples to be acquired for the measurement. | | |
| | - 4096 | | | | |
| | - 8192 | | | | |
| | - 16384 | | | | |
| | - 32768 | | | | |
| | - 65536 | | | | |
| | - 131072 | | | | |
| | - 262144 | | | | |
| | - 524288 | | | | |
| | - 1M | | | | |
| - 2M | | | | | |
| Input Range | Auto Range | - On - Off | Enable or disable the auto input range. | | |
| | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. | | |
| | Voltage Range | | Set the input voltage range. | | |
| DC Level | | | Refer to “Graph” on page 551 for the graph menu tree. | | |

Receiver sensitivity

Table A-33 Measurement settings > Receiver Sensitivity menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description |
|---|---|------------------------------|---------|--|
| Receiver Sensitivity (Signal Generation) | Instrument | - Keysight E4438C - Other | | Select the signal generator model. |
| | GPIB address | | | Set the GPIB address for the connected signal generator. |
| | Start Power | | | Set the sweep start RF power. |
| | Stop Power | | | Set the sweep stop RF power. |
| | Step Size | | | Set the step size. |
| | Dwell Time | | | Set the delay between each measured SINAD in seconds. |
| | Init Instrument | - On - Off | | Enable or disable the U8903B to send SCPI commands to initialize the connected signal generator. |
| | FM Frequency | | | Set the RF signal output frequency. This setting is only available if Instrument is set to Keysight E4438C and the Init Instrument is enabled. |
| | FM Deviation | | | Set the RF signal frequency modulation deviation. This setting is only available if Instrument is set to Keysight E4438C and the Init Instrument is enabled. |
| | FM Rate | | | Set the RF signal internal frequency modulation rate. This setting is only available if Instrument is set to Keysight E4438C and the Init Instrument is enabled. |
| | Init SCPI | - Edit - Import | | Set the SCPI commands that initialize the connected signal generator. You can set the SCPI command directly or load from a file. This setting is only available if Instrument is set to Other and the Init Instrument is enabled. |
| | Output Power SCPI | | | Set the SCPI command that adjusts the RF power of the connected signal generator. |
| | Receiver Sensitivity (Signal Analysis) | Meas Channel | | |
| Target SINAD | | | | Set the target SINAD value measured from the Meas Channel. |
| Min 1st Value | | | | Set the minimum first value. |
| Stop Condition | | - Until End - On Target | | Select the stop condition. |
| Freq Lock | | - Auto - Custom | | Select the searching method for the fundamental frequency. |

Table A-33 Measurement settings > Receiver Sensitivity menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|---|-----------|--|--|---|
| Receiver Sensitivity (Signal Analysis) | Fund Freq | | | Set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. |
| | | | <ul style="list-style-type: none"> - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz | |
| | LPF | | <ul style="list-style-type: none"> - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom | Select the low-pass filter. |
| | | | <ul style="list-style-type: none"> - None - 15 Hz - 20 Hz - 22 Hz - 30 Hz - 50 Hz - 70 Hz - 100 Hz - 200 Hz - 300 Hz - 400 Hz - Custom | |
| | HPF | | | Select the high-pass filter. |
| | | | <ul style="list-style-type: none"> - None - A - CCIR 1k - CCIR 2k - CCITT - C-Message - Custom | Select the weighting filter. |
| | | <ul style="list-style-type: none"> - None - 50 μs - 75 μs - Custom | Select the de-emphasis filter. | |

Table A-33 Measurement settings > Receiver Sensitivity menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|---|-------------------|---|-----------------------|--|
| Receiver Sensitivity (Signal Analysis) | Notch Filter | HP8903B | - On - Off | Enable or disable the HP8903B notch filter mode. |
| | | Custom Notch | - On - Off | Enable or disable custom notch filter. |
| | | Center Freq | | Set the center frequency value. This is only available when the Custom Notch is enabled. |
| | | Bandwidth | | Set the bandwidth value. This is only available when the Custom Notch is enabled. |
| | Mov Average | | | Set the number of measurement readings to be used for the average calculation. |
| | Sample Size | - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M | | Select the number of samples to be acquired for the measurement. |
| | Input Range | Auto Range | - On - Off | Enable or disable the auto input range. |
| | | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | Voltage Range | | Set the input voltage range. |
| | SINAD Vs RF Power | | | Refer to " Graph " on page 551 for the graph menu tree. |

External level sweep

Table A-34 Measurement settings > External Level Sweep menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | | | | | |
|--|--------------------|--|---|--|--|--|---------------------------------|---|---|
| Stepped Level Sweep (Signal Generation) | Instrument | - Keysight 33220A | | Select the instrument model. | | | | | |
| | | - Keysight 33250A | | | | | | | |
| | | - Keysight 33500A | | | | | | | |
| | | - Keysight 33600A | | | | | | | |
| | | - Other | | | | | | | |
| | GPIB Address | - 0 to 30 | | Select the GPIB address. | | | | | |
| | Init Instrument | - On | | Enable or disable the U8903B to send SCPI commands to initialize the connected signal generator. | | | | | |
| | | - Off | | | | | | | |
| | Init SCPI | - Edit | | Set the SCPI commands that initialize the connected instrument. You can set the SCPI command directly or load from a file. | | | | | |
| | | - Import | | | | | | | |
| | Sweep SCPI | - Edit | | Set the sweep SCPI commands that initialize the connected instrument. You can set the SCPI command directly or load from a file. | | | | | |
| | | - Import | | | | | | | |
| | Start | | Start | | Set the start value for the sweep parameter. | | | | |
| | | Stop | | Stop | Set the stop value for the sweep parameter. | | | | |
| | | | Spacing | | Spacing | Select Log, Linear, or Custom for the sweep spacing. | | | |
| | | | | Points | | Points | Set the number of sweep points. | | |
| | | | | | Step Size | | Step Size | Set the step size for linear spacing. This setting is only available when spacing is set to Linear. | |
| | | | | | | Dwell Time | | Dwell Time | Set the delay between the sweep points. |
| | | | | | | | Sweep Config | | Point No |
| | | Point Value | Set the point value. | | | | | | |
| | Insert Point Above | Insert a point above the selected point. | | | | | | | |
| | Insert Point Below | Insert a point below the selected point. | | | | | | | |
| Edit Points | | Remove Point | Remove the selected point. | | | | | | |
| | | Clear | Clear all points. | | | | | | |
| | | Reverse Order | Reverse the order of the points. | | | | | | |
| | | Sort | Sort the points in ascending order. | | | | | | |
| | | Load Points | Load points from a file. Refer to " Appendix 13: Recall Menu Tree " on page 496 for the recall menu tree. | | | | | | |
| Edit Points | | Save Points | Save the points to a file. Refer to " Appendix 12: Save Menu Tree " on page 495 for the save menu tree. | | | | | | |

Table A-34 Measurement settings > External Level Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--|------------|--|---------|--|
| Stepped Level Sweep (Signal Analysis) | Freq Lock | - Auto - Gen Lock - Custom | | Select the searching method for the fundamental frequency. |
| | Fund Freq | | | Set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. |
| | LPF | - None - 2 kHz - 3 kHz - 5 kHz - 8 kHz - 10 kHz - 15 kHz - 20 kHz - 22 kHz - 30 kHz - 40 kHz - 50 kHz - 80 kHz - Custom | | Select the low-pass filter. |
| | HPF | - None - 15 Hz - 20 Hz - 22 Hz - 30 Hz - 50 Hz - 70 Hz - 100 Hz - 200 Hz - 300 Hz - 400 Hz - Custom | | Select the high-pass filter. |
| | Weighting | - None - A - CCIR 1k - CCIR 2k - CCITT - C-Message - Custom | | Select the weighting filter. |
| | Deemphasis | - None - 50 μ s - 75 μ s - Custom | | Select the de-emphasis filter. |
| | | | | |
| | | | | |

Table A-34 Measurement settings > External Level Sweep menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|--|--------------|--------------|---|---|--|
| Stepped Level Sweep (Signal Analysis) | Notch Filter | HP8903B | - On - Off | Enable or disable the HP8903B mode. | |
| | | Custom Notch | - On - Off | Enable or disable the custom notch. | |
| | | Center Freq | | Set the center frequency value. This is only applicable when custom notch is enabled. | |
| | | Bandwidth | | Set the bandwidth value. This is only applicable when custom notch is enabled. | |
| | Sample Size | | - 2048 - 4096 - 8192 - 16384 - 32768 - 65536 - 131072 - 262144 - 524288 - 1M - 2M | | Select the number of samples to be acquired for the measurement. |
| | | Input Range | Auto Range | - On - Off | Enable or disable the auto input range. |
| | | | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | | Voltage Range | | Set the input voltage range. |
| | | | - AC Level - Gain - THD Ratio - THD Level - THD Ratio Vs Measured Amplitude - THD Level Vs Measured Amplitude - THD+N ratio - THD+N Level - THD+N Ratio Vs Measured Amplitude - THD+N Level Vs Measured Amplitude - SINAD | | Refer to “ Graph ” on page 551 for the graph menu tree. |

Measurement recorder

Table A-35 Measurement settings > Measurement Recorder menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|---|-----------------|----------------------------------|-----------------------|---|--|
| Measurement Recorder (Signal Generation) | Waveform | - Sine | | Select the waveform type. | |
| | | - Variable Phase | | | |
| | - Square | | | | |
| | - Arbitrary | | | | |
| | Output | | | Select the output channel. | |
| | Waveform Config | Track 1st Ch | - Enable - Disable | | Enable or disable the tracking of the first channel. |
| | | Frequency | | | Set the frequency value. |
| | | Amplitude | | | Set the amplitude value. |
| | | DC Offset | | | Set the DC offset value. |
| | Duration | | | | Set the length of the measurement record, |
| Ref Channel | | | | Set the reference channel number. | |
| Wrap Phase | | - On - Off | | Enable or disable the wrap phase. | |
| Freq Lock | | - Auto - Gen Lock - Custom | | Select the searching method for the fundamental frequency. | |
| Fund Freq | | | | Set the fundamental frequency value. This setting is only available when Freq Lock is set to Custom. | |
| Measurement Recorder (Signal Analysis) | LPF | - None | | Select the low-pass filter. | |
| | | - 2 kHz | | | |
| | | - 3 kHz | | | |
| | | - 5 kHz | | | |
| | | - 8 kHz | | | |
| | | - 10 kHz | | | |
| | | - 15 kHz | | | |
| | | - 20 kHz | | | |
| | | - 22 kHz | | | |
| | | - 30 kHz | | | |
| | - 40 kHz | | | | |
| - 50 kHz | | | | | |
| - 80 kHz | | | | | |
| - Custom | | | | | |

Table A-35 Measurement settings > Measurement Recorder menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|--|---------|---------------|-----------------------|--|
| Measurement Recorder (Signal Analysis) | HPF | - None | | Select the high-pass filter. |
| | | - 15 Hz | | |
| | | - 20 Hz | | |
| | | - 22 Hz | | |
| | | - 30 Hz | | |
| | | - 50 Hz | | |
| | | - 70 Hz | | |
| | | - 100 Hz | | |
| Weighting | | - 200 Hz | | Select the weighting filter. |
| | | - 300 Hz | | |
| | | - 400 Hz | | |
| | | - Custom | | |
| | | - None | | |
| | | - A | | |
| Deemphasis | | - CCIR 1k | | Select the de-emphasis filter. |
| | | - CCIR 2k | | |
| | | - CCITT | | |
| | | - C-Message | | |
| | | - Custom | | |
| | | - None | | |
| Sample Size | | - 50 μ s | | Select the number of samples to be acquired for the measurement. |
| | | - 75 μ s | | |
| | | - Custom | | |
| | | - 2048 | | |
| | | - 4096 | | |
| | | - 8192 | | |
| | | - 16384 | | |
| | | - 32768 | | |
| | | - 65536 | | |
| | | - 131072 | | |
| | | - 262144 | | |
| | | - 524288 | | |
| Input Range | | - 1M | | Enable or disable the auto input range. |
| | | - 2M | | |
| | | Auto Range | - On - Off | |
| Input Range | | Track 1st Ch | - Enable - Disable | Enable or disable the tracking of the first channel. |
| | | Voltage Range | | Set the input voltage range. |

Table A-35 Measurement settings > Measurement Recorder menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|---------------|---------|---------|---------|---|
| - AC Level | | | | |
| - Gain, Phase | | | | |
| - THD+N Ratio | | | | |
| - THD+N Level | | | | Refer to "Graph" on page 551 for the graph menu tree. |
| - DC Level | | | | |
| - Frequency | | | | |
| - SINAD | | | | |

Voice Quality

Table A-36 Measurement settings > Voice Quality menu tree description

| Tab | Level 1 | Level 2 | Level 3 | Description | |
|---------------|--------------|-------------------------------|--|---|---|
| Voice Quality | Test Config | Standard | POLQA | Select POLQA as the test standard. | |
| | | Bandwidth | - Narrowband | Select Narrowband or Super Wideband as the bandwidth type for POLQA standard. | |
| | | | - Wideband | | |
| | | | - Super Wideband (POLQA standard) | | |
| | | Level Align | | Enable or disable the automatic level alignment. This setting is only applicable for POLQA standard. | |
| | | Reference | Source | - File - Generator | Select the reference source to be used. |
| | | | Reference File | - Playback File - Recorded - Custom File | Use the Reference File as the comparison file if the Source is set to File. Use the Reference File option as the comparison file if the Source is set to Generator. |
| | | | Playback File | | This setting is only available when the Reference Source is set to Generator. Set the playback file to be used as the comparison file if Reference File is set to Playback File. Set the playback file to be recorded as the comparison file if Reference File is set to Recorded. Set the playback file to be recorded and the Custom File to be used as the comparison file if Reference File is set to Custom. |
| | | | Custom File | | Set the custom file to be used as the comparison file. This setting is only available when Reference Source is set to Generator and Reference File is set to Custom. |
| | Rec Channel | | | Set the channel number to be recorded from. This setting is only available when Source is set to Generator and Reference File is set to Recorded. | |
| | Rec Duration | | Set the recording duration to be recorded. This setting is only available when Source is set to Generator and Reference File is set to Recorded. | | |
| | Rec Step | - Auto - Delay - Prompt | Set the start recording type. This setting is only available when Source is set to Generator and Reference File is set to Recorded. | | |
| | Rec Delay | | Set the delay time before a recording is performed. This setting is only available when Source is set to Generator, Reference File is set to Recorded, and Rec Step is set to Delay. | | |
| | Rec to File | - Yes - No | Enable or disable exporting the recording function. This setting is only available when Source is set to Generator and Reference File is set to Recorded. | | |

Table A-36 Measurement settings > Voice Quality menu tree description (continued)

| Tab | Level 1 | Level 2 | Level 3 | Description |
|---------------|-------------------------|---------------|--|--|
| Voice Quality | Reference | Rec File | | Set the file path for the exported recording destination. This setting is only available when Source is set to Generator, Reference File is set to Recorded, and Rec To File is set to Yes. |
| | Degraded | Source | - File - Analyzer | Select file or analyzer as the reference source. |
| | | Degraded File | | Set the degraded file as the comparison file. This setting is only available when Source is set to File. |
| | | Rec Channel | | Set the channel number to be recorded from. This setting is only available when Source is set to Analyzer. |
| | | Rec Duration | | Set the recording duration to be recorded. This setting is only available when Source is set to Analyzer. |
| | | Rec Step | - Auto - Delay - Prompt | Set the start recording type. This setting is only available when Source is set to Analyzer. |
| | | Rec Delay | | Set the delay time before a recording is performed. This setting is only available when Source is set to Analyzer and Rec Step is set to Delay. |
| | | Rec to File | - Yes - No | Enable or disable exporting the recording function. This setting is only available when Source is set to Analyzer. |
| | | Rec File | | Set the file path for the exported recording destination. Set the file path for the exported recording destination. This setting is only available when Source is set to Analyzer and Rec To File is set to Yes. |
| | | IO Config | Output Level | Set the output level value. |
| | Show/Hide POLQA License | | Show or hide the POLQA license information. | |
| | - MOS- LQO - Levels | | Refer to “ Bar chart ” on page 550 for the bar chart menu tree. | |

Measurement results

Bar chart

Table A-37 Measurement Results > Bar chart menu tree description

| Level 1 | Level 2 | Level 3 | Description |
|------------------|-------------|-----------------------|--|
| Enable | | | Enable or disable the selected result tab. |
| Add Result | | | Add a new result tab to the measurement. |
| Delete Result | | | Delete the selected result tab from the measurement. |
| Save Data | | | Save the selected result data to a CSV file format in the internal storage or external USB flash storage. Refer to “Appendix 12: Save Menu Tree” on page 495 for the save menu tree. |
| Edit Limits | Track 1st | - Enable - Disable | Enable or disable the tracking of the first trace. |
| | Lower limit | - Enable - Disable | Enable or disable the lower limit. |
| | Upper limit | - Enable - Disable | Enable or disable the upper limit. |
| | Lower limit | | Set the lower limit value. |
| | Upper limit | | Set the upper limit value. |
| Graph Properties | Title | | Edit the bar chart title. |
| | X-axis | Auto Scale | Enable or disable the X-axis autoscale. On Off |
| | | Unit | Select the X-axis unit type. |
| | | Left | Set the X-axis left value. This setting is only available when the Autoscale is disabled. |
| | | Right | Set the X-axis right value. This setting is only available when the Autoscale is disabled. |

Graph

Table A-38 Measurement results > Graph menu tree description

| Level 1 | Level 2 | Level 3 | Description |
|---------------|------------|---|--|
| Enable | | | Enable or disable the selected result tab. |
| Add Result | | | Add a new result tab to the measurement. |
| Delete Result | | | Delete the selected result tab from the measurement. |
| Save Data | | | Save the selected result data to a CSV file format in the internal storage or external USB flash storage. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. |
| | Trace | <ul style="list-style-type: none"> - CH1 to CH8 - POLQA - Reference - Degraded - Error | Select the trace channel number or the trace type (POLQA) |
| | Limit Type | <ul style="list-style-type: none"> - Upper - Lower | Select the limit type. |
| | Track 1st | <ul style="list-style-type: none"> - Enable - Disable | Enable or disable the tracking of the first trace. |
| Edit Limits | Limit | <ul style="list-style-type: none"> - Enable - Disable | Enable or disable the limit. |
| | | Point No | Set the point number. |
| | | X | Set the X-axis value for the selected point number. |
| | | Y | Set the Y-axis value for the selected point number. |
| | Points | Add Point | Add a limit point. |
| | | Remove Point | Remove the selected limit point. |
| | | Clear Points | Clear all the limit points. |
| | | Load Points | Load limit points from a file. Refer to “ Appendix 13: Recall Menu Tree ” on page 496 for the recall menu tree. |
| Edit Limits | Points | Save Points | Save the selected limit points to a file. Refer to “ Appendix 12: Save Menu Tree ” on page 495 for the save menu tree. |

Table A-38 Measurement results > Graph menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description | |
|------------------|---------|------------|---|--|
| Graph Properties | Title | | Edit the graph title. | |
| | X-axis | Auto Scale | Enable or disable the X-axis autoscale. - On - Off | |
| | | Spacing | Select the X-axis spacing type. - Log - Linear | |
| | | Unit | Select the X-axis unit type. | |
| | | Left | Set the X-axis left value. This setting is only available when the X-axis autoscale is disabled. | |
| | | Right | Set the X-axis right value. This setting is only available when the X-axis autoscale is disabled. | |
| | | Center | Set the X-axis center value. This setting is only available when the X-axis autoscale is disabled. | |
| | | Span | Set the X-axis span value. This setting is only available when the X-axis autoscale is disabled. | |
| | Y-axis | Auto Scale | Enable or disable the Y-axis autoscale. - On - Off | |
| | | Spacing | Select the Y-axis spacing type. - Log - Linear | |
| | | Unit | Select the Y-axis unit type. | |
| | Y-axis | Top | Set the Y-axis bottom value. This setting is only available when the Y-axis autoscale is disabled. | |
| | | Bottom | Set the Y-axis top value. This setting is only available when the Y-axis autoscale is disabled. | |
| | Trace | Trace | Select the analyzer trace channel. - CH1 to CH8 | |
| | | State | Enable or disable the trace. - On - Off | |
| | | Color | | Select the trace color. - Yellow - Cyan - White |
| | | | | - Pink - Green - Orange |
| | | | | - Red - Purple |

Table A-38 Measurement results > Graph menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|---|------------|---------------|---|
| | Title | | Edit the graph title. |
| | Auto Scale | - On - Off | Enable or disable the X-axis autoscale. |
| Graph Properties (This is only applicable for POLQA measurement MOS-LQO and Delay results) | Left | | Set the X-axis left edge value. This setting is only available when the Autoscale is disabled. |
| | Right | | Set the X-axis right edge value. This setting is only available when the Autoscale is disabled. |
| | Top | | Set the X-axis top edge value. This setting is only available when the Autoscale is disabled. |
| | Bottom | | Set the Y-axis bottom edge value. This setting is only available when the Autoscale is disabled. |

Appendix 15: HP8903B Menu Tree

Table A-39 HP8903B menu tree description

| Level 1 | Level 2 | Level 3 | Description |
|-------------|---------------|----------------------------|---|
| Measurement | Function | - AC LEVEL | Select the HP8903B measurement mode. |
| | | - SINAD | |
| | - DISTN | | |
| | - DC LEVEL | | |
| | - SIG / NOISE | | |
| | - DISTN LEVEL | | |
| | LP Filter | - None | |
| | - 30 kHz | | |
| | - 80 kHz | | |
| | HP/W Filter | | Select the HP8903B high-pass or weighting filter value. The filter selection depends on the left and right filters set at HP8903B Config . |
| | Reference | | Set the reference value to be compared with the measured value in ratio mode. Changing the reference value will enable the measurement ratio mode. |
| | Ratio | - On - Off | Enable or disable the HP8903B measurement ratio mode. |
| | Format | - Log - Lin | Select the HP8903B measurement format type. |
| Generator | Frequency | | Set the HP8903B generator frequency value. Changing the frequency value will also set the step parameter to frequency. |
| | Amplitude | | Set the HP8903B generator amplitude value. Changing the amplitude value will also set the step parameter to amplitude. |
| | Step Param | - Frequency - Amplitude | Select the HP8903B generator step parameter type. |
| Generator | Freq. Step | | Set the HP8903B generator frequency step value. This setting is only available when the step parameter is set to frequency. |
| | Amp. Step | | Set the HP8903B generator amplitude step value. This setting is only available when the step parameter is set to amplitude. |
| | x 10 | | Multiply the current parameter step value by 10. |
| | ÷ 10 | | Divide the current parameter step value by 10. |
| Sweep | Freq. Start | | Set the HP8903B sweep frequency start value. |
| | Freq. Stop | | Set the HP8903B sweep frequency stop value. |
| | Sweep Status | - On - Off | Start or abort sweeping in the HP8903B mode. |

Table A-39 HP8903B menu tree description (continued)

| Level 1 | Level 2 | Level 3 | Description |
|-----------|---|---------|---|
| | <ul style="list-style-type: none"> - None - Input Level Range (except DC Level) - Input Level Range (DC Level only) - Post Notch Detector Response (except in SINAD) - Display Source Settings - Re-enter Ratio Mode - Signal-to-Noise Measurement Delay - SINAD and Signal-to-Noise Display Resolution - Sweep Resolution (maximum 255 points/sweep) - Display Level in Watts - Read Display to SCPI - GPIB Address (SCPI only) - GPIB Service Request Condition (SCPI only) - Source Output Impedance (Instrument powers up at 600 Ω) | | Select the HP8903B special function codes list to be displayed. |
| Code List | | | |
| SPCL | | | Set the HP8903B special function code except those indicated as SCPI only and execute the special function. |

Appendix 16: Units of the Measurement Function Returned Values

Analog analyzer

Table A-40 Analog analyzer units of the measurement function returned values

| Measurement function | Unit | Default |
|--|-----------------------------|---------|
| Frequency | - Hz | Hz |
| | - ΔHz | |
| AC voltage THD+N level THD level | - dBg | V |
| | - dBm | |
| | - dB _r | |
| | - dB _u | |
| | - dBV | |
| | - W | |
| | - V | |
| | - ΔV | |
| | - dB SPL | |
| | - x | |
| DC voltage | - V | V |
| | - ΔV | |
| | - x | |
| THD+N ratio SINAD THD ratio SMPTE IMD DFD IEC 60118 (2nd order) DFD IEC 60118 (3rd order) DFD IEC 60268 (2nd order) DFD IEC 60268 (3rd order) SNR SNR (Fast) Crosstalk | - dB - ΔdB - % - x | dB |
| Phase | ° | ° |

Digital analyzer

Table A-41 Digital analyzer units of the measurement function returned values

| Measurement function | Unit | Default |
|---|--|---------|
| Frequency | - Hz - ΔHz | Hz |
| AC voltage Max peak value Min peak value | - V - dBFS - dBr - dBu - dBV - FFS - x - pctFS - LSB - Hex - Dec | FFS |
| DC voltage | - FFS - V - LSB - Hex - Dec - x | FFS |
| THD+N level THD level | - V - dBFS - dBr - dBu - dBV - FFS - x - pctFS - LSB - Hex - Dec | dBFS |
| THD+N ratio SINAD SMPTE IMD DFD IEC 60118 (2nd order) DFD IEC 60118 (3rd order) DFD IEC 60268 (2nd order) DFD IEC 60268 (3rd order) Crosstalk (channel driven) | - dB - ΔdB - % - x | dB |
| Phase | ° | ° |

Bluetooth analyzer

Table A-42 Bluetooth analyzer units of the measurement function returned values

| Measurement function | Unit | Default |
|---|--|---------|
| Frequency | - Hz - ΔHz | Hz |
| AC voltage | - V - dBFS - dBr - dBu - dBV - FFS - x - pctFS - LSB - Hex - Dec | FFS |
| DC voltage | - FFS - V - LSB - Hex - Dec - x | FFS |
| THD+N level THD level | - V - dBFS - dBr - dBu - dBV - FFS - x - pctFS - LSB - Hex - Dec | dBFS |
| THD+N ratio SINAD SMPTE IMD DFD IEC 60118 (2nd order) DFD IEC 60118 (3rd order) DFD IEC 60268 (2nd order) DFD IEC 60268 (3rd order) Crosstalk (channel driven) SNR (Fast) | - dB - ΔdB - % - x | dB |
| Phase | ° | ° |

The units can be computed using the following formulas.

Table A-43 Unit conversion formula

| Unit | Formula | Description |
|------|---|---|
| ΔHz | $f - f_{ref}$ | f_{ref} = Reference frequency |
| dB | $20 \times \log_{10}(\text{ratio})$ | - |
| ΔdB | $(\text{ratio}) - R_{ref}$ | R_{ref} = Reference ratio |
| dBg | $20 \times \log_{10} \left(\frac{V_{rms}}{V_{gen}} \right)^2$ | V_{gen} = Amplitude of the generator signal for a corresponding channel |
| dBm | $10 \times \log_{10} \left(\frac{1000 V_{rms}^2}{Z_{ref}} \right)$ | Z_{ref} = Reference impedance |
| dBv | $20 \times \log_{10} \left(\frac{V_{rms}}{V_{ref}} \right)^2$ | V_{ref} = Reference level |
| dBu | $20 \times \log_{10} \left(\frac{V_{rms}}{\sqrt{0.6}} \right)$ | - |
| dBv | $20 \times \log_{10}(V_{rms})$ | - |
| W | $\frac{V}{Z_{ref}}$ | Z_{ref} = Reference impedance ^[a] |
| ΔV | $V - V_{ref}$ | V_{ref} = Reference level ^[b] |
| x | $\frac{V}{V_{ref}}$ | V_{ref} = Reference level ^[b] |
| | or $\frac{\text{Ratio (in \%)}}{R_{ref} \text{ (in \%)}}$ | R_{ref} = Reference ratio |
| % | $100 \times (\text{ratio})$ | - |

[a] When the V_{rms} measurement unit is changed to Watt or dBm, the reference impedance setting will be used for the power level calculation. The reference impedance refers to the circuitry impedance or load impedance connected to the analyzer when calculating power level. Note that in a loopback test with no load impedance, the measured voltage value will be twice the expected value as there is no voltage divider present. This will return a power measurement greater than 6.02 dB if a load is present.

[b] Reference level is defined as a user-entered or a captured value from the current reading as a relative level for the subsequent measurement reading. It can be set to delta, linear, or log scale.

Units for digital audio measurements

Table A-44 Units for digital audio measurements

| Unit | Description |
|---------|---|
| FFS | Fractional of Full Scale |
| %FS | Percent of Full Scale |
| dBFS | Decibels relative to Full Scale |
| LSB | Least Significant Bit |
| FS/Vrms | Ratio between cross-domain input and output levels measurements (analog input and digital output) |
| Vrms/FS | Ratio between cross-domain input and output levels measurements (digital input and analog output) |

Appendix 17: Arbitrary File Format

The U8903B arbitrary waveform mode allows you to load an arbitrary file or a wave file. To load waveform file for the analog arbitrary waveform, press the **Waveform Config** > **Recall** softkeys. The Recall menu page will be displayed to allow you to select the file to be loaded. Once you load the waveform file, press the **Info** softkey in the Waveform Config menu page to display the arbitrary waveform information as shown in **Figure A-1**.



Figure A-1 Analog Generator > Waveform Config > Info menu page (arbitrary waveform)

You may configure the arbitrary file format (*.arb) with the parameters as shown below.

```
#Vpeak: 2
#DC Offset: 0
#Points:
0
-0.2
-0.4
...
```

The allowable range of values for each arbitrary file parameters are as shown in **Table A-45**.

Table A-45 Allowable range for arbitrary file parameters

| Parameter | Range |
|------------------|--|
| Vpeak | - 0 to 22.6 Vp (Balanced output connection) - 0 to 11.3 Vp (Unbalanced or common output connection) |
| DC Offset | -11.3 V to 11.3 V |
| Points | 32 to 8000000 points |

NOTE

When the DC offset and amplitude are added together, it must not exceed the maximum voltage for the current output connection type:

- For the balanced output connection, $(V_{\text{peak}} + |\text{DC offset}|)$ must be within 0 V and 22.6 V.
- For the unbalanced and common mode output connections, $(V_{\text{peak}} + |\text{DC offset}|)$ must be within 0 V and 11.3 V.

The sampling rate for the arbitrary waveform is fixed at 192 kHz. Thus, the interval between samples is 1/192000 s.

For the following arbitrary file example, the highest numerical number of the sample points, which is 6, is output with the V_{peak} . The other samples are level-controlled according to their ratio to the maximum.

```
#Vpeak: 2
#DC offset: -3
#Points:
0
-1
-1.5
-1
0
2
4
6
4
2
...
```

Any of the following conditions may cause an error or warning message to appear.

- Unable to load the sample points, as the points may not be a valid float.
- Summation of the V_{peak} and DC offset exceeds the maximum voltage for the current output connection type.
- Invalid V_{peak} and DC offset values.
- Total of sample points less than 32.
- The arbitrary file does not exist.

Appendix 18: User-defined Filter File Format

Selecting Custom in either the low-pass, high-pass, or weighting filters menu enables you to load a user-defined filter file.

The available user-defined filter types are IIR (Infinite Impulse Response) and FIR (Finite Impulse Response). You need to specify the coefficients or sections as well as group delay for the respective filter type. Use the following examples to configure the filter file format. The file is saved in the *.juf format.

Example of an FIR filter file format is as follows.

```
#Type: FIR
#Delay: 250
#Coefficients:
0.00023394
-1.69E-05
-1.61E-05
-1.57E-05
...
```

The coefficients of the FIR filter are described as follows.

```
0.00023394 //A[0]
-1.69E-05 //A[1]
-1.61E-05 //A[2]
-1.57E-05 //A[3]
```

NOTE

The FIR filter transfer function, $H(z)$, is defined as:

$$H(z) = A[0] + A[1]z^{-1} + A[2]z^{-2} + A[3]z^{-3} + \dots$$

where z = complex variable

Example of an IIR filter file format is as follows.

```
#Type: IIR
#Delay: 250
#Sections:
0.02188812
1
-1.852219
0.9397715
1
2
1
0.02067037
1
-1.749171
0.8318526
1
2
1
...
```

The coefficients of the IIR filter are described as follows.

```
0.02188812 //Section 1: Gain1
1 //Section 1: A1[0]
-1.852219 //Section 1: A1[1]
0.9397715 //Section 1: A1[2]
1 //Section 1: B1[0]
2 //Section 1: B1[1]
1 //Section 1: B1[2]

[0.02067037 //Section 2: Gain2
1 //Section 2: A2[0]
-1.749171 //Section 2: A2[1]
0.8318526 //Section 2: A2[2]
1 //Section 2: B2[0]
2 //Section 2: B2[1]
1 //Section 2: B2[2]
```

where A_x = Denominator and B_x = Numerator

NOTE

The IIR filter transfer function, $H(z)$, is defined as:

$$H(z) = \prod_{x=1}^N \text{Gain}_x \left(\frac{B_x[0] + B_x[1]z^{-1} + B_x[2]z^{-2}}{A_x[0] + A_x[1]z^{-1} + A_x[2]z^{-2}} \right)$$

where z = complex variable, N = number of sections, x = section number

You may set up to 256 coefficients for the FIR filter type, and up to 36 sections for the IIR filter. The number of FIR coefficients must not be less than four, while the minimum number of sections allowed for IIR is one (seven coefficients). The delay is specified in the form of samples and within the range of 0 to 65535.

Appendix 19: DSI Input and Output Interface

The DSI input and output interface uses the 25-pin female D-SUB connector. The pins assignment for the connector are shown in **Figure A-2** and **Table A-46**.





Figure A-2 25-pin female D-SUB connector

Table A-46 25-pin female D-SUB connector pins assignment

| Pin no. | Label | Direction | Description |
|---------|-------------------|-----------|--|
| 1 | Master Clk Out | Out | Master clock out for digital audio |
| 2 | GND | - | Digital ground |
| 3 | DSI Gen Data-Out | Out | Digital generator DSI data output |
| 4 | DSI Gen FS-InOut | In/Out | DSI generator DSI frame sync |
| 5 | DSI Gen CLK-InOut | In/Out | DSI generator DSI bit clock |
| 6 | - | - | Unused |
| 7 | +5.0 V | - | +5.0 V supply with over-current protection |
| 8 | +3.3 V | - | +3.3 V supply with over-current protection |
| 9 | DSI Ana Data-In | In | Digital analyzer DSI data input |
| 10 | DSI Ana FS-InOut | In/Out | Digital analyzer DSI frame sync |
| 11 | DSI Ana Clk-InOut | In/Out | Digital analyzer DSI bit clock |
| 12 | GND | - | Digital ground |
| 13 | Sync Clock Out | Out | Sync clock output for AES3/SPDIF and DSI |
| 14 - 25 | GND | - | Digital ground |

Appendix 20: Digital System Clock Distribution Block Diagram

The digital system clock distribution block diagram is shown in **Figure A-3**.



PLL = Phase-Locked Loop

Figure A-3 Digital system clock distribution block diagram

Appendix 21: Typical DSI Test Configurations

The following sections describe the possible serial audio input and output configurations.

NOTE

Refer to “**Appendix 19: DSI Input and Output Interface**” on page 566 for more information on the pins assignment.

Configuration 1

In this configuration, the DUT uses the U8903B internal reference clock source as the reference clock. The DUT receives the clock references and data from the U8903B.

Press  on the FUNCTION panel to switch between audio generator or audio analyzer mode, and press  on the FUNCTION panel to switch to digital interface.




Figure A-4 DSI test configuration 1

- 1 At the digital generator, press **DSI Config > Master Clock**, and select **On** to enable the master clock.
- 2 At the digital generator, press **DSI Config > Sample Rate**, and set the sample rate.
- 3 At the digital generator, press **DSI Config > Word Length**, and set the word length. The bit clock rate is determined by the multiplication of the sample rate, word length, and number of channels.
- 4 At the digital generator, press **DSI Config > Multiplier**, and select the multiplier. The master clock rate is determined by the multiplication of the sample rate and multiplier.
- 5 At the digital generator, press **DSI Config > Fsync Polarity**, and select either **Rising** or **Falling** as the edge synchronization to the leading edge of the frame clock.

Configuration 2

In this configuration, the DUT uses an external master clock as the reference clock. The U8903B receives the data, frame sync, and bit clock from the DUT. A typical application for this configuration is analog to digital converter (ADC) evaluation.

Press **Generator Analyzer** on the FUNCTION panel to switch between audio generator or audio analyzer mode, and press **Interface** on the FUNCTION panel to switch to digital interface.




Figure A-5 DSI test configuration 2

- 1 At the digital analyzer, press **Input Config > Connector**, and select **DSI** as the digital analyzer input type.
- 2 At the digital generator, press **DSI Config > Master Clock**, and select **Off** to turn off the master clock.
- 3 At the digital analyzer, press **DSI Config > W/Bclk Dir**, and select **In** as the word and bit clock direction.

Configuration 3

In this configuration, an external master clock is used to synchronize the DUT and U8903B. A phase-locked loop (PLL) is used in the U8903B to lock the incoming master clock and regenerate the frame sync and bit clock. Data will be clocked in on each bit clock.

Press  on the FUNCTION panel to switch between audio generator or audio analyzer mode, and press  on the FUNCTION panel to switch to digital interface.




Figure A-6 DSI test configuration 3

- 1 At the digital analyzer, press **Input Config > Connector**, and select **DSI** as the digital analyzer input type.
- 2 At the digital generator, press **DSI Config > Master Clock**, and select **Off** to turn off the master clock.
- 3 At the digital analyzer, press **DSI Config > W/Bclk Dir**, and select **Out** as the word and bit clock direction.
- 4 At the digital generator, press **DSI Config > Multiplier**, and set the multiplier to determine the sampling rate.

Configuration 4

This configuration is similar to configuration 2, except that the DUT uses the U8903B internal reference clock source as the reference clock.

Press **Generator Analyzer** on the FUNCTION panel to switch between audio generator or audio analyzer mode, and press **Interface** on the FUNCTION panel to switch to digital interface.




Figure A-7 DSI test configuration 4

- 1 At the digital analyzer, press **Input Config > Connector**, and select **DSI** as the digital analyzer input type.
- 2 At the digital generator, press **DSI Config > Master Clock**, and select **On** to turn on the master clock.
- 3 At the digital analyzer, press **DSI Config > W/Bclk Dir**, and select **In** as the word and bit clock direction.
- 4 At the digital generator, press **DSI Config > Sample Rate**, and set the sample rate.
- 5 At the digital generator, press **DSI Config > Multiplier**, and set the multiplier to determine the master clock rate.

Configuration 5

This configuration is similar to configuration 3, except that the DUT uses the U8903B internal reference clock source as the reference clock.

Press **Generator Analyzer** on the FUNCTION panel to switch between audio generator or audio analyzer mode, and press **Interface** on the FUNCTION panel to switch to digital interface.




Figure A-8 DSI test configuration 5

- 1 Press **Input Config > Connector**, and select **DSI** as the digital analyzer input type.
- 2 At the digital generator, press **DSI Config > Master Clock**, and select **On** to turn on the master clock.
- 3 Press **DSI Config > W/Bclk Dir**, and select **Out** as the word and bit clock direction.

Appendix 22: U8903B Configuration Examples

Example 1: Generating a sine waveform with the digital generator and measuring its voltage with the digital analyzer

In this example, you will learn how to generate a simple sine waveform from the U8903B digital generator and measure its voltage using the U8903B digital analyzer.

To generate a sine waveform from the digital unbalanced output with a frequency of 1 kHz and amplitude of 1 FFS, perform the following steps.

- 1 Connect the digital generator unbalanced output to the digital analyzer unbalanced input channel in the rear panel using a BNC cable.
- 2 Press  on the FUNCTION panel to switch to audio generator mode, and press  on the FUNCTION panel to switch to digital interface.
- 3 Press **Waveform**, and select **Sine** as the waveform type.
- 4 Press **Output Config > Connector**, and select **Unbalanced** as the digital generator output type.
- 5 Press **Output Config > AES Output**, and enable the AES output.
- 6 Press **Waveform Config > Frequency**, and set the frequency to 1 kHz.
- 7 Press **Waveform Config > Amplitude**, and set the amplitude to 1 FFS.
- 8 Press  to start the signal generation on the digital generator channel 1.
- 9 After you have completed the steps above, the U8903B display should look as follows.



Figure A-9 Digital generator sine waveform generation

To measure the voltage of the sine waveform, perform the following steps.

- 1 Press  on the FUNCTION panel to switch to audio analyzer mode, and press  on the FUNCTION panel to switch to digital interface.
- 2 Press **Analysis Mode**, and select **Standard** as the digital analyzer analysis mode.
- 3 Press **Input Config > Connector**, and select **Unbalanced** as the digital analyzer input type.
- 4 Press **Functions > Function No.**, and select **1**.
- 5 Press **Functions > Function 1**, and select **Frequency** as the first measurement function.
- 6 Press **Functions > Function No.**, and select **2**.
- 7 Press **Functions > Function 2**, and select **AC Voltage** as the second measurement function.
- 8 Press  to start the signal measurement on the digital analyzer channel 1.

You should now obtain an AC voltage reading of 1 FFS for the generated sine waveform, within the tolerance as stated in “**Characteristics and Specifications**” on page 419. The U8903B display should look as follows.



Figure A-10 Digital analyzer voltage measurement

Example 2: Establishing a connection to a *Bluetooth* device and generating a sine waveform with the *Bluetooth* generator.

In this example, you will learn how to establish an A2DP profile connection to a *Bluetooth* device and generate a sine waveform with the U8903B's *Bluetooth* generator.

- 1 Connect the *Bluetooth* RF1 port to the DUT RF port using an RF cable.
- 2 Press  on the FUNCTION panel to switch to audio generator mode, and press  on the FUNCTION panel to switch to *Bluetooth* interface.
- 3 Press **Waveform**, and select **Sine** as the waveform type.
- 4 Press **Link Config > Common Settings**, and select **Profile** as A2DP SRC, HFP AG, AVRCP TRGT.
- 5 Press **Link Config > Device Scan**, and select **Device Search** to scan for all discoverable *Bluetooth* device.
- 6 Press **Link Config > Device Action**, and select the *Bluetooth* device to be paired. Press **Pair Device** to begin the pairing procedure.
- 7 Press **Link Config > Device Action**, and select **Profile Connection** as Connect A2DP to connect using the A2DP profile.
- 8 Press **Link Config > Device Action**, and select **A2DP Operation** as Open Media Connection to establish the media connection and start the audio streaming from the *Bluetooth* card to the connected device.
- 9 Press **Waveform Config > Frequency**, and set the frequency to 1 Vrms.
- 10 Press **Waveform Config > Amplitude**, and set the amplitude to 2 FFS.
- 11 Press  to start the signal generation on the *Bluetooth* generator channel 1.
- 12 After you have completed the steps above, the U8903B display should look as follows.





Figure A-11 Bluetooth generator sine waveform generation

Example 3: Generating a multitone waveform with the analog generator and viewing the multitone spectrum in the graph

In this example, you will learn how to generate a multitone waveform from the U8903B analog generator and view the multitone spectrum in the U8903B graph.

- 1 Connect the analog generator unbalanced output to the analog analyzer unbalanced input channel using a BNC cable.
- 2 Press  on the FUNCTION panel to switch to audio generator mode, and press  on the FUNCTION panel to switch to analog interface.
- 3 Press **Waveform**, and select **Multitone** as the waveform type.
- 4 Press **Output Config > Connector**, and select **Unbalanced** as the analog generator output type.
- 5 Press **Waveform Config > Amplitude**, and set the amplitude to 1 Vrms.
- 6 Press **Waveform Config > Start Freq.**, and set the start frequency to 937.5 Hz.
- 7 Press **Waveform Config > Stop Freq.**, and set the stop frequency to 5.0625 kHz.
- 8 Press  to start the signal generation on the analog generator channel 1.
- 9 Press  on the FUNCTION panel to switch to audio analyzer mode, and press  on the FUNCTION panel to switch to analog interface.
- 10 Press **Input Config > Connector**, and select **UnBal** as the analog analyzer input type.
- 11 Press  to start the signal measurement on the analog analyzer channel 1.
- 12 After you have completed the steps above, the U8903B display should look as follows.




Figure A-12 Analog analyzer multitone waveform measurement

To view the multitone spectrum in the U8903B graph, perform the following steps.

- 1 Press  on the FUNCTION panel to access the graph analysis mode.
- 2 Press  to enable the graph analysis mode.
- 3 Use the  function to select and measure the two-tone spectrum amplitude.
- 4 An example of the U8903B graph display is shown as follows.





Figure A-13 Graph analysis for multitone spectrum

Example 4: Running the Test Sequence App for the multitone analyzer measurement

In this example, you will learn how to use the Test Sequence App for the multitone analyzer measurement in the U8903B.

- 1 Press  to switch to Test Sequence App mode.
- 2 In the Project tab, press **Add Measurement**, and select **Multitone Analyzer** to be added for Test 1.
- 3 Press **Settings** to configure the multitone analyzer. For example, you can press **Waveform Config** to set the amplitude, and press **Tones Config** to set the start and stop frequency.
- 4 The multitone measurement results can be displayed in a graph (Spectrum, Waveform, Level, and Gain) and in a bar chart (Max Tone Level, Min Tone Level, TD+N Level, TD+N Ratio, and Tone Level). Refer to “**Multitone analyzer**” on page 345 for more information.
- 5 Press  and select **Start Test App** to begin the test sequence.
- 6 Depending on the settings parameter set for the multitone analyzer, the result will return as PASS or FAIL and is shown as follows.




Figure A-14 Test Sequence App result for multitone analyzer

- 7 Select the Report tab to view the test sequence results in the U8903B display. You can also save the result file as a .docx file type by pressing **Save**.



Figure A-15 Test Sequence App report for multitone analyzer

Example 5: Configuring the system clock reference settings

In this example, you will learn how to configure the U8903B system clock reference settings.

To configure the system clock reference source to external Master clock in with word length of 24 and multiplier of 192, perform the following steps.

- 1 Connect the external Master clock signal to the Sync In connector in the rear panel using a BNC cable.
- 2 Press  on the FUNCTION panel to switch to audio generator mode, and press  on the FUNCTION panel to switch to digital interface.
- 3 Press **Output Config > Ref Clock > Source**, and select **External** as the reference clock source.
- 4 Press **Output Config > Ref Clock > Type**, and select **MCLK** to set the external clock source type as Master clock.
- 5 Press **Output Config > Ref Clock > Word Length**, and set the Master clock word length to **24**.^{[1][2]}
- 6 Press **Output Config > Ref Clock > Multiplier**, and set the Master clock multiplier to **192**.^[3]

[1] Sampling rate constrains the master clock in word length values. Refer to “**Appendix 25: Word Length, Sampling Rate, and Multiplier for Master Clock In**” on page 591 for the range of word length that can be set with different sampling rate.

[2] When setting the word length, the error message, –221, “Settings conflict...” may be generated. This error message can be ignored as this is to notify that the word length or multiplier is auto adjusted to the nearest allowable value due to the settings conflict.

[3] Sampling rate and word length constrain the multiplier values. Refer to “**Appendix 25: Word Length, Sampling Rate, and Multiplier for Master Clock In**” on page 591 for the range of multiplier that can be set with different master clock in word length and sampling rate.

Example 6: Configuring the digital generator DSI output settings

In this example, you will learn how to configure the U8903B digital generator DSI output settings.

To configure the digital generator DSI output settings to DSP format, sampling rate of 192 kHz, word length of 24, and multiplier of 192, perform the following steps.

- 1 Press  on the FUNCTION panel to switch to audio generator mode, and press  on the FUNCTION panel to switch to digital interface.
- 2 Press **DSI Config > Format**, and select **DSP** as the DSI output format.
- 3 Press **DSI Config > Sample Rate**, and set the sampling rate to **192 kHz**.
- 4 Press **DSI Config > Word Length**, and set the DSI word length to **24**.^{[1][2]}
- 5 Press **DSI Config > Multiplier**, and set the DSI multiplier to **192**.^[3]

[1] Sampling rate constrains the DSI word length values. Refer to “**Appendix 24: Word Length, Sampling Rate, and Multiplier for DSI**” on page 585 for the range of word length that can be set with different sampling rate.

[2] When setting the word length, the error message, -221, “Settings conflict...” may be generated. This error message can be ignored as this is to notify that the word length or multiplier is auto adjusted to the nearest allowable value due to the settings conflict.

[3] Sampling rate and word length constrain the multiplier values. Refer to “**Appendix 24: Word Length, Sampling Rate, and Multiplier for DSI**” on page 585 for the range of multiplier that can be set with different DSI word length and sampling rate.

Appendix 23: Relationship between Digital Waveform Parameters and Channels

Table A-47 Relationship between digital waveform parameters and channels

| Waveform | Parameter | Channel |
|--|----------------------|--|
| Sine | Frequency | Channel 1 and Channel 2 are the same |
| | Amplitude | Channel 1 and Channel 2 can be different |
| | DC Offset | Channel 1 and Channel 2 are the same |
| Stereo | Frequency | Channel 1 and Channel 2 can be different |
| | Amplitude | Channel 1 and Channel 2 can be different |
| | DC Offset | Channel 1 and Channel 2 are the same |
| Square | Frequency | Channel 1 and Channel 2 are the same |
| | Amplitude | Channel 1 and Channel 2 can be different |
| | DC Offset | Channel 1 and Channel 2 are the same |
| Sine burst | Frequency | Channel 1 and Channel 2 are the same |
| | Amplitude | Channel 1 and Channel 2 can be different |
| | Burst On | Channel 1 and Channel 2 are the same |
| | Period | Channel 1 and Channel 2 are the same |
| | Low Level | Channel 1 and Channel 2 are the same |
| Variable phase | Frequency | Channel 1 and Channel 2 are the same |
| | Amplitude | Channel 1 and Channel 2 can be different |
| | Phase -> 1 | Channel 1 and Channel 2 are the same |
| Dual | Frequency 1 | Channel 1 and Channel 2 are the same |
| | Frequency 2 | Channel 1 and Channel 2 are the same |
| | Amplitude | Channel 1 and Channel 2 are the same |
| | Ratio | Channel 1 and Channel 2 are the same |
| | DC Offset | Channel 1 and Channel 2 are the same |
| SMPT E IMD 1:1/ 4:1/ 10:1 | Lower Frequency | Channel 1 and Channel 2 are the same |
| | Upper Frequency | Channel 1 and Channel 2 are the same |
| | Amplitude | Channel 1 and Channel 2 are the same |
| | DC Offset | Channel 1 and Channel 2 are the same |
| DFD IEC 60118 | Difference Frequency | Channel 1 and Channel 2 are the same |
| | Upper Frequency | Channel 1 and Channel 2 are the same |
| | Amplitude | Channel 1 and Channel 2 are the same |
| | DC Offset | Channel 1 and Channel 2 are the same |
| DFD IEC 60268 | Difference Frequency | Channel 1 and Channel 2 are the same |
| | Center Frequency | Channel 1 and Channel 2 are the same |
| | Amplitude | Channel 1 and Channel 2 are the same |
| | DC Offset | Channel 1 and Channel 2 are the same |
| Gaussian/Rectangular/ Triangular/Pink | Amplitude | Channel 1 and Channel 2 can be different |
| | DC Offset | Channel 1 and Channel 2 are the same |
| Constant | Amplitude | Channel 1 and Channel 2 are the same |

Table A-47 Relationship between digital waveform parameters and channels (continued)

| Waveform | Parameter | Channel |
|------------|--------------------------------------|--|
| Multitone | Amplitude | Channel 1 and Channel 2 can be different |
| | Start Frequency | Channel 1 and Channel 2 are the same |
| | Stop Frequency | Channel 1 and Channel 2 are the same |
| | Frequency Spacing | Channel 1 and Channel 2 are the same |
| | Count | Channel 1 and Channel 2 are the same |
| | Crest Factor | Channel 1 and Channel 2 can be different |
| | Tone Frequency | Channel 1 and Channel 2 are the same |
| | Tone Amplitude | Channel 1 and Channel 2 are the same |
| Tone Phase | Channel 1 and Channel 2 are the same | |
| Arbitrary | Amplitude | Channel 1 and Channel 2 can be different |
| | DC Offset | Channel 1 and Channel 2 are the same |

Appendix 24: Word Length, Sampling Rate, and Multiplier for DSI

Table A-48 Word Length, Sampling Rate, and Multiplier for DSI

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|---------------|
| 400 | 8 | 128 |
| 400 | 9 | 72, 144 |
| 400 | 10 | 80, 160 |
| 400 | 11 | 88, 176 |
| 400 | 12 | 96, 192 |
| 400 | 13 | 104, 208 |
| 400 | 14 | 112, 224 |
| 400 | 15 | 120, 240 |
| 400 | 16 | 64, 128 |
| 400 | 17 | 68, 136 |
| 400 | 18 | 72, 144 |
| 400 | 19 | 76, 152 |
| 400 | 20 | 80, 160 |
| 400 | 21 | 84, 168 |
| 400 | 22 | 88, 176 |
| 400 | 23 | 92, 184 |
| 400 | 24 | 96, 192 |
| 400 | 25 | 100, 200 |
| 400 | 26 | 104, 208 |
| 400 | 27 | 108, 216 |
| 400 | 28 | 112, 224 |
| 400 | 29 | 116, 232 |
| 400 | 30 | 120, 240 |
| 400 | 31 | 124, 248 |
| 400 | 32 | 128 |
| 200 | 8 | 128, 256 |
| 200 | 9 | 72, 144, 288 |
| 200 | 10 | 80, 160, 320 |
| 200 | 11 | 88, 176, 352 |
| 200 | 12 | 96, 192, 384 |
| 200 | 13 | 104, 208, 416 |

Table A-48 Word Length, Sampling Rate, and Multiplier for DSI (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|--------------------|
| 200 | 14 | 112, 224, 448 |
| 200 | 15 | 120, 240, 480 |
| 200 | 16 | 64, 128, 256 |
| 200 | 17 | 68, 136, 272 |
| 200 | 18 | 72, 144, 288 |
| 200 | 19 | 76, 152, 304 |
| 200 | 20 | 80, 160, 320 |
| 200 | 21 | 84, 168, 336 |
| 200 | 22 | 88, 176, 352 |
| 200 | 23 | 92, 184, 368 |
| 200 | 24 | 96, 192, 384 |
| 200 | 25 | 100, 200, 400 |
| 200 | 26 | 104, 208, 416 |
| 200 | 27 | 108, 216, 432 |
| 200 | 28 | 112, 224, 448 |
| 200 | 29 | 116, 232, 464 |
| 200 | 30 | 120, 240, 480 |
| 200 | 31 | 124, 248, 496 |
| 200 | 32 | 128, 256 |
| 100 | 8 | 128, 256, 512 |
| 100 | 9 | 72, 144, 288, 576 |
| 100 | 10 | 80, 160, 320, 640 |
| 100 | 11 | 88, 176, 352, 704 |
| 100 | 12 | 96, 192, 384, 768 |
| 100 | 13 | 104, 208, 416, 832 |
| 100 | 14 | 112, 224, 448, 896 |
| 100 | 15 | 120, 240, 480, 960 |
| 100 | 16 | 64, 128, 256, 512 |
| 100 | 17 | 68, 136, 272, 544 |
| 100 | 18 | 72, 144, 288, 576 |
| 100 | 19 | 76, 152, 304, 608 |
| 100 | 20 | 80, 160, 320, 640 |
| 100 | 21 | 84, 168, 336, 672 |

Table A-48 Word Length, Sampling Rate, and Multiplier for DSI (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|---------------------|
| 100 | 22 | 88, 176, 352, 704 |
| 100 | 23 | 92, 184, 368, 736 |
| 100 | 24 | 96, 192, 384, 768 |
| 100 | 25 | 100, 200, 400, 800 |
| 100 | 26 | 104, 208, 416, 832 |
| 100 | 27 | 108, 216, 432, 864 |
| 100 | 28 | 112, 224, 448, 896 |
| 100 | 29 | 116, 232, 464, 928 |
| 100 | 30 | 120, 240, 480, 960 |
| 100 | 31 | 124, 248, 496, 992 |
| 100 | 32 | 128, 256, 512 |
| 50 | 8 | 128, 256, 512, 1024 |
| 50 | 9 | 72, 144, 288, 576 |
| 50 | 10 | 80, 160, 320, 640 |
| 50 | 11 | 88, 176, 352, 704 |
| 50 | 12 | 96, 192, 384, 768 |
| 50 | 13 | 104, 208, 416, 832 |
| 50 | 14 | 112, 224, 448, 896 |
| 50 | 15 | 120, 240, 480, 960 |
| 50 | 16 | 64, 128, 256, 512 |
| 50 | 17 | 68, 136, 272, 544 |
| 50 | 18 | 72, 144, 288, 576 |
| 50 | 19 | 76, 152, 304, 608 |
| 50 | 20 | 80, 160, 320, 640 |
| 50 | 21 | 84, 168, 336, 672 |
| 50 | 22 | 88, 176, 352, 704 |
| 50 | 23 | 92, 184, 368, 736 |
| 50 | 24 | 96, 192, 384, 768 |
| 50 | 25 | 100, 200, 400, 800 |
| 50 | 26 | 104, 208, 416, 832 |
| 50 | 27 | 108, 216, 432, 864 |
| 50 | 28 | 112, 224, 448, 896 |
| 50 | 29 | 116, 232, 464, 928 |

Table A-48 Word Length, Sampling Rate, and Multiplier for DSI (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|---------------------|
| 50 | 30 | 120, 240, 480, 960 |
| 50 | 31 | 124, 248, 496, 992 |
| 50 | 32 | 128, 256, 512, 1024 |
| 25 | 8 | 128, 256, 512, 1024 |
| 25 | 9 | 72, 144, 288, 576 |
| 25 | 10 | 80, 160, 320, 640 |
| 25 | 11 | 88, 176, 352, 704 |
| 25 | 12 | 96, 192, 384, 768 |
| 25 | 13 | 104, 208, 416, 832 |
| 25 | 14 | 112, 224, 448, 896 |
| 25 | 15 | 120, 240, 480, 960 |
| 25 | 16 | 64, 128, 256, 512 |
| 25 | 17 | 68, 136, 272, 544 |
| 25 | 18 | 72, 144, 288, 576 |
| 25 | 19 | 76, 152, 304, 608 |
| 25 | 20 | 80, 160, 320, 640 |
| 25 | 21 | 84, 168, 336, 672 |
| 25 | 22 | 88, 176, 352, 704 |
| 25 | 23 | 92, 184, 368, 736 |
| 25 | 24 | 96, 192, 384, 768 |
| 25 | 25 | 100, 200, 400, 800 |
| 25 | 26 | 104, 208, 416, 832 |
| 25 | 27 | 108, 216, 432, 864 |
| 25 | 28 | 112, 224, 448, 896 |
| 25 | 29 | 116, 232, 464, 928 |
| 25 | 30 | 120, 240, 480, 960 |
| 25 | 31 | 124, 248, 496, 992 |
| 25 | 32 | 128, 256, 512, 1024 |
| 12.5 | 8 | 128, 256, 512, 1024 |
| 12.5 | 9 | 72, 144, 288, 576 |
| 12.5 | 10 | 80, 160, 320, 640 |
| 12.5 | 11 | 88, 176, 352, 704 |
| 12.5 | 12 | 96, 192, 384, 768 |

Table A-48 Word Length, Sampling Rate, and Multiplier for DSI (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|---------------------|
| 12.5 | 13 | 104, 208, 416, 832 |
| 12.5 | 14 | 112, 224, 448, 896 |
| 12.5 | 15 | 120, 240, 480, 960 |
| 12.5 | 16 | 64, 128, 256, 512 |
| 12.5 | 17 | 68, 136, 272, 544 |
| 12.5 | 18 | 72, 144, 288, 576 |
| 12.5 | 19 | 76, 152, 304, 608 |
| 12.5 | 20 | 80, 160, 320, 640 |
| 12.5 | 21 | 84, 168, 336, 672 |
| 12.5 | 22 | 88, 176, 352, 704 |
| 12.5 | 23 | 92, 184, 368, 736 |
| 12.5 | 24 | 96, 192, 384, 768 |
| 12.5 | 25 | 100, 200, 400, 800 |
| 12.5 | 26 | 104, 208, 416, 832 |
| 12.5 | 27 | 108, 216, 432, 864 |
| 12.5 | 28 | 112, 224, 448, 896 |
| 12.5 | 29 | 116, 232, 464, 928 |
| 12.5 | 30 | 120, 240, 480, 960 |
| 12.5 | 31 | 124, 248, 496, 992 |
| 12.5 | 32 | 128, 256, 512, 1024 |
| 6.75 | 8 | 128, 256, 512, 1024 |
| 6.75 | 9 | 72, 144, 288, 576 |
| 6.75 | 10 | 80, 160, 320, 640 |
| 6.75 | 11 | 88, 176, 352, 704 |
| 6.75 | 12 | 96, 192, 384, 768 |
| 6.75 | 13 | 104, 208, 416, 832 |
| 6.75 | 14 | 112, 224, 448, 896 |
| 6.75 | 15 | 120, 240, 480, 960 |
| 6.75 | 16 | 128, 256, 512 |
| 6.75 | 17 | 136, 272, 544 |
| 6.75 | 18 | 144, 288, 576 |
| 6.75 | 19 | 152, 304, 608 |
| 6.75 | 20 | 160, 320, 640 |

Table A-48 Word Length, Sampling Rate, and Multiplier for DSI (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|---------------------|
| 6.75 | 21 | 168, 336, 672 |
| 6.75 | 22 | 176, 352, 704 |
| 6.75 | 23 | 184, 368, 736 |
| 6.75 | 24 | 192, 384, 768 |
| 6.75 | 25 | 200, 400, 800 |
| 6.75 | 26 | 208, 416, 832 |
| 6.75 | 27 | 216, 432, 864 |
| 6.75 | 28 | 224, 448, 896 |
| 6.75 | 29 | 116, 232, 464, 928 |
| 6.75 | 30 | 120, 240, 480, 960 |
| 6.75 | 31 | 124, 248, 496, 992 |
| 6.75 | 32 | 128, 256, 512, 1024 |

[a] For sampling rate less than or equal to.

Appendix 25: Word Length, Sampling Rate, and Multiplier for Master Clock In

Table A-49 Word Length, Sampling Rate, and Multiplier for Master Clock In

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|--------------|
| 400 | 8 | 64, 128 |
| 400 | 9 | 72, 144 |
| 400 | 10 | 80, 160 |
| 400 | 11 | 88 |
| 400 | 12 | 96 |
| 400 | 13 | 104 |
| 400 | 14 | 112 |
| 400 | 15 | 120 |
| 400 | 16 | 64, 128 |
| 400 | 17 | 68, 136 |
| 400 | 18 | 72, 144 |
| 400 | 19 | 76 |
| 400 | 20 | 80 |
| 400 | 21 | 84 |
| 400 | 22 | 88 |
| 400 | 23 | 92 |
| 400 | 24 | 96, 192 |
| 400 | 25 | 100 |
| 400 | 26 | 104 |
| 400 | 27 | 108 |
| 400 | 28 | 112 |
| 400 | 29 | 116 |
| 400 | 30 | 120 |
| 400 | 31 | 124 |
| 400 | 32 | 128 |
| 200 | 8 | 64, 128, 256 |
| 200 | 9 | 72, 144, 288 |
| 200 | 10 | 80, 160 |
| 200 | 11 | 88, 176 |
| 200 | 12 | 96, 192 |

Table A-49 Word Length, Sampling Rate, and Multiplier for Master Clock In (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|-------------------|
| 200 | 13 | 104, 208 |
| 200 | 14 | 112, 224 |
| 200 | 15 | 120, 240 |
| 200 | 16 | 64, 128, 256 |
| 200 | 17 | 68, 136, 272 |
| 200 | 18 | 72, 144, 288 |
| 200 | 19 | 76, 152 |
| 200 | 20 | 80, 160 |
| 200 | 21 | 84, 168 |
| 200 | 22 | 88, 176 |
| 200 | 23 | 92, 184 |
| 200 | 24 | 96, 192 |
| 200 | 25 | 100, 200 |
| 200 | 26 | 104, 208 |
| 200 | 27 | 108, 216 |
| 200 | 28 | 112, 224 |
| 200 | 29 | 116, 232 |
| 200 | 30 | 120, 240 |
| 200 | 31 | 124, 248 |
| 200 | 32 | 128, 256 |
| 100 | 8 | 64, 128, 256, 512 |
| 100 | 9 | 72, 144, 288, 576 |
| 100 | 10 | 80, 160, 320 |
| 100 | 11 | 88, 176, 352 |
| 100 | 12 | 96, 192, 384 |
| 100 | 13 | 104, 208, 416 |
| 100 | 14 | 112, 224, 448 |
| 100 | 15 | 120, 240, 480 |
| 100 | 16 | 64, 128, 256, 512 |
| 100 | 17 | 68, 136, 272, 544 |
| 100 | 18 | 72, 144, 288, 576 |
| 100 | 19 | 76, 152, 304 |
| 100 | 20 | 80, 160, 320 |

Table A-49 Word Length, Sampling Rate, and Multiplier for Master Clock In (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|--------------------|
| 100 | 21 | 84, 168, 336 |
| 100 | 22 | 88, 176, 352 |
| 100 | 23 | 92, 184, 368 |
| 100 | 24 | 96, 192, 384 |
| 100 | 25 | 100, 200, 400 |
| 100 | 26 | 104, 208, 416 |
| 100 | 27 | 108, 216, 432 |
| 100 | 28 | 112, 224, 448 |
| 100 | 29 | 116, 232, 464 |
| 100 | 30 | 120, 240, 480 |
| 100 | 31 | 124, 248, 496 |
| 100 | 32 | 128, 256, 512 |
| 50 | 8 | 64, 128, 256, 512 |
| 50 | 9 | 72, 144, 288, 576 |
| 50 | 10 | 80, 160, 320, 640 |
| 50 | 11 | 88, 176, 352, 704 |
| 50 | 12 | 95, 192, 384, 768 |
| 50 | 13 | 104, 208, 416, 832 |
| 50 | 14 | 112, 224, 448, 896 |
| 50 | 15 | 120, 240, 480, 960 |
| 50 | 16 | 64, 128, 256, 512 |
| 50 | 17 | 68, 136, 272, 544 |
| 50 | 18 | 72, 144, 288, 576 |
| 50 | 19 | 76, 152, 304, 608 |
| 50 | 20 | 80, 160, 320, 640 |
| 50 | 21 | 84, 168, 336, 672 |
| 50 | 22 | 88, 176, 352, 704 |
| 50 | 23 | 92, 184, 368, 736 |
| 50 | 24 | 96, 192, 384, 768 |
| 50 | 25 | 100, 200, 400, 800 |
| 50 | 26 | 104, 208, 416, 832 |
| 50 | 27 | 108, 216, 432, 864 |
| 50 | 28 | 112, 224, 448, 896 |

Table A-49 Word Length, Sampling Rate, and Multiplier for Master Clock In (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|--------------------|
| 50 | 29 | 116, 232, 464, 928 |
| 50 | 30 | 120, 240, 480, 960 |
| 50 | 31 | 124, 248, 496, 992 |
| 50 | 32 | 128, 256, 512 |
| 25 | 8 | 64, 128, 256, 512 |
| 25 | 9 | 72, 144, 288, 576 |
| 25 | 10 | 80, 160, 320, 640 |
| 25 | 11 | 88, 176, 352, 704 |
| 25 | 12 | 96, 192, 384, 768 |
| 25 | 13 | 104, 208, 416, 832 |
| 25 | 14 | 112, 224, 448, 896 |
| 25 | 15 | 120, 240, 480, 960 |
| 25 | 16 | 64, 128, 256, 512 |
| 25 | 17 | 136, 272, 544 |
| 25 | 18 | 72, 144, 288, 576 |
| 25 | 19 | 152, 304, 608 |
| 25 | 20 | 80, 160, 320, 640 |
| 25 | 21 | 168, 336, 672 |
| 25 | 22 | 88, 176, 352, 704 |
| 25 | 23 | 184, 368, 736 |
| 25 | 24 | 96, 192, 384, 768 |
| 25 | 25 | 200, 400, 800 |
| 25 | 26 | 104, 208, 416, 832 |
| 25 | 27 | 216, 432, 864 |
| 25 | 28 | 112, 224, 448, 896 |
| 25 | 29 | 232, 464, 928 |
| 25 | 30 | 120, 240, 480, 960 |
| 25 | 31 | 248, 496, 992 |
| 25 | 32 | 128, 256, 512 |
| 12.5 | 8 | 64, 128, 256, 512 |
| 12.5 | 9 | 144, 288, 576 |
| 12.5 | 10 | 80, 160, 320, 640 |
| 12.5 | 11 | 176, 352, 704 |

Table A-49 Word Length, Sampling Rate, and Multiplier for Master Clock In (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|--------------------|
| 12.5 | 12 | 96, 192, 384, 768 |
| 12.5 | 13 | 208, 416, 832 |
| 12.5 | 14 | 112, 224, 448, 896 |
| 12.5 | 15 | 240, 480, 960 |
| 12.5 | 16 | 64, 128, 256, 512 |
| 12.5 | 17 | 272, 544 |
| 12.5 | 18 | 144, 288, 576 |
| 12.5 | 19 | 304, 608 |
| 12.5 | 20 | 160, 320, 640 |
| 12.5 | 21 | 336, 672 |
| 12.5 | 22 | 176, 352, 704 |
| 12.5 | 23 | 368, 736 |
| 12.5 | 24 | 192, 384, 768 |
| 12.5 | 25 | 400, 800 |
| 12.5 | 26 | 208, 416, 832 |
| 12.5 | 27 | 432, 864 |
| 12.5 | 28 | 224, 448, 896 |
| 12.5 | 29 | 464, 928 |
| 12.5 | 30 | 240, 480, 960 |
| 12.5 | 31 | 496, 992 |
| 12.5 | 32 | 128, 256, 512 |
| 6.75 | 8 | 64, 128, 256, 512 |
| 6.75 | 9 | 288, 576 |
| 6.75 | 10 | 160, 320, 640 |
| 6.75 | 11 | 352, 704 |
| 6.75 | 12 | 192, 384, 768 |
| 6.75 | 13 | 416, 832 |
| 6.75 | 14 | 224, 448, 896 |
| 6.75 | 15 | 480, 960 |
| 6.75 | 16 | 64, 128, 256, 512 |
| 6.75 | 17 | 544 |
| 6.75 | 18 | 288, 576 |
| 6.75 | 19 | 608 |

Table A-49 Word Length, Sampling Rate, and Multiplier for Master Clock In (continued)

| Sampling rate (kHz) ^[a] | Word length | Multiplier |
|------------------------------------|-------------|---------------|
| 6.75 | 20 | 320, 640 |
| 6.75 | 21 | 672 |
| 6.75 | 22 | 352, 704 |
| 6.75 | 23 | 736 |
| 6.75 | 24 | 384, 768 |
| 6.75 | 25 | 800 |
| 6.75 | 26 | 416, 832 |
| 6.75 | 27 | 864 |
| 6.75 | 28 | 448, 896 |
| 6.75 | 29 | 928 |
| 6.75 | 30 | 480, 960 |
| 6.75 | 31 | 992 |
| 6.75 | 32 | 128, 256, 512 |

[a] For sampling rate less than or equal to.

Appendix 26: U8903B Default Settings

Analog generator

Table A-50 Analog generator default settings

| Level 1 | Level 2 | Level 3 | Default |
|-----------------|------------------------------------|---------|------------------|
| Waveform | | | Sine |
| | Amplitude | | 0 Vrms |
| | Frequency | | 1 kHz |
| | DC Offset | | 0 V |
| | Phase -> 1 | | 0° |
| | Frequency 2 | | 2 kHz |
| | Ratio | | 100% |
| | Lower Feq | | 60 Hz |
| | Upper Freq (SMPTE 1:1/4:1/10:1) | | 7 kHz |
| | Upper Freq (IEC 60118) | | 10 kHz |
| | Diff Freq | | 80 Hz |
| | Center Freq | | 10 kHz |
| Waveform Config | Voltage | | 0 V |
| | Start Freq | | 1001.35803222656 |
| | Stop Freq | | 4997.25341796875 |
| | Freq Spacing | | Linear |
| | Tones | | 2 |
| | Length | | 1024 |
| | Dial (DTMF) | Mode | Single |
| | Amplitude (DTMF) | | -4.5 dBu |
| | Ratio (DTMF) | | 2 dB |
| | Tone Duration (DTMF) | | 90 ms |
| | Tone Delay (DTMF) | | 90 ms |
| | Pause Time (DTMF) | | 90 ms |
| | Repeat (DTMF) | | Off |

Table A-50 Analog generator default settings (continued)

| Level 1 | Level 2 | Level 3 | Default |
|---------------|----------------------|---------|--------------|
| Output Config | Connector | | UnBal |
| | Impedance | | 600 Ω |
| | IEC60268 10 Ω | | Pin 2 |
| | Ground | | Float |
| | Max Voltage | | 22.6 Vrms |
| References | Ref Impedance | | 600 Ω |

Analog analyzer

Table A-51 Analog analyzer default settings

| Level 1 | Level 2 | Level 3 | Default |
|-------------------------------|--------------------------|---------|------------|
| Functions | Multi-Chn Mode | | Off |
| | Function No. | | 1 |
| | Meas. Func. (Function 1) | | AC Voltage |
| | Meas. Func. (Function 2) | | Frequency |
| | Meas. Func. (Function 3) | | None |
| Functions (Frequency) | Meas. Func. (Function 4) | | None |
| | Unit | | Hz |
| Functions (AC Voltage) | Format | | Off |
| | Unit | | V |
| | Format | | Off |
| Functions (DC Voltage) | Detector | | RMS |
| | Unit | | V |
| Functions (THD+N Ratio/SINAD) | Format | | Off |
| | Freq Lock | | Auto |
| | Fund Freq | | 1000 |
| | Unit | | dB |
| Functions (THD+N Level) | Format | | Off |
| | Freq Lock | | Auto |
| | Fund Freq | | 1000 |
| | Unit | | V |

Table A-51 Analog analyzer default settings (continued)

| Level 1 | Level 2 | Level 3 | Default |
|---|---------------|---------|------------|
| Functions (THD Ratio) | Unit | | dB |
| | Format | | Off |
| | Even Harmonic | | 2, 4, 6, 8 |
| | Odd Harmonic | | 3, 5, 7, 9 |
| | Freq Lock | | Auto |
| | Fund Freq | | 1000 |
| Functions (THD Level) | Unit | | V |
| | Format | | Off |
| | Even Harmonic | | 2, 4, 6, 8 |
| | Odd Harmonic | | 3, 5, 7, 9 |
| | Freq Lock | | Auto |
| | Fund Freq | | 1000 |
| Functions (DFD60268 2nd/ DFD 60268 3rd/ DFD 60118 2nd/ DFD 60118 3rd) | Unit | | dB |
| | Format | | Off |
| Functions (SMPTE IMD) | Unit | | dB |
| | Format | | Off |
| | Freq Lock | | Gen Lock |
| | Upper Freq | | 60 |
| | Lower Freq | | 7000 |
| Functions (SNR) | Unit | | dB |
| | Format | | Off |
| | SNR Delay | | 0 ms |
| Functions (SNR (Fast)) | Unit | | dB |
| | Format | | Off |
| | Freq Lock | | Auto |
| | Fund Freq | | 1000 |
| | Harmonics | | 5 |
| Functions (Phase) | Ref. Channel | | 1 |
| | Freq Lock | | Auto |
| | Fund Freq | | 1000 |

Table A-51 Analog analyzer default settings (continued)

| Level 1 | Level 2 | Level 3 | Default | |
|-----------------------|----------------|-------------|--|----------|
| Functions (X-Talk) | Ref. Channel | | 1 | |
| | Unit | | dB | |
| | Format | | Off | |
| | Freq Lock | | Auto | |
| | Fund Freq | | 1000 | |
| Filters Config | LPF | | None | |
| | HPF | | None | |
| | Weighting | | None | |
| | Deemphasis | | None | |
| | Notch Filter | State | | Disabled |
| | | Center Freq | | 1000 Hz |
| Bandwidth | | | 500 Hz | |
| Meas Config | Auto Range | | On | |
| | Range | | 1 V | |
| | Sample Size | | 32768 | |
| | Mov Average | | 1 | |
| | Src Channel | | 1 | |
| | Trigger Source | | Free Run | |
| | Trigger Edge | | Rising | |
| Input Config | Connector | | UnBal | |
| | Impedance | | 100 k Ω (Unbal) 200 k Ω (Bal) | |
| | Coupling | | AC | |
| | Bandwidth | | 90 kHz | |
| | Ext. Gain | | 0 dB | |
| Wave File | Channel | | Left | |
| | Bits/Sample | | 8 | |
| | Duration | | 10 s | |
| Statistics | Show Stats | | Off | |
| | No. of Reading | | 10 | |
| | Stat 1 | | Min | |
| | Stat 2 | | Max | |
| | Stat 3 | | Average | |

Sweep

Table A-52 Sweep default settings

| Level 1 | Level 2 | Default |
|--|---------|-------------|
| Legacy Status | | Off |
| Parameter | | Frequency |
| Points Settings | Spacing | Log |
| | Unit | Hz |
| | Start | 20 |
| | Stop | 2000 |
| | Step | 1.268961003 |
| | Points | 30 |
| Points Settings (Parameter = Amplitude) | Spacing | Linear |
| | Unit | Vrms |
| | Start | 0.1 |
| | Stop | 1 |
| | Step | 0.031034483 |
| | Points | 30 |
| Points Settings (Parameter = Phase) | Spacing | Linear |
| | Unit | ° |
| | Start | 0 |
| | Stop | 90 |
| | Step | 3.103448276 |
| | Points | 30 |
| Dwell Time | | 0 |
| Sweep Mode | | Continuous |
| Channels | Source | 1 |
| | Measure | 1 |

HP8903B

Table A-53 HP8903B default settings

| Level 1 | Level 2 | Default |
|-------------|-------------|-----------|
| Measurement | Function | AC level |
| | LP Filter | 80 kHz |
| | HP/W Filter | None |
| | Ratio | Off |
| | Format | Lin |
| Generator | Frequency | 1 kHz |
| | Amplitude | 0 V |
| | Step Param | Frequency |
| | Freq. Step | 1 kHz |
| | Amp. Step | 100 mVrms |
| Sweep | Freq. Start | 20 Hz |
| | Freq. Stop | 20 kHz |

System

Table A-54 System default settings

| Key | Level 1 | Level 2 | Default |
|--------|----------------|----------------|---------|
| System | HP8903B Config | Active Channel | 1 |
| | | Left Filter | None |
| | | Right Filter | None |
| | | Default LPF | 80 kHz |

Appendix 27: Procedure to Rename, Copy, Move, and Delete Files

Renaming a file

- 1 In the file view, select the file to rename.
- 2 Press the **Rename** softkey.
- 3 Enter the new file name in the **New name** text box.
- 4 Press the **OK** softkey when done.
- 5 The selected file is renamed.

Copying a file

- 1 In the file view, navigate to the folder that contains the file to copy.
- 2 Press the **Copy or Move** softkey.
- 3 Press the **Mark** softkey to mark the file or multiple files to copy.
- 4 Navigate to the folder where the file is to be copied.
- 5 Press the **Copy Marked To Folder** softkey.
- 6 The marked file will be copied to the specified folder. Press the **Return** softkey when done.
- 7 If the file name to be copied already exists in the destination folder, the copied file name will be renamed to **Copy of [file name]**.

Moving a file

- 1 In the file view, navigate to the folder that contains the file to to move.
- 2 Press the **Copy or Move** softkey.
- 3 Press the **Mark** softkey to mark the file or multiple files to move.
- 4 Navigate to the folder where the file is to be moved.
- 5 Press the **Move Marked To Folder** softkey.
- 6 The marked file will be moved to the specified folder. Press the **Return** softkey when done.

Deleting a file

- 1 In the file view, select the file to delete.
- 2 Press the **Delete** softkey.
- 3 A dialog box will pop up prompting confirmation to delete the file. To delete the file, select **Yes** and press . To abort, select **No** and press .

Appendix 28: POLQA Recording Duration Analysis

The following shows the maximum wave file recording duration allowed for POLQA analysis based on the different option card configuration and settings in the U8903B.

Table A-55 U8903B option configuration

| Option | Configuration |
|--------|---|
| 1 | Analog cards only |
| 2 | Analog cards and Digital card |
| 3 | Analog cards and <i>Bluetooth</i> card |
| 4 | Analog cards, Digital card, and <i>Bluetooth</i> card |

Table A-56 Maximum wave file recording duration for the POLQA narrowband and super-wideband analysis

| Option Configuration | Narrowband analysis | | | Super-wideband analysis |
|----------------------|--|---|---|---|
| | Maximum wave file recording duration for 8 kHz sample rate | Maximum wave file recording duration for 16 kHz sample rate | Maximum wave file recording duration for 48 kHz sample rate | Maximum wave file recording duration for 48 kHz sample rate |
| Option 1 | 30 s | 16 s | 5 s | 5 s |
| Option 2 | 20 s | 14 s | 5 s | 4 s |
| Option 3 | 20 s | 16 s | 5 s | 5 s |
| Option 4 | 16 s | 10 s | 4 s | 4 s |

Appendix 29: Audio Measurement Ranging

In order to obtain measurements with high accuracy and resolution, selecting the appropriate audio measurement range is crucial. The U8903B is covered by switchable attenuation or gain from the input circuits of the audio analyzer. The two types of audio measurement ranging are manual ranging and auto ranging.

Manual ranging

Manual ranging is used to configure the level of the input signal to the optimum range for measurements. This allows you to set the gain of the analyzer to amplify a low input signal or attenuate a high input signal as required.

The U8903B provides the following input voltage ranges for both unbalanced and balanced inputs:

- 140 V
- 100 V
- 32 V
- 10 V
- 3.2 V
- 1 V
- 320 mV

For optimum range, you should select the lowest range with its upper limit exceeding the expected maximum input signal.

Auto ranging

The auto ranging mode automatically selects an appropriate range for each measurement. Auto ranging determines the correct range to use according to the signal level to achieve the optimum measurement accuracy for the input signal.

Auto ranging is suitable for measuring stable signals with levels that do not vary greatly. It is however not suitable for signals with rapid-changing pulses or spikes. As auto ranging needs to determine which range to use for each signal level, it may not be fast enough to accommodate signals with rapid-changing pulses or spikes. This may result in ranging errors leading to incorrect measurements.

Therefore in this case, manual ranging provides better and faster performance for your measurement needs.

It is recommended to know the characteristics of the input signal and its level variation before applying the manual or auto ranging mode.

Using manual ranging for continuous sweep and frequency response measurements

For continuous sweep and frequency response measurements, manual ranging is a better option as it ensures signals across all frequency ranges are measured within the same range.



This information is subject to change without notice. Always refer to the English version at the Keysight Web site for the latest revision.

© Keysight Technologies 2014–2024
Edition 9, January 2024

Printed in Malaysia



U8903-90045

www.keysight.com