






## How to enable resistance measurement


The resistance measurement operation is set to OFF in the default setting. To perform resistance measurement, you need to select the operation among AUTO, FIXED and V/I. For AUTO and FIXED, the B2901/02/11/12A performs resistance measurement by using the current source and voltage measure condition automatically set by the resistance measurement range setting. For V/I, the B2901/02/11/12A performs measurement by using the present source/measure condition and calculates the resistance value.

### Selecting FIXED operation



Step 1. Rotate and press  to select the resistance measurement operation, and then select  to set it to FIXED.




Step 2. Rotate and press  to select the resistance measurement range, and then select  to set the resistance measurement range to 2 kOhm for example.




Selecting V/I operation


Step 1. Rotate and press  to select the resistance measurement operation and then select  to set the resistance measurement operation to V/I.





Step 2. Press , then press  to set Channel 1 V/I Source Function to the current source.





Step 3. Press  and set Channel 1 Source Value to 1 mA.




Step 4. Press  and set Channel 1 Limit value to 2 V.




### Selecting AUTO operation

Step 1. Rotate and press  to select the resistance measurement operation, and then select  to set it to AUTO.



### Performing a measurement

Step 1. Press  to source the current.

Step 2. Press  to perform a measurement. Now you can see the measurement result on the GUI of the B2901/02/11/12A as bellow.

