

Keysight 10GbE Server (E7515AU-S02)

For the E7515A UXM Wireless Test Set

Notices

© Keysight Technologies, Inc.
2014-2017

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Trademark Acknowledgments

Manual Part Number

E7515-90021

Edition

Edition 1, February 2017

Printed in USA/Malaysia

Published by:
Keysight Technologies
1400 Fountaingrove Parkway
Santa Rosa, CA 95403

Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS

DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

U.S. Government Rights

The Software is "commercial computer software," as defined by Federal Acquisition Regulation ("FAR") 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement ("DFARS") 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public.

Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at

<http://www.keysight.com/find/sweula>

The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional

government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

Where to Find the Latest Information

Documentation is updated periodically. For the latest information about these products, including instrument software upgrades, application information, and product information, browse to one of the following URLs, according to the name of your product:

<http://www.keysight.com/find/uxm>

To receive the latest updates by email, subscribe to Keysight Email Updates at the following URL:

<http://www.keysight.com/find/MyKeysight>

Information on preventing instrument damage can be found at:

www.keysight.com/find/PreventingInstrumentRepair

Is your product software up-to-date?

Periodically, Keysight releases software updates to fix known defects and incorporate product enhancements. To search for software updates for your product, go to the Keysight Technical Support website at:

<http://www.keysight.com/find/techsupport>

Installation Guide

This document describes how to install the 10GbE (E7515AU-S02) in your E7515A UXM.

Topics covered:

- “Initial Inspection” on page 6
- “Installation Procedures” on page 8
- “Protecting Against Electrostatic Discharge” on page 23
- “Service” on page 24




The 10GbE Server (also known as the Server PC or SPC) is an additional personal computer that is easily installed in the rear-panel of the UXM. With this increased processor and disc-space functionality available to you outside the embedded PC of the UXM, you are able to utilize maximum speed and efficiency when performing User Equipment (UE) capability testing via the UXM.

The software application recommendations for installation on the 10 GbE Server are detailed in the UXM Getting Started Guide that you received with the shipment of your UXM and located on the web at:

www.keysight.com/find/UXM-Manuals

Initial Inspection

Inspect the shipping container and the cushioning material for signs of stress. Retain undamaged shipping materials for future use, as you may wish to ship the test set to another location or to Keysight Technologies for service. Verify the contents of the container against the table below.

Item	Deliverable	Description
10 GbE Server (E7515A-A02)		DESCRIPTION?????
10 GbE Server (E7515A-A02) Installation Guide		This document.
4-port USB Hub unpowered		

CAUTION

Do not install a powered USB Hub into the 10 GbE Server, as it may prevent this component from shutting down completely which could lead to data corruption. Use the 4-port USB Hub supplied, as described in the table above.

Shipping Problems?

If the shipping materials are damaged or the contents of the container are incomplete:

- Contact the nearest Keysight Technologies office.
- Keep the shipping materials for the carrier's inspection.
- If you must return a test set to Keysight Technologies, use the undamaged original or comparable shipping materials. See **“Returning Components for Service” on page 24.**

Installation Procedures

Tools Required

- Flat-head screw driver (to remove the filler panel)
- Torx T10 screwdriver (to install the Server PC).

Software Compatibility

NOTE



You must install E7515A software version 1.2.3.0 or above in order to use the 10GbE Server.

ESD Precautions

CAUTION

Ensure you are working at a static safe workstation before performing the installation process described below. Review the information presented in **“Protecting Against Electrostatic Discharge” on page 23** before beginning the installation process.

Hardware Installation Procedure

Step	Notes
1. Make sure the instrument is turned off by switching the Mains switch on the rear-panel to Off. Also, ensure there are no Ethernet cables connected to the instrument.	
2. Remove the filler panel from the rear panel of the UXM.	
<div>CAUTION Whenever the UXM is powered on, either the 10GbE Server or the filler panel must be in place, to ensure proper airflow within the instrument.</div>	

Step

Notes

3. Ensure the retention tab is unlocked (fully extended). Insert the Server PC in position shown.



4. Insert and tighten captive screws to 4.7 lb-in (~53 N-cm). Lock retention tab. NOTE: View shows retention tab extended, not locked. Push tab in to lock.



5. Attach retainer bracket in order to secure module in place.


Tighten captive screw to 4.7 lb-in (~ 53 N-cm)).








Step	Notes
6.	This completes the physical installation of the 10GbE Server. Continue to the next steps which enable its ability to function properly.


Software Installation Procedure

This procedure assumes that “**Hardware Installation Procedure**” on page 9 has already been done.

Step	Notes
1. Create a Clonezilla bootable USB.	<div>a. Format USB drive with FAT32 filesystem (minimum size: 4GB)</div> <div>b. Unzip the file “Keysight Xpc CentOS 0.0.0.4.zip”.</div> <div>c. Copy the contents to the USB drive:</div> <div></div>

Step	Notes
2. Make the USB bootable.	<p>a. Navigate to “utils” folder.</p>  <p>b. In this location the “makeboot” scripts are located.</p> <p>c. Select the correct folder, it depends on the operating system you’ll run the script. i.e.: If you are creating the bootable USB from a Windows 64-bit select “win64”.</p> <p>d. Right click on the “makeboot” script, and select “Run as administrator”.</p> 
3. Remove USB drive safely	



Step	Notes
4. Connect serial cable to the XPC "RS 232" port.	
5. Connect the serial cable to an adaptor.	<p data-bbox="683 751 1317 783">XPC serial cable is terminated with a DB9 male serial connector:</p>  <p data-bbox="683 1161 1208 1192">Therefore, a serial (female) to USB adaptor is needed:</p> 
6. Connect the serial cable to an external PC available USB port.	



Step	Notes
7. Identify the COM port.	<p>Determine in which COM port Windows maps the serial connection by opening Windows Device Manager and checking COM ports.</p>  <p>In this example, it is mapped in “COM6”.</p>
8. Use a terminal application to start the serial connection.	<p>For example, Putty is a free tool that supports this connection.</p>

Step

Notes

9. Configure speed 115200 and no hardware control.




Step	Notes
10. BIOS Configuration	<p>BIOS Configuration utility automatically pops up at boot up.</p> <p>Configure BIOS parameter “Wait For SPS” to value “Disabled”, as shown in the following screenshot:</p> 
11. Flash the XPC. From UXM desktop, launch a command window (click on “Start”, then type “cmd” and select it).	<p>Type “uxm stopplatform”. It is then possible to control the XPC power state by opening a session with ICM, and using the ICM commands: FRU:POWER:OFF AMC7, FRU:POWER:ON AMC7 (see example below)</p> <ol style="list-style-type: none"> Type “uxm scpi 10.168.0.110 hislipmng” to open the session with ICM 0.168.0.110:hislipmng> prompt will be shown Type “fru:power:on amc7” (to power on XPC) or “fru:power:off amc7” (to power off XPC) 
12. Power on the XPC board.	
13. Connect the bootable USB drive.	


Step

Notes

14. Boot from USB (Configure BIOS or press F12 when requested) by selecting the USB device.




15. When offered the choice, select Don't touch Keymap.



16. Start Clonezilla.


Choose device-image:




Step

Notes


17. Select local-dev and press ENTER.



18. Select sdb1.




19. Select home and press ENTER.




Step

Notes


20. Select Beginner.



21. Select restoredisk.



22. Select version (Normally, only one is stored in the USB key).




Step	Notes
23. Select target SSD (Only one option for XPC).	 A screenshot of a PuTTY window titled 'COM6 - PuTTY' showing the Clonesilla - Opensource Clone System (OCS) in 'Mode: restoredisk'. The text prompts the user to 'Choose the target disk(s) to be overwritten (ALL DATA ON THE ENTIRE DISK WILL BE LOST AND REPLACED!!)'. It explains that the disk name is the device name in GNU/Linux and lists the first two disks as 'hda' or 'sda' and 'hdb' or 'sdb'. A selection of 'sda 31.7GB SM631GEB BA SM631GEB BA A0215102608230000192' is highlighted in green. At the bottom are '<Ok>' and '<Cancel>' buttons.
24. Skip check image.	 A screenshot of a PuTTY window titled 'COM6 - PuTTY' showing the Clonesilla advanced extra parameters in 'Mode: restoredisk'. It asks if the user wants to check if the image is restorable before restoring. A note states that this action only checks the image and does not write data. The option 'scr No, skip checking the image before restoring' is highlighted in green. At the bottom are '<Ok>' and '<Cancel>' buttons.
	Press Enter.
	Two warnings will be shown informing the user that the hard disk information will be list. Select 'y' in both questions. The program will start flashing the SSD card.
25. Reboot XPC board.	<p>The grub console is shown, it is necessary to configure the boot location</p> <pre>grub> configfile /grub2/grub.cfg</pre>  A screenshot of a PuTTY window titled 'COM6 - PuTTY' showing the GNU GRUB version 2.02-beta2-35 console. It displays the command 'grub> configfile /gr' and the output 'Possible files are: grub/ grub2/'. The command 'grub> configfile /grub2/grub.cfg' is entered and highlighted in green.
26. Log in as: user= root pass=root	

Step

Notes

27. Execute “grub2-install /dev/sda”.



```
COM6 - PuTTY
[ 9.511586] tun: (C) 1999-2004 Max Krasnyansky <maxk@qualcomm.com>
[ 9.776040] device virbr0-nic entered promiscuous mode
[ 9.843445] nf_conntrack version 0.5.0 (16384 buckets, 65536 max)
[ 9.872862] virbr0: port 1(virbr0-nic) entered listening state
[ 9.878681] virbr0: port 1(virbr0-nic) entered listening state
[ 9.884535] IPv6: ADDRCONF(NETDEV_UP): virbr0: link is not ready

CentOS Linux 7 (Core)
Kernel 3.10.0-229.el7.x86_64 on an x86_64

AMC1x login: [ 11.568626] virbr0: port 1(virbr0-nic) entered disabled state
[ 13.129746] ixgbe 0000:01:00.0 enp1s0f0: NIC Link is Up 1 Gbps, Flow ControlX
[ 13.137632] IPv6: ADDRCONF(NETDEV_CHANGE): enp1s0f0: link becomes ready

CentOS Linux 7 (Core)
Kernel 3.10.0-229.el7.x86_64 on an x86_64

AMC1x login: root
Password:
Last login: Fri May 6 10:53:01 on ttyS0
[root@AMC1x ~]# grub2-install /dev/sda
Installing for i386-pc platform.
Installation finished. No error reported.
[root@AMC1x ~]#
```

28. Reboot.

Check that the board boots properly. (no stuck in grub> cmd)

Platform must then show green status (there is no specific status icon for the XPC).

A remote access icon in UXM desktop after installation should be shown (similar to SPC icons).

XPC module internal LAN interface is 10.168.0.40 (listed under arp -a in command window)

Protecting Against Electrostatic Discharge

Electrostatic discharge (ESD) can damage or destroy electronic components (the possibility of unseen damage caused by ESD is present whenever components are transported, stored, or used).

Test equipment and ESD

- Before connecting any coaxial cable to a test set connector for the first time each day, momentarily short the center and outer conductors of the cable together.
- Personnel should be grounded with a 1 M Ω resistor-isolated wrist-strap before touching the center pin of any connector and before removing any assembly from the test set.
- Be sure that all instruments are properly earth-grounded to prevent build-up of static charge.

Additional information about ESD

For more information about ESD and how to prevent ESD damage, contact the Electrostatic Discharge Association:

<http://www.esda.org>

The ESD standards developed by this agency are sanctioned by the American National Standards Institute (ANSI).

Service

WARNING

No operator serviceable parts inside. Refer servicing to qualified personnel. To prevent electrical shock do not remove covers. The only cover that can be removed is the plate covering the SPC slot.

Returning Components for Service

Calling Keysight Technologies

Keysight Technologies has offices around the world to provide you with complete support for your wireless test set. To obtain servicing information, or to order replacement parts, contact the nearest Keysight Technologies office listed under **“Locations for Keysight Technologies” on page 25**. In any correspondence or telephone conversations, refer to the part number and serial number of the 10 GbE Server.

For the 10 GbE Server referenced in this document, the following information is provided on the serial number label attached to its faceplate:

- Part number: E7515-XXXXX
- Serial Number: The serial number will be in the format: AB12345678.

Locations for Keysight Technologies

For online assistance: <http://www.keysight.com/find/assist>

To contact Keysight Technologies: <http://www.keysight.com/find/contactus>

Alternately, contact the nearest Keysight sales office:

Americas		
Canada (877) 894 4414	Brazil 55 11 3351 7010	Mexico 001 800 254 2440
United States (800) 829 4444		
Asia & Pacific		
Australia 1 800 629 485	China 800 810 0189	Hong Kong 800 938 693
India 1 800 112 929	Japan 0120 (421) 345	Korea 080 769 0800
Malaysia 1 800 888 848	Singapore 1 800 375 8100	Taiwan 0800 047 866
Other Asia-Pacific countries: (65) 6375 8100		
Europe & Middle East		
Austria 0800 001122	Belgium 0800 58580	Finland 0800 523252
France 0805 980333	Germany 0800 6270999	Ireland 1800 832700
Israel 1 809 343051	Italy 800 599100	Luxembourg +32 800 58580
Netherlands 0800 0233200	Russia 8800 5009286	Spain 0800 000154
Sweden 0200 882255	Switzerland 0800 805353 Opt. 1 (DE), Opt. 2 (FR), Opt. 3 (IT)	United Kingdom 0800 0260637



This information is subject to change without notice.

© Keysight Technologies 2017

Edition 1, February 2017

E7515-90021

www.keysight.com