

Keysight E36200 Series Autoranging DC Power Supplies

This manual provides the documentation for the following instruments:

- E36231A
- E36232A
- E36233A
- E36234A

Notices

Copyright Notice

© Keysight Technologies 2019

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies as governed by United States and international copyright laws.

Manual Part Number

E36200-90010

Edition

Edition 1, May 1, 2019

Printed in:

Printed in Malaysia

Published by:

Keysight Technologies
Bayan Lepas Free Industrial Zone,
11900 Penang, Malaysia

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Declaration of Conformity

Declarations of Conformity for this product and for other Keysight products may be downloaded from the Web. Go to <http://www.keysight.com/go/conformity>. You can then search by product number to find the latest Declaration of Conformity.

U.S. Government Rights

The Software is “commercial computer software,” as defined by Federal Acquisition Regulation (“FAR”) 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement (“DFARS”) 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at <http://www.keysight.com/find/sweula>. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED “AS IS,” AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR FOR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT SHALL CONTROL.

Safety Information

CAUTION

A CAUTION notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

Table of Contents

- 1 **Getting Started**
 - Warranty6
 - Where to Find the Latest Information6
 - Is Your Product Software Up-to-Date?7
 - Contacting Keysight Sales and Service Offices7
 - Products Covered by this Document8
 - Document purpose8
 - Security Terms and Definitions9
 - Instrument Memory10
 - Summary of Memory Declassification Procedures13
 - Procedure for Declassifying a Faulty Instrument15
 - References16

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

1 Getting Started

Warranty	6
Where to Find the Latest Information	6
Is Your Product Software Up-to-Date?	7
Contacting Keysight Sales and Service Offices	7
Products Covered by this Document	8
Security Terms and Definitions	9
Instrument Memory	10
Summary of Memory Declassification Procedures	13
Procedure for Declassifying a Faulty Instrument	15
References	16

This document describes instrument security features and the steps to declassify an instrument through memory clearing, sanitization, or removal.

Warranty

This Keysight Technologies product is warranted against defects in material and workmanship for a period of three years from the date of shipment. During the warranty period, Keysight Technologies will, at its option, either repair or replace products that prove to be defective. For warranty service or repair, this product must be returned to a service facility designated by Keysight Technologies. Buyer shall prepay shipping charges to Keysight Technologies, and Keysight Technologies shall pay shipping charges to return the product to Buyer. For products returned to Keysight Technologies from another country, Buyer shall pay all shipping charges, duties, and taxes.

Where to Find the Latest Information

Documentation is updated periodically. For the latest information about these products, including instrument software upgrades, application information, and product information, see the following URLs:

<http://www.keysight.com/find/e36200>

<http://www.keysight.com/find/e36231A>

<http://www.keysight.com/find/e36232A>

<http://www.keysight.com/find/e36233A>

<http://www.keysight.com/find/e36234A>

<http://www.keysight.com/find/e36200firmware>

To receive the latest updates by email, subscribe to Keysight Email Updates:

<http://www.keysight.com/find/MyKeysight>

Information on preventing instrument damage can be found at:

<http://www.keysight.com/find/PreventingInstrumentRepair>

Is Your Product Software Up-to-Date?

Periodically, Keysight releases software updates to fix known defects and incorporate product enhancements. To search for software updates for your product, go to the Keysight Technical Support website at:

<http://www.keysight.com/find/techsupport>

Contacting Keysight Sales and Service Offices

Assistance with test and measurement needs, and information on finding a local Keysight office, is available on the Internet at:

<http://www.keysight.com/find/assist>

If you do not have access to the Internet, please contact your field engineer.

NOTE

In any correspondence or telephone conversation, refer to the instrument by its model number and full serial number. With this information, the Keysight representative can determine whether your unit is still within its warranty period.

Products Covered by this Document

Product family name	Product name	Model numbers
Power Supply	Autoranging DC Power Supplies	E36231A, E36232A, E36233A, E36234A

Document purpose

This document describes instrument security features and the steps to declassify an instrument through memory clearing, sanitization, or removal.

For additional information, go to:

<http://www.keysight.com/find/security>

NOTE

Ensure that all information stored by the user in the instrument that needs to be saved is properly backed up before attempting to clear any of the instrument memory. Keysight Technologies cannot be held responsible for any lost files or data resulting from the clearing of memory. Be sure to read this document entirely before proceeding with any file deletion or memory clearing.

Security Terms and Definitions

Term	Definition
Clearing	As defined in Section 8-301a of DoD 5220.22-M, clearing is the process of eradicating the data on media before reusing the media so that the data can no longer be retrieved using the standard interfaces on the instrument. Clearing is typically used when the instrument is to remain in an environment with an acceptable level of protection.
Instrument Declassification	A term that refers to procedures that must be undertaken before an instrument can be removed from a secure environment, such as in the case when the instrument is returned for calibration. Declassification procedures include memory sanitization or memory removal, or both. Keysight declassification procedures are designed to meet the requirements specified in DoD 5220.22-M, Chapter 8.
Sanitization	As defined in Section 8-301b of DoD 5220.22-M, sanitization is the process of removing or eradicating stored data so that the data cannot be recovered using any known technology. Instrument sanitization is typically required when an instrument is moved from a secure to a non-secure environment, such as when it is returned to the factory for calibration. Keysight memory sanitization procedures are designed for customers who need to meet the requirements specified by the US Defense Security Service (DSS). These requirements are specified in the "Clearing and Sanitization Matrix" in Section 5.2.5.5.5 of the ISFO Process Manual.
Secure Erase	Secure Erase is a term that is used to refer to either the clearing or sanitization features of Keysight instruments.

Instrument Memory

This section contains information on the types of memory available in your instrument. It explains the size of memory, how it is used, its location, volatility, and the sanitization procedure.

Table 1-1 Summary of instrument memory

Memory type and size	User accessible as a mass storage device?	Writable during normal operation?	Data retained when powered off?	Purpose/Contents	Data input method	Location in instrument and remarks	Sanitization procedure
Main board microcontroller Channel 1 (ROM) 128 kByte	No	No	Yes	Channel 1 main board microcontroller execution code storage	Factory install/ Firmware upgrade	Channel 1 main board microcontroller	Not applicable, contains no application-specific information.
Main board microcontroller Channel 1 (RAM) 16 kByte	No	Yes	No	Channel 1 main board microcontroller temporary execution data	Microprocess or execution code/data	Channel 1 main board microcontroller	Power cycle
Main board microcontroller Channel 2 (ROM) 128 kByte	No	No	Yes	Channel 2 main board microcontroller execution code storage	Factory install/ Firmware upgrade	Channel 2 main board microcontroller	Not applicable, contains no application-specific information.
Main board microcontroller Channel 2 (RAM) 16 kByte	No	Yes	No	Channel 2 main board microcontroller temporary execution data	Microprocess or execution code/data	Channel 2 main board microcontroller	Power cycle

Table 1-1 Summary of instrument memory (continued)

Memory type and size	User accessible as a mass storage device?	Writable during normal operation?	Data retained when powered off?	Purpose/Contents	Data input method	Location in instrument and remarks	Sanitization procedure
Front panel internal flash (NORFlash) 1 MByte	No	No	Yes	Static images for firmware usage	Factory install	Front panel	Not applicable, contains no application-specific information.
Front panel internal flash (NORFlash) 15 MByte	Yes	Yes	Yes	Datalog	User-saved data	Front panel	EEPROM sanitize – See Table 1-2 .
Front panel microcontroller (ROM) 128 kByte	No	No	Yes	Front panel microcontroller execution code storage	Factory install/ Firmware upgrade	Front panel microcontroller	Not applicable, contains no application-specific information.
Front panel microcontroller (RAM) 16 kByte	No	Yes	No	Front panel microcontroller temporary execution data	Microprocess or execution code/data	Front panel microcontroller	Power cycle
IO controller microcontroller (ROM) 2 MByte	No	No	Yes	IO controller microcontroller execution code storage	Factory install/ Firmware upgrade	IO controller microcontroller	Not applicable, contains no application-specific information.

Table 1-1 Summary of instrument memory (continued)

Memory type and size	User accessible as a mass storage device?	Writable during normal operation?	Data retained when powered off?	Purpose/Contents	Data input method	Location in instrument and remarks	Sanitization procedure
IO controller microcontroller (RAM) 256 KByte	No	Yes	No	IO controller microcontroller temporary execution data	Microprocess or execution code/data	IO controller microcontroller	Power cycle
Main RAM (SDRAM) 16 MByte	No	Yes	No	Temporary execution data	Microprocess or execution code/data	Front panel	Power cycle
Instrument identification, calibration data, and power state (EEPROM) 246 Byte	No	Yes	Yes	Serial number, MAC address, versions, last power on state, calibration constants, calibration count, secure count, security code, and calibration message	Factory or service and user calibration	Front panel	Not applicable, contains no application-specific information.
Instrument state and setting (EEPROM) 127.7 KByte	Yes	Yes	Yes	User data, IO configuration, instrument configuration, and instrument state information.	User-saved data	Front panel	EEPROM sanitize – See Table 1-2 .

Summary of Memory Declassification Procedures

This section explains how to clear, sanitize, and remove memory from your instrument, for all classes of memory that are writable during normal operation.

NOTE

- Before you begin any memory clearing or sanitization procedures, be sure to record all the critical information (store and recall the instrument setting and record the IP address of the instrument). This information is essential for successful restoration of the instrument's operating system.
- Read this entire document before using any sanitization procedure. Failure to do so may necessitate returning the instrument to an Authorized Keysight Service Center for firmware downloads and recalibration.

Table 1-2 EEPROM

Description and purpose	This is the user's partition of the instrument's internal storage that uses a EEPROM device and internal flash. Storage may include user data, IO configuration, instrument configuration, state information, and datalogging.
Size	127.7 kBytes for EEPROM and 15 MBytes for internal NORFlash
Memory clearing	<p>To clear the user-accessible calibration message or passcode, set the passcode and message through SCPI commands:</p> <p>To clear calibration message:</p> <pre>cal:string 'This is cal string'</pre> <p>To clear calibration passcode:</p> <pre>cal:secure:code 0</pre>

Table 1-2 EEPROM

Memory sanitization ***** Requires instrument security option *****	<p>Performing an instrument sanitization requires the instrument security option (SEC) to be purchased.</p> <p>On the front panel press: Utilities > Test/Setup > Calibration > Reset to Factory > Yes</p> <p>From the remote interface, send: SYSTem:SECurity:IMMediate</p> <p>Note: The instrument's security setting must be unlocked to perform these actions.</p> <p>This sanitizes all user-accessible instrument memory and restarts the instrument. This includes deleting and sanitizing all user-defined state or preference information, and user-defined I/O settings. The instrument's firmware, serial/model number, MAC address, last power on state, and calibration data are preserved.</p> <p>This command complies with requirements in chapter 8 of the National Instrument Security Program Operating Manual (NISPOM). This command is for users, such as military contractors, who must comply with NISPOM. Specifically, the action will fully declassify all non-volatile memory using the methods specified in the June 28, 2007 DSS Memory Clearing and Sanitization Matrix.</p>
Memory removal	<p>This memory cannot be removed without damaging the instrument. The user may remove the front panel assembly on which the memory chip resides.</p>

Procedure for Declassifying a Faulty Instrument

If the instrument is not able to power on, the user information cannot be cleared using the front panel or the remote interface. The only choice in this situation is to take manual steps to remove any user information that may be present.

References

- 1** DoD 5220.22-M, “National Industrial Security Program Operating Manual (NISPOM)” United States Department of Defense. Revised February 28, 2006.
May be downloaded in Acrobat (PDF) format from:
<https://www.dss.mil/ma/ctp/io/fcb/nisp/>
- 2** ISFO Process Manual for the Certification and Accreditation of Classified Systems under the NISPOM Defense Security Service.
DSS-cleared industries may request a copy of this document via email, by following the instructions at:
https://www.dss.mil/contact/knowledge_center/



This information is subject to change without notice. Always refer to the Keysight website for the latest revision.

© Keysight Technologies 2019
Edition 1, May 1, 2019

Printed in Malaysia



E36200-90010

www.keysight.com