

---

# Keysight D9010EAPC 10GBASE-KR Electrical Compliance Test Application

# Notices

© Keysight Technologies, Inc. 2005-2022

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

## Revision

Version 3.20.0.0

## Edition

November 10, 2022

Available in electronic format only

Published by:

Keysight Technologies, Inc.  
1900 Garden of the Gods Road  
Colorado Springs, CO 80907 USA

## Warranty

**The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Keysight disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Keysight shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Keysight and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.**

## Technology License

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

## U.S. Government Rights

The Software is "commercial computer software," as defined by Federal Acquisition Regulation ("FAR") 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement ("DFARS") 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at [www.keysight.com/find/sweula](http://www.keysight.com/find/sweula). The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

## Safety Notices

### CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

---

### WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

---

## In This Book

This book is your guide to programming the Keysight Technologies D9010EAPC 10GBASE-KR Electrical Compliance Test Application.

- **Chapter 1**, “Introduction to Programming,” starting on page 7, describes compliance application programming basics.
- **Chapter 2**, “Configuration Variables and Values,” starting on page 9, **Chapter 3**, “Test Names and IDs,” starting on page 13, and **Chapter 4**, “Instruments,” starting on page 21 provide information specific to programming the D9010EAPC 10GBASE-KR Electrical Compliance Test Application.

### How to Use This Book

Programmers who are new to compliance application programming should read all of the chapters in order. Programmers who are already familiar with this may review chapters 2, 3, and 4 for changes.



# Contents

In This Book / 3

## 1 Introduction to Programming

Remote Programming Toolkit / 8

## 2 Configuration Variables and Values

## 3 Test Names and IDs

## 4 Instruments

Index



# 1 Introduction to Programming

Remote Programming Toolkit / 8

This chapter introduces the basics for remote programming a compliance/test application. The programming commands provide the means of remote control. Basic operations that you can do remotely with a computer and a compliance/test app running on an oscilloscope include:

- Launching and closing the application.
- Configuring the options.
- Running tests.
- Getting results.
- Controlling when and where dialogs get displayed
- Saving and loading projects.

You can accomplish other tasks by combining these functions.

## Remote Programming Toolkit

The majority of remote interface features are common across all the Keysight Technologies, Inc. family of compliance/test applications. Information on those features is provided in the N5452A Compliance Application Remote Programming Toolkit available for download from Keysight here: [www.keysight.com/find/rpi](http://www.keysight.com/find/rpi). The D9010EAPC 10GBASE-KR Electrical Compliance Test Application uses Remote Interface Revision 6.30. The help files provided with the toolkit indicate which features are supported in this version.

In the toolkit, various documents refer to "application-specific configuration variables, test information, and instrument information". These are provided in Chapters 2, 3, and 4 of this document, and are also available directly from the application's user interface when the remote interface is enabled (View>Preferences::Remote tab::Show remote interface hints). See the toolkit for more information.



## 2 Configuration Variables and Values

The following table contains a description of each of the D9010EAPC 10GBASE-KR Electrical Compliance Test Application options that you may query or set remotely using the appropriate remote interface method. The columns contain this information:

- GUI Location – Describes which graphical user interface tab contains the control used to change the value.
- Label – Describes which graphical user interface control is used to change the value.
- Variable – The name to use with the SetConfig method.
- Values – The values to use with the SetConfig method.
- Description – The purpose or function of the variable.

For example, if the graphical user interface contains this control on the **Set Up** tab:

- Enable Advanced Features

then you would expect to see something like this in the table below:

**Table 1** Example Configuration Variables and Values

GUI Location	Label	Variable	Values	Description
Set Up	Enable Advanced Features	EnableAdvanced	True, False	Enables a set of optional features.

and you would set the variable remotely using:

ARSL syntax

-----

```
arsl -a ipaddress -c "SetConfig 'EnableAdvanced' 'True'"
```

C# syntax

```
-----
remoteAte.SetConfig("EnableAdvanced", "True");
```

Here are the actual configuration variables and values used by this application:

**NOTE**

Some of the values presented in the table below may not be available in certain configurations. Always perform a "test run" of your remote script using the application's graphical user interface to ensure the combinations of values in your program are valid.

**NOTE**

The file, "ConfigInfo.txt", which may be found in the same directory as this help file, contains all of the information found in the table below in a format suitable for parsing.

**Table 2** Configuration Variables and Values

GUI Location	Label	Variable	Values	Description
Configure	Bandwidth	BW	(Accepts user-defined text), 25e9	Enter the scope bandwidth.
Configure	Disable Pattern Check	DisablePattern	Enable, Disable	Select "Disable" to disable the pattern verification for square 8 pattern tests and suppress pattern error pop-ups. Select "Enable" to ensure that the correct pattern is being tested as per specification.
Configure	ISI Filter Lag	ISILag	(Accepts user-defined text), 5	When using Arbitrary mode for the Jitter Pattern Length, set the Lagging ISI filter coefficient. Go to <a href="http://www.keysight.com">www.keysight.com</a> for application note 5989-4974EN to help select the correct ISI filter.
Configure	ISI Filter Lead	ISILead	(Accepts user-defined text), -2	When using Arbitrary mode for the Jitter Pattern Length, set the Leading ISI filter coefficient. Go to <a href="http://www.keysight.com">www.keysight.com</a> for application note 5989-4974EN to help select the correct ISI filter.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Jitter Pattern Length	PatLength	Periodic, Arbitrary	Choose Periodic or Arbitrary. Periodic is used for data patterns that are period and repeat through the scope memory. Arbitrary is used for random data patterns that does not repeat. Set ISI filter options below as well when selecting Arbitrary.
Configure	Lower Threshold	LowerThresh	(Accepts user-defined text), -50e-3	When using manual thresholds, set this value for the lower threshold. Set threshold value for a differential signal.
Configure	Manual Thresholds	ManThresh	Y, N	Select Yes to manually set measurement thresholds.
Configure	Middle Threshold	MidThresh	(Accepts user-defined text), 0	When using manual thresholds, set this value for the middle threshold. Set threshold value for a differential signal.
Configure	Number of Averages for Rise/Fall Time	NumAVG	(Accepts user-defined text), 16, 64, 256, 1024	Select the number of averages to use for rise and fall time measurements. "Use Averagin for Rise/Fall Time" must be set to "On".
Configure	Number of UI	NumUI	(Accepts user-defined text), 1e6	Enter in the number or UI to test. Memory depth will be set accordingly.
Configure	Rj Bandwidth	RjBandwidth	NARROW, WIDE	Choose the Rj Filter used in the jitter measurements.
Configure	Sample Rate	SR	(Accepts user-defined text), 80e9	Enter the scope sample rate.
Configure	Save Tested Waveforms	SaveWFM	No, Yes	Select Yes to save the waveform files of the tested signals. Files will be saved to directory set in Select waveform directory.
Configure	Select Waveform Directory	DirWFM	(Accepts user-defined text), C:\Temp\KRwfm	Type in a directory path to save your measured waveforms.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Signal Channels	CHANPAIR	1, 2, CHANnel1, CHANnel2, CHANnel3, CHANnel4, 3, 4, WMEMory1, WMEMory2, WMEMory3, WMEMory4, FUNCtion1, FUNCtion2, FUNCtion3, FUNCtion4	Select the oscilloscope input channel pair if connected dual single-ended. Or select the channel used for differential connection. All single channel, waveform memories, or functions that contain the word "differential", must be a single probe or signal that is differential. The channel or waveform memories with two channels are for dual single-ended connections. Note: All functions must be differential.
Configure	Switch Matrix Scope Channels	CHANPAIR2	3, 4	This configuration variable is automatically set. This is for information purposes, to show the user which channels were selected in the setup tab.
Configure	TX Off Voltage Scale	TXOFFSCALE	(Accepts user-defined text), Auto, 10e-3	Auto will automatically set the voltage scale for tests with the transmitter off. To manually set the scale, enter in the scale per division number (i.e. 10e-3)
Configure	TX On Voltage Scale	TXONSCALE	(Accepts user-defined text), Auto, 200e-3	Auto will automatically set the voltage scale for tests with the transmitter on. To manually set the scale, enter in a scale per division number (i.e. 200e-3).
Configure	Upper Threshold	UpperThresh	(Accepts user-defined text), 50e-3	When using manual thresholds, set this value for the upper threshold. Set threshold value for a differential signal.
Configure	Use Averaging for Rise/Fall Time	AVG	(Accepts user-defined text), Off, On	Select "On" to use averaging for rise and fall time measurements. If "On" is selected, set number of averages.
Run Tests	Event	RunEvent	(None), Fail, Margin < N, Pass	Names of events that can be used with the StoreMode=Event or RunUntil RunEventAction options
Run Tests	RunEvent=Margin < N: Minimum required margin %	RunEvent_Margin < N_MinPercent	Any integer in range: 0 <= value <= 99	Specify N using the 'Minimum required margin %' control.

## 3 Test Names and IDs

The following table shows the mapping between each test's numeric ID and name. The numeric ID is required by various remote interface methods.

- Name – The name of the test as it appears on the user interface **Select Tests** tab.
- Test ID – The number to use with the RunTests method.
- Description – The description of the test as it appears on the user interface **Select Tests** tab.

For example, if the graphical user interface displays this tree in the **Select Tests** tab:

- All Tests
  - Rise Time
  - Fall Time

then you would expect to see something like this in the table below:

**Table 3** Example Test Names and IDs

Name	Test ID	Description
Fall Time	110	Measures clock fall time.
Rise Time	100	Measures clock rise time.

and you would run these tests remotely using:

ARSL syntax

-----

```
arsl -a ipaddress -c "SelectedTests '100,110'"  
arsl -a ipaddress -c "Run"
```

C# syntax

-----

```
remoteAte.SelectedTests = new int[] {100,110};  
remoteAte.Run();
```

Here are the actual Test names and IDs used by this application. Listed at the end, you may also find:

- Deprecated IDs and their replacements.
- Macro IDs which may be used to select multiple related tests at the same time.

**NOTE**

The file, "TestInfo.txt", which may be found in the same directory as this help file, contains all of the information found in the table below in a format suitable for parsing.

**Table 4** Test IDs and Names

Name	TestID	Description
(v1+v4)/v1 (Additional) - Coefficient Status dis-max-dis	513	(v1+v4)/v1 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
(v1+v4)/v1 (Additional) - Coefficient Status dis-max-dis	1513	(v1+v4)/v1 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
(v1+v4)/v1 (Additional) - Coefficient Status dis-min-dis	505	(v1+v4)/v1 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
(v1+v4)/v1 (Additional) - Coefficient Status dis-min-dis	1505	(v1+v4)/v1 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
(v1+v4)/v1 (Additional) - Coefficient Status dis-min-min	527	(v1+v4)/v1 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
(v1+v4)/v1 (Additional) - Coefficient Status dis-min-min	1527	(v1+v4)/v1 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
(v1+v4)/v1 (Additional) - Coefficient Status min-min-dis	520	(v1+v4)/v1 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
(v1+v4)/v1 (Additional) - Coefficient Status min-min-dis	1520	(v1+v4)/v1 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
(v2+v5)/v2 (Additional) - Coefficient Status dis-max-dis	514	(v2+v5)/v2 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
(v2+v5)/v2 (Additional) - Coefficient Status dis-max-dis	1514	(v2+v5)/v2 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
(v2+v5)/v2 (Additional) - Coefficient Status dis-min-dis	506	(v2+v5)/v2 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
(v2+v5)/v2 (Additional) - Coefficient Status dis-min-dis	1506	(v2+v5)/v2 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
(v2+v5)/v2 (Additional) - Coefficient Status dis-min-min	528	(v2+v5)/v2 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
(v2+v5)/v2 (Additional) - Coefficient Status dis-min-min	1528	(v2+v5)/v2 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
(v2+v5)/v2 (Additional) - Coefficient Status min-min-dis	521	(v2+v5)/v2 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
(v2+v5)/v2 (Additional) - Coefficient Status min-min-dis	1521	(v2+v5)/v2 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
(v3+v6)/v3 (Additional) - Coefficient Status dis-max-dis	515	(v3+v6)/v3 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
(v3+v6)/v3 (Additional) - Coefficient Status dis-max-dis	1515	(v3+v6)/v3 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
(v3+v6)/v3 (Additional) - Coefficient Status dis-min-dis	507	(v3+v6)/v3 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
(v3+v6)/v3 (Additional) - Coefficient Status dis-min-dis	1507	(v3+v6)/v3 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
(v3+v6)/v3 (Additional) - Coefficient Status dis-min-min	529	(v3+v6)/v3 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
(v3+v6)/v3 (Additional) - Coefficient Status dis-min-min	1529	(v3+v6)/v3 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
(v3+v6)/v3 (Additional) - Coefficient Status min-min-dis	522	(v3+v6)/v3 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
(v3+v6)/v3 (Additional) - Coefficient Status min-min-dis	1522	(v3+v6)/v3 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
Common Mode Voltage Test	101	Test the common mode voltage. This test can only be tested in dual single ended connection
Common Mode Voltage Test	1101	Test the common mode voltage. This test can only be tested in dual single ended connection
DME Differential Peak to Peak Output Voltage Test	700	Test the maximum voltage of the signal during DME
DME Differential Peak to Peak Output Voltage Test	1700	Test the maximum voltage of the signal during DME
DME T1-Transition Position Spacing (period) Test	701	Test transition position spacing when in mode DME
DME T1-Transition Position Spacing (period) Test	1701	Test transition position spacing when in mode DME
DME T2-Clock Transition to Clock Transition Test	702	Test Clock Transition to Clock Transition in mode DME
DME T2-Clock Transition to Clock Transition Test	1702	Test Clock Transition to Clock Transition in mode DME
DME T3-Clock Transition to Data Transition Test	703	Test transition time between clock transition to data transition in mode DME

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
DME T3-Clock Transition to Data Transition Test	1703	Test transition time between clock transition to data transition in mode DME
Data Rate Mean	200	Average data rate of the signal
Data Rate Mean	1200	Average data rate of the signal
Deterministic Jitter	202	Deterministic Jitter measurement
Deterministic Jitter	1202	Deterministic Jitter measurement
Differential Peak to Peak Output Voltage Test	102	Test the maximum voltage with the TX enabled
Differential Peak to Peak Output Voltage Test	1102	Test the maximum voltage with the TX enabled
Differential Peak to Peak Output Voltage Test with TX disabled	100	Test the maximum voltage with the TX disabled
Differential Peak to Peak Output Voltage Test with TX disabled	1100	Test the maximum voltage with the TX disabled
Duty Cycle Distortion	203	Duty Cycle Distortion measurement
Duty Cycle Distortion	1203	Duty Cycle Distortion measurement
EEE Common Mode Voltage Deviation Test	802	Test the common mode voltage Deviation in EEE. This test can only be tested in dual single ended connection
EEE Common Mode Voltage Deviation Test	1802	Test the common mode voltage Deviation in EEE. This test can only be tested in dual single ended connection
EEE Differential Peak to Peak Output Voltage Test	801	Test the maximum voltage with the TX enabled in EEE
EEE Differential Peak to Peak Output Voltage Test	1801	Test the maximum voltage with the TX enabled in EEE
EEE Differential Peak to Peak Output Voltage Test with TX disabled	800	Test the maximum voltage with the TX disabled in EEE
EEE Differential Peak to Peak Output Voltage Test with TX disabled	1800	Test the maximum voltage with the TX disabled in EEE
Initialize State Rpst	901	Rpst measurement for Initialize Rpst
Initialize State Rpst	1901	Rpst measurement for Initialize Rpst
Intialize State Rpre	900	Rpre measurement when in Initialize State.
Intialize State Rpre	1900	Rpre measurement when in Initialize State.
Random Jitter	201	Random Jitter measurement
Random Jitter	1201	Random Jitter measurement



**Table 4** Test IDs and Names (continued)

Name	TestID	Description
Rpre - Coefficient Status dis-max-dis	508	Rpre measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
Rpre - Coefficient Status dis-max-dis	1508	Rpre measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
Rpre - Coefficient Status dis-min-dis	500	Rpre measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
Rpre - Coefficient Status dis-min-dis	1500	Rpre measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
Rpre - Coefficient Status dis-min-min	523	Rpre measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
Rpre - Coefficient Status dis-min-min	1523	Rpre measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
Rpre Result	608	Rpre measurement
Rpst - Coefficient Status dis-max-dis	509	Rpst measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
Rpst - Coefficient Status dis-max-dis	1509	Rpst measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
Rpst - Coefficient Status dis-min-dis	501	Rpst measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
Rpst - Coefficient Status dis-min-dis	1501	Rpst measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
Rpst - Coefficient Status min-min-dis	516	Rpst measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
Rpst - Coefficient Status min-min-dis	1516	Rpst measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
Rpst Result	609	Rpst measurement
Total Jitter	204	Total Jitter measurement
Total Jitter	1204	Total Jitter measurement
Transition Time (20%-80%) - Falling Edge	301	Fall Time measurement
Transition Time (20%-80%) - Falling Edge	1301	Fall Time measurement
Transition Time (20%-80%) - Rising Edge	300	Rise Time measurement
Transition Time (20%-80%) - Rising Edge	1300	Rise Time measurement

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
delta_v2 (Additional) - Coefficient Status dis-max-dis	511	delta_v2 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
delta_v2 (Additional) - Coefficient Status dis-max-dis	1511	delta_v2 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
delta_v2 (Additional) - Coefficient Status dis-min-dis	503	delta_v2 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
delta_v2 (Additional) - Coefficient Status dis-min-dis	1503	delta_v2 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
delta_v2 (Additional) - Coefficient Status dis-min-min	525	delta_v2 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
delta_v2 (Additional) - Coefficient Status dis-min-min	1525	delta_v2 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
delta_v2 (Additional) - Coefficient Status min-min-dis	518	delta_v2 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
delta_v2 (Additional) - Coefficient Status min-min-dis	1518	delta_v2 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
delta_v2 Result	606	delta_v2 measurement
delta_v5 (Additional) - Coefficient Status dis-max-dis	512	delta_v5 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
delta_v5 (Additional) - Coefficient Status dis-max-dis	1512	delta_v5 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
delta_v5 (Additional) - Coefficient Status dis-min-dis	504	delta_v5 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
delta_v5 (Additional) - Coefficient Status dis-min-dis	1504	delta_v5 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
delta_v5 (Additional) - Coefficient Status dis-min-min	526	delta_v5 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
delta_v5 (Additional) - Coefficient Status dis-min-min	1526	delta_v5 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
delta_v5 (Additional) - Coefficient Status min-min-dis	519	delta_v5 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
delta_v5 (Additional) - Coefficient Status min-min-dis	1519	delta_v5 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
delta_v5 Result	607	delta_v5 measurement
v1 - Coefficient Update dec-hold-hold	403	v1 measurement for Coefficient update c1-dec c0-hold c-1-hold
v1 - Coefficient Update dec-hold-hold	1403	v1 measurement for Coefficient update c1-dec c0-hold c-1-hold

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
v1 - Coefficient Update hold-dec-hold	409	v1 measurement for Coefficient update c1-hold c0-dec c-1-hold
v1 - Coefficient Update hold-dec-hold	1409	v1 measurement for Coefficient update c1-hold c0-dec c-1-hold
v1 - Coefficient Update hold-hold-dec	415	v1 measurement for Coefficient update c1-hold c0-hold c-1-dec
v1 - Coefficient Update hold-hold-dec	1415	v1 measurement for Coefficient update c1-hold c0-hold c-1-dec
v1 - Coefficient Update hold-hold-inc	412	v1 measurement for Coefficient update c1-hold c0-hold c-1-inc
v1 - Coefficient Update hold-hold-inc	1412	v1 measurement for Coefficient update c1-hold c0-hold c-1-inc
v1 - Coefficient Update hold-inc-hold	406	v1 measurement for Coefficient update c1-hold c0-inc c-1-hold
v1 - Coefficient Update hold-inc-hold	1406	v1 measurement for Coefficient update c1-hold c0-inc c-1-hold
v1 - Coefficient Update inc-hold-hold	400	v1 measurement for Coefficient update c1-inc c0-hold c-1-hold
v1 - Coefficient Update inc-hold-hold	1400	v1 measurement for Coefficient update c1-inc c0-hold c-1-hold
v1 Result	600	v1 measurement
v2 - Coefficient Status dis-max-dis	510	v2 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
v2 - Coefficient Status dis-max-dis	1510	v2 measurement for Coefficient status c1-disabled c0-maximum c-1-disabled
v2 - Coefficient Status dis-min-dis	502	v2 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
v2 - Coefficient Status dis-min-dis	1502	v2 measurement for Coefficient status c1-disabled c0-minimum c-1-disabled
v2 - Coefficient Status dis-min-min	524	v2 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
v2 - Coefficient Status dis-min-min	1524	v2 measurement for Coefficient status c1-disabled c0-minimum c-1-minimum
v2 - Coefficient Status min-min-dis	517	v2 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
v2 - Coefficient Status min-min-dis	1517	v2 measurement for Coefficient status c1-minimum c0-minimum c-1-disabled
v2 - Coefficient Update dec-hold-hold	404	v2 measurement for Coefficient update c1-dec c0-hold c-1-hold
v2 - Coefficient Update dec-hold-hold	1404	v2 measurement for Coefficient update c1-dec c0-hold c-1-hold
v2 - Coefficient Update hold-dec-hold	410	v2 measurement for Coefficient update c1-hold c0-dec c-1-hold
v2 - Coefficient Update hold-dec-hold	1410	v2 measurement for Coefficient update c1-hold c0-dec c-1-hold
v2 - Coefficient Update hold-hold-dec	416	v2 measurement for Coefficient update c1-hold c0-hold c-1-dec
v2 - Coefficient Update hold-hold-dec	1416	v2 measurement for Coefficient update c1-hold c0-hold c-1-dec

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
v2 - Coefficient Update hold-hold-inc	413	v2 measurement for Coefficient update c1-hold c0-hold c-1-inc
v2 - Coefficient Update hold-hold-inc	1413	v2 measurement for Coefficient update c1-hold c0-hold c-1-inc
v2 - Coefficient Update hold-inc-hold	407	v2 measurement for Coefficient update c1-hold c0-inc c-1-hold
v2 - Coefficient Update hold-inc-hold	1407	v2 measurement for Coefficient update c1-hold c0-inc c-1-hold
v2 - Coefficient Update inc-hold-hold	401	v2 measurement for Coefficient update c1-inc c0-hold c-1-hold
v2 - Coefficient Update inc-hold-hold	1401	v2 measurement for Coefficient update c1-inc c0-hold c-1-hold
v2 Result	601	v2 measurement
v3 - Coefficient Update dec-hold-hold	405	v3 measurement for Coefficient update c1-dec c0-hold c-1-hold
v3 - Coefficient Update dec-hold-hold	1405	v3 measurement for Coefficient update c1-dec c0-hold c-1-hold
v3 - Coefficient Update hold-dec-hold	411	v3 measurement for Coefficient update c1-hold c0-dec c-1-hold
v3 - Coefficient Update hold-dec-hold	1411	v3 measurement for Coefficient update c1-hold c0-dec c-1-hold
v3 - Coefficient Update hold-hold-dec	417	v3 measurement for Coefficient update c1-hold c0-hold c-1-dec
v3 - Coefficient Update hold-hold-dec	1417	v3 measurement for Coefficient update c1-hold c0-hold c-1-dec
v3 - Coefficient Update hold-hold-inc	414	v3 measurement for Coefficient update c1-hold c0-hold c-1-inc
v3 - Coefficient Update hold-hold-inc	1414	v3 measurement for Coefficient update c1-hold c0-hold c-1-inc
v3 - Coefficient Update hold-inc-hold	408	v3 measurement for Coefficient update c1-hold c0-inc c-1-hold
v3 - Coefficient Update hold-inc-hold	1408	v3 measurement for Coefficient update c1-hold c0-inc c-1-hold
v3 - Coefficient Update inc-hold-hold	402	v3 measurement for Coefficient update c1-inc c0-hold c-1-hold
v3 - Coefficient Update inc-hold-hold	1402	v3 measurement for Coefficient update c1-inc c0-hold c-1-hold
v3 Result	602	v3 measurement
v4 Result	603	v4 measurement
v5 Result	604	v5 measurement
v6 Result	605	v6 measurement

## 4 Instruments

The following table shows the instruments used by this application. The name is required by various remote interface methods.

- Instrument Name – The name to use as a parameter in remote interface commands.
- Description – The description of the instrument.

For example, if an application uses an oscilloscope and a pulse generator, then you would expect to see something like this in the table below:

**Table 5** Example Instrument Information

Name	Description
scope	The primary oscilloscope.
Pulse	The pulse generator used for Gen 2 tests.

and you would be able to remotely control an instrument using:

ARSL syntax (replace [description] with actual parameter)

```
-----  
arsl -a ipaddress -c "SendScpiCommandCustom 'Command=[scpi  
command];Timeout=100;Instrument=pulsegen'"
```

```
arsl -a ipaddress -c "SendScpiQueryCustom 'Command=[scpi  
query];Timeout=100;Instrument=pulsegen'"
```

C# syntax (replace [description] with actual parameter)

```
-----  
SendScpiCommandOptions commandOptions = new SendScpiCommandOptions();  
commandOptions.Command = "[scpi command]";  
commandOptions.Instrument = "[instrument name]";  
commandOptions.Timeout = [timeout];  
remoteAte.SendScpiCommand(commandOptions);
```

```
SendScpiQueryOptions queryOptions = new SendScpiQueryOptions();  
queryOptions.Query = "[scpi query]";  
queryOptions.Instrument = "[instrument name]";
```

```
queryOptions.Timeout = [timeout];
remoteAte.SendScpiQuery(queryOptions);
```

Here are the actual instrument names used by this application:

**NOTE**

The file, "InstrumentInfo.txt", which may be found in the same directory as this help file, contains all of the information found in the table below in a format suitable for parsing.

**Table 6** Instrument Names

Instrument Name	Description
Infiniium	The primary oscilloscope
Keysight PNA	Performance Network Analyzer
Keysight ENA	Economy Network Analyzer

# Index

## C

configuration variables and values, [9](#)  
copyright, [2](#)

## I

IDs and names of tests, [13](#)  
instrument names, [21](#)

## N

names and IDs of tests, [13](#)  
names of instruments, [21](#)  
notices, [2](#)

## P

programming, introduction to, [7](#)

## R

Remote Programming Toolkit, [8](#)

## T

test names and IDs, [13](#)

## V

variables and values, configuration, [9](#)

## W

warranty, [2](#)

