
Keysight D90203DJC / D93203DJC

IEEE 802.3 dj Compliance

Application

Notices

© Keysight Technologies, Inc. 2005-2026

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Revision

Version 1.2.0.0

Edition

March 10, 2026

Available in electronic format only

Published by:

Keysight Technologies, Inc.
1900 Garden of the Gods Road
Colorado Springs, CO 80907 USA

Warranty

The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Keysight disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Keysight shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Keysight and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

Technology License

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

U.S. Government Rights

The Software is "commercial computer software," as defined by Federal Acquisition Regulation ("FAR") 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement ("DFARS") 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at www.keysight.com/find/sweula. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

In This Book

This book is your guide to programming the Keysight Technologies D90203DJC / D93203DJC IEEE 802.3 dj Compliance Application.

- **Chapter 1**, “Introduction to Programming,” starting on page 7, describes compliance application programming basics.
- **Chapter 2**, “Configuration Variables and Values,” starting on page 9, **Chapter 3**, “Test Names and IDs,” starting on page 25, and **Chapter 4**, “Instruments,” starting on page 39 provide information specific to programming the D90203DJC / D93203DJC IEEE 802.3 dj Compliance Application.

How to Use This Book

Programmers who are new to compliance application programming should read all of the chapters in order. Programmers who are already familiar with this may review chapters 2, 3, and 4 for changes.

Contents

In This Book / 3

1 Introduction to Programming

Remote Programming Toolkit / 8

2 Configuration Variables and Values

3 Test Names and IDs

4 Instruments

Index

1 Introduction to Programming

Remote Programming Toolkit / 8

This chapter introduces the basics for remote programming a compliance/test application. The programming commands provide the means of remote control. Basic operations that you can do remotely with a computer and a compliance/test app running on an oscilloscope include:

- Launching and closing the application.
- Configuring the options.
- Running tests.
- Getting results.
- Controlling when and where dialogs get displayed
- Saving and loading projects.

You can accomplish other tasks by combining these functions.

Remote Programming Toolkit

The majority of remote interface features are common across all the Keysight Technologies, Inc. family of compliance/test applications. Information on those features is provided in the N5452A Compliance Application Remote Programming Toolkit available for download from Keysight here: www.keysight.com/find/rpi. The D90203DJC / D93203DJC IEEE 802.3 dj Compliance Application uses Remote Interface Revision 7.30. The help files provided with the toolkit indicate which features are supported in this version.

In the toolkit, various documents refer to "application-specific configuration variables, test information, and instrument information". These are provided in Chapters 2, 3, and 4 of this document, and are also available directly from the application's user interface when the remote interface is enabled (View>Preferences::Remote tab::Show remote interface hints). See the toolkit for more information.

2 Configuration Variables and Values

The following table contains a description of each of the D90203DJC / D93203DJC IEEE 802.3 dj Compliance Application options that you may query or set remotely using the appropriate remote interface method. The columns contain this information:

- GUI Location – Describes which graphical user interface tab contains the control used to change the value.
- Label – Describes which graphical user interface control is used to change the value.
- Variable – The name to use with the SetConfig method.
- Values – The values to use with the SetConfig method.
- Description – The purpose or function of the variable.

For example, if the graphical user interface contains this control on the **Set Up** tab:

- Enable Advanced Features

then you would expect to see something like this in the table below:

Table 1 Example Configuration Variables and Values

GUI Location	Label	Variable	Values	Description
Set Up	Enable Advanced Features	EnableAdvanced	True, False	Enables a set of optional features.

and you would set the variable remotely using:

ARSL syntax

```
arsl -a ipaddress -c "SetConfig 'EnableAdvanced' 'True'"
```

C# syntax

```
-----
remoteAte.SetConfig("EnableAdvanced", "True");
```

Here are the actual configuration variables and values used by this application:

NOTE

Some of the values presented in the table below may not be available in certain configurations. Always perform a "test run" of your remote script using the application's graphical user interface to ensure the combinations of values in your program are valid.

NOTE

The file, "ConfigInfo.txt", which may be found in the same directory as this help file, contains all of the information found in the table below in a format suitable for parsing.

Table 2 Configuration Variables and Values

GUI Location	Label	Variable	Values	Description
Configure	Auto Apply Infiniisim Settings	AutoApplyInfiniisim	No, Yes	Select "Yes" to automatically apply Infiniisim settings before performing manual channel deskew to the channels in the following cases: 1) When a project is loaded while this option is set to "Yes". 2) When Infiniisim setup is completed while this option is set to "Yes". 3) When this option is changed from "No" to "Yes". Not applicable to Infiniium Offline.
Configure	Auto Load Waveform with Interpolation	AutoLoadWfmInterp	No, Yes	Select "Yes" to automatically detect the saved waveform interpolation ratio, then load the waveform with the correct interpolation ratio. This option will automatically switch to "Yes" when performing an Online Run.
Configure	Bandwidth	BW	(Accepts user-defined text), 60e9	Enter the scope bandwidth.
Configure	Channel 1 Skew	Channel1Skew	(Accepts user-defined text), 0	Set the skew for Channel 1 (in seconds). For example, to set a skew of -2.2 picoseconds, enter -2.2e-12.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Channel 2 Skew	Channel2Skew	(Accepts user-defined text), 0	Set the skew for Channel 2 (in seconds). For example, to set a skew of -2.2 picoseconds, enter -2.2e-12.
Configure	Channel 3 Skew	Channel3Skew	(Accepts user-defined text), 0	Set the skew for Channel 3 (in seconds). For example, to set a skew of -2.2 picoseconds, enter -2.2e-12.
Configure	Channel 4 Skew	Channel4Skew	(Accepts user-defined text), 0	Set the skew for Channel 4 (in seconds). For example, to set a skew of -2.2 picoseconds, enter -2.2e-12.
Configure	Clock Recovery Method	CRMethod	FOPLL, SOPLL	Select the Clock Recovery Method to be used.
Configure	Damping Factor	DFactor	(Accepts user-defined text), 1	Enter the Damping Factor to use for clock recovery. This value is only used for Second Order PLL. You may enter any value.
Configure	Disable Pattern Check	DisablePattern	Enable, Disable	Select "Disable" to disable the pattern verification for square 8 pattern tests and suppress pattern error pop-ups. Select "Enable" to ensure that the correct pattern is being tested as per specification.
Configure	Disable SNDR Pre-requisites	DisSNDRPre	Enabled, Disabled	Sigma n and ES1/ES2 are pre-requisite measurements to SNDR. If you want to skip these pre-requisites and enter a user sigma-n value, Select "Disable". ES1/ES2 will be set to 0.33.
Configure	Dp	DpVal	(Accepts user-defined text), 2, 3, 4	Set the Dp value used for steady state, linear fit pulse peak, and error calculations.
Configure	Eye Gaussian Standard Deviation	EyeStd	(Accepts user-defined text), 2	Select or set the standard deviation used in eye measurements (EH, EW, VEC) when gaussian window shape is used.
Configure	Eye Height/Width Probability	NumUI	(Accepts user-defined text), 1e-5, 1e-6, 1e-15	Select the eye probability to test to for Eye Height and Width tests.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Eye Level Width	EyeLevWidth	(Accepts user-defined text), 5, 10	Select the eye level width used in eye measurements (EH, EW, VEC).
Configure	Eye Window Shape	EyeWinShape	GAUSSian, BOXCar	Select the eye window shape used in eye measurements (EH, EW, VEC).
Configure	Find Scope Optimal FFE	ScopeOptFFE	OFF, ON	Select to automatically find the optimal FFE with the scope at the start of the run. Use Test Tx FFE source to set whether FFE will be applied in the scope or the Tx. Note: this is not used for auto-tune. This is for debugging only using FFE for testing.
Configure	Host Designation	HostDesign	HostLow, HostNominal, HostHigh	Choose a host designation. Host-Low, Host-Nominal, and Host-High correspond to low, moderate, and high levels of insertion loss, respectively.
Configure	Jitter Edge Count	JitCount	(Accepts user-defined text), 200, 10000	Set the number of edges for jitter to start measuring results. Note: lower value than the default of 10000 will not be as accurate and consistent. However, will enable quick results.
Configure	Jitter Memory Depth per Acquisition	JitMem	(Accepts user-defined text), 10000000, 60000000	Set the memory depth used for jitter measurement. A lower memory depth requires more acquisitions to complete one measurement.
Configure	Jitter Pattern	JitPat	P9Q, P13Q	Select PRBS13Q or PRBS9Q to test jitter.
Configure	Loop Bandwidth	LoopBandwidth	(Accepts user-defined text), 4e6, 10e6, 10.3035e6	Enter the loop bandwidth to use for clock recovery. Value with automatically scale with signaling rate change. Manually set to desired value if different from autoset.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Measure Tfx Delay Method (ERL)	MeasureTfxDelayMethod	COM, User	This is for test point TP0v only. Select "COM" to have the COM measure the fixture delay time (Tfx) and apply in ERL calculation. If you select "User Provided", enter the value that you would like to use.
Configure	Measure Tfx Delay Method (Reference ERL)	MeasureRefERLTfxDelayMethod	COM, User	This is for test point TP0v only. Select "COM" to have the COM measure the fixture delay time (Tfx) and apply in Ref ERL calculation. If you select "User Provided", enter the value that you would like to use.
Configure	Nb	NbVal	(Accepts user-defined text), 1, 6, 10, 12, 13, 14, 16	Set the Nb value used for steady state, linear fit pulse peak, and error calculations.
Configure	NbSNRISI	NbSNRISIVa	(Accepts user-defined text), 6, 10, 12, 13, 14, 16, 20	Set the Nb value used for SNRISI calculations.
Configure	Np	NpVal	(Accepts user-defined text), 8, 12, 13, 14, 29, 200, 400	Set the Np value used for SNDR and SNR_ISI calculations.
Configure	Number of Averages	NumAvg	16, 32, 64, 128, 256	Specify the number of averages for the detected bit pattern output. The averaged pattern will be used to construct a linear fit pulse response. Use a lower value for faster test times.
Configure	Number of FFE Precursor Taps	NumFFEPre	(Accepts user-defined text), 5	Specify the total number of FFE Precursor Taps. The number of Postcursor Taps will be (NumTapsFFE - NumPreTapsFFE - 1). The minus one is due to Tap 0.
Configure	Number of FFE Taps	NumFFETaps	(Accepts user-defined text), 29	Specify the total number of FFE Taps including Tap 0

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Nv	NvVal	(Accepts user-defined text), 8, 12, 13, 14, 29, 200, 400	Set the Nv value used for steady state, linear fit pulse peak, and error calculations.
Configure	Output Voltage Probability	P	1e-5, 1e-6, 1e-7	Select the probability P with respect to the distribution of the output voltage Vout. Note: using higher P value will enable fast test times. However, the only P value that complies with the specification is 1e-7.
Configure	Package Class	PkgClass	ClassA, ClassB	Choose the Package Model Class (Class A or Class B). This selection applies to both the transmitter and receiver. The chosen configuration will be utilized for the dVf and J4u03 measurements of TP0v.
Configure	Reference SNDR File Path	PathSNDRref	defaultPathSNDRref, editablePathSNDRref	Specify the source of the reference SNDR values. If "Use Default File" is selected, the application will use the default CSV file located at "C:\Program Files\Keysight\Infiniium\Apps\IEEEdj Test\app\dSNDR\SNDR_ref_evaluation_and_data.csv". Alternatively, selecting "Use Editable File" will point to a custom CSV file located at "C:\ProgramData\Keysight\Infiniium\Apps\IEEEdj Test\dSNDR\SNDR_ref_evaluation_and_data.csv", which users can modify to define their own SNDR reference values for evaluation.
Configure	Sample Rate	SR	(Accepts user-defined text), 256e9	Enter the scope sample rate.
Configure	Save Tested Waveforms	SaveWFM	No, Yes	Select Yes to save the waveform files of the tested signals. Files will be saved to directory set in Select waveform directory.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Scope Level 0 RNrms (V)	UnifiedRN0	(Accepts user-defined text), 0	The known amount of "zero" random noise. This value is applied when Use Single Set of Scope Noises is set to Yes.
Configure	Scope Level 1 RNrms (V)	UnifiedRN1	(Accepts user-defined text), 0	The known amount of "one" random noise. This value is applied when Use Single Set of Scope Noises is set to Yes.
Configure	Scope Level 2 RNrms (V)	UnifiedRN2	(Accepts user-defined text), 0	The known amount of "two" random noise. This value is applied when Use Single Set of Scope Noises is set to Yes.
Configure	Scope Level 3 RNrms (V)	UnifiedRN3	(Accepts user-defined text), 0	The known amount of "three" random noise. This value is applied when Use Single Set of Scope Noises is set to Yes.
Configure	Scope Response	ScopeResp	BESSEL4, BUTT, WALL	Select the Scope Response. A selection of 4th order Bessel will better represent a reference receiver. A flat response will give a direct look at the exact signal at the test point.
Configure	Scope Response 3dB frequency	ScopeFreq	(Accepts user-defined text), 50e9, 59e9, 60e9, 63e9, 80e9	Select the Scope Response 3dB frequency.
Configure	Select Preset for SNDR/RLM	PresetSNDRRLM	1, 2, 3, 4, 5	Select the Preset that is desired for the SNDR/RLM Test. *NOTE: This settings is not applicable for Offline Run. Only Preset 1 is available for Offline Run.
Configure	Select Waveform Directory	DirWFM	(Accepts user-defined text), C:\Temp\IEEEwfm	Type in a directory path to save your measured waveforms.
Configure	Set Channel Skew Method	SetChannelSkewMethod	Auto, Manual	Select the method for setting the channel skew. Choose "Auto" to let the system determine the optimal skew automatically, or "Manual" to allow manual adjustment.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Sigma N	SigmaN	(Accepts user-defined text), 2e-3	Enter the value to use for Sigma N. This value will be used when SNDR pre-req are disabled. Format 0.002 or 2e-3.
Configure	Signal Channels	CHANPAIR	1, 2, Channel 1 and 2, Channel 3 and 4, CHANnel1, CHANnel2, CHANnel3, CHANnel4, 3, 4, WMemory1, WMemory2, WMemory3, WMemory4, FUNCTION1, FUNCTION2, FUNCTION3, FUNCTION4	Select the oscilloscope input channel pair if connected dual single-ended. Or select the channel used for differential connection. All single channel, waveform memories, or functions that contain the word "differential", must be a single probe or signal that is differential. The channel or waveform memories with two channels are for dual single-ended connections. Note: All functions must be differential.
Configure	Signaling Rate	SignalingRate	(Accepts user-defined text), 53.125e9, 106.25e9	Set the Signaling Rate to be tested. Enter value in the format 10.3125e9.
Configure	Test Tx FFE source	FFESource	Scope, DUT	Select where FFE is applied for eye tests. Optimal transmitter FFE is calculated during Auto-tune. User can select to have the scope use the values found, or set DUT FFE.
Configure	Tfx Delay for TP0v	TfxTP0v	(Accepts user-defined text), 0	Select the value of fixture delay time for TP0v (C2C). This is for ERL measurement. The fixture delay time (Tfx) is twice the propagation delay in ns associated with the test fixture. Please enter value in the format 2e-9.
Configure	Tfx Delay for TP0v	TfxTP0vKR	(Accepts user-defined text), 0	Select the value of fixture delay time for TP0v (KR). This is for ERL measurement. The fixture delay time (Tfx) is twice the propagation delay in ns associated with the test fixture. Please enter value in the format 2e-9.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Tfx Delay for TP0v (Reference ERL)	RefERLTfxTP0v	(Accepts user-defined text), 0	Select the value of fixture delay time for TP0v (C2C). This is for Ref ERL measurement. The fixture delay time (Tfx) is twice the propagation delay in ns associated with the test fixture. Please enter value in the format 2e-9.
Configure	Tfx Delay for TP0v (Reference ERL)	RefERLTfxTP0vKR	(Accepts user-defined text), 0	Select the value of fixture delay time for TP0v (KR). This is for Ref ERL measurement. The fixture delay time (Tfx) is twice the propagation delay in ns associated with the test fixture. Please enter value in the format 2e-9.
Configure	Tfx Delay for TP1a	TfxTP1a	(Accepts user-defined text), 0	Select the value of fixture delay time for TP1a. This is for ERL measurement. The fixture delay time (Tfx) is twice the propagation delay in ns associated with the test fixture. Please enter value in the format 2e-9.
Configure	Tfx Delay for TP2	TfxTP2	(Accepts user-defined text), 0	Select the value of fixture delay time for TP2. This is for ERL measurement. The fixture delay time (Tfx) is twice the propagation delay in ns associated with the test fixture. Please enter value in the format 2e-9.
Configure	Tfx Delay for TP4	TfxTP4	(Accepts user-defined text), 0	Select the value of fixture delay time for TP4. This is for ERL measurement. The fixture delay time (Tfx) is twice the propagation delay in ns associated with the test fixture. Please enter value in the format 2e-9.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Tx pattern	SNDRPat	PRBS13Q, PRBS13Qu, Other, OtherInv	Select the pattern to be used for SNDR, Coefficient, and DFE calculations. NOTE: This pattern is NOT for Jitter measurements. Due to specific edge definitions for the 12 edges, PRBS13Q grey code or PRBS9Q gray code are required. Use jitter pattern configuration for jitter selection. "PRBS13Q" is the specified PRBS13Q grey code signal. "PRBS13Q Uncoded" is PRBS13Q uncoded. "Other" is a PRBS13Q pattern that not only swapped the 3/2 (as defined by grey code), but also the 0/1. "Other Inv" is the inverse of "Other"
Configure	Use Optimized CTLE gDC for Eye Opening TP1a.	UseCTLE	0, -1, -2, -3, -4, -5, -6, -7, -8, -9, -10	Select the optimized setting to use. Default is off. Run "Auto-tune" Test under "Utilities" to find the optimal setting. When the utility is run, it will automatically set the optimal setting. This value will only be automatically set if utility is run any time after app load or if project is loaded with setting. All other instances, the setting will be the default of off and will need to be manually selected.
Configure	Use Optimized CTLE gDC for Far-end Eye Opening TP4 Short.	UseFarCTLE	0, -1, -2, -3, -4, -5, -6, -7, -8, -9, -10	Select the optimized setting to use. Default is off. Run "Auto-tune" Test under "Utilities" to find the optimal setting. When the utility is run, it will automatically set the optimal setting. This value will only be automatically set if utility is run any time after app load or if project is loaded with setting. All other instances, the setting will be the default of off and will need to be manually selected.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Use Optimized CTLE gDC for Far-end Eye Opening TP4.	UseFarCTLE	0, -1, -2, -3, -4, -5, -6, -7, -8, -9, -10	Select the optimized setting to use. Default is off. Run "Auto-tune" Test under "Utilities" to find the optimal setting. When the utility is run, it will automatically set the optimal setting. This value will only be automatically set if utility is run any time after app load or if project is loaded with setting. All other instances, the setting will be the default of off and will need to be manually selected.
Configure	Use Optimized CTLE gDC for Near-end Eye Opening TP4.	UseNearCTLE	0, -1, -2, -3, -4, -5, -6, -7, -8, -9, -10	Select the optimized setting to use. Default is off. Run "Auto-tune" Test under "Utilities" to find the optimal setting. When the utility is run, it will automatically set the optimal setting. This value will only be automatically set if utility is run any time after app load or if project is loaded with setting. All other instances, the setting will be the default of off and will need to be manually selected.
Configure	Use Optimized CTLE gDC2 for Eye Opening TP1a.	UseCTLEgDC2	0, -1, -2, -3, -4, -5	Select the optimized setting to use. Default is off. Run "Auto-tune" Test under "Utilities" to find the optimal setting. When the utility is run, it will automatically set the optimal setting. This value will only be automatically set if utility is run any time after app load or if project is loaded with setting. All other instances, the setting will be the default of off and will need to be manually selected.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Use Optimized CTLE gDC2 for Far-end Eye Opening TP4 Short.	UseFarCTLEgDC2	0, -1, -2, -3, -4, -5	Select the optimized setting to use. Default is off. Run "Auto-tune" Test under "Utilities" to find the optimal setting. When the utility is run, it will automatically set the optimal setting. This value will only be automatically set if utility is run any time after app load or if project is loaded with setting. All other instances, the setting will be the default of off and will need to be manually selected.
Configure	Use Optimized CTLE gDC2 for Far-end Eye Opening TP4.	UseFarCTLEgDC2	0, -1, -2, -3, -4, -5	Select the optimized setting to use. Default is off. Run "Auto-tune" Test under "Utilities" to find the optimal setting. When the utility is run, it will automatically set the optimal setting. This value will only be automatically set if utility is run any time after app load or if project is loaded with setting. All other instances, the setting will be the default of off and will need to be manually selected.
Configure	Use Optimized CTLE gDC2 for Near-end Eye Opening TP4.	UseNearCTLEgDC2	0, -1, -2, -3, -4, -5	Select the optimized setting to use. Default is off. Run "Auto-tune" Test under "Utilities" to find the optimal setting. When the utility is run, it will automatically set the optimal setting. This value will only be automatically set if utility is run any time after app load or if project is loaded with setting. All other instances, the setting will be the default of off and will need to be manually selected.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Use Predifined Function	UseFunc	Chan, FUNCTION1, FUNCTION3, FUNCTION4, FUNCTION5, FUNCTION6	This gives the option to use a function that the user sets up. Select the function the user has set. The app will skip default setup and scaling. Please ensure that the function you are using is properly scaled before starting run. Note: Function2 is used by the app, do not include Function 2 in your setup.
Configure	Use Scope Cal	ScopeCal	Y, N	Select Yes to use scope calibration. No, to not. This is automatically set to Yes when a scope cal is run on the setup tab.
Configure	Use Single Set of Scope Noises	UseUnifiedScopeNoise	Yes, No	Select Yes to apply the same set of scope noises across all presets. Select No to use different sets of scope noises for each preset. Note: If Yes is selected, the scope noise values must be specified in the configuration tab.
Configure	Vertical Scale Factor	VertScaleFactor	(Accepts user-defined text), 7, 6.5, 6, 5.5, 5, 4.5, 4	This setting specifies the fixed vertical scaling factor applied to the acquired signal when the Vertical Scaling Method is set to Manual. It allows users to define the exact scale used during signal acquisition, offering precise control over how signal amplitudes are represented. The value entered here represents the number of vertical divisions the signal will occupy on the display. Based on this setting, the vertical scale per division is automatically calculated by dividing the peak-to-peak voltage of the signal by the specified number of divisions.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Vertical Scaling Method	VertScaleMethod	Auto, Manual	This variable determines how vertical scaling is applied to the signal during acquisition. When set to "Auto", the system will automatically calculate and apply the appropriate vertical scale based on the acquired signal. If the method is set to "Manual", the user is required to specify the desired vertical scale factor explicitly in the "Vertical Scale Factor" configuration. This provides full control over the scaling behavior but requires manual input.
Configure	Vpp Pattern	VppPat	PRBS13Q, Square	Select the PRBS13Q pattern or the Square pattern (with a period of at least 128 UIs) to test the 'Differential Peak-to-Peak Output Voltage Test with Tx Enabled.
Run Tests	Event	RunEvent	(None), Fail, Margin < N, Pass	Names of events that can be used with the StoreMode=Event or RunUntil RunEventAction options
Run Tests	RunEvent=Margin < N: Minimum required margin %	RunEvent_Margin < N_MinPercent	Any integer in range: 0 <= value <= 99	Specify N using the 'Minimum required margin %' control.
Set Up	CalibrateBrickwall	CheckCalibrateBrickwall	0.0, 1.0	Enable scope noise calibration for a preset.
Set Up	CalibratePreset1	CheckCalibratePreset1	0.0, 1.0	Enable scope noise calibration for a preset.
Set Up	CalibratePreset2	CheckCalibratePreset2	0.0, 1.0	Enable scope noise calibration for a preset.
Set Up	CalibratePreset3	CheckCalibratePreset3	0.0, 1.0	Enable scope noise calibration for a preset.
Set Up	CalibratePreset4	CheckCalibratePreset4	0.0, 1.0	Enable scope noise calibration for a preset.
Set Up	CalibratePreset5	CheckCalibratePreset5	0.0, 1.0	Enable scope noise calibration for a preset.
Set Up	CalibratePreset6	CheckCalibratePreset6	0.0, 1.0	Enable scope noise calibration for a preset.

Table 2 Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	CalibratePresetInit	CheckCalibratePresetInit	0.0, 1.0	Enable scope noise calibration for a preset.
Set Up	CalibratePresetOpt Jitter	CheckCalibrate	0.0, 1.0	Enable scope noise calibration for a preset.
Set Up	CalibratePresetOpt NonJitter	CheckCalibratePresetOptNonJitter	0.0, 1.0	Enable scope noise calibration for a preset.
Set Up	Channel Pairs Option	ChanPairOpt	Channels 1 and 2, Channels 3 and 4	This option allows user to select which channel pair is being used for test. Note: Selecting main channels will bandwidth limit your signal, please select correct channels for signal you are measuring. Select Channel Pairs Option
Set Up	OfflineEnable	OfflineEnable	0.0, 1.0	Enable testing using saved waveforms.
Set Up	automate the ERL browse button		1	Browse the path to load the required ERL file Setup the ERL file
Set Up	automate the ERL clear button	ClearS4PERLFilePath	1	Clear the entry of ERL file path Clear the ERL file entry
Set Up	automate the Fixture Ref browse button		1	Browse the path to load the required reference fixture file Setup the Fixture Ref file
Set Up	automate the Fixture Ref clear button	ClearFixRefFilePath	1	Clear the entry of Fixture Ref file path Clear the Fixture Ref file entry

3 Test Names and IDs

The following table shows the mapping between each test's numeric ID and name. The numeric ID is required by various remote interface methods.

- Name – The name of the test as it appears on the user interface **Select Tests** tab.
- Test ID – The number to use with the RunTests method.
- Description – The description of the test as it appears on the user interface **Select Tests** tab.

For example, if the graphical user interface displays this tree in the **Select Tests** tab:

- All Tests
 - Rise Time
 - Fall Time

then you would expect to see something like this in the table below:

Table 3 Example Test Names and IDs

Name	Test ID	Description
Fall Time	110	Measures clock fall time.
Rise Time	100	Measures clock rise time.

and you would run these tests remotely using:

ARSL syntax

```
arsl -a ipaddress -c "SelectedTests '100,110'"  
arsl -a ipaddress -c "Run"
```

C# syntax

```
remoteAte.SelectedTests = new int[] {100,110};  
remoteAte.Run();
```

Here are the actual Test names and IDs used by this application. Listed at the end, you may also find:

- Deprecated IDs and their replacements.
- Macro IDs which may be used to select multiple related tests at the same time.

NOTE

The file, "TestInfo.txt", which may be found in the same directory as this help file, contains all of the information found in the table below in a format suitable for parsing.

Table 4 Test IDs and Names

Name	TestID	Description
AC Common Mode Voltage, Full-band VCMFB	103002	Test the AC common mode voltage, full band. This test can only be tested in dual single ended connection
AC Common Mode Voltage, Full-band VCMFB	113002	Test the AC common mode voltage, full band. This test can only be tested in dual single ended connection
AC Common Mode Voltage, Full-band VCMFB	123002	Test the AC common mode voltage, full band. This test can only be tested in dual single ended connection
AC Common Mode Voltage, Full-band VCMFB	203003	Test the AC common mode voltage, full band. This test can only be tested in dual single ended connection
AC Common Mode Voltage, Full-band VCMFB	303002	Test the AC common mode voltage, full band. This test can only be tested in dual single ended connection
AC Common Mode Voltage, Low-frequency VCMLF	103001	Test the AC common mode voltage, low-frequency, 100MHz low-pass filter. This test can only be tested in dual single ended connection
AC Common Mode Voltage, Low-frequency VCMLF	113001	Test the AC common mode voltage, low-frequency, 100MHz low-pass filter. This test can only be tested in dual single ended connection
AC Common Mode Voltage, Low-frequency VCMLF	123001	Test the AC common mode voltage, low-frequency, 100MHz low-pass filter. This test can only be tested in dual single ended connection
AC Common Mode Voltage, Low-frequency VCMLF	203002	Test the AC common mode voltage, low-frequency, 100MHz low-pass filter. This test can only be tested in dual single ended connection
AC Common Mode Voltage, Low-frequency VCMLF	303001	Test the AC common mode voltage, low-frequency, 100MHz low-pass filter. This test can only be tested in dual single ended connection
Coefficient Initialization Preset 2 c(-1)	101202	Measures the the coefficients for Preset 2 c(-1)
Coefficient Initialization Preset 2 c(-1)	111202	Measures the the coefficients for Preset 2 c(-1)
Coefficient Initialization Preset 2 c(-1)	121202	Measures the the coefficients for Preset 2 c(-1)
Coefficient Initialization Preset 2 c(-1)	201202	Measures the the coefficients for Preset 2 c(-1)

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Coefficient Initialization Preset 2 c(-1)	301202	Measures the the coefficients for Preset 2 c(-1)
Coefficient Initialization Preset 2 c(-2)	101201	Measures the the coefficients for Preset 2 c(-2)
Coefficient Initialization Preset 2 c(-2)	111201	Measures the the coefficients for Preset 2 c(-2)
Coefficient Initialization Preset 2 c(-2)	121201	Measures the the coefficients for Preset 2 c(-2)
Coefficient Initialization Preset 2 c(-2)	201201	Measures the the coefficients for Preset 2 c(-2)
Coefficient Initialization Preset 2 c(-2)	301201	Measures the the coefficients for Preset 2 c(-2)
Coefficient Initialization Preset 2 c(-3)	101200	Measures the the coefficients for Preset 2 c(-3)
Coefficient Initialization Preset 2 c(-3)	111200	Measures the the coefficients for Preset 2 c(-3)
Coefficient Initialization Preset 2 c(-3)	121200	Measures the the coefficients for Preset 2 c(-3)
Coefficient Initialization Preset 2 c(-3)	201200	Measures the the coefficients for Preset 2 c(-3)
Coefficient Initialization Preset 2 c(-3)	301200	Measures the the coefficients for Preset 2 c(-3)
Coefficient Initialization Preset 2 c(0)	101203	Measures the the coefficients for Preset 2 c(0)
Coefficient Initialization Preset 2 c(0)	111203	Measures the the coefficients for Preset 2 c(0)
Coefficient Initialization Preset 2 c(0)	121203	Measures the the coefficients for Preset 2 c(0)
Coefficient Initialization Preset 2 c(0)	201203	Measures the the coefficients for Preset 2 c(0)
Coefficient Initialization Preset 2 c(0)	301203	Measures the the coefficients for Preset 2 c(0)
Coefficient Initialization Preset 2 c(1)	101204	Measures the the coefficients for Preset 2 c(1)
Coefficient Initialization Preset 2 c(1)	111204	Measures the the coefficients for Preset 2 c(1)
Coefficient Initialization Preset 2 c(1)	121204	Measures the the coefficients for Preset 2 c(1)
Coefficient Initialization Preset 2 c(1)	201204	Measures the the coefficients for Preset 2 c(1)
Coefficient Initialization Preset 2 c(1)	301204	Measures the the coefficients for Preset 2 c(1)
Coefficient Initialization Preset 3 c(-1)	101207	Measures the coefficients for Preset 3 c(-1)
Coefficient Initialization Preset 3 c(-1)	111207	Measures the coefficients for Preset 3 c(-1)
Coefficient Initialization Preset 3 c(-1)	121207	Measures the coefficients for Preset 3 c(-1)
Coefficient Initialization Preset 3 c(-1)	201207	Measures the coefficients for Preset 3 c(-1)
Coefficient Initialization Preset 3 c(-1)	301207	Measures the coefficients for Preset 3 c(-1)
Coefficient Initialization Preset 3 c(-2)	101206	Measures the coefficients for Preset 3 c(-2)
Coefficient Initialization Preset 3 c(-2)	111206	Measures the coefficients for Preset 3 c(-2)
Coefficient Initialization Preset 3 c(-2)	121206	Measures the coefficients for Preset 3 c(-2)
Coefficient Initialization Preset 3 c(-2)	201206	Measures the coefficients for Preset 3 c(-2)
Coefficient Initialization Preset 3 c(-2)	301206	Measures the coefficients for Preset 3 c(-2)

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Coefficient Initialization Preset 3 c(-3)	101205	Measures the coefficients for Preset 3 c(-3)
Coefficient Initialization Preset 3 c(-3)	111205	Measures the coefficients for Preset 3 c(-3)
Coefficient Initialization Preset 3 c(-3)	121205	Measures the coefficients for Preset 3 c(-3)
Coefficient Initialization Preset 3 c(-3)	201205	Measures the coefficients for Preset 3 c(-3)
Coefficient Initialization Preset 3 c(-3)	301205	Measures the coefficients for Preset 3 c(-3)
Coefficient Initialization Preset 3 c(0)	101208	Measures the coefficients for Preset 3 c(0)
Coefficient Initialization Preset 3 c(0)	111208	Measures the coefficients for Preset 3 c(0)
Coefficient Initialization Preset 3 c(0)	121208	Measures the coefficients for Preset 3 c(0)
Coefficient Initialization Preset 3 c(0)	201208	Measures the coefficients for Preset 3 c(0)
Coefficient Initialization Preset 3 c(0)	301208	Measures the coefficients for Preset 3 c(0)
Coefficient Initialization Preset 3 c(1)	101209	Measures the coefficients for Preset 3 c(1)
Coefficient Initialization Preset 3 c(1)	111209	Measures the coefficients for Preset 3 c(1)
Coefficient Initialization Preset 3 c(1)	121209	Measures the coefficients for Preset 3 c(1)
Coefficient Initialization Preset 3 c(1)	201209	Measures the coefficients for Preset 3 c(1)
Coefficient Initialization Preset 3 c(1)	301209	Measures the coefficients for Preset 3 c(1)
Coefficient Initialization Preset 4 c(-1)	101212	Measures the coefficients for Preset 4 c(-1)
Coefficient Initialization Preset 4 c(-1)	111212	Measures the coefficients for Preset 4 c(-1)
Coefficient Initialization Preset 4 c(-1)	121212	Measures the coefficients for Preset 4 c(-1)
Coefficient Initialization Preset 4 c(-1)	201212	Measures the coefficients for Preset 4 c(-1)
Coefficient Initialization Preset 4 c(-1)	301212	Measures the coefficients for Preset 4 c(-1)
Coefficient Initialization Preset 4 c(-2)	101211	Measures the coefficients for Preset 4 c(-2)
Coefficient Initialization Preset 4 c(-2)	111211	Measures the coefficients for Preset 4 c(-2)
Coefficient Initialization Preset 4 c(-2)	121211	Measures the coefficients for Preset 4 c(-2)
Coefficient Initialization Preset 4 c(-2)	201211	Measures the coefficients for Preset 4 c(-2)
Coefficient Initialization Preset 4 c(-2)	301211	Measures the coefficients for Preset 4 c(-2)
Coefficient Initialization Preset 4 c(-3)	101210	Measures the coefficients for Preset 4 c(-3)
Coefficient Initialization Preset 4 c(-3)	111210	Measures the coefficients for Preset 4 c(-3)
Coefficient Initialization Preset 4 c(-3)	121210	Measures the coefficients for Preset 4 c(-3)
Coefficient Initialization Preset 4 c(-3)	201210	Measures the coefficients for Preset 4 c(-3)
Coefficient Initialization Preset 4 c(-3)	301210	Measures the coefficients for Preset 4 c(-3)
Coefficient Initialization Preset 4 c(0)	101213	Measures the coefficients for Preset 4 c(0)

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Coefficient Initialization Preset 4 c(0)	111213	Measures the coefficients for Preset 4 c(0)
Coefficient Initialization Preset 4 c(0)	121213	Measures the coefficients for Preset 4 c(0)
Coefficient Initialization Preset 4 c(0)	201213	Measures the coefficients for Preset 4 c(0)
Coefficient Initialization Preset 4 c(0)	301213	Measures the coefficients for Preset 4 c(0)
Coefficient Initialization Preset 4 c(1)	101214	Measures the coefficients for Preset 4 c(1)
Coefficient Initialization Preset 4 c(1)	111214	Measures the coefficients for Preset 4 c(1)
Coefficient Initialization Preset 4 c(1)	121214	Measures the coefficients for Preset 4 c(1)
Coefficient Initialization Preset 4 c(1)	201214	Measures the coefficients for Preset 4 c(1)
Coefficient Initialization Preset 4 c(1)	301214	Measures the coefficients for Preset 4 c(1)
Coefficient Initialization Preset 5 c(-1)	101217	Measures the coefficients for Preset 5 c(-1)
Coefficient Initialization Preset 5 c(-1)	111217	Measures the coefficients for Preset 5 c(-1)
Coefficient Initialization Preset 5 c(-1)	121217	Measures the coefficients for Preset 5 c(-1)
Coefficient Initialization Preset 5 c(-1)	201217	Measures the coefficients for Preset 5 c(-1)
Coefficient Initialization Preset 5 c(-1)	301217	Measures the coefficients for Preset 5 c(-1)
Coefficient Initialization Preset 5 c(-2)	101216	Measures the coefficients for Preset 5 c(-2)
Coefficient Initialization Preset 5 c(-2)	111216	Measures the coefficients for Preset 5 c(-2)
Coefficient Initialization Preset 5 c(-2)	121216	Measures the coefficients for Preset 5 c(-2)
Coefficient Initialization Preset 5 c(-2)	201216	Measures the coefficients for Preset 5 c(-2)
Coefficient Initialization Preset 5 c(-2)	301216	Measures the coefficients for Preset 5 c(-2)
Coefficient Initialization Preset 5 c(-3)	101215	Measures the coefficients for Preset 5 c(-3)
Coefficient Initialization Preset 5 c(-3)	111215	Measures the coefficients for Preset 5 c(-3)
Coefficient Initialization Preset 5 c(-3)	121215	Measures the coefficients for Preset 5 c(-3)
Coefficient Initialization Preset 5 c(-3)	201215	Measures the coefficients for Preset 5 c(-3)
Coefficient Initialization Preset 5 c(-3)	301215	Measures the coefficients for Preset 5 c(-3)
Coefficient Initialization Preset 5 c(0)	101218	Measures the coefficients for Preset 5 c(0)
Coefficient Initialization Preset 5 c(0)	111218	Measures the coefficients for Preset 5 c(0)
Coefficient Initialization Preset 5 c(0)	121218	Measures the coefficients for Preset 5 c(0)
Coefficient Initialization Preset 5 c(0)	201218	Measures the coefficients for Preset 5 c(0)
Coefficient Initialization Preset 5 c(0)	301218	Measures the coefficients for Preset 5 c(0)
Coefficient Initialization Preset 5 c(1)	101219	Measures the coefficients for Preset 5 c(1)
Coefficient Initialization Preset 5 c(1)	111219	Measures the coefficients for Preset 5 c(1)

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Coefficient Initialization Preset 5 c(1)	121219	Measures the coefficients for Preset 5 c(1)
Coefficient Initialization Preset 5 c(1)	201219	Measures the coefficients for Preset 5 c(1)
Coefficient Initialization Preset 5 c(1)	301219	Measures the coefficients for Preset 5 c(1)
Coefficient Initialization Preset 6 c(-1)	101222	Measures the coefficients for Preset 6 c(-1)
Coefficient Initialization Preset 6 c(-1)	111222	Measures the coefficients for Preset 6 c(-1)
Coefficient Initialization Preset 6 c(-1)	121222	Measures the coefficients for Preset 6 c(-1)
Coefficient Initialization Preset 6 c(-1)	201222	Measures the coefficients for Preset 6 c(-1)
Coefficient Initialization Preset 6 c(-1)	301222	Measures the coefficients for Preset 6 c(-1)
Coefficient Initialization Preset 6 c(-2)	101221	Measures the coefficients for Preset 6 c(-2)
Coefficient Initialization Preset 6 c(-2)	111221	Measures the coefficients for Preset 6 c(-2)
Coefficient Initialization Preset 6 c(-2)	121221	Measures the coefficients for Preset 6 c(-2)
Coefficient Initialization Preset 6 c(-2)	201221	Measures the coefficients for Preset 6 c(-2)
Coefficient Initialization Preset 6 c(-2)	301221	Measures the coefficients for Preset 6 c(-2)
Coefficient Initialization Preset 6 c(-3)	101220	Measures the coefficients for Preset 6 c(-3)
Coefficient Initialization Preset 6 c(-3)	111220	Measures the coefficients for Preset 6 c(-3)
Coefficient Initialization Preset 6 c(-3)	121220	Measures the coefficients for Preset 6 c(-3)
Coefficient Initialization Preset 6 c(-3)	201220	Measures the coefficients for Preset 6 c(-3)
Coefficient Initialization Preset 6 c(-3)	301220	Measures the coefficients for Preset 6 c(-3)
Coefficient Initialization Preset 6 c(0)	101223	Measures the coefficients for Preset 6 c(0)
Coefficient Initialization Preset 6 c(0)	111223	Measures the coefficients for Preset 6 c(0)
Coefficient Initialization Preset 6 c(0)	121223	Measures the coefficients for Preset 6 c(0)
Coefficient Initialization Preset 6 c(0)	201223	Measures the coefficients for Preset 6 c(0)
Coefficient Initialization Preset 6 c(0)	301223	Measures the coefficients for Preset 6 c(0)
Coefficient Initialization Preset 6 c(1)	101224	Measures the coefficients for Preset 6 c(1)
Coefficient Initialization Preset 6 c(1)	111224	Measures the coefficients for Preset 6 c(1)
Coefficient Initialization Preset 6 c(1)	121224	Measures the coefficients for Preset 6 c(1)
Coefficient Initialization Preset 6 c(1)	201224	Measures the coefficients for Preset 6 c(1)
Coefficient Initialization Preset 6 c(1)	301224	Measures the coefficients for Preset 6 c(1)
Coefficient Initialization Preset Initialize c(-1)	101227	Measures the coefficients for Preset Initialize c(-1)

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Coefficient Initialization Preset Initialize c(-1)	111227	Measures the coefficients for Preset Initialize c(-1)
Coefficient Initialization Preset Initialize c(-1)	121227	Measures the coefficients for Preset Initialize c(-1)
Coefficient Initialization Preset Initialize c(-1)	201227	Measures the coefficients for Preset Initialize c(-1)
Coefficient Initialization Preset Initialize c(-1)	301227	Measures the coefficients for Preset Initialize c(-1)
Coefficient Initialization Preset Initialize c(-2)	101226	Measures the coefficients for Preset Initialize c(-2)
Coefficient Initialization Preset Initialize c(-2)	111226	Measures the coefficients for Preset Initialize c(-2)
Coefficient Initialization Preset Initialize c(-2)	121226	Measures the coefficients for Preset Initialize c(-2)
Coefficient Initialization Preset Initialize c(-2)	201226	Measures the coefficients for Preset Initialize c(-2)
Coefficient Initialization Preset Initialize c(-2)	301226	Measures the coefficients for Preset Initialize c(-2)
Coefficient Initialization Preset Initialize c(-3)	101225	Measures the coefficients for Preset Initialize c(-3)
Coefficient Initialization Preset Initialize c(-3)	111225	Measures the coefficients for Preset Initialize c(-3)
Coefficient Initialization Preset Initialize c(-3)	121225	Measures the coefficients for Preset Initialize c(-3)
Coefficient Initialization Preset Initialize c(-3)	201225	Measures the coefficients for Preset Initialize c(-3)
Coefficient Initialization Preset Initialize c(-3)	301225	Measures the coefficients for Preset Initialize c(-3)
Coefficient Initialization Preset Initialize c(0)	101228	Measures the coefficients for Preset Initialize c(0)
Coefficient Initialization Preset Initialize c(0)	111228	Measures the coefficients for Preset Initialize c(0)
Coefficient Initialization Preset Initialize c(0)	121228	Measures the coefficients for Preset Initialize c(0)
Coefficient Initialization Preset Initialize c(0)	201228	Measures the coefficients for Preset Initialize c(0)
Coefficient Initialization Preset Initialize c(0)	301228	Measures the coefficients for Preset Initialize c(0)

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Coefficient Initialization Preset Initialize c(1)	101229	Measures the coefficients for Preset Initialize c(1)
Coefficient Initialization Preset Initialize c(1)	111229	Measures the coefficients for Preset Initialize c(1)
Coefficient Initialization Preset Initialize c(1)	121229	Measures the coefficients for Preset Initialize c(1)
Coefficient Initialization Preset Initialize c(1)	201229	Measures the coefficients for Preset Initialize c(1)
Coefficient Initialization Preset Initialize c(1)	301229	Measures the coefficients for Preset Initialize c(1)
Common-mode to Common-mode Output Return Loss	104000	Common-mode to Common-mode Output Return Loss measurement
Common-mode to Common-mode Output Return Loss	114000	Common-mode to Common-mode Output Return Loss measurement
Common-mode to Common-mode Output Return Loss	124000	Common-mode to Common-mode Output Return Loss measurement
Common-mode to Common-mode Output Return Loss	204000	Common-mode to Common-mode Output Return Loss measurement
Common-mode to Common-mode Output Return Loss	304000	Common-mode to Common-mode Output Return Loss measurement
Common-mode to Differential Output Return Loss	114001	Common-mode to Differential Output Return Loss measurement
Common-mode to Differential Output Return Loss	124001	Common-mode to Differential Output Return Loss measurement
Common-mode to Differential Output Return Loss	204001	Common-mode to Differential Output Return Loss measurement
DC Common Mode Output Voltage Test	203001	Test the DC common mode voltage. This test can only be tested in dual single ended connection
DC Common Mode Output Voltage Test	103003	Test the DC common mode voltage. This test can only be tested in dual single ended connection. Must be DC coupled.
DC Common Mode Output Voltage Test	113003	Test the DC common mode voltage. This test can only be tested in dual single ended connection. Must be DC coupled.
DC Common Mode Output Voltage Test	123003	Test the DC common mode voltage. This test can only be tested in dual single ended connection. Must be DC coupled.
DC Common Mode Output Voltage Test	303003	Test the DC common mode voltage. This test can only be tested in dual single ended connection. Must be DC coupled.
Difference Linear Fit Pulse Peak Ratio, dRpeak (Preset 1)	101006	Difference Linear Fit Pulse Peak Ratio, dRpeak

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Difference Linear Fit Pulse Peak Ratio, dRpeak (Preset 1)	301006	Difference Linear Fit Pulse Peak Ratio, dRpeak
Difference Signal-to-Noise-and-Distortion Ratio, dSNDR	101007	Please provide the path to the CSV file containing the SNDR (reference) values for all presets. To use the default values, leave the CSV file path as default. To use a different set of values, provide the path to a custom CSV file. Another option is to edit the default CSV file directly to modify the SNDR values.
Difference Signal-to-Noise-and-Distortion Ratio, dSNDR	111005	Please provide the path to the CSV file containing the SNDR (reference) values for all presets. To use the default values, leave the CSV file path as default. To use a different set of values, provide the path to a custom CSV file. Another option is to edit the default CSV file directly to modify the SNDR values.
Difference Signal-to-Noise-and-Distortion Ratio, dSNDR	121005	Please provide the path to the CSV file containing the SNDR (reference) values for all presets. To use the default values, leave the CSV file path as default. To use a different set of values, provide the path to a custom CSV file. Another option is to edit the default CSV file directly to modify the SNDR values.
Difference Signal-to-Noise-and-Distortion Ratio, dSNDR	201005	Please provide the path to the CSV file containing the SNDR (reference) values for all presets. To use the default values, leave the CSV file path as default. To use a different set of values, provide the path to a custom CSV file. Another option is to edit the default CSV file directly to modify the SNDR values.
Difference Signal-to-Noise-and-Distortion Ratio, dSNDR	301007	Please provide the path to the CSV file containing the SNDR (reference) values for all presets. To use the default values, leave the CSV file path as default. To use a different set of values, provide the path to a custom CSV file. Another option is to edit the default CSV file directly to modify the SNDR values.
Difference Steady-State Voltage, dVf (Preset 1)	101005	Difference Steady-State Voltage, dVf measurement
Difference Steady-State Voltage, dVf (Preset 1)	301005	Difference Steady-State Voltage, dVf measurement
Differential Peak to Peak Output Voltage Test with TX Disabled	123000	Test the maximum voltage with the Output disabled
Differential Peak to Peak Output Voltage Test with TX Disabled	103000	Test the maximum voltage with the TX disabled
Differential Peak to Peak Output Voltage Test with TX Disabled	113000	Test the maximum voltage with the TX disabled
Differential Peak to Peak Output Voltage Test with TX Disabled	203000	Test the maximum voltage with the TX disabled
Differential Peak to Peak Output Voltage Test with TX Disabled	303000	Test the maximum voltage with the TX disabled

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Differential Peak to Peak Output Voltage Test with TX Enabled	103004	Test the maximum voltage with the TX enabled
Differential Peak to Peak Output Voltage Test with TX Enabled	113004	Test the maximum voltage with the TX enabled
Differential Peak to Peak Output Voltage Test with TX Enabled	123004	Test the maximum voltage with the TX enabled
Differential Peak to Peak Output Voltage Test with TX Enabled	203004	Test the maximum voltage with the TX enabled
Differential Peak to Peak Output Voltage Test with TX Enabled	303004	Test the maximum voltage with the TX enabled
EOJ03	100101	Even-Odd Jitter 03 measurement
EOJ03	110101	Even-Odd Jitter 03 measurement
EOJ03	120101	Even-Odd Jitter 03 measurement
EOJ03	200101	Even-Odd Jitter 03 measurement
EOJ03	300101	Even-Odd Jitter 03 measurement
ERL	301004	Calculates ERL TP0v(KR).
ERL	101004	Calculates ERL TP0v.
ERL	111004	Calculates ERL TP1a.
ERL	121004	Calculates ERL TP4.
ERL	201004	Calculates ERL.
Eye Height	105000	Measures the height of each the eye at user selected CTLE
Eye Height	115000	Measures the height of each the eye at user selected CTLE
Eye Height	125004	Measures the height of each the eye at user selected CTLE
Eye Height	205000	Measures the height of each the eye at user selected CTLE
Eye Height	305000	Measures the height of each the eye at user selected CTLE
J4u03	100102	J4u03 Jitter measurement
J4u03	110102	J4u03 Jitter measurement
J4u03	120102	J4u03 Jitter measurement
J4u03	200102	J4u03 Jitter measurement
J4u03	300102	J4u03 Jitter measurement
JRMS	100100	JRMS measurement
JRMS	110100	JRMS measurement

Table 4 Test IDs and Names (continued)

Name	TestID	Description
JRMS	120100	JRMS measurement
JRMS	200100	JRMS measurement
JRMS	300100	JRMS measurement
Level - PRBS pattern	102000	Tests the level for each level in the PRBS pattern
Level - PRBS pattern	112000	Tests the level for each level in the PRBS pattern
Level - PRBS pattern	122000	Tests the level for each level in the PRBS pattern
Level - PRBS pattern	202000	Tests the level for each level in the PRBS pattern
Level - PRBS pattern	302000	Tests the level for each level in the PRBS pattern
Level RMS - PRBS pattern	102001	Tests the level rms for each level in the PRBS pattern
Level RMS - PRBS pattern	112001	Tests the level rms for each level in the PRBS pattern
Level RMS - PRBS pattern	122001	Tests the level rms for each level in the PRBS pattern
Level RMS - PRBS pattern	202001	Tests the level rms for each level in the PRBS pattern
Level RMS - PRBS pattern	302001	Tests the level rms for each level in the PRBS pattern
Level Separation Mismatch Ratio - RLM	102002	Tests the level mismatch ratio
Level Separation Mismatch Ratio - RLM	112002	Tests the level mismatch ratio
Level Separation Mismatch Ratio - RLM	122002	Tests the level mismatch ratio
Level Separation Mismatch Ratio - RLM	202002	Tests the level mismatch ratio
Level Separation Mismatch Ratio - RLM	302002	Tests the level mismatch ratio
Linear Fit Pulse Peak Ratio, Rpeak (Preset 1)	101001	Linear Fit Pulse Peak Ratio, Rpeak
Linear Fit Pulse Peak Ratio, Rpeak (Preset 1)	111001	Linear Fit Pulse Peak Ratio, Rpeak
Linear Fit Pulse Peak Ratio, Rpeak (Preset 1)	121001	Linear Fit Pulse Peak Ratio, Rpeak
Linear Fit Pulse Peak Ratio, Rpeak (Preset 1)	201001	Linear Fit Pulse Peak Ratio, Rpeak
Linear Fit Pulse Peak Ratio, Rpeak (Preset 1)	301001	Linear Fit Pulse Peak Ratio, Rpeak
Signal to AC Common-mode Noise Ratio, SCMR (Preset 1)	101008	Measures the SCMR
Signal to AC Common-mode Noise Ratio, SCMR (Preset 1)	301008	Measures the SCMR

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Signal-to-Noise-and-Distortion Ratio, SNDR	101002	Measures the SNDR
Signal-to-Noise-and-Distortion Ratio, SNDR	111002	Measures the SNDR
Signal-to-Noise-and-Distortion Ratio, SNDR	121002	Measures the SNDR
Signal-to-Noise-and-Distortion Ratio, SNDR	201002	Measures the SNDR
Signal-to-Noise-and-Distortion Ratio, SNDR	301002	Measures the SNDR
Signal-to-Residual-Intersymbol-Interference Ratio, SNRISI	101003	Measures the SNRISI
Signal-to-Residual-Intersymbol-Interference Ratio, SNRISI	111003	Measures the SNRISI
Signal-to-Residual-Intersymbol-Interference Ratio, SNRISI	121003	Measures the SNRISI
Signal-to-Residual-Intersymbol-Interference Ratio, SNRISI	201003	Measures the SNRISI
Signal-to-Residual-Intersymbol-Interference Ratio, SNRISI	301003	Measures the SNRISI
Signaling Rate (PRBS13Q)	100000	Signaling rate of the signal
Signaling Rate (PRBS13Q)	110000	Signaling rate of the signal
Signaling Rate (PRBS13Q)	120000	Signaling rate of the signal
Signaling Rate (PRBS13Q)	200000	Signaling rate of the signal
Signaling Rate (PRBS13Q)	300000	Signaling rate of the signal
Steady-State Voltage, Vf (Preset 1)	201000	Steady-State Voltage, Vf measurement
Steady-State Voltage, Vf (Preset 1)	301000	Steady-State Voltage, Vf measurement
Steady-State Voltage, Vf (Preset 1)	101000	Steady-State Voltage, Vf measurement
Steady-State Voltage, Vf (Preset 1)	111000	Steady-State Voltage, Vf measurement
Steady-State Voltage, Vf (Preset 1)	121000	Steady-State Voltage, Vf measurement
Vertical Eye Closure	305001	Measures the Vertical Eye Closure TP0v_KR
Vertical Eye Closure	105001	Measures the Vertical Eye Closure TP1a
Vertical Eye Closure	115001	Measures the Vertical Eye Closure TP1a
Vertical Eye Closure	205001	Measures the Vertical Eye Closure TP2

Table 4 Test IDs and Names (continued)

Name	TestID	Description
Vertical Eye Closure	125005	Measures the Vertical Eye Closure TP4
abs Step Size for c(-1)	101102	abs Coefficient Step Size measurement for Coefficient c(-1)
abs Step Size for c(-1)	111102	abs Coefficient Step Size measurement for Coefficient c(-1)
abs Step Size for c(-1)	121102	abs Coefficient Step Size measurement for Coefficient c(-1)
abs Step Size for c(-1)	201102	abs Coefficient Step Size measurement for Coefficient c(-1)
abs Step Size for c(-1)	301102	abs Coefficient Step Size measurement for Coefficient c(-1)
abs Step Size for c(-2)	101101	abs Coefficient Step Size measurement for Coefficient c(-2)
abs Step Size for c(-2)	111101	abs Coefficient Step Size measurement for Coefficient c(-2)
abs Step Size for c(-2)	121101	abs Coefficient Step Size measurement for Coefficient c(-2)
abs Step Size for c(-2)	201101	abs Coefficient Step Size measurement for Coefficient c(-2)
abs Step Size for c(-2)	301101	abs Coefficient Step Size measurement for Coefficient c(-2)
abs Step Size for c(-3)	101100	abs Coefficient Step Size measurement for Coefficient c(-3)
abs Step Size for c(-3)	111100	abs Coefficient Step Size measurement for Coefficient c(-3)
abs Step Size for c(-3)	121100	abs Coefficient Step Size measurement for Coefficient c(-3)
abs Step Size for c(-3)	201100	abs Coefficient Step Size measurement for Coefficient c(-3)
abs Step Size for c(-3)	301100	abs Coefficient Step Size measurement for Coefficient c(-3)
abs Step Size for c(0)	101103	abs Coefficient Step Size measurement for Coefficient c(0)
abs Step Size for c(0)	111103	abs Coefficient Step Size measurement for Coefficient c(0)
abs Step Size for c(0)	121103	abs Coefficient Step Size measurement for Coefficient c(0)
abs Step Size for c(0)	201103	abs Coefficient Step Size measurement for Coefficient c(0)
abs Step Size for c(0)	301103	abs Coefficient Step Size measurement for Coefficient c(0)
abs Step Size for c(1)	101104	abs Coefficient Step Size measurement for Coefficient c(1)
abs Step Size for c(1)	111104	abs Coefficient Step Size measurement for Coefficient c(1)
abs Step Size for c(1)	121104	abs Coefficient Step Size measurement for Coefficient c(1)
abs Step Size for c(1)	201104	abs Coefficient Step Size measurement for Coefficient c(1)
abs Step Size for c(1)	301104	abs Coefficient Step Size measurement for Coefficient c(1)
dERL	301009	Calculates dERL TP0v(KR).
dERL	101009	Calculates dERL TP0v.
value at max. state for c(-1)	101110	Measures the value of c(-1) at max
value at max. state for c(-2)	101108	Measures the value of c(-2) at max
value at max. state for c(-2)	111106	Measures the value of c(-2) at max

Table 4 Test IDs and Names (continued)

Name	TestID	Description
value at max. state for c(-2)	121106	Measures the value of c(-2) at max
value at max. state for c(-2)	201106	Measures the value of c(-2) at max
value at max. state for c(-2)	301106	Measures the value of c(-2) at max
value at max. state for c(-3)	101106	Measures the value of c(-3) at max
value at max. state for c(1)	101113	Measures the value of c(1) at max
value at min. state for c(-1)	101109	Measures the value of c(-1) at min
value at min. state for c(-1)	111107	Measures the value of c(-1) at min
value at min. state for c(-1)	121107	Measures the value of c(-1) at min
value at min. state for c(-1)	201107	Measures the value of c(-1) at min
value at min. state for c(-1)	301107	Measures the value of c(-1) at min
value at min. state for c(-2)	101107	Measures the value of c(-2) at min
value at min. state for c(-3)	101105	Measures the value of c(-3) at min
value at min. state for c(-3)	111105	Measures the value of c(-3) at min
value at min. state for c(-3)	121105	Measures the value of c(-3) at min
value at min. state for c(-3)	201105	Measures the value of c(-3) at min
value at min. state for c(-3)	301105	Measures the value of c(-3) at min
value at min. state for c(0)	101111	Measures the value of c(0) at min
value at min. state for c(0)	111108	Measures the value of c(0) at min
value at min. state for c(0)	121108	Measures the value of c(0) at min
value at min. state for c(0)	201108	Measures the value of c(0) at min
value at min. state for c(0)	301108	Measures the value of c(0) at min
value at min. state for c(1)	101112	Measures the value of c(1) at min
value at min. state for c(1)	111109	Measures the value of c(1) at min
value at min. state for c(1)	121109	Measures the value of c(1) at min
value at min. state for c(1)	201109	Measures the value of c(1) at min
value at min. state for c(1)	301109	Measures the value of c(1) at min

4 Instruments

The following table shows the instruments used by this application. The name is required by various remote interface methods.

- Instrument Name – The name to use as a parameter in remote interface commands.
- Description – The description of the instrument.

For example, if an application uses an oscilloscope and a pulse generator, then you would expect to see something like this in the table below:

Table 5 Example Instrument Information

Name	Description
scope	The primary oscilloscope.
Pulse	The pulse generator used for Gen 2 tests.

and you would be able to remotely control an instrument using:

ARSL syntax (replace [description] with actual parameter)

```
-----  
arsl -a ipaddress -c "SendScpiCommandCustom 'Command=[scpi  
command];Timeout=100;Instrument=pulsegen'"
```

```
arsl -a ipaddress -c "SendScpiQueryCustom 'Command=[scpi  
query];Timeout=100;Instrument=pulsegen'"
```

C# syntax (replace [description] with actual parameter)

```
-----  
SendScpiCommandOptions commandOptions = new SendScpiCommandOptions();  
commandOptions.Command = "[scpi command]";  
commandOptions.Instrument = "[instrument name]";  
commandOptions.Timeout = [timeout];  
remoteAte.SendScpiCommand(commandOptions);
```

```
SendScpiQueryOptions queryOptions = new SendScpiQueryOptions();  
queryOptions.Query = "[scpi query]";  
queryOptions.Instrument = "[instrument name]";
```

```
queryOptions.Timeout = [timeout];  
remoteAte.SendScpiQuery(queryOptions);
```

Here are the actual instrument names used by this application:

NOTE

The file, "InstrumentInfo.txt", which may be found in the same directory as this help file, contains all of the information found in the table below in a format suitable for parsing.

Table 6 Instrument Names

Instrument Name	Description
Infiniium	The primary oscilloscope
Keysight PNA	Performance Network Analyzer
Keysight ENA	Economy Network Analyzer

Index

C

configuration variables and values, [9](#)
copyright, [2](#)

I

IDs and names of tests, [25](#)
instrument names, [39](#)

N

names and IDs of tests, [25](#)
names of instruments, [39](#)
notices, [2](#)

P

programming, introduction to, [7](#)

R

Remote Programming Toolkit, [8](#)

T

test names and IDs, [25](#)

V

variables and values, configuration, [9](#)

W

warranty, [2](#)

