

Keysight Technologies

CX3300 Current Waveform Analyzer

Quick Operation Guide

How to change the horizontal scale and position



You can change the horizontal scale and position using any of the following methods:

- Using the knobs on the Horizontal Controls
- Using the Horizontal mini dialog box
- Using the X Axis dialog box for fine control.

Horizontal Controls

Change the scale

Change the position. Pressing it sets zero offset.

Horizontal Summary

Click

Double-Click

Timebase

Scale: 500.0 μ s/

Position: 0.000 s

Main Waveform - Channel 1 - XAxis

Invert: Auto

Scale: 500.0 μ s

Offset: 0.000 s

Maximum: 2.500 ms

Minimum: -2.500 ms