

# Keysight Technologies CX3300 Current Waveform Analyzer

## Quick Operation Guide


### How to change the vertical scale and position



#### 1. How to select the channel.

Select the target waveform by either:

- Pressing [1], [2], [3] or [4] for the analog input channels OR
- Clicking on the icons on the Waveform tray for the analog input channels or function waveform.



The color of the Y axis is the same color as the selected waveform.

Next page

## 2. How to Change the horizontal scale and position

You can change the horizontal scale and position using any of the following methods:

- Using the knobs on Vertical Controls
- Using the Vertical mini dialog box
- Using the Y Axis dialog box for fine control.

