

# Keysight Technologies

## CX3300 Current Waveform Analyzer

### Quick Operation Guide

#### How to set the bandwidth limit



1. Click on the Channel summary to open the Channel mini dialog box.
2. Click on the “□” at the upper right of the window to open the Setting dialog box.
3. Select “ON”.
4. Set the bandwidth limit.

