


Keysight Laser Interferometer Systems Compensation Number Calculations

The Keysight Technologies, Inc. laser interferometer systems require compensation when used in an air environment. Several ways exist to obtain a compensation number (Comp Num). One is to use the Modified Edlén equation with pressure, temperature, and humidity sensors. Another is to measure an artifact with a known fixed length using a laser measurement axis, and calculate a Comp Num from the raw data. A third is to track changes with a Wavelength Tracking Interferometer (WTI). Note that this method requires an initial compensation value from one of the other two methods.

Reset at position 0 and then move to other end of 100 mm artifact



Artifact measurement setup

Key features

- Operation in air requires compensation
- Use environmental sensors and modified Edlén equation to get Comp Num
- Translate reading from artifact measurement into initial Comp Num
- Translate readings from WTI axis into real time Comp Num

1. Rearrange position equation¹ to calculate Initial Comp Num from artifact measurement:

$$\text{Initial Comp Num} = \frac{\text{Artifact Length} \times \text{Resolution Extension}^2 \times \text{Optics Fold Factor}^2}{\text{Integer Counts} \times \text{Lambda}}$$

¹ Refer pub# 5991-0329EN.

² Values depend on axis board and optics type used. See pub# 5990-8206EN and 5990-9943EN.

Example using 100 mm artifact with Linear optics (optics fold factor=2) and N1231B electronics (Resolution Extension = 1024):

$$\text{Initial Comp Num} = \frac{100,000 \mu\text{m} \times 1024 \times 2}{323,631,564 \times 0.63299137 \mu\text{m}} = 0.99972670$$

2. Use fundamental equation twice, along with Initial Comp Num, to calculate Comp Num from WTI axis data:

$$\text{Etalon Length} = \frac{\text{Initial Comp Num} \times \text{Preset Counts} \times \text{Lambda}}{\text{Resolution Extension} \times \text{Optics Fold Factor}}$$

solve for Preset Counts

$$\text{Comp Num} = \frac{\text{Etalon Length} \times \text{Resolution Extension} \times \text{Optics Fold Factor}}{(\text{Accumulated Counts} + \text{Preset Counts}) \times \text{Lambda}}$$

Example with 5.0137" (127.34798 mm) WTI (optics fold factor of 4) and 2 ppm change in environmental conditions:

$$\text{Preset Counts} = \frac{127347.98 \mu\text{m} \times 1024 \times 4}{0.63299137 \mu\text{m} \times 0.99972670} = 824,276,519$$

$$\text{Comp Num} = \frac{127347.98 \mu\text{m} \times 1024 \times 4}{(-1649 + 824,276,519) \times 0.63299137 \mu\text{m}} = 0.99972870$$

myKeysight

myKeysight

www.keysight.com/find/mykeysight

A personalized view into the information most relevant to you.

http://www.keysight.com/find/emt_product_registration

Register your products to get up-to-date product information and find warranty information.



Keysight Assurance Plans

www.keysight.com/find/AssurancePlans

Up to ten years of protection and no budgetary surprises to ensure your instruments are operating to specification, so you can rely on accurate measurements.

For more details on configuring, setting up, and using Keysight laser interferometer systems, please obtain the Keysight Laser and Optics User's Manual Volume I and II, part number 05517-90086.

For online information on Keysight laser interferometers, please visit:

www.keysight.com/find/lasers