

Agilent 5DX 8.52 Patch Software

Software Release Date: March 2009

5DX System Requirements: Series 3 & Series 5000 **Controller Requirements:** 1 GHz IPC or greater

Operating System: Windows® XP Professional Service Pack 2

Software Requirements: 8.50

Installation Requirements:

384MB of RAM or greater & 500MB of free disk space.

Administrative Rights log on, with Administrative privileges.

NOTE: The Agilent 5DX 8.52 patch contains only the files necessary for the patch and requires that 8.50 be previously installed.

Installation Instructions for the 5DX & TDW:

- 1. Exit out of the User Interface.
- 2. Double-click the Agilent 5DX Reset icon to reset the system.
- 3. Close all other programs; close any open windows.
- 4. Installation of the patch:
 - a) Download the patch from the Agilent web site to a local drive.
 - You can get the patch from http://www.agilent.com/see/5DX under:
 - "Technical Support"
 - "Drivers and Software"
 - "Agilent 5DX 8.52 Software Release"
 - In the "Documents & Downloads" section you will find a link to download the patch.
 - Save the file as "5DX 8.52.zip".
 - b) Create the following subdirectory: C:\Temp\8.52 patch\
 - c) Move the patch file to the subdirectory: C:\Temp\8.52 patch\
 - d) From Windows Explorer, double click on the "5DX 8.52.zip".
 - e) Extract all files to C:\Temp\8.52 patch\
 - f) Navigate to C:\Temp\8.52 patch\
 - g) Double click on the "Setup.exe".
 - h) Follow the on-screen instructions to install the patch.
 - i) Once the installation process is complete, reboot the PC.
 - i) After the system reboots, log back into the operating system and User Interface.
 - k) Verifying proper patch installation:
 - The top of the 5DX User Interface screen will now reflect the current software revision, 8.52.
 - The TDW User Interface will now reflect the current software revision in Help > About.

More 5DX info at:

www.agilent.com/see/5dx