



## To Install the Agilent B4622A DDR2/3 Protocol Compliance and Analysis Tool

When purchased with a logic analyzer, the application software you ordered is installed on the instrument hard drive.

If you ordered the application software separately:

- To use this software, you must install the latest version of three packages:
  - 16900, 16800, and 1680/90 Series Application Software
  - DDR2 and DDR3 Bus Decoder
  - DDR2/3 Protocol Compliance and Analysis Tool
- The software may not be available on the enclosed CD. To ensure you always have the latest software, download the software from the web at:  
<http://www.agilent.com/find/la-sw-download>
- After you have downloaded the software, double-click on the setup file then follow the instructions which are displayed.
- Follow the instructions on the Entitlement Certificate to redeem your license and enable the application.

To ensure you are notified when new versions are available, sign up for software update notification at:  
<http://www.agilent.com/find/emailupdates>

### To run the software

- 1 Start the logic analyzer application.
- 2 Select **Tools>External Applications**.
- 3 To access the online help, select the Help menu or press the F1 key.

B4622-92000, Printed in USA, © Agilent Technologies, Inc. 2009



**Agilent Technologies**