



V3500A Driver Uninstallation Procedure

1. Under **Ports (COM & LPT)** tab, right click '**Agilent V3500A PowerMeter**' and click "**Uninstall**". Remember to check the box before clicking "**OK**".



2. Under **USB controllers** tab, right click '**Agilent V3500A PowerMeter**' and click "**Uninstall**". Remember to check the box before clicking "**OK**".



Note: Uninstall the driver according to sequence.