Keysight x1149 Boundary Scan Analyzer

Software Revision 2.0.1.51 Instruction Sheet



This is an Instruction Sheet for part number N1125A. More details about this product can be obtained at x1149

Boundary Scan Analyzer | Keysight



Download Software Installer

1. Make sure to have received your Keysight Entitlement Certificate through email upon purchase of your Keysight x1149 Boundary Scan Analyzer



2. Go to Keysight Software Manager (KSM):

www.keysight.com/find/softwaremanager


- 3. Log in using your credentials or click on "New User" if you don't have an account.
- 4. Provide details as below upon successful log in:
 - a. Order Number
 - b. Certificate Number



5. "Return to Main Menu" and click on the "Software Updates" tab to download your Keysight x1149 Boundary Scan Analyzer, Software Revision, 2.0.1.51




- 6. Installer will install applications as below:
 - a. Keysight x1149 Boundary Scan Analyzer, Software Revision, 2.0.1.51
 - b. Keysight PathWave License Manager



Redeem Software License

- 1. Launch your Keysight PathWave Manager to obtain your PC Host ID
 - a. Click on the Copy icon next to the "This machine's host IDs



2. Redeem your license using your machine Host ID from the "License Management" tab



- 3. Upon successful redemption, you can either download or email your license file.
- 4. Click "Add a License File" to install the license.
- 5. Get help:
 - a. Other guide/information for Keysight x1149 Boundary Scan Analyzer can be found in C:\Program Files (x86)\Keysight\x1149\help
 - b. For technical and sales support, visit us at www.keysight.com/find/contactus.
 - **c.** Go to www.keysight.com/find/x1149license to learn more about the Keysight x1149 Boundary Scan Analyzer, Software Revision 2.0.1.51.