



Agilent Medalist i5000 06.02pe Software Package

Software Release Date: December, 2007

System Requirements: Agilent Medalist i5000 test systems or Test Development PC

Controller Requirements: Windows PC

Operating System: Microsoft® Windows® XP SP2

Software Requirement: Agilent Medalist i5000 06.02p

Patch Requirement: NA

This Software Patch may be installed only on MS Windows systems with i5000 06.02p software release. It can be installed on systems with i5000 Test System Software or i5000 Development Software.

The installer will automatically check for 06.02sa, 06.02sb, 06.02sc, 06.02sd site specific patches and automatically uninstall them if they are present in the system.

The Software Update must be installed by the administrator login (or a login with administrator privileges).

If you have any previous ScanWorks version installed on your machine. Please uninstall them prior to installing 06.02p/06.02pe.

To install the 06.02pe Software Update on Windows systems running the i3070 software:

1. Save Agilenti5000_0602pe.exe file to disk.
2. Close all open programs.
3. Go to the directory in which the file was saved and Double-click on Agilenti5000_0602pe.exe.
4. Follow the Install Shield instructions for installation.
5. To validate that the software installed correctly, bring up a Korn Shell window. On the menu bar, click START then click Programs then click Agilent ICT then click Korn Shell. In the Korn Shell window, type version and return. The software revision "Patch i5000 06.02pe 0606 WN. released on December 2007" should display at the end of the output.

6. Delete the AgilentI5000_0602pe.exe.

Agilent Medalist i5000 06.02pe Software Release Bulletin

This is a Software Patch for Agilent Medalist i5000 06.02p for Windows.

You must already have version i5000 **06.02p** on your computer before you install the 06.02pe software patch.

If you have any previous ScanWorks version installed on your machine. Please uninstall them prior to installing 06.02p/06.02pe.

Software patch 06.02pe includes all fixes in 06.02sa, 06.02sb, 06.02sc and 06.02sd.

Software patch 06.02pe also addresses these issues:

| Change Request Identification | Description |
|-------------------------------|---|
| CR29559 | Unmuxed pin cards are intermittently damaged when running unpowered command. Discharge scans not protecting relays. |

Agilent Medalist i5000 06.02sa Software Release Bulletin

This is a Software Patch for i5000 06.02p for Windows.

You must already have version i5000 06.02p on your computer before you install the 06.02sa software patch.

Software patch 06.02sa addresses these issues:

| Change Request Identification | Description |
|-------------------------------|--|
| CR23825 | Boundary-scan interconnect tests may not generate the appropriate test patterns for the configuration of an output3 cell |
| CR24901 | In BT-Basic, hex data '00' can not be sent via RS232. |
| CR23102 | During board development, if only module 1 is defined and Bank1(modules 0,1) is set. If the user selects Default Placement, the board is misplaced to the outside of the fixture outline. |
| CR24296 | Board placement does not work with Graphical User Interface. When dragging and dropping board outline to different spot on fixture, the Graphical User interface simply moves it back where it was and nothing is changed. |

Agilent Medalist i5000 06.02sb Software Release Bulletin

This is a Software Patch for i5000 06.02p for Windows.

You must already have version i5000 06.02p on your computer before you install the 06.02sb software patch.

Software patch 06.02sb addresses these issues:

| Change Request Identification | Description |
|-------------------------------|---|
| CR22897 | Add Test Result Highlight: User can now use "board graphics highlight device" and "board graphics highlight nodes" commands to highlight device/node's status as active, fail, pass in i5000 browser. |

Agilent Medalist i5000 06.02sc Software Release Bulletin

This is a Software Patch for i5000 06.02p for Windows.

You must already have version i5000 06.02p on your computer before you install the 06.02sc software patch.

Software patch 06.02sc addresses these issues:

| Change Request Identification | Description |
|-------------------------------|--|
| CR27037 | Board graphics display in operator interface will not appear after repeated loading/unloading of different boards in some instances. |

Agilent Medalist i5000 06.02sd Software Release Bulletin

This is a Software Patch for i5000 06.02p for Windows.

You must already have version i5000 06.02p on your computer before you install the 06.02sd software patch.

Software patch 06.02sd addresses these issues:

| Change Request Identification | Description |
|-------------------------------|--|
| CR27992 | Operator and engineer interface will freeze during DUT board test: testplan would stop running and no response from the GUI interface. |