

# Agilent Medalist i3070 08.30pa Software Patch

## Release Notes

- Software Release Date** : August 2012  
**System Requirements** : Agilent Medalist i3070 test system or  
test development workstation  
**Controller Requirements**: Microsoft® Windows® PC  
**Operating System** : Windows 7 or Windows XP  
**Software Requirement** : Agilent Medalist i3070 08.30p

The Agilent Medalist i3070 08.30pa software patch should only be installed on systems with i3070 08.30p software release. It can be installed on systems with i3070 test system software or i3070 development software.

The 08.30pa software patch addresses the following change requests.

<b>Change Request</b>	<b>Description</b>
CR34372 / CR34371	08.30: Pushbutton Q-STATS hang if failure report has more than one page.
CR34365 / CR34392	08.30: Operator toolbar STOP button failed but PPU credit was deducted.
CR34391	08.30: Unexpected DGN Test 8 appeared on ASRU Module Cards for Mux systems.

Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

## Installing the 08.30pa Software Patch


This software patch must be installed using the administrator login (or a login with administrator privileges).

Follow these steps to install the 08.30pa software patch:

- 1 Save the **Agilenti3070\_0830pa.exe** file to your hard disk.
- 2 Close all open programs.
- 3 Double-click **Agilenti3070\_0830pa.exe**.
- 4 Follow the on-screen instructions for installation.
- 5 To validate that the software was installed correctly:
  - a On the **Start** menu, select **Programs > Agilent ICT > Korn Shell**.
  - b In the Korn Shell window, type `version` and press **Enter**.

The following software revision should be displayed:  
**Agilent Medalist i3070 08.30pa 0612 WN**

© Agilent Technologies, Inc. 2012  
Printed in Malaysia 08/12



E9901-90030