



# Agilent Medalist i3070 08.20pa Software Patch

## Release Notes

**Software Release Date** : April 2011

**System Requirements** : Agilent Medalist i3070 or test development PC

**Controller Requirements**: Windows PC

**Operating System** : Microsoft Windows XP

**Software Requirement** : Agilent Medalist i3070 08.20p

This software patch should only be installed only on Microsoft Windows systems with Medalist i3070 08.20p software release. It can be installed on systems with i3070 test system software or i3070 development software.

The software patch enables external dynamic-link library (DLL) calls for any application usage such as retrieval and update of test data to server. This software patches also addresses the following change request: CR34150 – Resolved ASRU N revision diagnostics test number 2824 failure.

The software patch must be installed using the administrator login (or a login with administrator privileges).

## Installing the 08.20pa Software Patch

Follow these steps to install the 08.20pa software patch on Windows systems running the Medalist i3070 software:

- 1 Save the Agilenti3070\_08.20pa.exe and update.exe files to your hard disk.
- 2 Close all open programs.
- 3 Double-click **Agilenti3070\_08.20pa.exe**.
- 4 Follow the on-screen instructions for installation.
- 5 To validate that the software was installed correctly:
  - a On the **Start** menu, select **Programs > Agilent ICT > Korn Shell**.
  - b In the Korn Shell window, type `version` and press **Enter**.

The following software revision should be displayed:

**Agilent Medalist i3070 08.20pa 1110 WN**



[www.agilent.com](http://www.agilent.com)

© Agilent Technologies, Inc. 2011

Printed in Malaysia



E9901-90023



**Agilent Technologies**