

# N5452A Automated Test Application Remote Programming Toolkit

Keysight N5452A Automated Test Application Remote Programming Toolkit Version 7.20

---

Release Date:	1 September 2023
Supported Operating Systems:	Microsoft Windows 10/11
File Name:	SetupInfRemDevTool07200000.exe

---

## Highlights:

Exported CSV reports now include simple tables from results.

## Additions:

Keysight DigitalTestApps Remote Interface for LabView

- GetCsvOpsDataFormat
- SetCsvOpsDataFormat

## Modifications:

Keysight DigitalTestApps Remote Interface for .NET

- ExportCsvOptions DataFormat=3 now includes simple result tables.

Keysight DigitalTestApps Remote Interface for TAP

- Export Results step CSVFormat=3 now includes simple result tables.

# Keysight N5452A Automated Test Application Remote Programming Toolkit Version 7.12

---

Release Date:	21 June 2023
Supported Operating Systems:	Microsoft Windows 10/11
File Name:	SetupInfRemDevTool07120000.exe

---

## Highlights:

You can now include waveforms in saved projects.

## Additions:

Keysight DigitalTestApps Remote Interface for .NET

- IRemoteAte.ExportProject
- ExportProjectOptions.IncludeDataFiles
- SaveProjectOptions.IncludeDataFiles

Keysight DigitalTestApps Remote Interface for .LabView

- ExportProject
- GetExportProjIncludeDataFiles
- GetSaveProjIncludeDataFiles
- SetExportProjIncludeDataFiles
- SetSaveProjIncludeDataFiles

## Modifications:

Keysight DigitalTestApps Remote Interface for TAP

- ExportProjectStep
- SaveProjectStep

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 7.11

---

Release Date:	May 1, 2023
Supported Operating Systems:	Microsoft Windows 10
File Name:	SetupInfRemDevTool07110000.exe

---

### Highlights:

Added support for partial result deletion and custom message button handling.

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- IRemoteAte:DeleteResultsCustom
- DeleteResultsOptions
- MessageEventArgs.ButtonsCustom
- MessageEventArgs.SuppressionResponseCustom
- MessageEventArgs.ResponseCustom

Keysight DigitalTestApps Remote Interface for .LabView

- DeleteResultsCustom
- GetDeleteOpsAllResults
- SetDeleteOpsAllResults
- GetDeleteOpsTestIds
- SetDeleteOpsTestIds

# Keysight N5452A Automated Test Application Remote Programming Toolkit Version 7.10

---

Release Date:	February 1, 2023
Supported Operating Systems:	Microsoft Windows 10
File Name:	SetupInfRemDevTool07100000.exe

---

## Highlights:

Added support for project archives.

## Additions:

Keysight DigitalTestApps Remote Interface for .NET

- IRemoteAte:ExportProjectCustom
- IRemoteAtelImportProjectCustom
- ExportProjectOptions
- ImportProjectOptions

Keysight DigitalTestApps Remote Interface for .LabView

- ExportProjectCustom
- GetExportOverwriteProj
- GetExportProjBaseDir
- GetExportProjFullPath
- GetExportProjName
- SetExportOverwriteProj
- SetExportProjBaseDir
- SetExportProjName
- ImportProjectCustom
- GetImportProjDiscardChanges
- GetImportProjFullPath
- GetImportProjUseSaveTest
- SetImportProjDiscardChanges
- SetImportProjFullPath
- SetImportProjUseSaveTest

Keysight DigitalTestApps Remote Interface for TAP

- Export Project Step
- Import Project Step

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 7.2

---

Release Date:	October 5, 2022
Supported Operating Systems:	Microsoft Windows 10
File Name:	SetupInfRemDevTool07020000.exe

---

### Highlights:

Added support for result tags.

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- DefineResultTags
- setResultTagValues

Keysight DigitalTestApps Remote Interface for .LabView

- DefineResultTags
- setResultTagValues

Keysight DigitalTestApps Remote Interface for TAP

- Define Result Tag Step
- Set Result Tag Values Step

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 7.1

<b>Released Date:</b>	1 July 2022
<b>Supported Operating Systems:</b>	Microsoft Windows 7, Microsoft Windows 10
<b>File Name:</b>	SetupInfRemDevTool07010000.exe

### Highlights:

Added support for the Measurement Server feature.

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- ExecutionPhaseTypes
- IRemoteAte.ExecutionPhases

Keysight DigitalTestApps Remote Interface for .LabView

- GetExecutionPhases
- SetExecutionPhases

Keysight DigitalTestApps Remote Interface for TAP

- ConfigureTestExecution step

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 6.30.1

<b>Released Date:</b>	15 July 2021
<b>Supported Operating Systems:</b>	Microsoft Windows 7, Microsoft Windows 10
<b>File Name:</b>	SetupInfRemDevTool06300001.exe

### Additions:

Keysight DigitalTestApps Remote Interface for TAP

- Added InfiniiSim-DCA SetSettings Step
- Support for Measurement Server will be added in version 6.40.

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 06.30

Released Date:	18 December 2020
Supported Operating Systems:	Microsoft Windows 7, Microsoft Windows 10
File Name:	SetupInfRemDevTool06300000.exe

### Highlights:

Added support for the Measurement Server feature.

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- AteEventSink.MeasServerResultsAvailableEvent
- HtmlRefreshType
- IRemoteAte.AbortedTestIds
- IRemoteAte.AbortedTestInfos
- IRemoteAte.ConnectAppToResourceArbiter
- IRemoteAte.MeasServerAbort
- IRemoteAte.MeasServerDidAbortOccur
- IRemoteAte.MeasServerGetAbortedTestIds
- IRemoteAte.MeasServerGetAbortedTestInfos
- MeasServerResultsAvailableEventArgs
- RunOptions.AutoHtmlRefresh
- RunOptions.AutoProjectSaveBasePath
- RunOptions.AutoProjectSaveName
- RunOptions.RunId

#### Keysight DigitalTestApps Remote Interface for .LabView

- ConnectAppToResourceArbiter
- GetAbortedTestIds
- GetAbortedTestInfos
- GetRunOpsAutoHtmlRefresh
- GetRunOpsAutoProjectSaveBasePath
- GetRunOpsAutoProjectSaveName
- GetRunOpsRunId
- MeasServerAbort
- MeasServerDidAbortOccur
- MeasServerGetAbortedTestIds
- MeasServerGetAbortedTestInfos
- SetRunOpsAutoHtmlRefresh
- SetRunOpsAutoProjectSaveBasePath
- SetRunOpsAutoProjectSaveName
- SetRunOpsRunId

#### Keysight DigitalTestApps Remote Interface for TAP

- Support for Measurement Server will be added in the next release.



## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 06.21

Released Date:	1 September 2020
Supported Operating Systems:	Microsoft Windows 7, Microsoft Windows 10
File Name:	SetupInfRemDevTool06210000.exe

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- During connection changes, the message that gets sent to the remote client now contains
  - MessageEventArgs.ApplyInfiniiSim
  - MessageEventArgs.CanSetApplyInfiniiSim

# Keysight N5452A Automated Test Application Remote Programming Toolkit Version 06.12

<b>Released Date:</b>	<b>1 March 2020</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows 7, Microsoft Windows 10</b>
<b>File Name:</b>	<b>SetupInfRemDevTool06120000.exe</b>

## Modifications:

Keysight DigitalTestApps Remote Interface for .NET / .TAP

- MeasurementResult.TableData deprecated, now use MeasurementResult.Tables.

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 06.10

Released Date:	21 October 2019
Supported Operating Systems:	Microsoft Windows Vista, Microsoft Windows 7, Microsoft Windows 10
File Name:	SetupInfRemDevTool06100000.exe

### Additions:

#### Compliance App Automation Tab

- New Automation Control commands (available in user interface only): ^Sleep, ^Pause and ^Prompt.
- New Pause/Resume button.

#### Keysight DigitalTestApps Remote Interface for .NET / .TAP

- Improved cross-references between these two help files.

#### Keysight DigitalTestApps Remote Interface for LabVIEW

- GetConnectOpsCloseStartupMessageBoxes
- SetConnectOpsCloseStartupMessageBoxes

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 06.03

<b>Released Date:</b>	10 July 2019
<b>Supported Operating Systems:</b>	Microsoft Windows Vista, Microsoft Windows 7, Microsoft Windows 10
<b>File Name:</b>	SetupInfRemDevTool06030000.exe

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- ChannelOptions
- NewProjectOptions.PreserveChannelSetup
- IRemoteAte.GetChannelSettings
- IRemoteAte.SetChannelSettings

Keysight DigitalTestApps Remote Interface for LabVIEW

- GetChannelSettings
- GetChannelSettingsCustom
- GetChanOpsInvert
- GetNewProjectOpsPreserveChannelSetup
- SetChannelSettings
- SetChannelSettingsCustom
- SetChanOpsInvert
- SetNewProjectOpsPreserveChannelSetup

# Keysight N5452A Automated Test Application Remote Programming Toolkit Version 06.01

Released Date:	24 June 2019
Supported Operating Systems:	Microsoft Windows Vista, Microsoft Windows 7, Microsoft Windows 10
File Name:	SetupInfRemDevTool06010000.exe

## Additions:

Keysight DigitalTestApps Remote Interface for .NET

- TestInfoContainer.PassLimits

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 06.00

<b>Released Date:</b>	17 May 2019
<b>Supported Operating Systems:</b>	Microsoft Windows Vista, Microsoft Windows 7, Microsoft Windows 10
<b>File Name:</b>	SetupInfRemDevTool06000000.exe

### Highlights:

You can now automate a compliance app or a user-defined app from Keysight's KS8400A Test Automation for PathWave. Please see the *Getting Started Guide* for more information.

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- TestInfoContainer.PassLimits

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 05.92

<b>Released Date:</b>	<b>21 December 2018</b>
<b>Supported Operating Systems:</b>	Microsoft Windows Vista, Microsoft Windows 7, Microsoft Windows 10
<b>File Name:</b>	SetupInfRemDevTool05920000.exe

### Highlights:

You can now automate generation of a single file HTML (.mht) report, and can include a .pdf or .mht report in the results object.

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- IRemoteAte.DefaultInstrument
- IRemoteAte.DefaultInstrumentCustom
- IRemoteAte.ExportResultsHtml
- DefaultInstrumentOptions
- ResultOptions.IncludeHtmlReport
- ResultOptions.IncludePdfReport

## Keysight DigitalTestApps Remote Interface for LabVIEW

- DefaultInstrument
- DefaultInstrumentCustom
- GetDefaultInstrumentOptions
- GetDefaultInstrumentOpsInstrumentName
- SetDefaultInstrumentOpsInstrumentName
- ExportResultsHtml
- GetResultOpsIncHtml
- SetResultOpsIncHtml
- GetResultOpsIncPdf
- SetResultOpsIncPdf



## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 05.90

Released Date:	20 August 2018
Supported Operating Systems:	Microsoft Windows Vista, Microsoft Windows 7, Microsoft Windows 10
File Name:	SetupInfRemDevTool05900000.exe

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- IRemoteAte.Pause
- IRemoteAte.Resume

Keysight DigitalTestApps Remote Interface for LabVIEW

- Pause
- Resume

### Modifications:

Source code for sample programs now requires Microsoft Visual Studio version 2013 or later.

# Keysight N5452A Automated Test Application Remote Programming Toolkit Version 05.70

<b>Released Date:</b>	15 December 2017
<b>Supported Operating Systems:</b>	Microsoft Windows Vista, Microsoft Windows 7, Microsoft Windows 10
<b>File Name:</b>	SetupInfRemDevTool05700000.exe

## Additions:

Keysight DigitalTestApps Remote Interface for .NET

- ExportPdfOptions
- IRemoteAte.ExportResultsPdf
- IRemoteAte.ExportResultsPdfCustom

Keysight DigitalTestApps Remote Interface for LabVIEW

- ExportResultsPdf
- ExportResultsPdfCustom
- GetPdfOpsFileName
- SetPdfOpsFileName
- GetPdfOpsPath
- SetPdfOpsPath
- GetPdfOpsOverwrite
- SetPdfOpsOverwrite

## Modifications:

Fixed: Remote commands that do not alter an app's state no longer place it in an "unsaved changes exist" state

### Keysight DigitalTestApps Remote Interface for .NET

- IRemoteAte.Show now forces the application window to the foreground
- ExportCsvOptions: FileName now defaults to: (app name)\_Results\_(results date/time).csv
- ExportCsvOptions: OverwriteExisting now defaults to false

### Keysight DigitalTestApps Remote Interface for LabVIEW

- Show now forces the application window to the foreground

# Keysight N5452A Automated Test Application Remote Programming Toolkit Version 05.63

<b>Released Date:</b>	15 November 2017
<b>Supported Operating Systems:</b>	Microsoft Windows Vista, Microsoft Windows 7, Microsoft Windows 10
<b>File Name:</b>	SetupInfRemDevTool05630000.exe

## Additions:

Keysight DigitalTest Application Sequencer

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 05.61

Released Date:	1 September 2017
Supported Operating Systems:	Microsoft Windows Vista, Microsoft Windows 7, Microsoft Windows 10
File Name:	SetupInfRemDevTool05610000.exe

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- TableData.Caption
- InfiniiSimFilterResponse
- InfiniiSimState.FilterResponse
- TestInfoContainer
- IRemoteAte.BertSaveCalibrations
- IRemoteAte.BertLoadCalibrations
- IRemoteAte.GetTestInfo

Keysight DigitalTestApps Remote Interface for LabVIEW

- BertSaveCalibrations
- BertLoadCalibrations
- GetISimOpsFilterResponse
- GetTestInfo
- SetISimOpsFilterResponse

### Modifications:

Keysight DigitalTestApps Remote Interface for .NET

- Fixed: GetAllOptionsForMember

Python support changes:

- Use only Pythonnet 2.0.0. For details, see Programming Guide, Chapter 3, Python section.

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 05.30

Released Date:	13 February 2017
Supported Operating Systems:	Microsoft Windows Vista, Microsoft Windows 7
File Name:	SetupInfRemDevTool05300000.exe

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- `NewProjectOptions.PreserveTypeC`
- `RunOptions.DisableInstrumentGui`

Keysight DigitalTestApps Remote Interface for LabVIEW

- `GetNewProjectOpsPreserveTypeC`
- `SetNewProjectOpsPreserveTypeC`
- `GetRunOpsDisableInstrumentGui`
- `SetRunOpsDisableInstrumentGui`
- `Dispose`

## Modifications:

### File Folder changes:

- The Agilent-Keysight Transition folder has been renamed “Deprecated”, acknowledging that the two-year transition period is now complete. You should now be using a Keysight-Only client. See the Deprecated\_Readme.txt file in the Deprecated folder for more information.
- The Keysight Apps Only folder has been deleted and its contents moved to the main toolkit installation folder.
- The Miscellaneous folder has been renamed “Utilities”.

### Keysight DigitalTestApps Remote Interface for COM

The N5452A Remote Toolkit installer no longer registers the remote interface with COM. After installing Toolkit version 5.21, if your remote client uses COM to control Keysight automated test apps then please see the readme.txt file in the **Tools\COM** subfolder.

### Keysight DigitalTestApps Remote Interface for LabVIEW

- Fixed **Run** command.
- Fixed ability to repeatedly **Connect/Disconnect**.

### Agilent-Keysight Transition DigitalTestApps Remote Interface for .NET

- When connected to a Keysight app, **GetResults** now includes ExtraData values.

### Agilent-Keysight Transition DigitalTestApps Remote Interface for LabVIEW

- Fixed ability to use a new **RemoteClient** object per **Connect/Disconnect** (reusing the same object for multiple connect/disconnect calls is still supported, too)
- Fixed ability to repeatedly **Connect/Disconnect**.



## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 03.50

<b>Released Date:</b>	<b>1 December 2015</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows Vista, Microsoft Windows 7</b>
<b>File Name:</b>	<b>SetupInfRemDevTool03500000.exe</b>

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- TestLimits.Id
- TestLimits.Description

Keysight DigitalTestApps Remote Interface for LabVIEW

- AllowExceptionsToReachLabVIEW

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 03.41

<b>Released Date:</b>	<b>22 June 2015</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows Vista, Microsoft Windows 7</b>
<b>File Name:</b>	<b>SetupInfRemDevTool03410000.exe</b>

### Modifications:

Fixed uninstaller removal of COM registry entries.

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 03.40

<b>Released Date:</b>	<b>3 December 2014</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows Vista, Microsoft Windows 7</b>
<b>File Name:</b>	<b>SetupInfRemDevTool03400000.exe</b>

### Additions:

Keysight DigitalTestApps Remote Interface for .NET

- InfiniiSimOptions.FourPortPairChannel
- InfiniiSimOptions.FourPortPairTestPoint
- InfiniiSimOptions.FourPortNumbering
- InfiniiSimOptions.OperatorOutput
- InfiniiSimOptions.InfiniiSimState.ApplyS4P
- InfiniiSimOptions.InfiniiSimState.RemoveS4P
- InfiniiSimOptions.InfiniiSimOperatorOutput
- InfiniiSimOptions.InfiniiSimFourPortNumbering
- RemoteAteUtilities.CreateAteEventSink

## Keysight DigitalTestApps Remote Interface for LabVIEW

- GetISimOpsFourPortNumbering
- GetISimOpsFourPortPairChannel
- GetISimOpsFourPortPairTestPoint
- GetISimOpsOperatorOutput
- SetISimOpsFourPortNumbering
- SetISimOpsFourPortPairChannel
- SetISimOpsFourPortPairTestPoint
- SetISimOpsOperatorOutput

## Modifications:

Default timeout for GetRemoteAte increased from 30 seconds to 60 seconds

# Keysight N5452A Automated Test Application Remote Programming Toolkit Version 03.30

<b>Released Date:</b>	<b>1 October 2014</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows Vista, Microsoft Windows 7</b>
<b>File Name:</b>	<b>SetupInfRemDevTool03300000.exe</b>

## Additions:

Keysight DigitalTestApps Remote Interface for .NET

- `GetRemoteAteOptions.ScopeAppAddressOrAlias`

Keysight DigitalTestApps Remote Interface for LabVIEW

- `RemoteClient.SetConnectOpsScopeAppAddressOrAlias`
- `RemoteClient.GetConnectOpsScopeAppAddressOrAlias`

## Modifications:

Keysight DigitalTestApps Remote Interface for .NET

- `Remote.dll` assemblies are now COM-visible
- Improved initial connection behavior when controlling apps that are launching on a PC
- Fixed exception handling when controlling Keysight apps

Keysight DigitalTestApps Remote Interface for LabVIEW

- Improved initial connection behavior when controlling apps that are launching on a PC
- Fixed exception handling when controlling Keysight apps

## Keysight N5452A Automated Test Application Remote Programming Toolkit Version 03.20

Released Date:	4 September 2014
Supported Operating Systems:	Microsoft Windows Vista, Microsoft Windows 7
File Name:	SetupInfRemDevTool03200000.exe

### Modifications:

#### Keysight DigitalTestApps Remote Interface for .NET

- There are now two sets of remote interface documents
  - Transition (compatible with Agilent or Keysight apps): Please see the readme.txt document in “Agilent-Keysight Transition” subfolder
  - Keysight-Only (compatible only with Keysight apps): Please see the readme.txt document in the “Keysight Apps Only” subfolder

#### Keysight DigitalTestApps Remote Interface for LabVIEW

- There are now two sets of remote interface documents
  - Transition (compatible with Agilent or Keysight apps): Please see the readme.txt document in “Agilent-Keysight Transition” subfolder
  - Keysight-Only (compatible only with Keysight apps): Please see the readme.txt document in the “Keysight Apps Only” subfolder

#### Keysight DigitalTestApps Getting Started Guide

- Updated to reflect Agilent-to-Keysight transition

#### Keysight DigitalTestApps Programming Guide

- Updated to reflect Agilent-to-Keysight transition

# Agilent N5452A Automated Test Application Remote Programming Toolkit Version 03.00

<b>Released Date:</b>	11 August 2014
<b>Supported Operating Systems:</b>	Microsoft Windows Vista, Microsoft Windows 7
<b>File Name:</b>	SetupInfRemDevTool03000000.exe

## Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET

- Added new event:
  - AteEventSink.RunEndedEvent

Agilent Automated DigitalTest Application Remote Interface for LabVIEW

- Added new event:
  - RemoteClient.RunEndedEvent

Agilent Automated DigitalTest Applications Programming Guide

- Added new sample application (including source code): Simple Message Handling Remote Client

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.90

<b>Released Date:</b>	<b>2 June 2014</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows Vista, Microsoft Windows 7</b>
<b>File Name:</b>	<b>SetupInfRemDevTool02900000.exe</b>

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET

- Added new methods:
  - IRemoteAte.GetInfiniiSimSettingsCustom
  - IRemoteAte.SetInfiniiSimSettingsCustom
- Added new types:
  - GetInfiniiSimSettingsOptions
  - SetInfiniiSimSettingsOptions
- (FlexDCA only) Added new properties:
  - InfiniiSimOptions.SParamsFullPath
  - InfiniiSimOptions.FlipSParams
- (FlexDCA only) Added new enumeration values:
  - InfiniiSimOptions.InfiniiSimState.ApplyS2P
  - InfiniiSimOptions.InfiniiSimState.RemoveS2P

## Agilent Automated DigitalTest Application Remote Interface for LabVIEW

- Added new methods:
  - GetInfiniiSimSettingsCustomB
  - GetISimOpsFlipSParams
  - GetISimOpsSParamsFullPath
  - SetInfiniiSimSettingsCustomB
  - SetISimOpsFlipSParams
  - SetISimOpsSParamsFullPath

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.80

Released Date:	25 April 2014
Supported Operating Systems:	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
File Name:	SetupInfRemDevTool02800000.exe

### Additions:

#### Agilent Automated DigitalTest Application Remote Interface for .NET

- Added new property:
  - MessageEventArgs.ID



## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.70

<b>Released Date:</b>	<b>7 March 2014</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7</b>
<b>File Name:</b>	<b>SetupInfRemDevTool02700000.exe</b>

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET

- Added new methods:
  - IRemoteAte.SwitchMatrixGetPathNormCustom
  - IRemoteAte.SwitchMatrixSetPathNormCustom

Agilent Automated DigitalTest Application Remote Interface for LabVIEW

- Added new methods:
  - SwitchMatrixGetPathNormCustom
  - SwitchMatrixSetPathNormCustom

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.60

<b>Released Date:</b>	13 January 2014
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
<b>File Name:</b>	SetupInfRemDevTool02600000.exe

### Additions:

#### Agilent Automated DigitalTest Application Remote Interface for .NET

- Added new property:
  - InfiniiSimOption.DisableApc

#### Agilent Automated DigitalTest Application Remote Interface for LabVIEW

- Added new methods:
  - SetISimOpsDisableApc
  - GetISimOpsDisableApc

#### Agilent Automated DigitalTest Application Programming Guide

- Added Microsoft .NET Advanced Topic: Parallel Testing (see Chapter 3, Remote Programming Languages and Sample Code)
- Added information to Python Advanced Topic: Event Handling (see Chapter 3, Remote Programming Languages and Sample Code)

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.50

Released Date:	15 November 2013
Supported Operating Systems:	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
File Name:	SetupInfRemDevTool02500000.exe

### Additions:

#### Agilent Automated DigitalTest Application Remote Interface for .NET

- Added new methods:
  - IRemoteAte.SwitchMatrixDefineMultiSwitchSignalPath
  - IRemoteAte.SwitchMatrixGetSwitchesForSignalPath
- Added new properties:
  - InfiniiSimOption.NormalizeGain
  - InfiniiSimOption.FilterType
  - SwitchInfo.Output
  - SwitchInfo.Module
  - SwitchInfo.Switch
- Added new types:
  - InfiniiSimDelay.InfiniiSimFilterType

#### Agilent Automated DigitalTest Application Remote Interface for LabVIEW

- Added new methods:
  - GetISimOpsFilterType
  - GetISimOpsNormalizeGain
  - SetISimOpsFilterType
  - SetISimOpsNormalizeGain
  - SwitchMatrixDefineMultiSwitchSignalPath
  - SwitchMatrixDefineSignalPath (new signature)
  - SwitchMatrixGetSwitchesForSignalPath

Agilent Automated DigitalTest Application Programming Guide

- Added information on using Python for .Net to Chapter 3
- Added information on troubleshooting .Net to Chapter 6

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.41

<b>Released Date:</b>	<b>22 October 2013</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7</b>
<b>File Name:</b>	<b>SetupInfRemDevTool02410000.exe</b>

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET  
RemoteAteUtilities:LoggingEnabled

### Modifications:

Agilent Automated DigitalTest Application Remote Interface for .NET  
You no longer have to create the base directory before using the following:

- IRemoteAte.ProjectPath
- IRemoteAte.SaveProjectCustom

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.40

<b>Released Date:</b>	<b>8 July 2013</b>
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
<b>File Name:</b>	SetupInfRemDevTool02400000.exe

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET

- Added new methods:
  - IRemoteAte.NewProjectCustom()
  - IRemoteAte.SwitchMatrixGetInstrumentAddress
  - IRemoteAte.SwitchMatrixGetPathNormMode
  - IRemoteAte.SwitchMatrixGetPathInfiniiSim
  - IRemoteAte.SwitchMatrixGetPathPrecisionProbe
  - IRemoteAte.SwitchMatrixLoad()
  - IRemoteAte.SwitchMatrixLoadCustom()
  - IRemoteAte.SwitchMatrixSave()
  - IRemoteAte.SwitchMatrixSaveCustom()
- Added new properties:
  - InfiniiSimOptions.Delay
  - PrecisionProbeOptions.IncludeCableDelay
- Added new types:
  - NewProjectOptions
  - SwitchMatrixNormalizationMode
  - SwitchMatrixLoadOptions
  - SwitchMatrixSaveOptions

## Agilent Automated DigitalTest Application Remote Interface for LabVIEW

- Added new methods:
  - GetISimOpsDelay()
  - GetNewProjectOptions()
  - GetNewProjectOptionsDiscardUnsaved()
  - GetNewProjectOptionsPreserveAcqSetup()
  - GetNewProjectOptionsPreserveInfiniiSim()
  - GetNewProjectOptionsPreservePrecisionProbe()
  - GetNewProjectOptionsPreserveSwitchMatrix()
  - GetPrecProbeOpsIncludeCableDelay()
  - NewProjectCustom()
  - SetISimOpsDelay()
  - SetNewProjectOptions()
  - SetNewProjectOptionsDiscardUnsaved()
  - SetNewProjectOptionsPreserveAcqSetup()
  - SetNewProjectOptionsPreserveInfiniiSim()
  - SetNewProjectOptionsPreservePrecisionProbe()
  - SetNewProjectOptionsPreserveSwitchMatrix()
  - SetPrecProbeOpsIncludeCableDelay()
  - SwitchMatrixGetInstrumentAddress
  - SwitchMatrixGetPathNormMode
  - SwitchMatrixGetPathInfiniiSim
  - SwitchMatrixGetPathPrecisionProbe
  - SwitchMatrixGetLoadOpsFullPath()
  - SwitchMatrixGetSaveOpsFullPath()
  - SwitchMatrixGetSaveOpsOverwriteExisting()

- SwitchMatrixLoad()
- SwitchMatrixLoadCustom()
- SwitchMatrixSave()
- SwitchMatrixSaveCustom()
- SwitchMatrixSetLoadOpsFullPath()
- SwitchMatrixSetSaveOpsFullPath()
- SwitchMatrixSetSaveOpsOverwriteExisting()

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.30

Released Date:	10 May 2013
Supported Operating Systems:	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
File Name:	SetupInfRemDevTool02300000.exe

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET:

- Help file: Added new Switch Matrix methods and properties.

Agilent Automated DigitalTest Application Remote Interface for LabVIEW:

- Help file: Added new Switch Matrix methods.
- API: Fixed LabVIEW SetPrecisionProbeSettings method.

### Programming Guide

- Chapter 3: Added “Advanced Topic: Switch Matrix” to each language section.

### Tools:

- Added file Agilent.Infiniium.AppFW.Remote.xml for use in Microsoft Visual Studio to add Intellisense support for items in Agilent.Infiniium.AppFW.Remote.dll.

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.22

<b>Released Date:</b>	7 March 2013
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
<b>File Name:</b>	SetupInfRemDevTool02220000.exe

### Modifications:

Changed format of probe info returned from call to `IRemoteAte.GetTestSessionInfo("Probe (Channel #)")`

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.21

<b>Released Date:</b>	1 February 2013
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
<b>File Name:</b>	SetupInfRemDevTool02210000.exe

### Additions:

#### Programming Guide:

- Chapter 3: Added "Advanced Topic: Event Handling" sections.
- Chapter 6: Added "If your PC Has Two Network Interface Cards" section.

#### Agilent Automated DigitalTest Application Remote Interface for .NET:

- Help file: Added "see also" links from topics `GetAllOptions`, `GetCurrentOptions` and `GetAllOptionsForMember` to the supported elements.

#### Tools:

- Added file `Agilent.Infiniium.AppFW.Remote.config` for use in remote clients that activate the "automated test app - > remote client callback path.



### Modifications:

Fixed crash when remote client machine's Windows installation has an incompatible icon library.

### Programming Guide:

- Chapter 3: Fixed ExportResultsCsv examples.

Agilent Automated DigitalTest Application Remote Interface for .NET:

- Fixed operation of GetCurrentOptionsOptions("RunEventNames").

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.20

Released Date:	1 December 2012
Supported Operating Systems:	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
File Name:	SetupInfRemDevTool02200000.exe

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET:

- Added methods:
  - GetTestSessionInfo

Agilent Automated DigitalTest Application Remote Interface for LabVIEW:

- Added methods:
  - GetTestSessionInfo

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.14

<b>Released Date:</b>	1 September 2012
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
<b>File Name:</b>	SetupInfRemDevTool02140000.exe

### Modifications:

Agilent Automated DigitalTest Application Remote Interface for .NET

- New Method: ExecuteScript.
- SuppressSimpleMessages now suppresses Debug/Compliance mode toggle prompts.

Agilent Automated DigitalTest Application Remote Interface for LabVIEW

- New Method: ExecuteScript.

### Tools

- Now includes a Global Assembly Cache –compatible version of Agilent.Infiniium.AppFW.Remote.dll, located in the ...\\Tools\\GAC\\ subdirectory.
- You may now use a scope's machine name instead of its IP address.

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.13

<b>Released Date:</b>	13 July 2012
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7
<b>File Name:</b>	SetupInfRemDevTool02130000.exe

### Modifications:

Agilent Automated DigitalTest Application Remote Interface for .NET

- Now supports applications built for Agilent FlexDCA.

Agilent Automated DigitalTest Application Remote Interface for LabVIEW

- Now supports applications built for Agilent FlexDCA.

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.12

<b>Released Date:</b>	<b>5 April 2012</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7</b>
<b>File Name:</b>	<b>SetupInfRemDevTool02120000.exe</b>

### Modifications:

Agilent Automated DigitalTest Application Remote Interface for .NET

- Fixed exception issued from method AteEventSink.Dispose when ending a session with a legacy compliance application.

Agilent Automated DigitalTest Application Remote Interface for LabVIEW

- You may now register for events and Connect in either order.
- You may now unregister for events and Disconnect in either order.
- Fixed LabVIEW Demo client.

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.11

<b>Released Date:</b>	<b>8 February 2012</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista, Microsoft Windows 7</b>
<b>File Name:</b>	<b>SetupInfRemDevTool02110000.exe</b>

### Modifications:

Agilent Automated DigitalTest Application Remote Interface for .NET.chm:

- Fixed use of remote interface user port for automated test applications running on Windows 7.

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.10

<b>Released Date:</b>	5 October 2011
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista
<b>File Name:</b>	SetupInfRemDevTool02100000.exe

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET.chm:

- Added types:
  - AcquisitionOptions
- Added methods:
  - IRemoteAte.GetAcquisitionSettings
  - IRemoteAte.SetAcquisitionSettings

Agilent Automated DigitalTest Application Remote Interface for LabVIEW.chm:

- Added methods:
  - GetAcqOpsBandwidth
  - GetAcqOpsBandwidthLimitEnabled
  - GetAcquisitionSettings
  - GetAcquisitionSettingsCustom
  - SetAcqOpsBandwidth
  - SetAcqOpsBandwidthLimitEnabled
  - SetAcquisitionSettings
  - SetAcquisitionSettingsCustom

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 02.00

Released Date:	1 September 2011
Supported Operating Systems:	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista
File Name:	SetupInfRemDevTool02000000.exe

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET.chm:

- Added types:
  - PrecisionProbeOptions
  - PermutationStartingEventArgs
  - TrialStartingEventArgs
  - TestGroupStartingEventArgs
  - TestStartingEventArgs
  - TestEndedEventArgs
- Added properties:
  - IRemoteAte.AbortOccurred
  - IRemoteAte.LogEvents
- Added methods:
  - IRemoteAte.GetPrecisionProbeSettings
  - IRemoteAte.SetPrecisionProbeSettings
  - IRemoteAte.ReadProbeConfiguration
- Added events:
  - AteEventSink.TrialStartingEvent
  - AteEventSink.PermutationStartingEvent
  - AteEventSink.TestGroupStartingEvent
  - AteEventSink.TestStartingEvent

- AteEventSink.TestEndedEvent
- AteEventSink.PermutationEndedEvent
- AteEventSink.TrialEndedEvent

Agilent Automated DigitalTest Application Remote Interface for LabVIEW.chm:

- Added methods:
  - GetAbortOccurred
  - GetLogEvents
  - GetPrecisionProbeSettings
  - GetPrecisionProbeSettingsCustom
  - GetPrecProbeOpsOn
  - GetPrecProbeOpsMode
  - GetPrecProbeOpsCalibration
  - GetPrecProbeOpsBandwidthCorrection
  - GetPrecProbeOpsLimitBoost
  - GetPrecProbeOpsBandwidth
  - ReadProbeConfiguration
  - SetLogEvents
  - SetPrecisionProbeSettings
  - SetPrecisionProbeSettingsCustom
  - SetPrecProbeOpsOn
  - SetPrecProbeOpsMode
  - SetPrecProbeOpsCalibration
  - SetPrecProbeOpsBandwidthCorrection
  - SetPrecProbeOpsLimitBoost
  - SetPrecProbeOpsBandwidth
- Added events:

- TrialStartingEvent
- PermutationStartingEvent
- TestGroupStartingEvent
- TestStartingEvent
- TestEndedEvent
- PermutationEndedEvent
- TrialEndedEvent

#### Modifications:

- You may now use the automated test application remote interface free of charge, by either:
  - Upgrading your 9xxx or 9xxx-series scope to Infiniium version 3.20
  - OR -
  - Upgrading your automated test application to one that supports remote interface version 2.00 or later.

If these options are not available yet, please contact your Agilent sales representative to obtain a free temporary license.

- The following members and types now throw an exception when the feature is not available on the oscilloscope:
  - InfiniiSimOptions
  - IRemoteAte.GetInfiniiSimSettings
  - IRemoteAte.SetInfiniiSimSettings

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 01.90

<b>Released Date:</b>	20 June 2011
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista
<b>File Name:</b>	SetupInfRemDevTool01900000.exe

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET.chm:

- Added types:
  - ExportCsvOptions
  - ExportHtmlOptions
- Added methods:
  - IRemoteAte.ExportResultsCsv()
  - IRemoteAte.ExportResultsCsvCustom()
  - IRemoteAte.ExportResultsHtmlCustom()

Agilent Automated DigitalTest Application Remote Interface for LabVIEW.chm:

- Added methods:
  - Exit()
  - ExportResultsCsv()
  - ExportResultsCsvCustom()
    - GetCsvOpsFileName()
    - SetCsvOpsFileName()
    - GetCsvOpsPath()
    - SetCsvOpsPath()
    - GetCsvOpsOverwrite()
    - SetCsvOpsOverwrite()
    - GetCsvOpsTestIDs()
    - SetCsvOpsTestIDs()



- ExportResultsHtmlCustom()
  - GetHtmlOpsReportName()
  - SetHtmlOpsReportName()
  - GetHtmlOpsBasePath()
  - SetHtmlOpsBasePath()
  - GetHtmlOpsOverwrite()
  - SetHtmlOpsOverwrite()

#### Modifications:

Agilent Automated DigitalTest Application Remote Interface for .NET.chm:

- Deprecated methods (continue to work but have been replaced):
  - IRemoteAte.GenerateCsvFile – Now use IRemoteAte.ExportResultsCsv or IRemoteAte.ExportResultsCsvCustom

Agilent Automated DigitalTest Application Remote Interface for LabVIEW.chm:

- Deprecated methods (continue to work but have been replaced):
  - GenerateCsvFile – Now use ExportResultsCsv or ExportResultsCsvCustom

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 01.80

<b>Released Date:</b>	22 April 2011
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista
<b>File Name:</b>	SetupInfRemDevTool01800000.exe

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET.chm:

- Added methods:
  - IRemoteAte.SelectAllTests()

Agilent Automated DigitalTest Application Remote Interface for LabVIEW.chm:

- Added methods:
  - SelectAllTests()

Agilent\_Automated\_DigitalTest\_Application\_Programming\_Guide.pdf:

- Added more example code to chapter 3.

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 01.70

<b>Released Date:</b>	2 November 2010
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista
<b>File Name:</b>	SetupInfRemDevTool01700000.exe

### Additions:

Agilent Automated DigitalTest Application Remote Interface for .NET.chm:

- Added methods:
  - IRemoteAte.ExecuteArsl(string commandLine, bool preserveLineBreaks)
  - IRemoteAte.GenerateCsvFile(string fileName)

- Added properties:
  - IRemoteAte.Passed
  - ResultOptions.IncludeExtremeDataDetails
  - InfiniiSimOptions.InfiniiSimState.FourPortOneChannel
  - InfiniiSimOptions.PortExtraction
- Added types:
  - InfiniiSimOptions.InfiniiSimPortExtraction

Agilent Automated DigitalTest Application Remote Interface for LabVIEW.chm:

- Added methods:
  - SetInfiniiSimSettingsCustom()
  - SetISimOpsBandwidth()
  - SetISimOpsBandwidthLimitEnabled()
  - SetISimOpsIncludeDelay()
  - SetISimOpsPortExtraction()
  - SetISimOpsResponseCorrection()
  - SetISimOpsSpan()
  - SetISimOpsState()
  - SetISimOpsTransferFunction()
  - SetResultOpsIncExtreme
  - GenerateCsvFile()
  - GetInfiniiSimSettingsCustom()
  - GetISimOpsBandwidth()
  - GetISimOpsBandwidthLimitEnabled()
  - GetISimOpsIncludeDelay()
  - GetISimOpsPortExtraction()
  - GetISimOpsResponseCorrection()

- GetSimOpsSpan()
- GetSimOpsState()
- GetSimOpsTransferFunction()
- GetPassed()
- GetResultOpsIncExtreme()

#### Modifications:

- ARSL Command Line Utility now preserves line breaks when displaying result of GetRemoteFile.
- When you execute “GetRemoteFile” via the ExecuteArsl() methods, the file is now closed.
- Added Python programming information to the Getting Started Guide and the Programming Guide.

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 01.61

<b>Released Date:</b>	<b>6 October 2010</b>
<b>Supported Operating Systems:</b>	<b>Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista</b>
<b>File Name:</b>	<b>SetupInfRemDevTool01610000.exe</b>

#### Modifications:

In the .NET assembly (Agilent.Infiniium.AppFW.dll):

- Added an option to the GetRemoteAteCustom method to automatically close message boxes that get displayed during the remote application’s launch.

In the LabVIEW adapter assembly (Agilent.Infiniium.RemoteTestClient.dll):

- Fixed GetCurrentOptions method to return only the current options instead of all options.
- Fixed GetAvailableStoreModes method.

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 01.60

<b>Released Date:</b>	<b>19 March 2010</b>
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista
<b>File Name:</b>	SetupInfRemDevTool01600000.exe

### Modifications:

Agilent Automated DigitalTest Application Remote Interface for .NET.chm:

- Added new types, properties & methods:
  - o GetRemoteAteOptions
  - o MessageEventArgs.SuppressionResponse
  - o RemoteAteUtilities.GetRemoteAteCustom()

Agilent Automated DigitalTest Application Remote Interface for LabVIEW.chm:

- Added eight new methods:
  - o RemoteClient.ConnectCustom()
  - o RemoteClient.GetConnectOptions()
  - o RemoteClient.GetConnectOpsIpAddress()
  - o RemoteClient.GetConnectOpsUseCustomPort()
  - o RemoteClient.SetConnectOpsIpAddress()
  - o RemoteClient.SetConnectOpsUseCustomPort()
  - o RemoteClient.SetConnectOpsTimeoutInSeconds()
  - o RemoteClient.SetConnectOpsTimeoutInSeconds()

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 01.50

<b>Released Date:</b>	<b>9 March 2010</b>
<b>Supported Operating Systems:</b>	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista
<b>File Name:</b>	SetupInfRemDevTool01500000.exe

### Modifications:

Agilent Automated DigitalTest Application Remote Interface for .NET.chm:

- Added two new methods:
  - o IRemoteAte.ConnectAppToInstrument()
  - o IRemoteAte.ConnectAppToInstrumentCustom()

Agilent Automated DigitalTest Application Remote Interface for LabVIEW.chm:

- Added eight new methods:
  - o RemoteClient.ConnectAppToInstrument()
  - o RemoteClient.ConnectAppToInstrumentCustom()
  - o RemoteClient.GetConnectAppToInstrumentOptions()
  - o RemoteClient.GetConnectAppToInstrumentOpsInstrumentName()
  - o RemoteClient.GetConnectAppToInstrumentOpsInstrumentAddress()
  - o RemoteClient.SetConnectAppToInstrumentOpsInstrumentName()
  - o RemoteClient.SetConnectAppToInstrumentOpsInstrumentAddress()

## Agilent N5452A Automated Test Application Remote Programming Toolkit Version 01.40

Released Date:	11 November 2009
Supported Operating Systems:	Microsoft Windows XP Service Pack 2 or later, Microsoft Windows Vista
File Name:	SetupInfRemDevTool01400000.exe

### Modifications:

Infiniium Automated Test Application Remote Interface for .Net.chm:

- Added two new methods: IRemoteAte.Hide() and IRemoteAte.Show().

Infiniium Automated Test Application Remote Interface for LabVIEW.chm:

- Added two new methods: RemoteClient.Hide() and RemoteClient.Show().
- Added the three .Net interface namespaces Agilent.Infiniium.AppFW.Remote.\* to enable linking LabVIEW topics to their corresponding .Net topics so you no longer need to keep both help files open at the same time.

© Keysight Technologies 2009-2023