



Agilent Medalist i3070 08.20pb Software Patch

Release Notes

Software Release Date : June 2011
System Requirements : Agilent Medalist i3070 or test development PC
Controller Requirements: Windows® PC
Operating System : Microsoft Windows® XP
Software Requirement : Agilent Medalist i3070 08.20p

This software patch should be installed only on Microsoft Windows systems with Medalist i3070 08.20p software release. It can be installed on systems with Medalist i3070 Test System Software or Medalist i3070 Development Software.

This software patch addresses the following change requests.

Change Request Identification	Description
CR34150/ CR34179	08.10p: Resolved failure in ASRU-N diagnostics test number 2824.
CR34180	08.20p: Wrong error message for ASRU calibration.
CR34163	08.20p: Enhanced Lost Heart Beat message and time stamp in the pmlog file.
CR34136	08.10p: Resolved symbolic link and iNode in the software when using Network File Sharing.
CR34170	08.20p: FPY and WPR view can be customized for initial view.

Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation.

Installing the 08.20pb Patch

This software patch must be installed using the administrator login (or a login with administrator privileges).

Follow these steps to install the 08.20pb software patch on Windows systems running the Medalist i3070 08.20p software:

- 1 Save the **Agilenti3070_08.20pb.zip** file to the hard disk and unzip it.
- 2 Close all open programs.
- 3 Double-click **Agilenti3070_08.20pb.exe**.
- 4 Follow the on-screen instructions for installation.
- 5 To validate that the software was installed correctly:
 - a On the **Start** menu, select **Programs > Agilent ICT > Korn Shell**.
 - b In the Korn Shell window, type `version` and press **Enter**.

The following software revision should be displayed:
Agilent Medalist i3070 08.20pb 1110 WN.

© Agilent Technologies, Inc. 2011
Printed in Malaysia 06/11



E9901-90023



Agilent Technologies