



Agilent 5DX 8.51 Patch Software

Software Release Date:	November 2008
5DX System Requirements:	Series 3 & Series 5000
Controller Requirements:	1 GHz IPC or greater
Operating System:	Windows® XP Professional Service Pack 2
Software Requirements:	8.50

Installation Requirements:

- 384MB of RAM or greater & 500MB of free disk space.
- Administrative Rights log on, with Administrative privileges.

NOTE: The Agilent 5DX 8.51 patch contains only the files necessary for the patch and requires that 8.50 be previously installed.

Installation Instructions for the 5DX & TDW:

1. Exit out of the User Interface.
2. Double-click the **Agilent 5DX Reset** icon to reset the system.
3. Close all other programs; close any open windows.
4. Installation of the patch:
 - a) Download the patch from the Agilent web site to a local drive.
 - You can get the patch from <http://www.agilent.com/see/5DX> under:
 - "Technical Support"
 - "Drivers and Software"
 - "Agilent 5DX 8.51 Software Release"
 - In the "Documents & Downloads" section you will find a link to download the patch.
 - Save the file as "5DX_8.51.zip".
 - b) Create the following subdirectory: C:\Temp\8.51_patch\
 - c) Move the patch file to the subdirectory: C:\Temp\8.51_patch\
 - d) From Windows Explorer, double click on the "5DX_8.51.zip".
 - e) Extract all files to C:\Temp\8.51_patch\
 - f) Navigate to C:\Temp\8.51_patch\
 - g) Double click on the "Setup.exe".
 - h) Follow the on-screen instructions to install the patch.
 - i) Once the installation process is complete, reboot the PC.
 - j) After the system reboots, log back into the operating system and User Interface.
 - k) Verifying proper patch installation:
 - The top of the 5DX User Interface screen will now reflect the current software revision, 8.51.
 - The TDW User Interface will now reflect the current software revision in Help > About.

More 5DX info at:

www.agilent.com/see/5dx