

---

# Keysight EasyEXPERT+ Software for B1500 Mainframe

## Installation Instruction

This is an Instruction Sheet for EasyEXPERT+ Software. More details about this product can be obtained at : [B1500 Driver, Firmware and Software | Keysight](#)

## Notices

© Copyright 2006 - 2025 Keysight Technologies, Inc.

The information contained in this document is subject to change without notice.

Keysight Technologies makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Keysight Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

### **Manual Part Number**

B1500-90941

### **Edition**

Edition 2, June 2025

Printed in Japan/Malaysia

Published by:

Keysight Technologies, Inc.

9-1 Takakura-machi, Hachioji-shi, Tokyo

Japan, 192-8550

## About this document

This document contains the following:

- Note
- Software Requirements
- Update Instructions

## Software Requirement

In order to update the EasyEXPERT Rev. A.05.04 or prior revisions to Rev. A.05.50 or later revisions, the following software is required.

- Microsoft Windows Installer 3.1
- Microsoft .NET Framework 3.5 Service Pack 1

NOTE:

If all the required software has not been installed to your computer, install them in the above sequence.

For example, if Microsoft Windows Installer 3.1 is not installed, install it, and then install Microsoft .NET Framework 3.5 Service Pack 1.

The required software is stored in the "Prerequisites" folder in this Package.

## Update Instruction

To update the EasyEXPERT for B1500, follow the procedure below.

1. If the downloaded file is saved to a PC, copy it to B150xA by using a media such as CD-R/DVD-R/USB memory.
2. On B150xA, if you see [Start EasyEXPERT] button on the screen, close the window by clicking "x" button on the window title bar.
3. Expand the contents of the downloaded file into a working folder as follows.
  - a) Go to the folder where the downloaded file is saved and open the folder.
  - b) Place the pointer on the downloaded file and click the mouse right bitton and select "Extract All...".

NOTE: If any unzip tool is installed, the above may not work.  
In this case, follow the instruction of the tool. Below is an example for the tool "winzip".

- a) Double-click the downloaded file, then click "unzip" in the menu bar.
  - b) Then specify the folder and click "unzip".
4. Double click the EasyEXPERT folder.
  5. Click the executable file to start the installation and follow the instructions of the setup wizard.
  6. Wait for installation to complete, and restart the B150xA.

Microsoft and Windows are registered trademarks of Microsoft Corporation.  
All other trademarks are the property of their respective owners.

End of document.