

Installing the E6655A WiMAX Lab Application from a Web Download

This topic describes the installation of the E6655A WiMAX Lab Application on the network gateway computer.

The E6655A WiMAX Lab Application

The WiMAX Lab Application provides convergence service network emulation to enable testing in a realistic network environment, supporting real-time, end-to-end functional test.

The E6655A WiMAX Lab Application is delivered from the Internet as an executable (.exe) file. During installation, you can choose to install the IPX Protocol, the license key drivers and WinPacket Filters. IP Protocol is installed automatically. Earlier versions (prior to 5.2.1.x) offered the required installation of the IPX protocol.

Procedure

To install the E6655A Lab Application on the network gateway computer, proceed as follows:

1. After downloading, locate and double click the E6655A Lab Application installation file **<setup-E6655A-5.2.1.0.exe>**. (The version number at the end of the filename is subject to change.)
2. Click **OK** to start the installation. The Welcome screen is displayed.



3. Click **Next>** and follow the displayed instructions to complete the installation.



4. Ensure all elements in the Device Driver group are selected unless you are simply upgrading a current installation and require only the Lab Application installation.



5. You should now re-start the network gateway computer to complete the installation of the E6655A WiMAX Lab Application.

NOTE

Ensure the license key is located in a USB port on the network gateway computer before starting the WiMAX Lab Application.
