
Keysight Add LO Source Capability Upgrade Kit For Version 6, Single- Source Synthesizers

To Upgrade PNA-X N5264A
Option 108

Upgrade Kit Order Number:
N5264AU- 108

Keysight Kit Number:
N5264-60101

This is Installation Note is for upgrading the N5264A Microwave Network Analyzers with LO Source, Option 108.

Notices

© Keysight Technologies, Inc.
2010-2023

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Trademark Acknowledgments

Manual Part Number

N5264-90002

Edition

Edition 1, October 2023

Supersedes: March 2016

Printed in USA/Malaysia

Published by:
Keysight Technologies
1400 Fountaingrove Parkway
Santa Rosa, CA 95403

Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS

COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

U.S. Government Rights

The Software is "commercial computer software," as defined by Federal Acquisition Regulation ("FAR") 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement ("DFARS") 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public.

Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at

<http://www.keysight.com/find/sweula>

The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software

documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

Description of the Upgrade

This upgrade adds the internal hardware necessary to provide a synthesized 10 MHz to 26.5 GHz LO source, with a maximum +10 dBm output power, at a rear panel LO OUT connector by adding Option 108. This option includes:

- a 13.5 GHz LO synthesizer board
- a multiplier/amplifier 26.5 GHz (HMA26.5)
- cables

Getting Assistance from Keysight

By internet or phone, get assistance with all your test and measurement needs.

Contacting Keysight

Assistance with test and measurements needs and information on finding a local Keysight office are available on the Web at:


<http://www.keysight.com/find/assist>

If you do not have access to the Internet, please contact your Keysight field engineer.

NOTE

In any correspondence or telephone conversation, refer to the Keysight product by its model number and full serial number. With this information, the Keysight representative can determine whether your product is still within its warranty period.

If You Have Problems With the Upgrade Kit Contents

Keysight stands behind the quality of the upgrade kit contents. If you have problems with any item in the kit, refer to www.keysight.com and the **Contact Keysight** () link.

Getting Prepared

To successfully install this upgrade kit, you will need the following:

- A license key - refer to **“License Key Redemption”** below.
- A PDF copy or a paper copy of the PNA Service Guide - refer to **“Downloading the Online PNA Service Guide” on page 3**.
- An ESD-safe work area - refer to **“Protecting Your Workspace from Electrostatic Discharge” on page 3**.
- Correct tools - refer to **“Tools Required for the Installation” on page 3**.
- Enough time - refer to **“About Installing the Upgrade” on page 4**.
- Test equipment for the post-upgrade adjustments and full instrument calibration. To view the equipment list, click the Chapter 3 PDF bookmark "Tests and Adjustments" in the online Service Guide¹.

License Key Redemption

NOTE

The enclosed Software Entitlement Certificate is a receipt, verifying that you have purchased a licensed option for the PNA of your choice. You must now use a Keysight Web page to request a license key for the instrument that will receive the option.

To enable the option product, you must request a license key from: <http://www.keysight.com/find/softwaremanager>. To complete the request, you will need to gather the following information:

- From the certificate
 - Order number
 - Certificate number
- From your instrument
 - Model number
 - Serial number

From the online Keysight HostID utility:

- Part of the OEC procedure to obtain the 12-digit license key online requires you to provide the HostID number of the PNA. This HostID number is NOT the one currently shown on the PNA. To determine your new HostID, Keysight personnel should use the new model number with the utility at go to <http://mktwww.srs.is.keysight.com/field/service/network/pna/upgrades.html>. Non-Keysight personnel should contact Keysight at <http://www.keysight.com/key/contactus>.

1. See **“Downloading the Online PNA Service Guide” on page 3**.

— Host ID

Using the information just gathered, you must request license key(s) from the Keysight Software Manager: <http://www.keysight.com/find/softwaremanager>.

You will need to provide an email address, to which Keysight will promptly email your license key file. Refer to [“License Key Redemption” on page 7](#).

Downloading the Online PNA Service Guide

To view the online Service Guide for your PNA model number, use the following steps:

1. Go to www.keysight.com.
2. In the Search box, enter the model number of the analyzer (e.g., N5225B) and click **Search**.
3. Click **Support** > **Keysight Product Support**.
4. In the **Search Support** area type your instrument’s model number (e.g., N2225B).
5. Press **Enter**.
6. Scroll down to the **PRINT DOCUMENTATION** section and click to select **Service Manual**.
The **Service Manual** for your instrument will be displayed near the top of the right column.
7. Click the hyperlink of the Service Guide title to download the PDF file.
8. When the PDF of the Service Guide is displayed, scroll through the Contents section bookmarks to locate the information needed.

Protecting Your Workspace from Electrostatic Discharge

For information, click on the Chapter 1 PDF bookmark, “Electrostatic Discharge Protection” in the online Service Guide¹.

ESD Equipment Required for the Installation

Description	Keysight Part Number
ESD grounding wrist strap	9300-1367
5-ft grounding cord for wrist strap	9300-0980
2 x 4 ft conductive table mat and 15-ft grounding wire	9300-0797
ESD heel strap (for use with conductive floors)	9300-1308

Tools Required for the Installation

Description	Qty	Part Number
T-10 TORX driver - set to 9 in-lbs (1.02 N.m)	1	N/A
T-20 TORX driver - set to 21 in-lbs (2.38 N.m)	1	N/A

1. See [“Downloading the Online PNA Service Guide” on page 3](#).

Getting Prepared

Description	Qty	Part Number
5/16-in (8 mm) nutsetter or open end torque wrench - set to 10 in-lbs (1.13 N.m)	1	N/A

CAUTION

Use a 5/16-in torque wrench set to 10 in-lbs on all cable connections required in this upgrade kit.

About Installing the Upgrade

Products affected	N5264A PNA-X Measurement Receiver
Installation to be performed by	Keysight service center or personnel qualified by Keysight
Estimated installation time	1.0 hour
Estimated adjustment time	0.5 hour
Estimated full instrument calibration time	1.0 hour

Items Included in the Upgrade Kit

Items Included in the Upgrade Kit¹

Check the contents of your kit against the following list. If any part is missing or damaged, contact Keysight Technologies. Refer to **“Getting Assistance from Keysight” on page 1**.

Table 1 Contents of Upgrade Kit N5264-60101

Ref Desig.	Description	Qty	Part Number
-	Installation note (this document)	1	N5264-90002
-	Software Entitlement Certificate	1	9300-0000
-	China RoHS Addendum	1	9320-6722
Assemblies			
A21	LO multiplier/amplifier 26.5 GHz (HMA26.5)	1	5087-7765
A11	13.5 GHz LO synthesizer board (with tabs removed)	1	N5240-60076 ^a
All Prefixes			
Hardware/Miscellaneous			
	Bracket, HMA26.5	1	N5242-00005
	Machine screw, M3.0 x 8, pan head	4	0515-0372
	Machine screw, M3.0 x 6, pan head	2	0515-0430
	Termination, 50 ohm load	1	1250-4261
	Installation note (this document)	1	N5264-90002
Cables (listed in the order in which they are installed)			
W47	A21 HMA26.5 to rear panel LO OUT (J5)	1	N5264-20002
W41	A11 13.5 GHz LO synthesizer board to A21 HMA26.5	1	N5242-20067 ^b
W65	A10 frequency reference board J5 to A11 13.5 GHz LO synthesizer board J5	1	N5242-60028
--	A19 test set motherboard J209 to A21 HMA26.5	1	N5242-60014

- a. N5240-60076 synth board has been qualified with PNA firmware A.10.45.xx and above with Windows 7 OS. If your instrument is running Windows XP, and you do not want to upgrade to Windows 7, it is highly recommended that you upgrade your firmware to 9.90.17 or above. Please be aware that Keysight cannot guarantee 100% compatibility with Windows XP and or older versions of firmware <10.45.xx. To upgrade your firmware go to <https://www.keysight.com/us/en/lib/resources/miscellaneous/pna-windows-upgrades.html>.
- b. N5222-20067 cables are only used with a N5240-60076 synth boards.

1. In addition to the upgrade kit, the shipment includes an Option Entitlement Certificate. Refer to **“License Key Redemption” on page 2** for important information about this certificate.

Installation Procedure for the Upgrade

The network analyzer must be in proper working condition prior to installing this option. Any necessary repairs must be made before proceeding with this installation.

WARNING

This installation requires the removal of the analyzer's protective outer covers. The analyzer must be powered down and disconnected from the mains supply before performing this procedure.

Overview of the Installation Procedure

- Step 1. Obtain a Keyword.
- Step 2. Remove the Outer Cover.
- Step 3. Remove the Inner Cover.
- Step 4. Remove the A19 Test Set Motherboard.
- Step 5. Remove the A20 IF Multiplexer Board.
- Step 6. Assemble the A21 LO Multiplier/Amplifier (HMA26.5) onto the Bracket.
- Step 7. Install the A21 LO Multiplier/Amplifier (HMA26.5) and Cables.
- Step 8. Reinstall the A20 IF Multiplexer Board.
- Step 9. Reinstall the A19 Test Set Motherboard.
- Step 10. Install the Ribbon Cable from the A21 HMA26.5 to the A19 Test Set Motherboard.
- Step 11. Install the 50 Ohm Load on the PNA Rear Panel.
- Step 12. Connect the Gray Cable to the A11 13.5 GHz LO Synthesizer Board.
- Step 13. Install the A11 13.5 GHz LO Synthesizer Board and Cables.
- Step 14. Reinstall the Inner Cover.
- Step 15. Reinstall the Outer Cover.
- Step 16. Enable Option 108.
- Step 17. Perform Post-Upgrade Adjustments and Calibration.

Step 1. Obtain a Keyword

Follow the instructions on the keyword Entitlement Certificate supplied to obtain a keyword for installation of this upgrade.

Once the keyword has been obtained, you can proceed with the installation.

Installation Procedure for the Upgrade

Step 2. Remove the Outer Cover

For instructions, click the Chapter 7 bookmark "Removing the Covers" in the PDF Service Guide¹.

Step 3. Remove the Inner Cover

For instructions, click the Chapter 7 bookmark "Removing the Covers" in the PDF Service Guide¹.

Step 4. Remove the A19 Test Set Motherboard

CAUTION

Be careful not to damage the center pins of the semirigid cables. Some flexing of the cables may be necessary but do not over-bend them.

NOTE

Leave the gray flexible cables, the wire harnesses, and the ribbon cables connected where possible. Any that are removed should be labeled for reconnection later.

For instructions, click the Chapter 7 bookmark "Removing and Replacing the A19 test set motherboard" in the PDF Service Guide¹.


Step 5. Remove the A20 IF Multiplexer Board

For instructions, click the Chapter 7 bookmark "Removing and Replacing the A20 IF Multiplexer Board" in the PDF Service Guide¹.

1. See "Downloading the Online PNA Service Guide" on page 3.

Step 6. Assemble the A21 LO Multiplier/Amplifier (HMA26.5) onto the Bracket
Follow the instruction shown in **Figure 2** for this step of the procedure. New parts are listed in **Table 1 on page 5** of this document.

Figure 2 A21 LO Multiplier/Amplifier (HMA26.5) Assembly (0515-0372, 5087-7765, N5242-00005)




N5264_002_01

Installation Procedure for the Upgrade

Step 7. Install the A21 LO Multiplier/Amplifier (HMA26.5) and Cables

Follow the three instructions shown in **Figure 3** for this step of the procedure. New parts are listed in **Table 1 on page 5** of this document.

Figure 3 A21 LO Multiplier/Amplifier (HMA26.5) Installation (0515-0430, 5087-7711, N5264-20002, N5242-20010)



N5264_002_02

Step 8. Reinstall the A20 IF Multiplexer Board

For instructions, click the Chapter 7 bookmark “Removing and Replacing the A20 IF Multiplexer Board” in the PDF Service Guide¹.

Step 9. Reinstall the A19 Test Set Motherboard

For instructions on reinstalling the board, click the Chapter 7 bookmark “Removing and Replacing the A19 Test Set Motherboard” in the PDF Service Guide¹.

Step 10. Install the Ribbon Cable from the A21 HMA26.5 to the A19 Test Set Motherboard

CAUTION

Follow instructions carefully when making cable connections, especially wire harness connections. Incorrect connections can destroy components, resulting in additional customer costs.

To view a graphic showing the location of this ribbon cable, click the Chapter 6 bookmark “Bottom Cables, All Options” in the PDF Service Guide¹.

Step 11. Install the 50 Ohm Load on the PNA Rear Panel


Connect the 50 ohm load termination (1250-4261) to J5 on the PNA rear panel and torque to 10 in-lbs.

Installation Procedure for the Upgrade

Step 12. Connect the Gray Cable to the A11 13.5 GHz LO Synthesizer Board

Follow the two instructions shown in **Figure 4** for this step of the procedure. New parts are listed in **Table 1 on page 5** of this document.


Figure 4 Gray Cable Connection to A11 13.5 GHz LO Synthesizer Board (N5230-60002, N5242-60028)



Step 13. Install the A11 13.5 GHz LO Synthesizer Board and Cables

1. Place the analyzer top-side up on a flat surface.
2. Follow the three instructions shown in **Figure 4** for this step of the procedure. To view a graphic showing the location of the A11 LO Synthesizer board, click the Chapter 7 bookmark “Removing and Replacing the A10, A11, and A12 Boards” in the PDF Service Guide¹. New parts are listed in **Table 1 on page 5** of this document.

Figure 5 A11 13.5 GHz LO Synthesizer Board Installation (N5242-20110, N5230-60002, N5242-60028)



N5264_002_04

Step 14. Reinstall the Inner Cover

For instructions, click the Chapter 7 bookmark “Removing the Covers” in the PDF Service Guide¹.

Step 15. Reinstall the Outer Cover

For instructions, click the Chapter 7 bookmark “Removing the Covers” in the PDF Service Guide¹.

1. See “[Downloading the Online PNA Service Guide](#)” on page 3.

Step 16. Enable Option 108

Procedure Requirements

- The analyzer must be powered up and operating to perform this procedure.
- The Network Analyzer program must be running.
- A keyboard must be connected to the network analyzer.

Option Enable Procedure

NOTE: You must have a keyword to enable this option. If you have not yet obtained the necessary keyword, refer to **“Step 1. Obtain a Keyword” on page 6** for instructions.

1. To start the option enable utility, press UTILITY **System**, then **Service**, then **Option Enable**. An option enable dialog box will appear.
2. Click the arrow in the Select Desired Option box. A list of available options will appear.
3. In the Select Desired Option list, click 108 - LO Source 26.5 GHz.
4. Using the keyboard, enter the keyword you obtained, in the box provided. Enter this keyword exactly as provided.
5. Click Enable.
6. Click Yes in answer to the displayed question in the Restart Analyzer? box.
7. When the installation is complete, click Exit.

Option Verification Procedure

Once the analyzer has restarted and the Network Analyzer program is again running:

1. On the analyzer's Help menu, click About Network Analyzer.
2. Verify that “108” is listed after “Options:” in the display. Click OK.

NOTE

If Option 108 has not been enabled, perform the **"Option Enable Procedure"** again. If the option is still not enabled, contact Keysight Technologies. Refer to **“Getting Assistance from Keysight” on page 1**.

Step 17. Perform Post-Upgrade Adjustments and Calibration

Adjustments

Due to the hardware changes of the analyzer, perform the Synthesizer Bandwidth adjustment.

Next, perform the Default EE adjustment. On the dialog box, select Initialize rather than Adjust/Verify because an adjustment is typically unnecessary.

These adjustments are described in the PNA Service Guide and in the PNA on-line HELP. A list of equipment required to perform these adjustments is also found in the service guide.

To view the Service Guide online, use the following steps:

1. Go to www.keysight.com
2. In the Search box, enter the model number of your analyzer, N5264A, and click **Search**.
3. Click Technical Support > Manuals.
4. Click Service Manual.
5. Click the service guide title to load the PDF file.
6. When the PDF of the Service Guide is displayed, scroll through the Contents section bookmarks to locate the “Tests & Adjustments” chapter.

After the specified adjustments have been performed, the analyzer should operate and phase lock over its entire frequency range.

EEPROM Backup


The analyzer uses arrays of correction constants to enable the analyzer to produce accurate, leveled source signals and receive clean test signals. These constants are stored in non-volatile EEPROM memory and in flash memory files.

The adjustments listed here generate new correction constants. The analyzer must have a backup of this new data in case any of the data becomes corrupted.

To store the backup data, perform these steps:

- Navigate to the EEPROM Backup Utility, located at:
 - Windows 7 -- C:\Program Files (x86)\Keysight\Network Analyzer\Service\eebackup.exe
 - Windows 10 -- C:\Program Files\Keysight\Network Analyzer\Service\eebackup.exe
- Run the program.
- Click Backup EEPROM.
- Click Backup TSMB Mem.
- Click Backup Synth Mem. (Applies to Version 7 Synthesizers Only)
- Click Exit when the program has finished.

Figure 6 EEPROM Backup Menu



Operator's Check

Perform the Operator's Check to check the basic functionality of the analyzer. For instructions, refer to the "Tests & Adjustments" chapter of the Service Guide.

If you experience difficulty with the basic functioning of the analyzer, contact Keysight. Refer to **"Contacting Keysight" on page 1**.

Calibration

Although the analyzer functions, its performance relative to its specifications has not been verified. It is recommended that a full instrument calibration be performed using the analyzer's internal performance test software. Refer to the analyzer's service guide for information on this performance test software.



This information is subject to change
without notice.

© Keysight Technologies 2010-2023

Edition 1, October 2023



N5264- 90002

www.keysight.com