

# Keysight U7238C/D MIPI® D-PHY<sup>SM</sup> Compliance Application

# Notices

© Keysight Technologies, Inc. 2008-2017

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

## Revision

Version 03.51.0000

## Edition

March 23, 2017

Available in electronic format only

Published by:  
Keysight Technologies, Inc.  
1900 Garden of the Gods Road  
Colorado Springs, CO 80907 USA

## Trademarks

MIPI® service marks and logo marks are owned by MIPI Alliance, Inc. and any use of such marks by Keysight Technologies is under license. Other service marks and trade names are those of their respective owners.

## Warranty

**The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Keysight disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Keysight shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Keysight and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.**

## Technology License

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

## U.S. Government Rights

The Software is "commercial computer software," as defined by Federal Acquisition Regulation ("FAR") 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement ("DFARS") 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at [www.keysight.com/find/sweula](http://www.keysight.com/find/sweula). The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater

than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

## Safety Notices

### CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

---

### WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

---

## In This Book

This book is your guide to programming the Keysight Technologies U7238C/D MIPI D-PHY Compliance Application.

- **Chapter 1**, “Introduction to Programming,” starting on page 7, describes compliance application programming basics.
- **Chapter 2**, “Configuration Variables and Values,” starting on page 9, **Chapter 3**, “Test Names and IDs,” starting on page 33, and **Chapter 4**, “Instruments,” starting on page 49, provide information specific to programming the U7238C/D MIPI D-PHY Compliance Application.

### How to Use This Book

Programmers who are new to compliance application programming should read all of the chapters in order. Programmers who are already familiar with this may review chapters 2, 3, and 4 for changes.



# Contents

In This Book / 3

## 1 Introduction to Programming

Remote Programming Toolkit / 8

## 2 Configuration Variables and Values

## 3 Test Names and IDs

## 4 Instruments

Index



# 1 Introduction to Programming

Remote Programming Toolkit / 8

This chapter introduces the basics for remote programming a compliance application. The programming commands provide the means of remote control. Basic operations that you can do remotely with a computer and a compliance app running on an oscilloscope include:

- Launching and closing the application.
- Configuring the options.
- Running tests.
- Getting results.
- Controlling when and where dialogs get displayed
- Saving and loading projects.

You can accomplish other tasks by combining these functions.

## Remote Programming Toolkit

The majority of remote interface features are common across all the Keysight Technologies, Inc. family of compliance applications. Information on those features is provided in the N5452A Compliance Application Remote Programming Toolkit available for download from Keysight here: [www.keysight.com/find/rpi](http://www.keysight.com/find/rpi). The U7238C/D MIPI D-PHY Compliance Application uses Remote Interface Revision 3.70. The help files provided with the toolkit indicate which features are supported in this version.

In the toolkit, various documents refer to "application-specific configuration variables, test information, and instrument information". These are provided in Chapters 2, 3, and 4 of this document, and are also available directly from the application's user interface when the remote interface is enabled (View>Preferences::Remote tab::Show remote interface hints). See the toolkit for more information.



## 2 Configuration Variables and Values

The following table contains a description of each of the U7238C/D MIPI D-PHY Compliance Application options that you may query or set remotely using the appropriate remote interface method. The columns contain this information:

- GUI Location – Describes which graphical user interface tab contains the control used to change the value.
- Label – Describes which graphical user interface control is used to change the value.
- Variable – The name to use with the SetConfig method.
- Values – The values to use with the SetConfig method.
- Description – The purpose or function of the variable.

For example, if the graphical user interface contains this control on the **Set Up** tab:

- Enable Advanced Features

then you would expect to see something like this in the table below:

**Table 1** Example Configuration Variables and Values

GUI Location	Label	Variable	Values	Description
Set Up	Enable Advanced Features	EnableAdvanced	True, False	Enables a set of optional features.

and you would set the variable remotely using:

ARSL syntax

-----

```
arsl -a ipaddress -c "SetConfig 'EnableAdvanced' 'True'"
```

C# syntax

```
-----
remoteAte.SetConfig("EnableAdvanced", "True");
```

Here are the actual configuration variables and values used by this application:

**NOTE**

Some of the values presented in the table below may not be available in certain configurations. Always perform a "test run" of your remote script using the application's graphical user interface to ensure the combinations of values in your program are valid.

**NOTE**

The file, "ConfigInfo.txt", which may be found in the same directory as this help file, contains all of the information found in the table below in a format suitable for parsing.

**Table 2** Configuration Variables and Values

GUI Location	Label	Variable	Values	Description
Configure	CLK Connection Type	ClkConnectionType	Single Ended, Differential	Identifies the Clock connection type.
Configure	CLK(Diff)	ClkChan	CHAN1, CHAN2, CHAN3, CHAN4	Identifies the oscilloscope channels probing clock(differentially). This value will be use if the Connection Type set to "Differential". CAUTION: Differential Clock input will not be able to run ALL clock related tests.
Configure	CLKn	ClkNChan	CHAN1, CHAN2, CHAN3, CHAN4	Identifies the oscilloscope channels probing clock. This value will be use if the Connection Type set to "Single Ended".
Configure	CLKp	ClkPChan	CHAN1, CHAN2, CHAN3, CHAN4	Identifies the oscilloscope channels probing clock. This value will be use if the Connection Type set to "Single Ended".
Configure	ClockNWfmFile(Must be hidden)	ClockNWfmFile	(Accepts user-defined text), None	For supporting offline.
Configure	ClockPWfmFile(Must be hidden)	ClockPWfmFile	(Accepts user-defined text), None	For supporting offline.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	DataNWfmFile(Must be hidden)	DataNWfmFile	(Accepts user-defined text), None	For supporting offline.
Configure	DataPWfmFile(Must be hidden)	DataPWfmFile	(Accepts user-defined text), None	For supporting offline.
Configure	DiffClockWfmFile(Must be hidden)	DiffClockWfmFile	(Accepts user-defined text), None	For supporting offline.
Configure	Dn	DataNChan	CHAN1, CHAN2, CHAN3, CHAN4	Identifies the oscilloscope channels probing Dn signal.
Configure	Dp	DataPChan	CHAN1, CHAN2, CHAN3, CHAN4	Identifies the oscilloscope channels probing Dp signal.
Configure	Export Tested Waveform Data	RawDataExport	non, all, bin, wfm	Specifies whether to export waveform data that used in the test. Selecting to export will cause the tests take slightly longer time to complete.
Configure	Eye Height	Eye_Height_limit	(Accepts user-defined text), 0.14	Specifies the limit for the Eye Height value. By default, this value is set to 140mVpp.
Configure	Eye Height Location	Eye_Height_location	(Accepts user-defined text), 50	Specifies the location for the eye height of the eye. By default, this value is set to 50.
Configure	Eye Width	Eye_Width_limit	(Accepts user-defined text), 0.5	Specifies the limit for the Eye Width value. By default, this value is 0.5UI. UI value is dependent on selected data rate.
Configure	HS Data Rate Check	HSDataRateCheck	1, 0	Enable this setting to perform HS Data Rate verification when running the HS tests. Select "Disable" to skip the HS data rate verification process. This option only affects HS tests.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	HS Full Dynamic Range	HSFullDynamicRange	YES, NO	To enable/disable the use of full dynamic range when measuring HS data and HS Clock electrical characteristic. LP trigger threshold will be changed when this feature is turned on. This config is not applicable for continuous signal.
Configure	High Threshold [Window Trigger Mode ONLY]	WindowTriggerHighThreshold	(Accepts user-defined text), 0.6	High trigger level used when the "Trigger Method" option is set to "Window".
Configure	Histogram Result	HistogramMeasResult	MODE, MEAN	Select the histogram statistical result to be used in VOL and VOH tests.
Configure	Hysteresis Level	Hysteresis_Level	(Accepts user-defined text), 0	Specify the value of the hysteresis level voltages used in setting the measurement thresholds. By default, this value is set to 0V. This config is used as - measurement threshold setting for HS Data Rate measurement - measurement threshold setting for explicit clock recovery in VOD and VOHHS tests.
Configure	Hysteresis Range	Hysteresis_Range	(Accepts user-defined text), 0.050	Specify the value of the hysteresis range used in setting the measurement thresholds. By default, this value is set to +/-50mV. This config is used as - measurement threshold setting for HS Data Rate measurement - measurement threshold setting for explicit clock recovery in VOD and VOHHS tests.
Configure	Interpolation	LPInterpolation	OFF, INT1, INT2, INT4, INT8, INT16	This option is used to turn on interpolation for LP tests. This config is only applicable for Test 1.1.1 VOH, Test 1.1.2 VOL, Test 1.1.4 TFLP, Test 1.2.1 VOH, Test 1.2.2 VOL and Test 1.2.4 TFLP tests.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	LP Escape Timeout	LPEscapeTimeOut	(Accepts user-defined text), 0	Time in seconds the application will wait for the LP Escape signal to appear in each observation. Select 0 if the DUT is capable of outputting LP escape mode continuously. This option only affects LP tests that need LP Escape signal.
Configure	LP Escape User Prompt	LPUserPrompt	ENABLE, DISABLE	Enable this setting to prompt user to set the DUT to Escape Mode before the tests are run. Select "Disable" if the DUT is capable of outputting LP escape mode continuously. This option only affects LP tests that need LP Escape signal.
Configure	LP Observations	NumLPElectricalTestObservation	(Accepts user-defined text), 10	Number of LP measurement instances to be observed.
Configure	LP Trigger Threshold	LPTriggerThreshold	(Accepts user-defined text), 0.650	Trigger level for LP edges, set it such that it will not trigger wrongly on HS. Possible values are between 0.200 and 0.880. The D-PHY specification recommends 0.550-0.880.
Configure	Low Threshold [Window Trigger Mode ONLY]	WindowTriggerLowThreshold	(Accepts user-defined text), -0.1	Low trigger level used when the "Trigger Method" option is set to "Window".
Configure	Manual Vertical Max voltage level	MaxVoltageLevel	(Accepts user-defined text), 1.50	Determine the max voltage level for each channel. This value will be observed only when Signal Scaling Mode is MANUAL. The D-PHY specification for VOH recommends 1.10 - 1.30V. This value should be greater than VOH to allow some headroom. Default value is 1.50V.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Manual Vertical Min voltage level	MinVoltageLevel	(Accepts user-defined text), -0.40	Determine the min voltage level for each channel. This value will be observed only when Signal Scaling Mode is MANUAL. The D-PHY specification for VOL recommends -0.05 - 0.05V. This value should be greater than VOL to allow some headroom. Default value is -0.40V.
Configure	Measurement Time Range(ns)	LPMeasurementTimeRangeL nns	(Accepts user-defined text), 160	Specifies the time range in nanoseconds the application will be using when measuring DC and transition time of LP signal. Set it such that only one transition is visible when measuring.
Configure	Minimum Valid HS Length	MinValidHSLength	(Accepts user-defined text), 0.0, 500e-9, 1.50e-6	Set this value to avoid extremely short HS stream, default value is 1.5 $\mu$ s. Set value to 0 to disable this feature.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Number of Iterations[End of TCLK-PRE]	NumOfIterateCheck_EndOfTCLKPRE	2, 3, 4, 5, 6, 7	<p>This config is used to specify the maximum number of iterations for "End of TCLK-PRE" position searching. By default, maximum of 5 iterations will be executed before "End Of TCLK-PRE" position is identified. It is useful to avoid glitch problem that appear on single-ended DataP signal at the LP to HS transition. By setting this config to larger value, it will affect the efficiency. This configuration option only applicable for Test 1.5.1 HS Exit: CLK TX TCLK-PRE. The algorithm of TCLK-PRE is as below: "Start of TCLK-PRE" position: The point where the Clock Lane differential waveform crosses below the minimum valid HS-RX differential threshold level of +/-70mV "End of TCLK-PRE" position: The point where the Data Lane single-ended, DataP LP-01 falling edge crosses VIL,MAX (550mV). - If there's no crossing edge at VIL,MAX found on the first burst, the test will fail. - If only one crossing edge at VIL,MAX found within the first burst, this edge will be identified as the "End Of TCLK-PRE" position". - If more than one crossing edge at VIL,MAX found within the first burst, the searching algorithm will iterate until "End Of TCLK-PRE" position is identified. Within the maximum trials, the first crossing edge next to "Start of TCLK-PRE" position found will be identified as the "End Of TCLK-PRE" position". The result of "TCLK-PRE" will be a positive value. Within the maximum trials, if all crossing edges found are less than "Start of TCLK-PRE" position, then the</p>

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Number of Iterations[End of TCLK-PRE] (cont'd)	NumOfIterateCheck_EndOfTCLKPRE (cont'd)	2, 3, 4, 5, 6, 7 (cont'd)	last edge found will be identified as "End Of TCLK-PRE" position". This "End of TCLK-PRE" position is less than "Start of TCLK-PRE" position. The result of "TCLK-PRE" will be a negative value and the test will fail. Maximum number of iterations will be based on "Number of Iterations[End of TCLK-PRE]" configuration option.
Configure	Number of ULPS Slew Edge	ULPSSlewEdge	(Accepts user-defined text), 10	Set this value to get number of ULPS slew edge. This value will only affect ULPS Clock Tx Slew Rate test. This value will affect the number of rising/falling edge when performing the measurement. For example: The default value is set to 10. ClockP rising will digitize 10 time and get the average value. ClockP falling will digitize 10 time and get the average value. ClockN rising will digitize 10 time and get the average value. ClockN falling will digitize 10 time and get the average value.
Configure	Pattern Check[VOHHS,VOD ]	Pattern_check	1, 0	Enable or disable the pattern check "011111" and "100000" for VOHHS and VOD tests only. This config is only applicable to Test 1.3.4 Differential Voltage(VOD0 Pulse), Test 1.3.4 Differential Voltage(VOD1 Pulse), Test 1.3.5 Differential Voltage Mismatch(Pulse) and Test 1.3.6 Single-Ended Output High Voltage(VOHHS Pulse).



**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Pattern Check[tR,tF]	Pattern_check_RiseFallTime	1, 0	Enable or disable the pattern check "000111" and "111000" for tR and tF tests only. If "Pattern Check[tR,tF]" is enabled, minimum of 2 copies of patterns are required to run these tests. This config is only applicable to Test 1.3.11 20%-80% Rise Time(tR) and Test 1.3.12 80%-20% Fall Time(tF).
Configure	Save ULPS Wfm	SaveULPSWfm	1, 0	Save the waveform when running ULPS mode.
Configure	Scope Sampling Rate	ScopeSampleRate	10e9, 20e9, 40e9	The scope sampling rate. Default value 10GSa/s.
Configure	Signal Scaling Mode	SignalScalingMode	AUTO, MANUAL	Set signal scaling to AUTO or MANUAL mode. AUTO: Use the scope autoscale to determine the vertical range of each channel. Only for signals with LP and HS intervals less than 60ms. MANUAL: Set the vertical range for each channel based on the manual vertical max and min voltage level settings. "MANUAL" mode is used as default setting for Signal Scaling Mode because "AUTO" mode does not work for all test signals. For example, "AUTO" mode does not work for test signal with long HS-burst that is more than 60ms.
Configure	Single-Ended HS Threshold Level	HSSETriggerThreshold	(Accepts user-defined text), 0.200	Trigger level for Single-Ended HS edges. This is the voltage level that will be used by the application to determine edges of single-ended HS signal. Possible values are between 0 and 0.650.
Configure	Slew rate test CLoad(pF)	SlewratesCLoad	(Accepts user-defined text), 0, 5, 20, 70	Load capacitance to determine the LP Slew Rate min and max values.
Configure	Switch Matrix Data Lane Probing Method	SwitchMatrixProbeMethod	SMA, DiffProbe	The method used to connect the data lane testpoint to the scope. This option is used when the Switch Matrix option is enabled.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	THS-SKIP(s)	THS_SKIP	(Accepts user-defined text), 0, 40e-9, 55e-9	This config is used to specify the value of THS-SKIP which is useful to avoid glitch problem during THS-TRAIL measurement. Any transition on the Data Lane in THS-SKIP time interval will be ignored when finding last payload data bit of HS transmission burst. The default value of THS-SKIP is set to 0s to prevent invalid THS-TRAIL measurement. For example, in the case of: TREOT = 20e-9s, THS-TRAIL = 10e-9s, THS-SKIP is set to 40e-9s, Some of the payload is within THS-SKIP and since THS-SKIP is set to 40e-9s, all the payload within this time interval will be ignored. This will cause invalid measurement for THS-TRAIL measurement. This config is only applicable to Test 1.3.13.
Configure	THSBurstStart Threshold	THSBurstStartThreshold	(Accepts user-defined text), 0.080, 0.180	Threshold value used to determine the starting location of the HS burst data.
Configure	THSprepareStart Threshold	THSprepareStartThreshold	(Accepts user-defined text), 0.550, 0.080	Threshold value used to determine the starting location of the THSprepare parameter. The D-PHY specification define this value to use the VIL(max) which is 0.550V. When using the default 0.550V as the threshold, the app will not support data signals that are not terminated properly as the differential data level may not cross this voltage level. For debugging purposes, this value can be set to 0.080V to support testing with improper terminated data signals.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Time Range(ns)	GlobalOperationTimeStep	(Accepts user-defined text), 200, 300, 400, 500	Specify the value of time range(nanoseconds) to be used when perform measurement on the HS exit/entry sequence. This config is only applicable to the tests in Global Operation test group. For example, set it such that the TLPX, THS-PREPARE, THS-ZERO and THS-SYNC are visible on the oscilloscope display when measuring for HS Entry tests. By default, this value is set to 200ns.
Configure	Transition Time Measurement Lower Threshold(%)	HSACLowerThreshold	(Accepts user-defined text), 20	Specifies in percentage the lower measurement threshold for transition time measurement. This config is only applicable to Test 1.3.11 20%-80% Rise Time(tR), Test 1.3.12 80%-20% Fall Time(tF), Test 1.4.11 20%-80% Rise Time(tR) and Test 1.4.12 80%-20% Fall Time(tF).
Configure	Transition Time Measurement Upper Threshold(%)	HSACUpperThreshold	(Accepts user-defined text), 80	Specifies in percentage the upper measurement threshold for transition time measurement. This config is only applicable to Test 1.3.11 20%-80% Rise Time(tR), Test 1.3.12 80%-20% Fall Time(tF), Test 1.4.11 20%-80% Rise Time(tR) and Test 1.4.12 80%-20% Fall Time(tF).
Configure	Trigger Check	TriggerCheck	0, 1	Enable/disable valid test signal trigger checking. Enable: Application will check if any valid trigger condition is met by making a dummy test acquisition upon setting up required trigger conditions. An exception will be thrown if NO trigger condition is met within a timeout duration specified in the "Trigger Timeout" configuration option. Disable: Application will NOT perform any signal trigger checking when performing the tests.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	Trigger Method	TriggerMethod	0, 1	Set the signal triggering method to find burst data. For "Window" triggering method, the minimum valid HS burst length must greater than the maximum duration between LP edges in LP Escape region. For "Pattern/State with InfiniiScan" triggering method, it is not recommended to use this triggering method to trigger on long HS burst if the signal contain both long HS burst and short HS burst due to efficiency.
Configure	Trigger Timeout [ms]	TriggerTimeout	(Accepts user-defined text), 150000, 25000, 10000	This option is specify as a whole number in mili-seconds (does not accept decimal point values) with a minimum of 1000 ms. This option DOES NOT affect LP tests that need LP Escape signal. For those mentioned tests, please refer to the "LP Escape Timeout" configuration option.
Configure	Tskew Histogram Window	TskewHistogramWindow	0.0, 0.010, 0.020, 0.070	Increase the Tskew histogram window for short HS stream that may not have enough data points for histogram measurement. Default value is $\pm 10$ mV.
Configure	Ulnst Min	Ulnst_Min_limit	(Accepts user-defined text), 0	Specifies the limit for the Ulnst min value define by the DUT.
Configure	UseWfmFile(Must be hidden)	UseWfmFile	(Accepts user-defined text), 0.0, 1.0	For supporting offline
Configure	WIDTH(max)	WIDTHMax	(Accepts user-defined text), 0.070	WIDTH(max) is used to determine the stop point for THS-PREPARE. Please see D-Phy specification for the allowable value.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Configure	VIH(min)	VIHMin	(Accepts user-defined text), 0.88, 0.74	VIH(min) is used to determine the ending point for CLK TX TEOT. The default value for VIH(min) is 880mV(for HS rate $\leq$ 1.5Gbps) and 740mV(for HS rate $>$ 1.5Gbps). Please see D-Phy specification for the allowable value.
Configure	VIL(max)	VILMax	(Accepts user-defined text), 0.550	VIL(max) is used to determine the starting point for TLPX and THS-PREPARE. Please see D-Phy specification for the allowable value.
Run Tests	Event	RunEvent	(None), Fail, Margin < N, Pass	Names of events that can be used with the StoreMode=Event or RunUntil RunEventAction options
Run Tests	RunEvent=Margin < N: Minimum required margin %	RunEvent_Margin < N_MinPercent	Any integer in range: $0 \leq \text{value} \leq 100$	Specify N using the 'Minimum required margin %' control.
Set Up	CTSVersion	CTSVersion	v1.0, v1.1, v1.2	Select the CTS Version. Select the CTS Version.
Set Up	ClkEscapeMode	ClkLPEscapeMode	0.0, 1.0	Escape Mode in Clock Lane. Check this if the device has LP Escape mode on the clock lane. Escape Mode in Clock Lane.
Set Up	ClockULPSMode	ClkULPSMode	0.0, 1.0	ULPS Mode in Clock Lane. Check this if the device has ULPS mode on the clock lanes. ULPS Mode in Clock Lane.
Set Up	DataEscapeMode	LPEscapeMode	0.0, 1.0	Escape Mode in Data Lane. Check this if the device has LP Escape mode on the data lanes. Escape Mode in Data Lane.
Set Up	DeviceID	DeviceID	(Accepts user-defined text)	Device ID

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	ElecHSClk_ClkWfmFile	ElecHSClk_ClkWfmFile	(Accepts user-defined text)	Saved Clkn single-ended signal for all tests in "Electrical Characteristics-HS Clock TX" test group. This option is applicable only for Offline Mode. Saved Clkn single-ended signal for all tests in "Electrical Characteristics-HS Clock TX" test group. This option is applicable only for Offline Mode.
Set Up	ElecHSClk_ClkpWfmFile	ElecHSClk_ClkpWfmFile	(Accepts user-defined text)	Saved Clkp single-ended signal for all tests in "Electrical Characteristics-HS Clock TX" test group. This option is applicable only for Offline Mode. Saved Clkp single-ended signal for all tests in "Electrical Characteristics-HS Clock TX" test group. This option is applicable only for Offline Mode.
Set Up	ElecHSClk_DiffClkWfmFile	ElecHSClk_DiffClkWfmFile	(Accepts user-defined text)	Saved Clock Differential signal for all tests in "Electrical Characteristics-HS Clock TX" test group. This option is applicable only for Offline Mode. Saved Clock Differential signal for all tests in "Electrical Characteristics-HS Clock TX" test group. This option is applicable only for Offline Mode.
Set Up	ElecHSData_ClkWfmFile	ElecHSData_ClkWfmFile	(Accepts user-defined text)	Saved Clkn single-ended signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode. Saved Clkn single-ended signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	ElechSDData_ClkWfmFile	ElechSDData_ClkWfmFile	(Accepts user-defined text)	Saved Clkp single-ended signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode. Saved Clkp single-ended signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode.
Set Up	ElechSDData_DatnWfmFile	ElechSDData_DatnWfmFile	(Accepts user-defined text)	Saved Datn single-ended signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode. Saved Datn single-ended signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode.
Set Up	ElechSDData_DatpWfmFile	ElechSDData_DatpWfmFile	(Accepts user-defined text)	Saved Datp single-ended signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode. Saved Datp single-ended signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode.
Set Up	ElechSDData_DiffClkWfmFile	ElechSDData_DiffClkWfmFile	(Accepts user-defined text)	Saved Clock Differential signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode. Saved Clock Differential signal for all tests in "Electrical Characteristics-HS Data TX" test group. This option is applicable only for Offline Mode.
Set Up	FixtureSetup	FixtureSetup	Auto Load Switching, Manual Load Switching	Auto or Manual Switching Auto or Manual Switching

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	GlobalHSClkEntry_ClknWfmFile	GlobalHSClkEntry_ClknWfmFile	(Accepts user-defined text)	Saved Clkn single-ended signal for all HS-Entry tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode. Saved Clkn single-ended signal for all HS-Entry tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode.
Set Up	GlobalHSClkEntry_ClkpWfmFile	GlobalHSClkEntry_ClkpWfmFile	(Accepts user-defined text)	Saved Clkp single-ended signal for all HS-Entry tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode. Saved Clkp single-ended signal for all HS-Entry tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode.
Set Up	GlobalHSClkEntry_DatnWfmFile	GlobalHSClkEntry_DatnWfmFile	(Accepts user-defined text)	Saved Datn single-ended signal for all HS-Entry tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode. Saved Datn single-ended signal for all HS-Entry tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode.
Set Up	GlobalHSClkEntry_DatpWfmFile	GlobalHSClkEntry_DatpWfmFile	(Accepts user-defined text)	Saved Datp single-ended signal for all HS-Entry tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode. Saved Datp single-ended signal for all HS-Entry tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode.



**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	GlobalHSClkExit_ClkWfmFile	GlobalHSClkExit_ClkWfmFile	(Accepts user-defined text)	Saved Clkn single-ended signal for all HS-Exit tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode. Saved Clkn single-ended signal for all HS-Exit tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode.
Set Up	GlobalHSClkExit_ClkpWfmFile	GlobalHSClkExit_ClkpWfmFile	(Accepts user-defined text)	Saved Clkp single-ended signal for all HS-Exit tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode. Saved Clkp single-ended signal for all HS-Exit tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode.
Set Up	GlobalHSClkExit_DatnWfmFile	GlobalHSClkExit_DatnWfmFile	(Accepts user-defined text)	Saved Datn single-ended signal for all HS-Exit tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode. Saved Datn single-ended signal for all HS-Exit tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode.
Set Up	GlobalHSClkExit_DatpWfmFile	GlobalHSClkExit_DatpWfmFile	(Accepts user-defined text)	Saved Datp single-ended signal for all HS-Exit tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode. Saved Datp single-ended signal for all HS-Exit tests in "Global Operation-Clock TX" test group. This option is applicable only for Offline Mode.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	GlobalHSDataEntry_DatnWfmFile	GlobalHSDataEntry_DatnWfmFile	(Accepts user-defined text)	Saved Datn single-ended signal for all HS-Entry tests in "Global Operation-Data TX" test group. This option is applicable only for Offline Mode. Saved Datn single-ended signal for all HS-Entry tests in "Global Operation-Data TX" test group. This option is applicable only for Offline Mode.
Set Up	GlobalHSDataEntry_DatpWfmFile	GlobalHSDataEntry_DatpWfmFile	(Accepts user-defined text)	Saved Datp single-ended signal for all HS-Entry tests in "Global Operation-Data TX" test group. This option is applicable only for Offline Mode. Saved Datp single-ended signal for all HS-Entry tests in "Global Operation-Data TX" test group. This option is applicable only for Offline Mode.
Set Up	GlobalHSDataExit_DatnWfmFile	GlobalHSDataExit_DatnWfmFile	(Accepts user-defined text)	Saved Datn single-ended signal for all HS-Exit tests in "Global Operation-Data TX" test group. This option is applicable only for Offline Mode. Saved Datn single-ended signal for all HS-Exit tests in "Global Operation-Data TX" test group. This option is applicable only for Offline Mode.
Set Up	GlobalHSDataExit_DatpWfmFile	GlobalHSDataExit_DatpWfmFile	(Accepts user-defined text)	Saved Datp single-ended signal for all HS-Exit tests in "Global Operation-Data TX" test group. This option is applicable only for Offline Mode. Saved Datp single-ended signal for all HS-Exit tests in "Global Operation-Data TX" test group. This option is applicable only for Offline Mode.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	HSClkFirstBitAlignment_ClkWfmFile	HSClkFirstBitAlignment_ClkWfmFile	(Accepts user-defined text)	Saved Clkn single-ended signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode. Saved Clkn single-ended signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode.
Set Up	HSClkFirstBitAlignment_ClkpWfmFile	HSClkFirstBitAlignment_ClkpWfmFile	(Accepts user-defined text)	Saved Clkp single-ended signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode. Saved Clkp single-ended signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode.
Set Up	HSClkFirstBitAlignment_DatnWfmFile	HSClkFirstBitAlignment_DatnWfmFile	(Accepts user-defined text)	Saved Datn single-ended signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode. Saved Datn single-ended signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode.
Set Up	HSClkFirstBitAlignment_DatpWfmFile	HSClkFirstBitAlignment_DatpWfmFile	(Accepts user-defined text)	Saved Datp single-ended signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode. Saved Datp single-ended signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode.
Set Up	HSClkFirstBitAlignment_DiffClkWfmFile	HSClkFirstBitAlignment_DiffClkWfmFile	(Accepts user-defined text)	Saved Clock Differential signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode. Saved Clock Differential signal for Test 1.5.3 HS Clock Rising Edge Alignment to First Payload Bit. This option is applicable only for Offline Mode.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	HSDataRate	HSDataRate	(Accepts user-defined text)	High Speed Data Rate High Speed Data Rate
Set Up	HSZIDTermination	HSZIDTermination	80 ohm, 100 ohm, 125 ohm	Select the ZID termination value for HS tests. Select the ZID termination value for HS tests.
Set Up	LPCLoad	LPCLoad	50pF, Without CLoad	Select the CLoad value for all LP tests. Select the CLoad value for all LP tests.
Set Up	ShowInfoTest	ShowInfoTest	0.0, 1.0	Show Informative Test. Check this to enable or disable informative test group. Show Informative Test.
Set Up	SkewCallInitial_DatnWfmFile	SkewCallInitial_DatnWfmFile	(Accepts user-defined text)	Saved Datn single-ended signal for Test 1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL-SYNC) and Test 1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL). This option is applicable only for Offline Mode. Saved Datn single-ended signal for Test 1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL-SYNC) and Test 1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL). This option is applicable only for Offline Mode.
Set Up	SkewCallInitial_DatpWfmFile	SkewCallInitial_DatpWfmFile	(Accepts user-defined text)	Saved Datp single-ended signal for Test 1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL-SYNC) and Test 1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL). This option is applicable only for Offline Mode. Saved Datp single-ended signal for Test 1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL-SYNC) and Test 1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL). This option is applicable only for Offline Mode.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	SkewCalPeriodic_DatnWfmFile	SkewCalPeriodic_DatnWfmFile	(Accepts user-defined text)	Saved Datn single-ended signal for Test 1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL-SYNC) and Test 1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL). This option is applicable only for Offline Mode. Saved Datn single-ended signal for Test 1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL-SYNC) and Test 1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL). This option is applicable only for Offline Mode.
Set Up	SkewCalPeriodic_DatpWfmFile	SkewCalPeriodic_DatpWfmFile	(Accepts user-defined text)	Saved Datp single-ended signal for Test 1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL-SYNC) and Test 1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL). This option is applicable only for Offline Mode. Saved Datp single-ended signal for Test 1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL-SYNC) and Test 1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL). This option is applicable only for Offline Mode.
Set Up	TSkewAndEyeHeightWidth_ClknWfmFile	TSkewAndEyeHeightWidth_ClknWfmFile	(Accepts user-defined text)	Saved Clkn single-ended signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode. Saved Clkn single-ended signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	TSkewAndEyeHeightWidth_ClkpWfmFile	TSkewAndEyeHeightWidth_ClkpWfmFile	(Accepts user-defined text)	Saved Clkp single-ended signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode. Saved Clkp single-ended signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode.
Set Up	TSkewAndEyeHeightWidth_DatnWfmFile	TSkewAndEyeHeightWidth_DatnWfmFile	(Accepts user-defined text)	Saved Datn single-ended signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode. Saved Datn single-ended signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode.
Set Up	TSkewAndEyeHeightWidth_DatpWfmFile	TSkewAndEyeHeightWidth_DatpWfmFile	(Accepts user-defined text)	Saved Datp single-ended signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode. Saved Datp single-ended signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode.

**Table 2** Configuration Variables and Values (continued)

GUI Location	Label	Variable	Values	Description
Set Up	TSkewAndEyeHeightWidth_DiffClkWfmFile	TSkewAndEyeHeightWidth_DiffClkWfmFile	(Accepts user-defined text)	Saved Clock Differential signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode. Saved Clock Differential signal for Test 1.5.4 Data-to-Clock Skew(TSKEW(TX), Test HS Data Eye Height(Informative) and Test HS Data Eye Width(Informative) tests. This option is applicable only for Offline Mode.
Set Up	UserComment	UserComment	(Accepts user-defined text)	User Comment
Set Up	pcbClockContinuousMode	pcbClockContinuousMode	0.0, 1.0	For continuous clock. Check this if clock lane has no LP. For continuous clock.
Set Up	pcbDataContinuousMode	pcbDataContinuousMode	0.0, 1.0	For continuous data. Check this if data lane has no LP. For continuous data.
Set Up	pcbLane0	Lane0	0.0, 1.0	Data Lane - Lane0
Set Up	pcbLane1	Lane1	0.0, 1.0	Data Lane - Lane1
Set Up	pcbLane2	Lane2	0.0, 1.0	Data Lane - Lane2
Set Up	pcbLane3	Lane3	0.0, 1.0	Data Lane - Lane3

## 2 Configuration Variables and Values



## 3 Test Names and IDs

The following table shows the mapping between each test's numeric ID and name. The numeric ID is required by various remote interface methods.

- Name – The name of the test as it appears on the user interface **Select Tests** tab.
- Test ID – The number to use with the RunTests method.
- Description – The description of the test as it appears on the user interface **Select Tests** tab.

For example, if the graphical user interface displays this tree in the **Select Tests** tab:

- All Tests
  - Rise Time
  - Fall Time

then you would expect to see something like this in the table below:

**Table 3** Example Test Names and IDs

Name	Test ID	Description
Fall Time	110	Measures clock fall time.
Rise Time	100	Measures clock rise time.

and you would run these tests remotely using:

ARSL syntax

-----

```
arsl -a ipaddress -c "SelectedTests '100,110'"  
arsl -a ipaddress -c "Run"
```

C# syntax

-----

```
remoteAte.SelectedTests = new int[] {100,110};  
remoteAte.Run();
```

Here are the actual Test names and IDs used by this application:

**NOTE**

The file, "TestInfo.txt", which may be found in the same directory as this help file, contains all of the information found in the table below in a format suitable for parsing.

**Table 4** Test IDs and Names

Name	TestID	Description
1.1.1 LP TX Thevenin Output High Voltage Level (VOH)	821	This test is to verify that the Thevenin Output High Voltage of data lane is between the minimum conformance limit(LPThevenin_VOH_Limit_min) and the maximum conformance limit of 1.3V. For CTS v1.0 and CTS v1.1, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V. For CTS v1.2, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V for Datarate ≤ 1.5Gbps, 0.95V for Datarate > 1.5Gbps.
1.1.1 LP TX Thevenin Output High Voltage Level (VOH) ESCAPEMODE	8211	This test is to verify that the Thevenin Output High Voltage of data lane using escape mode is between the minimum conformance limit(LPThevenin_VOH_Limit_min) and the maximum conformance limit of 1.3V. For CTS v1.0 and CTS v1.1, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V. For CTS v1.2, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V for Datarate ≤ 1.5Gbps, 0.95V for Datarate > 1.5Gbps.
1.1.2 LP TX Thevenin Output Low Voltage Level (VOL)	822	This test is to verify that the Thevenin Output Low Voltage of data lane is within the conformance limits.
1.1.2 LP TX Thevenin Output Low Voltage Level (VOL) ESCAPEMODE	8221	This test is to verify that the Thevenin Output Low Voltage of data lane using escape mode is within the conformance limits.
1.1.3 LP TX 15%-85% Rise Time (TRLP)	824	15%-85% rise time of LP signal.
1.1.3 LP TX 15%-85% Rise Time (TRLP) ESCAPEMODE	8241	15%-85% rise time of LP signal. (Escape Mode)
1.1.4 LP TX 15%-85% Fall Time (TFLP)	825	15%-85% fall time of LP signal.
1.1.4 LP TX 15%-85% Fall Time (TFLP) ESCAPEMODE	8251	15%-85% fall time of LP signal in Escape Mode.
1.1.5 LP TX Slew Rate Vs. CLoad (Margin)	8292	Slew rate at different capacitance load condition. Note: Please set the value of Cload in the configuration tab before running the test.
1.1.5 LP TX Slew Rate Vs. CLoad (Max)	829	Slew rate at different capacitance load condition. Note: Please set the value of Cload in the configuration tab before running the test.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.1.5 LP TX Slew Rate Vs. CLoad (Min)	8291	Slew rate at different capacitance load condition. Note: Please set the value of Cload in the configuration tab before running the test.
1.1.6 LP Clock TX Pulse Width of LP TX Exclusive-OR Clock (TLP-PULSE-TX)	1827	Pulse width measurement for all pulses of the LP exclusive-OR clock excluding the first pulse and last pulse for clock lane.
1.1.6 LP Clock TX Pulse Width of LP TX Exclusive-OR Clock (TLP-PULSE-TX) [Initial]	18271	Pulse width measurement for first pulse of the LP exclusive-OR clock for clock lane.
1.1.6 LP Clock TX Pulse Width of LP TX Exclusive-OR Clock (TLP-PULSE-TX) [Last]	18272	Pulse width measurement for last pulse of the LP exclusive-OR clock for clock lane.
1.1.6 LP TX Pulse Width of LP TX Exclusive-OR Clock (TLP-PULSE-TX)	827	Pulse width measurement for all pulses of the LP exclusive-OR clock excluding the first pulse and last pulse.
1.1.6 LP TX Pulse Width of LP TX Exclusive-OR Clock (TLP-PULSE-TX) [Initial]	8271	Pulse width measurement for first pulse of the LP exclusive-OR clock.
1.1.6 LP TX Pulse Width of LP TX Exclusive-OR Clock (TLP-PULSE-TX) [Last]	8272	Pulse width measurement for last pulse of the LP exclusive-OR clock.
1.1.7 LP Clock TX Period of LP TX Exclusive-OR Clock (TLP-PER-TX)	1828	Period of the LP exclusive-OR clock for clock lane.
1.1.7 LP TX Period of LP TX Exclusive-OR Clock (TLP-PER-TX)	828	Period of the LP exclusive-OR clock.
1.2.1 LP Clock TX Thevenin Output High Voltage Level (VOH)	1821	This test is to verify that the Thevenin Output High Voltage of clock lane is between the minimum conformance limit(LPThevenin_VOH_Limit_min) and the maximum conformance limit of 1.3V. For CTS v1.0 and CTS v1.1, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V. For CTS v1.2, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V for Datarate ≤ 1.5Gbps, 0.95V for Datarate > 1.5Gbps.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.2.1 LP Clock TX Thevenin Output High Voltage Level (VOH) ESCAPEMODE	18211	This test is to verify that the Thevenin Output High Voltage of clock lane using escape mode is between the minimum conformance limit(LPThevenin_VOH_Limit_min) and the maximum conformance limit of 1.3V. For CTS v1.0 and CTS v1.1, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V. For CTS v1.2, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V for Datarate $\leq$ 1.5Gbps, 0.95V for Datarate $>$ 1.5Gbps.
1.2.1 ULPS Clock TX Thevenin Output High Voltage Level (VOH) ULPSMODE	28211	This test is to verify that the Thevenin Output High Voltage of clock lane using ULPS mode is between the minimum conformance limit(LPThevenin_VOH_Limit_min) and the maximum conformance limit of 1.3V. For CTS v1.0 and CTS v1.1, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V. For CTS v1.2, the minimum conformance limit(LPThevenin_VOH_Limit_min) is 1.1V for Datarate $\leq$ 1.5Gbps, 0.95V for Datarate $>$ 1.5Gbps.
1.2.2 LP Clock TX Thevenin Output Low Voltage Level (VOL)	1822	This test is to verify that the Thevenin Output Low Voltage of clock lane is within the conformance limits.
1.2.2 LP Clock TX Thevenin Output Low Voltage Level (VOL) ESCAPEMODE	18221	This test is to verify that the Thevenin Output Low Voltage of clock lane using escape mode is within the conformance limits.
1.2.2 ULPS Clock TX Thevenin Output Low Voltage Level (VOL) ULPSMODE	28221	This test is to verify that the Thevenin Output Low Voltage of clock lane using ULPS mode is within the conformance limits.
1.2.3 LP Clock TX 15%-85% Rise Time (TRLP)	1824	15%-85% rise time of LP signal on clock lane.
1.2.3 LP Clock TX 15%-85% Rise Time (TRLP) ESCAPEMODE	18241	15%-85% rise time of LP signal on clock lane using Escape Mode.
1.2.3 ULPS Clock TX 15%-85% Rise Time (TRLP) ULPSMODE	28241	15%-85% rise time of LP signal on clock lane using Escape Mode.
1.2.4 LP Clock TX 15%-85% Fall Time (TFLP)	1825	15%-85% fall time of LP signal for clock lane.
1.2.4 LP Clock TX 15%-85% Fall Time (TFLP) ESCAPEMODE	18251	15%-85% fall time of LP signal for clock lane using Escape Mode.
1.2.4 ULPS Clock TX 15%-85% Fall Time (TFLP) ULPSMODE	28251	15%-85% fall time of LP signal for clock lane using Escape Mode.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.2.5 LP CLK Slew Rate Vs. CLoad (Margin)	18292	Slew rate at different capacitance load condition. Note: Please set the value of Cload in the configuration tab before running the test.
1.2.5 LP CLK Slew Rate Vs. CLoad (Min)	18291	Slew rate at different capacitance load condition. Note: Please set the value of Cload in the configuration tab before running the test.
1.2.5 LP Clock TX Slew Rate Vs. CLoad (Max)	1829	Slew rate at different capacitance load condition. Note: Please set the value of Cload in the configuration tab before running the test.
1.2.5 ULPS CLK Slew Rate Vs. CLoad (Margin) ULPSMODE	28292	Slew rate at different capacitance load condition. Note: Please set the value of Cload in the configuration tab before running the test.
1.2.5 ULPS CLK Slew Rate Vs. CLoad (Min) ULPSMODE	28291	Slew rate at different capacitance load condition. Note: Please set the value of Cload in the configuration tab before running the test.
1.2.5 ULPS Clock TX Slew Rate Vs. CLoad (Max) ULPSMODE	2829	Slew rate at different capacitance load condition. Note: Please set the value of Cload in the configuration tab before running the test.
1.3.1 HS Entry: DATA TLPX	511	Length of any Low-Power state period.
1.3.10 HS Data TX Common-Level Variations Above 450MHz (VCMTX(HF))	818	Common-level variations above 450MHz.
1.3.11 HS Data TX 20%-80% Rise Time (tR)	8110	This test is to verify that the 20%-80% rise time of the HS Differential signal is greater than the minimum conformance limit(DataRiseTime_LimitMin) and less than the maximum conformance limit(DataRiseTime_LimitMax). For CTS v1.0, the minimum conformance limit(DataRiseTime_LimitMin) is 150ps and the maximum conformance limit(DataRiseTime_LimitMax) is 0.3UI. For CTS v1.1, the minimum conformance limit(DataRiseTime_LimitMin) is 150ps for Datarate ≤ 1Gbps, 100ps for Datarate > 1Gbps. The maximum conformance limit(DataRiseTime_LimitMax) is 0.3*UI for Datarate ≤ 1Gbps, 0.35*UI for Datarate > 1Gbps. The VOD(0) and VOD(1) measured from Data Lane in Test 1.3.4 will be used to calculate 20/80% reference voltage for rise time measurement in this test.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.3.11 HS Data TX 20%-80% Rise Time (tR)[Burst Data]	81101	This test is to verify that the 20%-80% rise time of the HS Differential signal is less than the maximum conformance limit(DataRiseTime_LimitMax). For CTS v1.2, the maximum conformance limit(DataRiseTime_LimitMax) is $0.3*UI$ for Datarate $\leq 1$ Gbps, $0.35*UI$ for Datarate $> 1$ Gbps and $\leq 1.5$ Gbps , $0.4*UI$ for Datarate $> 1.5$ Gbps. This test will measure the rise time based on the reference data patterns(000111) of differential signal. This test is applicable for Burst Data signal only. The VHS_ZERO level measured from Data Lane will be used to calculate 20/80% reference voltage for rise time measurement in this test.
1.3.11 HS Data TX 20%-80% Rise Time (tR)[Burst Data](Min Conformance Limit)(Informative)	81104	This test is an informative test. This test is to verify that the 20%-80% rise time of the HS Differential signal is greater than the minimum conformance limit(DataRiseTime_LimitMin). For CTS v1.2, the minimum conformance limit(DataRiseTime_LimitMin) is for informative purpose only: DataRiseTime_LimitMin is 150ps for Datarate $\leq 1$ Gbps, 100ps for Datarate $> 1$ Gbps and $\leq 1.5$ Gbps , 50ps for Datarate $> 1.5$ Gbps. This test will measure the rise time based on the reference data patterns(000111) of differential signal. This test is applicable for Burst Data signal only. The VHS_ZERO level measured from Data Lane will be used to calculate 20/80% reference voltage for rise time measurement in this test.
1.3.11 HS Data TX 20%-80% Rise Time (tR)[Continuous Data]	81102	This test is to verify that the 20%-80% rise time of the HS Differential signal is less than the maximum conformance limit(DataRiseTime_LimitMax). For CTS v1.2, the maximum conformance limit(DataRiseTime_LimitMax) is $0.3*UI$ for Datarate $\leq 1$ Gbps, $0.35*UI$ for Datarate $> 1$ Gbps and $\leq 1.5$ Gbps , $0.4*UI$ for Datarate $> 1.5$ Gbps. This test will measure the rise time based on the reference data patterns(000111) of differential signal. This test is applicable for Continuous Data signal only. The VOD(0) and VOD(1) measured from Data Lane in Test 1.3.4 will be used to calculate 20/80% reference voltage for rise time measurement in this test.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.3.11 HS Data TX 20%-80% Rise Time (tR)[Continuous Data](Min Conformance Limit)(Informative)	81105	This test is an informative test. This test is to verify that the 20%-80% rise time of the HS Differential signal is greater than the minimum conformance limit(DataRiseTime_LimitMin). For CTS v1.2, the minimum conformance limit(DataRiseTime_LimitMin) is for informative purpose only: DataRiseTime_LimitMin is 150ps for Datarate $\leq$ 1Gbps, 100ps for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, 50ps for Datarate $>$ 1.5Gbps. This test will measure the rise time based on the reference data patterns(000111) of differential signal. This test is applicable for Continuous Data signal only. The VOD(0) and VOD(1) measured from Data Lane in Test 1.3.4 will be used to calculate 20/80% reference voltage for rise time measurement in this test.
1.3.12 HS Data TX 80%-20% Fall Time (tF)	8111	This test is to verify that the 80%-20% fall time of the HS Differential signal is greater than the minimum conformance limit(DataFallTime_LimitMin) and less than the maximum conformance limit(DataFallTime_LimitMax). For CTS v1.0, the minimum conformance limit(DataFallTime_LimitMin) is 150ps and the maximum conformance limit(DataFallTime_LimitMax) is 0.3UI. For CTS v1.1, the minimum conformance limit(DataFallTime_LimitMin) is 150ps for Datarate $\leq$ 1Gbps, 100ps for Datarate $>$ 1Gbps. The maximum conformance limit(DataFallTime_LimitMax) is 0.3*UI for Datarate $\leq$ 1Gbps, 0.35*UI for Datarate $>$ 1Gbps. The VOD(0) and VOD(1) measured from Data Lane in Test 1.3.4 will be used to calculate 20/80% reference voltage for fall time measurement in this test.
1.3.12 HS Data TX 80%-20% Fall Time (tF)[Burst Data]	81111	This test is to verify that the 80%-20% fall time of the HS differential signal is less than the maximum conformance limit(DataFallTime_LimitMax). For CTS v1.2, the maximum conformance limit(DataFallTime_LimitMax) is 0.3*UI for Datarate $\leq$ 1Gbps, 0.35*UI for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, 0.4*UI for Datarate $>$ 1.5Gbps. This test will measure the fall time based on the reference data patterns(111000) of differential signal. This test is applicable for Burst Data signal only. The VHS_ZERO level measured from Data Lane will be used to calculate 20/80% reference voltage for fall time measurement in this test.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.3.12 HS Data TX 80%-20% Fall Time (tF)[Burst Data](Min Conformance Limit)(Informative)	81114	This test is an informative test. This test is to verify that the 80%-20% fall time of the HS Differential signal is greater than the minimum conformance limit(DataFallTime_LimitMin). For CTS v1.2, the minimum conformance limit(DataFallTime_LimitMin) is for informative purpose only: DataFallTime_LimitMin is 150ps for Datarate $\leq$ 1Gbps, 100ps for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, 50ps for Datarate $>$ 1.5Gbps. This test will measure the fall time based on the reference data patterns(111000) of differential signal. This test is applicable for Burst Data signal only. The VHS_ZERO level measured from Data Lane will be used to calculate 20/80% reference voltage for fall time measurement in this test.
1.3.12 HS Data TX 80%-20% Fall Time (tF)[Continuous Data]	81112	This test is to verify that 80%-20% fall time of the HS differential signal is less than the maximum conformance limit(DataFallTime_LimitMax). For CTS v1.2, the maximum conformance limit(DataFallTime_LimitMax) is $0.3*UI$ for Datarate $\leq$ 1Gbps, $0.35*UI$ for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, $0.4*UI$ for Datarate $>$ 1.5Gbps. This test will measure the fall time based on the reference data patterns(111000) of differential signal. This test is applicable for Continuous Data signal only. The VOD(0) and VOD(1) measured from Data Lane in Test 1.3.4 will be used to calculate 20/80% reference voltage for fall time measurement in this test.
1.3.12 HS Data TX 80%-20% Fall Time (tF)[Continuous Data](Min Conformance Limit)(Informative)	81115	This test is an informative test. This test is to verify that the 80%-20% fall time of the HS Differential signal is greater than the minimum conformance limit(DataFallTime_LimitMin). For CTS v1.2, the minimum conformance limit(DataFallTime_LimitMin) is for informative purpose only: DataFallTime_LimitMin is 150ps for Datarate $\leq$ 1Gbps, 100ps for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, 50ps for Datarate $>$ 1.5Gbps. This test will measure the fall time based on the reference data patterns(111000) of differential signal. This test is applicable for Continuous Data signal only. The VOD(0) and VOD(1) measured from Data Lane in Test 1.3.4 will be used to calculate 20/80% reference voltage for fall time measurement in this test.



**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.3.13 HS Exit: DATA TX THS-TRAIL	546	Time to drive flipped differential state after last payload data bit of a HS transmission burst. TXTHSTrail_LimitMin is based on $60ns+n*4*UI$ . The THS-SKIP parameter is useful to avoid glitch problem during THS-TRAIL measurement. Any transition on the Data Lane in THS-SKIP time interval will be ignored when finding last payload data bit of HS transmission burst. The default value of THS-SKIP is set to 0s to prevent invalid THS-TRAIL measurement.
1.3.14 HS Exit: DATA TX TREOT	549	30%-85% rise time and fall time
1.3.15 HS Exit: DATA TX TEOT	547	Time from start of THS-TRAIL period to start of LP-11 state. TXTEOT_LimitMax is based on $105ns+n*12*UI$ .
1.3.16 HS Exit: DATA TX THS-EXIT	548	Time to drive LP-11 after HS burst.
1.3.2 HS Entry: DATA TX THS-PREPARE	557	Time to drive LP-00 to prepare for HS Transmission. THSPrepate_LimitMin is based on $40ns+4*UI$ . THSPrepate_LimitMax is based on $85ns+6*UI$ .
1.3.3 HS Entry: DATA TX THS-PREPARE+THS-ZERO	558	THS-PREPARE+Time to drive HS-0 before Sync sequence. TXTHSPrepateTHSZero_LimitMin is based on $145ns+10*UI$ .
1.3.4 HS Data TX Differential Voltage(VOD0 Pulse)	8131	HS transmit differential voltage. This test will measure the VOD0 based on the reference data patterns(100000) of differential signal.
1.3.4 HS Data TX Differential Voltage(VOD1 Pulse)	8132	HS transmit differential voltage. This test will measure the VOD1 based on the reference data patterns(011111) of differential signal.
1.3.5 HS Data TX Differential Voltage Mismatch (Pulse)	8141	VOD mismatch when output is Differential-1 or Differential-0.
1.3.6 HS Data TX Single Ended Output High Voltage(VOHHS Pulse)	8151	HS Single Ended output high voltage. This test will measure the VOHHS based on the reference pulses(100000) of single-ended Dp and Dn signals.
1.3.7 HS Data TX Static Common Mode Voltage(Vcmtx)	811	HS transmit static common-mode voltage.
1.3.8 HS Data TX Vcmtx Mismatch	812	VCMTX mismatch when output is Differential-1 or Differential-0.
1.3.9 HS Data TX Common-Level Variations Between 50-450MHz (VCMTX(LF))	819	Common-level variation between 50-450MHz.
1.4.1 HS Entry: CLK TX TLPX	5510	Length of any Low-Power state period.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.4.10 HS Clock TX Common-Level Variations Above 450MHz (VCMTX(HF))	1818	Common-level variations above 450MHz.
1.4.11 HS Clock TX 20%-80% Rise Time (tR)	18110	This test is to verify that the 20%-80% rise time of the HS Differential signal is greater than the minimum conformance limit(CLK RiseTime_LimitMin) and less than the maximum conformance limit(CLK RiseTime_LimitMax). For CTS v1.0, the minimum conformance limit(CLK RiseTime_LimitMin) is 150ps and the maximum conformance limit(CLK RiseTime_LimitMax) is 0.3UI. For CTS v1.1, the minimum conformance limit(CLK RiseTime_LimitMin) is 150ps for Datarate ≤ 1Gbps, 100ps for Datarate > 1Gbps. The maximum conformance limit(CLK RiseTime_LimitMax) is 0.3*UI for Datarate ≤ 1Gbps, 0.35*UI for Datarate > 1Gbps. The VOD(0) and VOD(1) measured from Clock Lane in Test 1.4.4 will be used to calculate 20/80% reference voltage for rise time measurement in this test.
1.4.11 HS Clock TX 20%-80% Rise Time (tR)[Burst Clock]	181101	This test is to verify that the 20%-80% rise time of the HS differential signal is less than the maximum conformance limit(CLK RiseTime_LimitMax). For CTS v1.2, the maximum conformance limit(CLK RiseTime_LimitMax) is 0.3*UI for Datarate ≤ 1Gbps, 0.35*UI for Datarate > 1Gbps and ≤ 1.5Gbps, 0.4*UI for Datarate > 1.5Gbps. This test is applicable for Burst Clock signal only. The VHS_ZERO level measured from Clock Lane will be used to calculate 20/80% reference voltage for rise time measurement in this test.
1.4.11 HS Clock TX 20%-80% Rise Time (tR)[Burst Clock](Min Conformance Limit)(Informative)	181104	This test is an informative test. This test is to verify that the 20%-80% rise time of the HS differential signal is greater than the minimum conformance limit(CLK RiseTime_LimitMin). For CTS v1.2, the minimum conformance limit(CLK RiseTime_LimitMin) is for informative purpose only: CLK RiseTime_LimitMin is 150ps for Datarate ≤ 1Gbps, 100ps for Datarate > 1Gbps and ≤ 1.5Gbps, 50ps for Datarate > 1.5Gbps. This test is applicable for Burst Clock signal only. The VHS_ZERO level measured from Clock Lane will be used to calculate 20/80% reference voltage for rise time measurement in this test.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.4.11 HS Clock TX 20%-80% Rise Time (tR)[Continuous Clock, Burst Data]	181102	This test is to verify that the 20%-80% rise time of the HS differential signal is less than the maximum conformance limit(CLK RiseTime_LimitMax). For CTS v1.2, the maximum conformance limit(CLK RiseTime_LimitMax) is $0.3 \cdot UI$ for Datarate $\leq 1$ Gbps, $0.35 \cdot UI$ for Datarate $> 1$ Gbps and $\leq 1.5$ Gbps, $0.4 \cdot UI$ for Datarate $> 1.5$ Gbps. This test is applicable for Continuous Clock and Burst Data signal only. The VHS_ZERO level measured from Data Lane will be used to calculate 20/80% reference voltage for rise time measurement in this test.
1.4.11 HS Clock TX 20%-80% Rise Time (tR)[Continuous Clock, Burst Data](Min Conformance Limit)(Informative)	181105	This test is an informative test. This test is to verify that the 20%-80% rise time of the HS differential signal is greater than the minimum conformance limit(CLK RiseTime_LimitMin). For CTS v1.2, the minimum conformance limit(CLK RiseTime_LimitMin) is for informative purpose only: CLK RiseTime_LimitMin is 150ps for Datarate $\leq 1$ Gbps, 100ps for Datarate $> 1$ Gbps and $\leq 1.5$ Gbps, 50ps for Datarate $> 1.5$ Gbps. This test is applicable for Continuous Clock and Burst Data signal only. The VHS_ZERO level measured from Data Lane will be used to calculate 20/80% reference voltage for rise time measurement in this test.
1.4.11 HS Clock TX 20%-80% Rise Time (tR)[Continuous Clock, Continuous Data]	181103	This test is to verify that the 20%-80% rise time of the HS differential signal is less than the maximum conformance limit(CLK RiseTime_LimitMax). For CTS v1.2, the maximum conformance limit(CLK RiseTime_LimitMax) is $0.3 \cdot UI$ for Datarate $\leq 1$ Gbps, $0.35 \cdot UI$ for Datarate $> 1$ Gbps and $\leq 1.5$ Gbps, $0.4 \cdot UI$ for Datarate $> 1.5$ Gbps. This test is applicable for Continuous Clock and Continuous Data signal only. The VOD(0) and VOD(1) measured from Clock Lane in Test 1.4.4 will be used to calculate 20/80% reference voltage for rise time measurement in this test.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.4.11 HS Clock TX 20%-80% Rise Time (tR)[Continuous Clock, Continuous Data](Min Conformance Limit)(Informative)	181106	This test is an informative test. This test is to verify that the 20%-80% rise time of the HS differential signal is greater than the minimum conformance limit(CLK RiseTime_LimitMin) For CTS v1.2, the minimum conformance limit(CLK RiseTime_LimitMin) is for informative purpose only: CLK RiseTime_LimitMin is 150ps for Datarate $\leq$ 1Gbps, 100ps for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, 50ps for Datarate $>$ 1.5Gbps. This test is applicable for Continuous Clock and Continuous Data signal only. The VOD(0) and VOD(1) measured from Clock Lane in Test 1.4.4 will be used to calculate 20/80% reference voltage for rise time measurement in this test.
1.4.12 HS Clock TX 80%-20% Fall Time (tF)	18111	This test is to verify that the 80%-20% fall time of the HS Differential signal is greater than the minimum conformance limit(CLK FallTime_LimitMin) and less than the maximum conformance limit(CLK FallTime_LimitMax). For CTS v1.0, the minimum conformance limit(CLK FallTime_LimitMin) is 150ps and the maximum conformance limit(CLK FallTime_LimitMax) is 0.3UI. For CTS v1.1, the minimum conformance limit(CLK FallTime_LimitMin) is 150ps for Datarate $\leq$ 1Gbps, 100ps for Datarate $>$ 1Gbps. The maximum conformance limit(CLK FallTime_LimitMax) is 0.3*UI for Datarate $\leq$ 1Gbps, 0.35*UI for Datarate $>$ 1Gbps. The VOD(0) and VOD(1) measured from Clock Lane in Test 1.4.4 will be used to calculate 20/80% reference voltage for fall time measurement in this test.
1.4.12 HS Clock TX 80%-20% Fall Time (tF)[Burst Clock]	181111	This test is to verify that the 80%-20% fall time of the HS differential signal is less than the maximum conformance limit(CLK FallTime_LimitMax). For CTS v1.2, the maximum conformance limit(CLK FallTime_LimitMax) is 0.3*UI for Datarate $\leq$ 1Gbps, 0.35*UI for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, 0.4*UI for Datarate $>$ 1.5Gbps. This test is applicable for Burst Clock signal only. The VHS_ZERO level measured from Clock Lane will be used to calculate 20/80% reference voltage for fall time measurement in this test.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.4.12 HS Clock TX 80%-20% Fall Time (tF)[Burst Clock](Min Conformance Limit)(Informative)	181114	This test is an informative test. This test is to verify that the 80%-20% fall time of the HS differential signal is greater than the minimum conformance limit(CLKFallTime_LimitMin). For CTS v1.2, the minimum conformance limit(CLKFallTime_LimitMin) is for informative purpose only: CLKFallTime_LimitMin is 150ps for Datarate $\leq$ 1Gbps, 100ps for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, 50ps for Datarate $>$ 1.5Gbps. This test is applicable for Burst Clock signal only. The VHS_ZERO level measured from Clock Lane will be used to calculate 20/80% reference voltage for fall time measurement in this test.
1.4.12 HS Clock TX 80%-20% Fall Time (tF)[Continuous Clock, Burst Data]	181112	This test is to verify that the 80%-20% fall time of the HS differential signal is less than the maximum conformance limit(CLKFallTime_LimitMax). For CTS v1.2, the maximum conformance limit(CLKFallTime_LimitMax) is $0.3*UI$ for Datarate $\leq$ 1Gbps, $0.35*UI$ for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, $0.4*UI$ for Datarate $>$ 1.5Gbps. This test is applicable for Continuous Clock and Burst Data signal only. The VHS_ZERO level measured from Data Lane will be used to calculate 20/80% reference voltage for fall time measurement in this test.
1.4.12 HS Clock TX 80%-20% Fall Time (tF)[Continuous Clock, Burst Data](Min Conformance Limit)(Informative)	181115	This test is an informative test. This test is to verify that the 80%-20% fall time of the HS differential signal is greater than the minimum conformance limit(CLKFallTime_LimitMin). For CTS v1.2, the minimum conformance limit(CLKFallTime_LimitMin) is for informative purpose only: CLKFallTime_LimitMin is 150ps for Datarate $\leq$ 1Gbps, 100ps for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, 50ps for Datarate $>$ 1.5Gbps. This test is applicable for Continuous Clock and Burst Data signal only. The VHS_ZERO level measured from Data Lane will be used to calculate 20/80% reference voltage for fall time measurement in this test.
1.4.12 HS Clock TX 80%-20% Fall Time (tF)[Continuous Clock, Continuous Data]	181113	This test is to verify that the 80%-20% fall time of the HS differential signal is less than the maximum conformance limit(CLKFallTime_LimitMax). For CTS v1.2, the maximum conformance limit(CLKFallTime_LimitMax) is $0.3*UI$ for Datarate $\leq$ 1Gbps, $0.35*UI$ for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, $0.4*UI$ for Datarate $>$ 1.5Gbps. This test is applicable for Continuous Clock and Continuous Data signal only. The VOD(0) and VOD(1) measured from Clock Lane in Test 1.4.4 will be used to calculate 20/80% reference voltage for fall time measurement in this test.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.4.12 HS Clock TX 80%-20% Fall Time (tF)[Continuous Clock, Continuous Data](Min Conformance Limit)(Informative)	181116	This test is an informative test. This test is to verify that the 80%-20% fall time of the HS differential signal is greater than the minimum conformance limit(CLKFallTime_LimitMin). For CTS v1.2, the minimum conformance limit(CLKFallTime_LimitMin) is for informative purpose only: CLKFallTime_LimitMin is 150ps for Datarate $\leq$ 1Gbps, 100ps for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps, 50ps for Datarate $>$ 1.5Gbps. This test is applicable for Continuous Clock and Continuous Data signal only. The VOD(0) and VOD(1) measured from Clock Lane in Test 1.4.4 will be used to calculate 20/80% reference voltage for fall time measurement in this test.
1.4.13 HS Exit: CLK TX TCLK-TRAIL	543	Time to drive HS differential state after last payload clock bit of HS transmission burst.
1.4.14 HS Exit: CLK TX TREOT	559	30%-85% rise time and fall time
1.4.15 HS Exit: CLK TX TEOT	544	Time from start of TCLK-TRAIL period to start of LP-11 state. CLKTEOT_LimitMax is based on $105ns+n*12*UI$ .
1.4.16 HS Exit: CLK TX THS-EXIT	556	Time to drive LP-11 after HS burst.
1.4.17 HS Clock Instantaneous (UIinst)(Max)	911	Maximum UI instantaneous of HS Clock.
1.4.17 HS Clock Instantaneous (UIinst)(Min)	914	Minimum UI instantaneous (Min) of HS Clock.
1.4.18 Clock Lane HS Clock Delta UI (UI variation)	1911	This test is to verify that the Clock lane HS Clock Delta UI is in between the minimum conformance limit(UIVariant_Limit_Min) and the maximum conformance limit(UIVariant_Limit_Max). For CTS v1.1, UIVariant_Limit_Min is -10% and UIVariant_Limit_Max is 10% for Datarate $\leq$ 1Gbps, UIVariant_Limit_Min is -5% and UIVariant_Limit_Max is 5% for Datarate $>$ 1Gbps. For CTS v1.2, UIVariant_Limit_Min is -10% and UIVariant_Limit_Max is 10% for Datarate $\leq$ 1Gbps, UIVariant_Limit_Min is -5% and UIVariant_Limit_Max is 5% for Datarate $>$ 1Gbps and $\leq$ 1.5Gbps .
1.4.2 HS Entry: CLK TX TCLK-PREPARE	552	Time to drive LP-00 to prepare for HS clock transmission.
1.4.3 HS Entry: CLK TX TCLK-PREPARE+TCLK-ZERO	554	TCLK-PREPARE + Time for lead HS-0 drive period before starting Clock.
1.4.4 HS Clock TX Differential Voltage(VODO Pulse)	18131	HS clock transmitter differential voltage.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.4.4 HS Clock TX Differential Voltage(VOD1 Pulse)	18132	HS clock transmitter differential voltage.
1.4.5 HS Clock TX Differential Voltage Mismatch (Pulse)	18141	VOD mismatch when output is Differential-1 or Differential-0.
1.4.6 HS Clock TX Single Ended Output High Voltage(VOHHS Pulse)	18151	HS Single Ended output high voltage.
1.4.7 HS Clock TX Static Common Mode Voltage(Vcmtx)	1811	HS transmit static common-mode voltage for Clock.
1.4.8 HS Clock TX Vcmtx Mismatch	1812	VCMTX mismatch when output is Differential-1 or Differential-0.
1.4.9 HS Clock TX Common-Level Variations Between 50-450MHz (VCMTX(LF))	1819	Common-level variation between 50-450MHz.
1.5.1 HS Entry: CLK TX TCLK-PRE	551	Time that the HS clock shall be driven prior to any associated Data Lane beginning the transition time from LP to HS mode. TCLKPRE_LimitMin is based on 8*UI.
1.5.2 HS Exit: CLK TX TCLK-POST	555	Time that the transmitter shall continue sending HS clock after the last associated Data Lane has transitioned to LP mode. TCLKPOST_LimitMin is based on 60ns+52*UI.
1.5.3 HS Clock Rising Edge Alignment to First Payload Bit	912	Test will pass when there is a rising edge during the first payload bit. "First Payload Bit Alignment" will be set to "PASS" ONLY when a rising edge is detected during the first payload bit.
1.5.4 Data-to-Clock Skew (TSKEW(TX))(Max,Min)	913	Data to Clock Skew [measured at transmitter].
1.5.4 Data-to-Clock Skew (TSKEW(TX))(Mean)	9131	Data to Clock Skew [measured at transmitter].
1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL)	918	TSKEWCAL measurement for repetitive initial HS skew calibration burst on Data Lane. To verify that TSKEWCAL is at least 32768UI.
1.5.5 Initial HS Skew Calibration Burst(TSKEWCAL-SYNC)	917	TSKEWCAL-SYNC measurement for repetitive initial HS skew calibration burst on Data Lane. To verify that TSKEWCAL-SYNC is within the range of $(16 \pm 0.25UI)$ .
1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL)	920	TSKEWCAL measurement for repetitive periodic HS skew calibration burst on Data Lane. To verify that TSKEWCAL is at least 4096UI.

**Table 4** Test IDs and Names (continued)

Name	TestID	Description
1.5.6 Periodic HS Skew Calibration Burst(TSKEWCAL-SYNC)	919	TSKEWCAL-SYNC measurement for repetitive periodic HS skew calibration burst on Data Lane. To verify that TSKEWCAL-SYNC is within the range of $(16 \pm 0.25UI)$ .
HS Data Eye Height (Informative)	915	HS Data Eye Height
HS Data Eye Width (Informative)	916	HS Data Eye Width.



## 4 Instruments

The following table shows the instruments used by this application. The name is required by various remote interface methods.

- Instrument Name – The name to use as a parameter in remote interface commands.
- Description – The description of the instrument.

For example, if an application uses an oscilloscope and a pulse generator, then you would expect to see something like this in the table below:

**Table 5** Example Instrument Information

Name	Description
scope	The primary oscilloscope.
Pulse	The pulse generator used for Gen 2 tests.

and you would be able to remotely control an instrument using:

ARSL syntax (replace [description] with actual parameter)

```
-----  
arsl -a ipaddress -c "SendScpiCommandCustom 'Command=[scpi  
command];Timeout=100;Instrument=pulsegen'"
```

```
arsl -a ipaddress -c "SendScpiQueryCustom 'Command=[scpi  
query];Timeout=100;Instrument=pulsegen'"
```

C# syntax (replace [description] with actual parameter)

```
-----  
SendScpiCommandOptions commandOptions = new SendScpiCommandOptions();  
commandOptions.Command = "[scpi command]";  
commandOptions.Instrument = "[instrument name]";  
commandOptions.Timeout = [timeout];  
remoteAte.SendScpiCommand(commandOptions);
```

```
SendScpiQueryOptions queryOptions = new SendScpiQueryOptions();  
queryOptions.Query = "[scpi query]";  
queryOptions.Instrument = "[instrument name]";
```

```
queryOptions.Timeout = [timeout];  
remoteAte.SendScpiQuery(queryOptions);
```

Here are the actual instrument names used by this application:

**NOTE**

The file, "InstrumentInfo.txt", which may be found in the same directory as this help file, contains all of the information found in the table below in a format suitable for parsing.

---

**Table 6** Instrument Names

Instrument Name	Description
scope	The primary oscilloscope.

# Index

## C

configuration variables and values, [9](#)  
copyright, [2](#)

## I

IDs and names of tests, [33](#)  
instrument names, [49](#)

## N

names and IDs of tests, [33](#)  
names of instruments, [49](#)  
notices, [2](#)

## P

programming, introduction to, [7](#)

## R

Remote Programming Toolkit, [8](#)

## T

test names and IDs, [33](#)  
trademarks, [2](#)

## V

variables and values, configuration, [9](#)

## W

warranty, [2](#)

