



75000 Series C

User Manual

Keysight E1463A 32-Channel 5-Amp Form C Switch

Notices

© Keysight Technologies, Inc. 1996-2019

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Manual Part Number

E1463-90004

Edition

Fifth Edition, October 2019

Published by

Keysight Technologies, Inc.
900 S. Taft Ave.
Loveland, CO 80537 USA

Sales and Technical Support

To contact Keysight for sales and technical support, refer to the support links on the following Keysight websites:

www.keysight.com/find/E1463A

(product-specific information and support, software and documentation updates)

www.keysight.com/find/assist (world-wide contact information for repair and service)

Declaration of Conformity

Declarations of Conformity for this product and for other Keysight products may be downloaded from the Web. Go to <http://keysight.com/go/conformity> and click on "Declarations of Conformity." You can then search by product number to find the latest Declaration of Conformity.

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR OF ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT SHALL CONTROL.

Keysight Technologies does not warrant third-party system-level (combination of chassis, controllers, modules, etc.) performance, safety, or regulatory compliance unless specifically stated.

DFARS/Restricted Rights Notices

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Safety Information

The following general safety precautions must be observed during all phases of operation of this instrument. Failure to comply with these precautions or with specific warnings or operating instructions in the product manuals violates safety standards of design, manufacture, and intended use of the instrument. Keysight Technologies assumes no liability for the customer's failure to comply with these requirements.

General

Do not use this product in any manner not specified by the manufacturer. The protective features of this product must not be impaired if it is used in a manner specified in the operation instructions.

Before Applying Power

Verify that all safety precautions are taken. Make all connections to the unit before applying power. Note the external markings described under "Safety Symbols".

Ground the Instrument

Keysight chassis' are provided with a grounding-type power plug. The instrument chassis and cover must be connected to an electrical ground to minimize shock hazard. The ground pin must be firmly connected to an electrical ground (safety ground) terminal at the power outlet. Any interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in personal injury.

Do Not Operate in an Explosive Atmosphere

Do not operate the module/chassis in the presence of flammable gases or fumes.

Do Not Operate Near Flammable Liquids

Do not operate the module/chassis in the presence of flammable liquids or near containers of such liquids.

Cleaning

Clean the outside of the Keysight module/chassis with a soft, lint-free, slightly dampened cloth. Do not use detergent or chemical solvents.

Do Not Remove Instrument Cover

Only qualified, service-trained personnel who are aware of the hazards involved should remove instrument covers. Always disconnect the power cable and any external circuits before removing the instrument cover.

Keep away from live circuits

Operating personnel must not remove equipment covers or shields. Procedures involving the removal of covers and shields are for use by service-trained personnel only. Under certain conditions, dangerous voltages may exist even with the equipment switched off. To avoid dangerous electrical shock, DO NOT perform procedures involving cover or shield removal unless you are qualified to do so.

DO NOT operate damaged equipment

Whenever it is possible that the safety protection features built into this product have been impaired, either through physical damage, excessive moisture, or any other reason, REMOVE POWER and do not use the product until safe operation can be verified by service-trained personnel. If necessary, return the product to a Keysight Technologies Sales and Service Office for service and repair to ensure the safety features are maintained.

DO NOT block the primary disconnect

The primary disconnect device is the appliance connector/power cord when a chassis used by itself, but when installed into a rack or system the disconnect may be impaired and must be considered part of the installation.

Do Not Modify the Instrument

Do not install substitute parts or perform any unauthorized modification to the product. Return the product to a Keysight Sales and Service Office to ensure that safety features are maintained.

In Case of Damage

Instruments that appear damaged or defective should be made inoperative and secured against unintended operation until they can be repaired by qualified service personnel

CAUTION

Do NOT block vents and fan exhaust: To ensure adequate cooling and ventilation, leave a gap of at least 50mm (2") around vent holes on both sides of the chassis.

Do NOT operate with empty slots: To ensure proper cooling and avoid damaging equipment, fill each empty slot with an AXle filler panel module.

Do NOT stack free-standing chassis: Stacked chassis should be rack-mounted.

All modules are grounded through the chassis: During installation, tighten each module's retaining screws to secure the module to the chassis and to make the ground connection.

WARNING

Operator is responsible to maintain safe operating conditions. To ensure safe operating conditions, modules should not be operated beyond the full temperature range specified in the Environmental and physical specification. Exceeding safe operating conditions can result in shorter lifespan, improper module performance and user safety issues. When the modules are in use and operation within the specified full temperature range is not maintained, module surface temperatures may exceed safe handling conditions which can cause discomfort or burns if touched. In the event of a module exceeding the full temperature range, always allow the module to cool before touching or removing modules from the chassis.

Safety Symbols

CAUTION

A CAUTION denotes a hazard. It calls attention to an operating procedure or practice, that, if not correctly performed or adhered to could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

WARNING

A WARNING denotes a hazard. It calls attention to an operating procedure or practice, that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

Products display the following symbols:



Warning, risk of electric shock



Refer to manual for additional safety information.



Earth Ground.



Chassis Ground.



Alternating Current (AC).



Direct Current (DC)

Contents

2 Getting Started

Using This Chapter	13
Form C Switch Description	13
Basic Operation	13
Typical Configurations	15
Configuring the Form C Switch	17
Warnings and Cautions	17
Setting the Logical Address Switch	17
Setting the Interrupt Priority	18
Installing the Form C Switch in a Mainframe	19
Configuring a Terminal Module	21
Standard Terminal Module Description	21
Terminal Module Option A3G Description	22
Connecting User Inputs	23
Wiring a Terminal Module	24
Attaching a Terminal Module to the Form C Switch	26
Protecting Relays and Circuits	27
Relay Life Factors	27
Extending Relay Life	28
Adding Relay and Circuit Protection	29
Maximum Allowable Module Switch Current	30
Programming the Form C Switch	32
Using SCPI Commands	32
Addressing the Form C Switch	33
Initial Operation	34

3 Using the Form C Switch

Using This Chapter	37
Form C Switch Commands	38
Power-on and Reset Conditions	38
Module Identification	39
Example: Module Identification (BASIC)	39
Example: Module Identification (TURBO C)	39
Switching Channels	41
Example: Opening/Closing Channels (BASIC)	41
Example: Voltage Switching (BASIC)	41
Example: Controlling RF Switches/Step Attenuators (BASIC)	42

Example: Digital Output Configuration (BASIC)	44
Example: Matrix Switching (BASIC)	44
Scanning Channels	47
Example: Scanning Using Trig In and Trig Out Ports (BASIC)	47
Example: Scanning Using the TTL Trigger Bus (BASIC)	49
Querying the Form C Switch	51
Example: Querying Channel Closures (BASIC)	51
Using the Scan Complete Bit.	51
Example: Using the Scan Complete Bit (BASIC)	52
Saving and Recalling States	53
Example: Saving and Recalling State (BASIC)	53
Detecting Error Conditions	54
Example: Detecting Error Conditions (BASIC)	54
Example: Detecting Error Conditions (Turbo C)	54
Synchronizing the Form C Switch	55
Example: Synchronizing the Form C Switch (BASIC)	55

4 E1463A Command Reference

Using This Chapter.	57
Command Types.	57
Common Command Format	57
SCPI Command Format	57
Command Separator.	58
Abbreviated Commands	58
Implied Commands	58
Variable Command Syntax	59
SCPI Command Reference.	60
ABORT.	60
Subsystem Syntax.	60
ARM	61
Subsystem Syntax.	61
ARM:COUNT	61
ARM:COUNT?	62
DISPlay	63
Subsystem Syntax.	63
DISPlay:MONitor:CARD	63
DISPlay:MONitor[:STATe]	64
INITiate	65
Subsystem Syntax.	65
INITiate:CONTinuous.	65

INITiate:CONTinuous?	66
INITiate[:IMMediate]	66
OUTPut	67
Subsystem Syntax	67
OUTPut:EXTernal[:STATe]	67
OUTPut:EXTernal[:STATe]?	68
OUTPut[:STATe]	68
OUTPut[:STATe]?	69
OUTPut:TTLTrgn[:STATe]	69
OUTPut:TTLTrgn[:STATe]?	70
[ROUTe:]	71
[ROUTe:]CLOSe	71
[ROUTe:]CLOSe?	72
[ROUTe:]OPEN	73
[ROUTe:]OPEN?	74
[ROUTe:]SCAN	74
STATus	76
Subsystem Syntax	76
STATus:OPERation:CONDition?	78
STATus:OPERation:ENABle	78
STATus:OPERation:ENABle?	78
STATus:OPERation[:EVENT]?	79
STATus:PRESet	80
SYSTem	81
Subsystem Syntax	81
SYSTem:CDEscription?	81
SYSTem:CPON	82
SYSTem:CTYPe?	82
SYSTem:ERRor?	83
TRIGger	84
Subsystem Syntax	84
TRIGger[:IMMediate]	84
TRIGger:SOURce	85

TRIGger:SOURce?	87
SCPI Commands Quick Reference.	88
IEEE 488.2 Common Commands Reference	89

A Form C Switch Specifications

B Register-Based Programming

About This Appendix	93
Register Programming vs. SCPI Programming	93
Addressing the Registers	93
The Base Address	94
A16 Address Space Outside the Command Module	94
A16 Address Space Inside the Command Module or Mainframe	94
Register Offset.	95
Register Descriptions.	96
Reading and Writing to the Registers	96
Manufacturer Identification Register	96
Device Type Register.	96
Status/Control Register	97
Reading the Status/Control Register	97
Relay Control Register	98
Programming Examples.	99
Example: Reading the Registers (BASIC)	99
Example: Reading the Registers (C/HP-UX)	100
Example: Making Measurements (BASIC)	101
Example: Making Measurements (C/HP-UX)	102
Example: Scanning Channels (BASIC)	104
Example: Scanning Channels (C/HP-UX).	105

C E1463A Error Messages

Error Types	107
Error Messages.	108

1 Getting Started

Using This Chapter

This chapter gives guidelines to get started using the E1463A 32-Channel, 5 Amp Form C Switch module (Form C switch), including:

Form C Switch Description	page 13
Configuring the Form C Switch	page 17
Configuring a Terminal Module	page 21
Protecting Relays and Circuits	page 27
Programming the Form C Switch	page 32

Form C Switch Description

The E1463A 32-Channel, 5 Amp, Form C Switch module (Form C switch) is defined as a VXIbus *instrument*. VXIbus plug-in modules installed in a mainframe or used with a command module are treated as independent instruments each having a unique secondary address.

Each instrument is also assigned a dedicated error queue, input and output buffers, status registers and, if applicable, dedicated mainframe/command module memory space for readings or data. An instrument may be composed of a single plug-in module (such as a counter) or multiple plug-in modules (for a switchbox or scanning multimeter instrument).

Basic Operation

The Form C switch is a C-Size VXIbus and VMEbus register-based product that can be used for switching, scanning, and control. The switch can operate in a C-Size VXIbus or VMEbus mainframe. The switch has 32 channels of Form C relays. Each channel includes a relay with common (C), normally open (NO), and normally closed (NC) contacts.

For the Form C switch, switching consists of opening or closing a channel relay to provide alternate connections to user devices. Scanning consists of closing a set of relays, one at a time.

As shown in Figure 1-1, the Form C switch module consists of 32 channels (channels 00 through 31). Each channel uses a nonlatching relay. Varistors (MOVs) can be added for relay protection and resistors or fuses can be added for circuit protection. See "Adding Relay and Circuit Protection" for more information on protecting relays.

External pull-up resistors can also be added for digital output applications. See "Digital Output Configuration" for additional information about these applications.




Figure 1-1 Form C Switch Simplified Schematic

Each channel is switched by opening or closing the appropriate channel relay. Since the relays are nonlatching, the relays are all open during power-up or power-down.

When a reset occurs, all channel commons (C) are connected to the corresponding normally closed (NC) contacts. When a channel is closed, the common contact (C) is connected to the normally open contact (NO). User inputs and outputs to each channel are via the NO, NC, and C terminal connectors on the terminal module.

Typical Configurations

The Form C switch accepts user inputs up to 125 Vdc or 250 Vrms. Maximum rated power capacity (external load) is 150 Wdc or 1250 VA per channel. Per module, you can switch 1500 Wdc or 12500 VA.

As noted, the switch may be configured for general purpose switching/scanning or digital output applications. For general purpose switching or scanning, no additional configuration is required. To configure the switch for digital output applications, install external pull-up resistors as required.

Multiple Form C switch modules can be configured as a switchbox instrument. When using a switchbox instrument, multiple Form C switch modules within the switchbox instrument can be addressed using a single interface address. This configuration, however, requires the use of Standard Commands for Programmable Instruments (SCPI).

General Purpose Relay Configuration

As factory-configured, the Form C switch module is set for general purpose relay configuration. For this configuration, you can switch channels by opening or closing channel relays or you can scan a set of channels.

Figure 1-2 shows a typical general purpose relay configuration for channel 00. When the relay is open (NC terminal is connected to the C terminal), load 1 is connected. When the relay is closed (NO terminal is connected to the C terminal), load 2 is connected.




Figure 1-2 General Purpose Relay Configuration

Digital Output Configuration

By installing external pull-up resistors, the Form C switch can be configured as a digital output device. Figure 1-3 shows channel 00 configured for digital output operation. When the channel 00 relay is open (NC connected to C), point 1 is at +V. When the channel 00 relay is closed (NO connected to C), point 1 is at 0V.




Figure 1-3 Digital Output Configuration

Configuring the Form C Switch

This section gives guidelines to configure the Form C switch, including the following topics. See "Configuring a Terminal Module" for guidelines to configure the terminal modules. Section topics include:

- Warnings and Cautions
- Setting the Logical Address Switch
- Setting the Interrupt Priority
- Installing the Form C Switch in a Mainframe

Warnings and Cautions

WARNING

SHOCK HAZARD. Only qualified, service-trained personnel who are aware of the hazards involved should install, configure, or remove the Form C switch module. Use only wire rated for the highest input voltage and remove all power sources from the mainframe and installed modules before installing or removing a module.

CAUTION

MAXIMUM VOLTAGE/CURRENT. Maximum allowable voltage per channel for the Form C switch is 125 Vdc or 250 Vrms. Maximum current per channel is 5 Adc or ac rms (non-inductive). Maximum power of an external load is 150 W or 1250 VA per channel or 1500 W or 12500 VA per module. Exceeding any limit may damage the Form C switch.

CAUTION

STATIC ELECTRICITY. Static electricity is a major cause of component failure. To prevent damage to the electrical components in the Form C switch, observe anti-static techniques whenever removing a module from the mainframe or whenever working on a module. The Form C switch is susceptible to static discharges. Do not install the Form C switch without its metal shield attached.

Setting the Logical Address Switch

The logical address switch (LADDR) factory setting is 120. Valid addresses are from 1 to 255. The Form C switch can be configured as a single instrument or as a switchbox. See Figure 1-4 for switch position information.

NOTE

The address switch selected value must be a multiple of 8 if the module is the first module in a switchbox used with a VXIbus command module and is being instructed by SCPI commands.




Figure 1-4 Setting the Logical Address Switch

Setting the Interrupt Priority

The Form C switch generates an interrupt after a channel has been closed. These interrupts are sent to, and acknowledgments are received from, the command module (E1406, for example) via the VXIbus backplane interrupt lines.

For most applications where the Form C switch is installed in a C-Size mainframe, the interrupt priority jumper does not have to be moved. This is because the VXIbus interrupt lines have the same priority and interrupt priority is established by installing modules in slots numerically closest to the command module. Thus, slot 1 has a higher priority than slot 2, slot 2 has a higher priority than slot 3, etc.

See Figure 1-5 to change the interrupt priority. You can select eight different interrupt priority levels. Level 1 is the lowest priority and Level 7 is the highest priority. Level X disables the interrupt. The Form C switch factory setting is Level

1. To change the interrupt priority, remove the 4-pin jumper from the old priority location and reinstall in the new priority location. If the 4-pin jumper is not used, the two jumper locations must have the same interrupt priority level selected.

NOTE

The interrupt priority jumper **MUST** be installed in position 1 when using the E1406 Command Module. Level X interrupt priority should not be used under normal operating conditions. Changing the priority level jumper is not recommended. Do not change unless specifically instructed to do so.




Figure 1-5 Setting the Interrupt Priority

Installing the Form C Switch in a Mainframe

The E1463A may be installed in any slot, except slot 0, in a C-size VXibus mainframe. See Figure 1-6 to install the Form C switch in a mainframe.




Figure 1-6 Installing the Form C Switch in a VXIbus Mainframe

Configuring a Terminal Module

The E1463A 32-Channel, 5 Amp, Form C Switch consists of a relay switch card and a screw type standard terminal module. In addition, a solder eye terminal module (Option A3G) is available. User inputs to the Form C switch are to the normally open (NO), normally closed (NC), and common (C) terminal connectors on the terminal module. This section shows how to configure the terminal modules, including:

- Standard Terminal Module Description
- Terminal Module Option A3G Description
- Connecting User Inputs
- Wiring a Terminal Module
- Attaching a Terminal Module to the Form C Switch

Standard Terminal Module Description

Figure 1-7 shows the standard screw type terminal module connectors and associated channel numbers.




Figure 1-7 Standard Screw-type Terminal Module

Terminal Module Option A3G Description

Option A3G provides a plastic terminal module housing with solder eye connectors (see Figure 1-8) that allows you to solder wires onto connectors which are then inserted directly into the mating connector of the Form C switch. See Figure 1-9 for pin-outs.




Figure 1-8 Option A3G Terminal Module

Connecting User Inputs

Figure 1-9 shows the front panel of the E1463A and the Form C switch connector pin-out that mates to the terminal module. Actual user inputs are connected to the applicable terminal module.




Figure 1-9 Form C Switch Pin-outs

Wiring a Terminal Module

Figures 1-10 and 1-11 show how to connect field wiring to the terminal module. When making wiring connections, be sure the wires make good connections on screw terminals. Maximum terminal wire size is No. 16 AWG. When wiring all channels, a smaller gauge wire (No. 20 - 22 AWG) is recommended. Wire ends should be stripped 6 mm (0.25 inch) and tinned to prevent single strands from shorting to adjacent terminals.





Figure 1-10 Wiring a Terminal Module (continued on next page)

**Figure 1-11** Wiring a Terminal Module

Attaching a Terminal Module to the Form C Switch

Figure 1-12 gives guidelines to attach a terminal module to the Form C switch.




Figure 1-12 Attaching a Terminal Module to the Form C Switch

Protecting Relays and Circuits

This section gives guidelines to protect relays and circuits in the Form C switch, including:

- Relay Life Factors
- Extending Relay Life
- Adding Relay and Circuit Protection
- Maximum Allowable Module Switch Current

NOTE

Relays that wear out normally or fail due to misuse should not be considered defective and are not covered by the product's warranty.

Relay Life Factors

Relays have a shorter life span than other electronic parts, such as ICs. Because of their mechanical nature, relays usually have about 10 million operations (at 30 operations per second) which is not quite 100 hours. Therefore, to get the full life out of a relay in a switching module, you must protect the relay.

Loading and Switching Frequency

Electromechanical relays are subject to normal wear-out. Relay life depends on several factors. The effects of loading and switching frequency are:

Relay Load. In general, higher power switching reduces relay life. In addition, capacitive/inductive loads and high inrush currents (for example, turning on a lamp or starting a motor) reduces relay life.

CAUTION

Exceeding specified maximum inputs can cause catastrophic failure.

Switching Frequency. Relay contacts heat up when switched. As the switching frequency increases, the contacts have less time to dissipate heat. The resulting increase in contact temperature also reduces relay life.

End-of-Life Detection

A preventive maintenance routine can prevent problems caused by unexpected relay failure. The end of the life of the relay can be determined by using one or more of the following three methods. The best method (or combination of methods), as well as the failure criteria, depends on the application in which the relay is used.

Contact Resistance. As the relay begins to wear out, its contact resistance increases. When the resistance exceeds a predetermined value, the relay should be replaced.

Stability of Contact Resistance. The stability of the contact resistance decreases with age. Using this method, the contact resistance is measured several (5-10) times and the variance of the measurements is determined. An increase in the variance indicates deteriorating performance.

Number of Operations. Relays can be replaced after a predetermined number of contact closures. However, this method requires knowledge of the applied load and life specifications for the applied load.

Replacement Strategy

The replacement strategy depends on the application. If some relays are used more often, or at a higher load, than the others, the relays can be individually replaced as needed. If all the relays see similar loads and switching frequencies, the entire circuit board can be replaced when the end of relay life approaches. The sensitivity of the application should be weighed against the cost of replacing relays with some useful life remaining.

Extending Relay Life

To help ensure full life for the relays, you should consider the following items.

Be aware of non-resistive loads. When switching inductive loads, high voltages (thousands of volts) are produced across the relay contacts. This causes arcing and transfer of material between contacts. Oxides and carbides from components of the atmosphere coat the contacts and cause high contact resistance.

The transfer of material creates hills and valleys that lock together to "weld" contacts. Motor loads, for example, produce large inrush currents that can be 5 to 10 times greater than the steady state current. Table 1-1 summarizes inrush current magnitudes for different types of loads.

Table 1-1 Inrush Currents

Type of Load	Inrush Current Times Steady State	Type of Load	Inrush Current Times Steady State
Resistive	1	Incandescent Lamp	10 - 15
Capacitive	20 - 40	Mercury Lamp	3
Solenoid	10 - 20	Sodium Vapor Lamp	1 - 3
Motor	5 - 10	Transformer	5 - 15

Be aware of heavy current applications. When a relay is used in heavy current applications, the thin layer of gold plating on the contact may be destroyed. This will not affect the heavy current application. However, if you go back to a low current application, a high contact resistance may be present and the relay cannot be used for low current applications.

Use protective circuits with relay connections. The relay manufacturer (Aromat) recommends some protective circuits that can be used with your relay connections. See the *Aromat Technical Data Book* (AGC-C0064-A-1) for additional information. Contact Aromat at (408) 433-0466 for more information.

Do not use capacitors. Capacitors are not to be placed across the load or relay contacts. Capacitors may suppress arcs, but the energy stored in the capacitors will flow through the relay contacts, welding them.

Adding Relay and Circuit Protection

The Form C switch has space for adding relay and circuit protection. Relay protection can be added by placing a protective device across the specified pads. This is done by adding metal oxide varistors (MOVs) between the common (C) and normally open (NO) or normally closed (NC) terminals. As the voltage goes up, the varistor draws current to protect the relay.

Circuit protection can be added by placing a protective device in series with the common lead. This is done by adding a resistor between the common (C) terminal and your circuit. When installing circuit protection, a jumper must be removed first.

To install these protective devices it is necessary to remove the sheet metal covers from the module. The locations for installing the devices are labeled as shown in Table 1-2, where xx = the channel number. Do not install a capacitor in any of these locations. Figure 1-13 shows locations where these protective devices can be added.

Table 1-2 Protective Devices Board Locations

Relay Protection	Circuit Protection
VxxO	Varistor location across common (C) and normally open (NO).
VxxC	Varistor location across common (C) and normally closed (NC).
Circuit Protection	
JMxx	Resistor or fuse location in series with common (C).




Figure 1-13 Adding Relay and Circuit Protection

Maximum Allowable Module Switch Current

The Form C switch has an individual channel current specification of 5A. However, if you apply 5A to all the channels with a relay contact resistance of .25 Ohms, the power dissipation is 200 W. Since, for example, the E1401B mainframe can only provide cooling for 55W per slot (to keep the temperature rise to 10°C), this cannot be allowed to happen.

A reasonable maximum current for the entire mainframe is 50A. That is, 10 channels each carrying 5A or some combination of channels and currents that total 50A. This will produce about 67.5 W of internal dissipation, leading to an approximate 15°C temperature rise.

Figure 1-14 shows a typical way to derate the channels, in terms of current throughout the channels, to keep internal power dissipation under 45 W and 67.5 W or 10°C and 15°C temperature rise, respectively.




Figure 1-14 Typical Form C Switch Allowable Switch Current

Programming the Form C Switch

This section gives guidelines to program the Form C switch, including:

- Using SCPI Commands
- Addressing the Form C Switch
- Initial Operation

Using SCPI Commands

There are several ways you can program the Form C switch. One way is to write directly to the registers. This method can provide better throughput speed. However, it requires more knowledge of the Form C switch design.

Another way to program the Form C switch is to use an E1406 Command Module and SCPI commands. With SCPI commands, the command module parses the commands and writes to the appropriate Form C switch register.

You can use different controllers and different programming languages. However, most examples in this manual use SCPI commands and an HP 9000 Series 200/300 (or equivalent) computer running BASIC or a PC with an 82350A (or equivalent) Interface Card (with command library) running Borland® Turbo C.

NOTE

Most examples in this manual use SCPI commands. See Appendix B for information on writing directly to the registers.

To address specific channels (relays) within a Form C switch, you must specify the SCPI command and switch channel list. Table 1-3 lists the most commonly used commands.

Table 0-1. Typical SCPI Commands

SCPI Command	Description
CLOSE <channel_list>	Connects the normally open (NO) terminal to the common (C) terminal for the channels specified.
OPEN <channel_list>	Connects the normally closed (NC) terminal to the common (C) terminal for the channels specified.
SCAN <channel_list>	Closes the set of Form C relays, one at a time.

Addressing the Form C Switch

Relays (channels) within the Form C switch are addressed using the *channel_list* statement. The *channel_list* is a combination of the switch card number and the channel numbers. The *channel_list* takes the form @ccnn where cc = switch card number (01-99) and nn = channel number (00-31).

Card Numbers

The card number (cc of the *channel_list*) identifies the module within a switchbox. The card number assigned depends on the switch configuration used. Leading zeroes can be ignored for the card number.

In a *single-module switchbox* configuration, the card number is always 01.
In a *multiple-module switchbox* configuration, modules are set to successive logical addresses.

The module with the lowest logical address is always card number 01. The module with the next successive logical address is card number 02, etc. Figure 1-15 illustrates card numbers and logical addresses of a typical multiple-module switchbox configuration.




Figure 1-15 Typical Card Numbers in a Multiple-module Switchbox

Channel Addresses

The channel address (nn of the channel list) determines which relay on the selected card will be addressed. Form C switch channel numbers are 00 through 31. The channels can be addressed using channel numbers or channel ranges:

- single channels (@ccnn);

- multiple channels (@ccnn,ccnn,...);
- sequential channels (@ccnn:ccnn);
- groups of sequential channels (@ccnn:ccnn,ccnn:ccnn);
- or any combination of the above.

Use a comma (,) to form a channel list or a colon (:) to form a channel range. Only valid channels can be accessed in a channel list or channel range. Also, the channel range must be from a lower channel number to a higher channel number. For example, **CLOS(@100:215)** is acceptable, but **CLOS(@215:100)** generates an error.

Initial Operation

Two example programs follow to help get you started using the Form C switch. The first example assumes an HP 9000 Series 200/300 controller running BASIC and a GPIB interface. The second example assumes a PC running Borland Turbo C and an 82350A (or equivalent) Interface Card (with command library)

Example: Closing a Channel (BASIC)

This program closes channel 02 of a Form C switch at logical address 120 (secondary address = $120/8 = 15$) and queries the channel closure state. The result is returned to the computer and displayed (1 = channel closed, 0 = channel open). See Chapter 3 for information on the SCPI commands.

```
10  OUTPUT 70915;"*RST" ! Reset the module
20  OUTPUT 70915;"CLOS(@102)" ! Close channel 02
30      OUTPUT 70915;"CLOS?(@102)" ! Query channel 02 state
40      ENTER 70915;Value ! Enter result into Value
50      PRINT Value ! Display result
60  END
```

Example: Closing a Channel (TURBO C)

This program closes channel 02 of a Form C switch at logical address 120 (secondary address = $120/8 = 15$) and queries the channel closure state. The result is returned to the computer and displayed (1 = channel closed, 0 = channel open). See Chapter 3 for information on the SCPI commands.

```
#include <stdio.h>
#include <chpib.h>                                /*Include file for
GPIB*/

#define ISC 7L
#define FORMC 70915L                               /*Form C default
address*/
```



```

#define TASK1 "*RST"                                /*Command for a reset*/
#define TASK2 "CLOSE (@102)"                        /*Command to close
channel 02*/ #define TASK3 "CLOS? (@102)"          /*Command to query
channel 02*/

main()
{
    char into[257];
    int length = 256;

    /*Output commands to Form C switch*/
    error_handler (IOTIMEOUT (7L,5.0), "TIMEOUT");
    error_handler (IOOUTPUTS (FORMC, TASK1, 4), "OUTPUT command");
    error_handler (IOOUTPUTS (FORMC, TASK2, 12), "OUTPUT command");
    error_handler (IOOUTPUTS (FORMC, TASK3, 12), "OUTPUT command");

    /*Enter from Form C switch*/
    error_handler (IOENTERS (FORMC, into, &length), "ENTER command");
    printf("Now let's see if the switch is closed: %s",into);
    return;
}

int error_handler (int error, char *routine)
{
    char ch;
    if (error != NOERR)
    {
        printf ("\n Error %d %s \n", error, strerror(error));
        printf (" in call to function %s \n\n", routine);
        printf ("Press 'Enter' to exit: ");
        scanf ("%c", &ch);
        exit(0);
    }
    return 0;
}

```


2 Using the Form C Switch

Using This Chapter

This chapter uses typical examples to show ways to use the E1463A Form C switch module for switching channels and scanning channels. See Chapter 3 for command information. Chapter contents are:

Form C Switch Commands	page 38
Power-on and Reset Conditions	page 38
Module Identification	page 39
Switching Channels	page 41
Scanning Channels	page 47
Querying the Form C Switch	page 51
Using the Scan Complete Bit	page 51
Saving and Recalling States	page 53
Detecting Error Conditions	page 54
Synchronizing the Form C Switch	page 55

NOTE

All examples in this chapter use GPIB select code 7, primary address 09, and secondary address 15 (LADDR = 120).

Form C Switch Commands

Table 2-1 explains some of the SCPI commands used in this chapter.
See Chapter 3 for more information on these commands.

Table 2-1 E1463A Form C Switch Commands Used in Chapter 2

SCPI Command	Command Description
[ROUTe:]CLOSe <channel_list>	Closes the channels in the <channel_list>
[ROUTe:]CLOSe? <channel_list>	Queries the state of the channels in the <channel_list>
[ROUTe:]OPEN <channel_list>	Opens the channels in the <channel_list>
[ROUTe:]OPEN? <channel_list>	Queries the state of the channels in the <channel_list>
[ROUTe:]SCAN <channel_list>	Closes the channels in the <channel_list>, one at a time
INITiate[:IMMediate]	Starts scan sequence and closes first channel in the <channel_list>
TRIGger:SOURce BUS EXT HOLD IMM TTL	Selects the trigger source to advance the scan

Power-on and Reset Conditions

Since the Form C switch module has nonlatching relays, all relays condition are in the normally closed (NC) position at power-down and power-up. The *RST command opens all channels, invalidates the current channel list for scanning and sets the conditions shown in Table 2-2.

Table 2-2 Reset Conditions

Parameter	Default	Description
ARM:COUNT	1	Number of scanning cycles is 1
TRIGger:SOURce	IMM	Will advance scanning cycles automatically
INITiate:CONTinuous	OFF	Number of scanning cycles is set by ARM:COUNT
OUTPut[:STATe]	OFF	Trigger output from EXT or TTL sources is disabled

Module Identification

The following example programs use the *RST, *CLS, *IDN?, SYST:CTYP?, and SYST:CDES commands to reset and identify the E1463A Form C switch module. A typical print for the E1463A Form C switch is:

```
HEWLETT-PACKARD,SWITCHBOX,0,A.04.00
32 Channel General Purpose Relay
HEWLETT-PACKARD,E1463A,0,A.04.00
```

Example: Module Identification (BASIC)

```
10  DIM A$(50), B$(50), C$(50) !Dimensions three string variables to
    fifty characters
20  OUTPUT 70915; "*RST; *CLS" !Outputs the commands to reset and
    clears the status register
30  OUTPUT 70915; "*IDN?" !Queries for module identification
40  ENTER 70915; A$ !Enters the results into A$
50  OUTPUT 70915; "SYST:CDES? 1" !Outputs the command for a card
    description
60  ENTER 70915; B$ !Enters the results into B$
70  OUTPUT 70915; "SYST:CTYP? 1" !Outputs the command for the card
    type
80  ENTER 70915; C$ !Enters the results into C$
90  PRINT A$, B$, C$ !Prints the contents of variables A$, B$, and
    C$
100 END
```

Example: Module Identification (TURBO C)

```
#include <stdio.h>
#include <chpib.h>                                /*Include file for GPIB*/

#define ISC 7L
#define FORMC 70915L                               /*Form C default address*/
#define TASK1 "*RST;*CLS;*IDN?"                   /*Reset, clear, and query
id*/
#define TASK2 "SYST:CDES? 1"                       /*Command for card
description*/
#define TASK3 "SYST:CTYP? 1"                       /*Command for card type*/

main( )
{
    char into1[51], into2[51], into3[51];
    int length = 50;    /*Output and enter commands to Form C*/
```

```

    error_handler (IOTIMEOUT (7L,5.0), "TIMEOUT");
    error_handler (IOOUTPUTS (FORMC, TASK1, 15), "OUTPUT command");
    error_handler (IOENTERS (FORMC, into1, &length), "ENTER command");
    error_handler (IOOUTPUTS (FORMC, TASK2, 12), "OUTPUT command");
    error_handler (IOENTERS (FORMC, into2, &length), "ENTER command");
    error_handler (IOOUTPUTS (FORMC, TASK3, 12), "OUTPUT command");
    error_handler (IOENTERS (FORMC, into3, &length), "ENTER command");

    printf("IDENTIFICATION: %s",into1);
    printf("CARD DESCRIPTION: %s",into2);
    printf("CARD TYPE: %s",into3);
    return;
}
int error_handler (int error, char *routine)
{
    char ch;
    if (error != NOERR)
    {
        printf ("\n Error %d %s \n", error, strerror(error));
        printf (" in call to GPIB function %s \n\n", routine);
        printf ("Press 'Enter' to exit: ");
        scanf ("%c", &ch);
        exit(0);
    }
    return 0;
}

```

Switching Channels

For general purpose relay operation, you can connect or disconnect a load by opening or closing specified channel relays. By adding external pull-up resistors, the switch can be configured for digital output operations.

Use CLOS <channel_list> to connect a channel's normally open (NO) terminal to its common (C) terminal or use OPEN channel_list to connect a channel's normally closed (NC) contact to its common (C) terminal. The channel_list has the form (@ccnn) where cc = card number (01-99) and nn = channel number (00-31).

To OPEN or CLOSe multiple channels place a comma (,) between the channel numbers. For example, to close channels 101 and 103 execute CLOS (@101,103). To OPEN or CLOSe a continuous range of channels place a colon (:) between the first and last channel numbers.

Example: Opening/Closing Channels (BASIC)

This BASIC program shows one way to close and open channel 2 on an E1463A Form C module (card #1).

NOTE

Implied commands are those that appear in square brackets ([]) in the command syntax. The brackets are not part of the command and are not sent to the instrument. For example, in the following program, ROUTe can be eliminated and just the CLOSe command can be used.

```
10 DISP "TEST E1463A Module"
20 OUTPUT 70915; "ROUT:CLOS (@102)"
30 OUTPUT 70915; "ROUT:OPEN (@102)"
40 END
```

Example: Voltage Switching (BASIC)

This example closes channel 00 of a Form C switch module to switch the load voltage (E) from load 1 to load 2. When the channel relay is open, the load voltage is applied to load 1. When the relay is closed, the voltage is applied to load 2. See Figure 2-1 for typical user connections. The program shows how to close channel 00 of the E463A Form C Switch. To open channel 00, use OPEN (@100).

```
10 DISP "Testing the E1463A"
20 OUTPUT 70915; "CLOS (@100)" !Close channel 00 relay (connect NO to C). 1 is the card number and 00 is the channel number.
30 END
```




Figure 2-1 Example: Voltage Switching

Example: Controlling RF Switches/Step Attenuators (BASIC)

Figure 2-2 shows one way to drive the 8761 SPDT RF Switches or 33300 Series Programmable Step Attenuators. (Figure 2-2 only shows control for the 33300 40 dB step. Additional drive relays are required for the 10 dB and 20 dB steps.)

The 8761A and 33300A/C operate from a 12V - 15V coil voltage, while the 8761B and 33300B/D operate from a 24V - 30V coil voltage. To close channel 00, execute the following. To open channel 00, use OPEN (@100).

```
10 DISP "Applying -12V"
20 OUTPUT 70915; "CLOS (@100)" !Close channel 00 relay (connect NO to
   C). 1 is the card number and 00 is the channel number.
30 END
```





Figure 2-2 Example: Controlling RF Switches/Step Attenuators

Example: Digital Output Configuration (BASIC)

Figure 2-3 shows channel 00 configured for digital output operation. When the channel 00 relay is open (NC connected to C), point 1 is at +V and point 2 is at 0V. When the channel 00 relay is closed (NO connected to C), points 1 and 2 are both at 0V. To close channel 00, execute the following. To open channel 00, use OPEN (@100).

10 DISP "Closing channel 0"

```
20 OUTPUT 70915; "CLOS (@100)" !Close channel 00 relay (connect NO to C). 1 is the card number and 00 is the channel number.

30 END
```




Figure 2-3 Example: Digital Output Configuration

Example: Matrix Switching (BASIC)

The Form C switch module can be configured as a 4 x 8 single-wire matrix to connect any combination of up to four user sources (S0, S1, S2, S3) to any combination of up to eight user instruments (I0, I1, I1...I7) at a time. To do this, make the connections shown in Table 2-3.

Table 2-3 Matrix Switching Connections

Connect These Common (C) Channel Numbers Together	Connect These Normally Open (NO) Channel Numbers Together
0, 8, 16, and 24	0 - 7
1, 9, 17, and 25	8 - 15
2, 10, 18, and 26	16 - 23
3, 11, 19, and 27	24 - 31
4, 12, 20, and 28	
5, 13, 21, and 29	
6, 14, 22, and 30	
7, 15, 23, and 31	

Close the channel number enclosed in the circle in Figure 2-4 to connect the corresponding row and column. This example closes channel 25 to connect S3 to I1 and closes channel 20 to connect S2 to I4. To close channels 20 and 25, execute the following. To open the channels, use OPEN (@120,125).

```
10 DISP "Testing Switch Matrix"
```

```
20 OUTPUT 70915; "CLOS (@120,125)"
```

!Close channels 20 and 25. 1 is the card number; 20 and 25 are channel numbers.

```
30 END
```




Figure 2-4 Example: Matrix Switching

Scanning Channels

For the Form C switch, scanning channels consists of closing a specified set of channels, one channel at a time. You can scan any combination of channels for a single-module or a multiple-module switchbox. Single, multiple, or continuous scanning modes are available. See Chapter 3 for additional information on scanning Form C switch channels.

Channel lists can extend across boundaries. For multiple-module switchbox instruments, the channels to be scanned can extend across switch modules. For example, for a two-module switchbox instrument, `SCAN (@100:231` will scan all channels of both Form C switch modules.

Use `ARM:COUNT <number>` to set multiple/continuous scans (from 1 to 32,767 scans). Use `INITiate:CONTinuous ON` to set continuous scanning. See Chapter 3 for information about these SCPI commands.

Example: Scanning Using Trig In and Trig Out Ports (BASIC)

This example shows one way to synchronize instrument measurements of a device under test (DUT) with Form C switch channel closures. For measurement synchronization, the E1406A Command Module "Trig In" and "Trig Out" ports are connected to the instrument "Voltmeter Complete" and "External Trigger" ports. See Figure 2-5 for typical user connections.

For this example, the normally closed (NC) contacts (channels 00-02) are connected to ground and the measurements are made on the common (C) contacts. The command module and instrument are connected via GPIB. The Form C switch module has a logical address 120 (secondary address 15) and the external instrument has an address of 722.




Figure 2-5 Example: Scanning Using Trig In and Trig Out Ports

```

10  OUTPUT 70915; "*RST;*CLS" !Reset and clear the module
20  OUTPUT 722;"TRIG EXT;DCV" !External trigger, dc volts
30  OUTPUT 722;"MEM FIFO" !Memory first in, first out
40  OUTPUT 70915;"OUTP ON" !Enable "Trig Out"
50  OUTPUT 70915;"TRIG:SOUR EXT" !External triggering
60  OUTPUT 70915;"SCAN (@100:102)" !Scan channels 00-02
70  OUTPUT 70915;"INIT" !Enable scan
80  WAIT 2 !Wait for switch closures
90  FOR Channel=1 TO 3 !Start loop
100  ENTER 722;Result !Enter result
110  PRINT Result !Display result
120  NEXT Channel !Increment count
130  END

```

Example: Scanning Using the TTL Trigger Bus (BASIC)

This example uses the E1406A Command Module TTL trigger bus lines to synchronize Form C channel closures to an E1412A System Multimeter. For measurement synchronization, the E1406A TTL trigger bus line 0 is used by the Form C module to trigger the multimeter to perform a measurement and the E1406A TTL trigger bus line 1 is used by the multimeter to advance the Form C scan.

Figure 2-6 shows one way to connect the Form C module to the E1412A multimeter module. The connections shown with dotted lines are not actual hardware connections. These connections indicate how the firmware operates to accomplish the triggering.




Figure 2-6 Example: Scanning Using the TTL Trigger Bus

The following BASIC program sets up the multimeter (GPIB address 70903) to scan making 2-wire resistance measurements. The common terminals for channels 0 through 2 are connected together for this example. When one of these switches is closed (C connected to NO), different DUTs are switched in for a measurement. Triggering is accomplished by the E1406A firmware. The measurement is taken from the common (C) terminal.

```
10  ALLOCATE REAL Rdgs(1:3)
20  OUTPUT 70915; "*RST;*CLS" !Reset and clear Form C switch
30  OUTPUT 70903; "*RST;*CLS" !Reset and clear multimeter
40  OUTPUT 70903;"ABORT;:TRIG:SOUR TTLTRG0" !Multimeter triggers on
                                         TTL trigger line 0
50  OUTPUT 70903; "OUTP:TTLT1:STAT ON" !Multimeter pulses TTL
                                         trigger line 1 on measurement complete
60  OUTPUT 70903; "CONF:RES AUTO,DEF" !Set multimeter function to
                                         resistance, range, NPLC
70  OUTPUT 70903; "TRIG:DEL 0; COUN 3;:CAL:ZERO:AUTO ON"
                                         !Set multimeter trigger delay, counts, calibration state
80  OUTPUT 70903; "*OPC?"           ! Check to see if multimeter is ready.
                                         When ready, initialize trigger 1.
90  ENTER 70903; Check
100 OUTPUT 70903; "INIT"
110 OUTPUT 70915; "OUTPUT:TTLT0:STATE ON"           !Set up the Form C.
                                         Form C pulses TTL Trigger line 0 on channel closed
120 OUTPUT 70915;"TRIG:SOUR TTLT1"           !Set Form C to be triggered by
                                         TTL Trigger line 1.
130 OUTPUT 70915; "SCAN (@100:102)"
140 OUTPUT 70915; "INIT"
150 OUTPUT 70903; "FETCH?"
160 ENTER 70903; Rdgs(*)
170 PRINT Rdgs(*) !Enter and print readings
180 END
```


Querying the Form C Switch

All query commands end with a "?". These commands are used to determine a specific state of the module. The data is sent to the output buffer where you can retrieve it into your computer. See Chapter 3 for more information on these commands.

Use CLOSe? <channel_list> or OPEN? <channel_list> to query the channel state (open/closed). CLOS? returns a "1" for channel(s) closed and a "0" for channel(s) open. OPEN? returns a "0" for channel(s) closed and a "1" for channel(s) open. (Commands are software queries and do not account for relay hardware failures.)

Example: Querying Channel Closures (BASIC)

This example closes a range of channels and queries for the results.

```

10 DIM Channels$(32) !Dimensions a string variable to 32 characters
20 OUTPUT 70915;"CLOS (@100:131)" !Closes channels 00 through 31
30 OUTPUT 70915;"CLOS? (@100:131)" !Queries to see if the channels
    are closed

40 ENTER 70915; Channels$ !Enters the results from the switch card
    into the variable Channels$

50 PRINT "Channels Closed: ";Channels$ ! Prints the channels closed
    (should print 1s)

60 END

```

Using the Scan Complete Bit

You can use the Scan Complete bit (bit 8) in the Operation Status Register (in the command module) of a switchbox to determine when a scanning cycle completes (no other bits in the register apply to the switchbox).

Bit 8 has a decimal value of 256 and you can read it directly with the STAT:OPER? command. Refer to the STATus:OPERation[:EVENT]? command in Chapter 3 for an example.

When enabled by the STAT:OPER:ENAB 256 command, the Scan Complete bit will be reported as bit 7 of the Status Register. Use the GPIB Serial Poll or the IEEE 488.2 Common Command *STB? to read the Status Register.

When bit 7 of the Status Register is enabled by the *SRE 128 Common Command to assert a GPIB Service Request, you can interrupt the computer when the Scan Complete bit is set, after a scanning cycle completes. This allows the computer to do other operations while the scanning cycle is in progress.

Example: Using the Scan Complete Bit (BASIC)

This example monitors bit 7 in the Status Register to determine when the scanning cycle is complete. The computer interfaces with an E1406A Command Module over GPIB. The GPIB select code is 7, the GPIB primary address is 09, and the GPIB secondary address is 15.

```

10  OUTPUT 70915;"*RST; *CLS" !Reset and clear the module
20  OUTPUT 70915;"STAT:OPER:ENAB 256" !Enable Scan Complete Bit
30  OUTPUT 70915; "TRIG:SOUR IMM" !Set the Form C switch for
    continuous triggering
50  OUTPUT 70915; "SCAN (@100:115)" !Select channels to scan
60  OUTPUT 70915; "*OPC?" !Wait for operation complete
70  ENTER 70915; A$
80  PRINT "*OPC? = ";A$
90  OUTPUT 70915;"STAT:OPER:ENAB?" !Query the contents in the
    operation status register

100 ENTER 70915; A$
110 PRINT "STAT:OPER:ENAB?=";A$ !Print the contents of the operation
    status register

120 OUTPUT 70915; "*STB?" !Query the contents of the status byte
    register

130 ENTER 70915; A$
140 PRINT "Switch Status = ";A$ !Print the contents of the status
    byte register

150 OUTPUT 70915; "INIT" !Start scan cycle
160 I = 0 !Initialize the value of the counter
170 WHILE (I=0) !Stay in loop until some value is returned from the
    SPOLL (70915) command

180     I = SPOLL(70915)
190     PRINT "Waiting for scan to complete: SPOLL = ";I
200 END WHILE
210 I = SPOLL(70915)
220 PRINT "Scan complete: SPOLL = ";I
230 END

```

Saving and Recalling States

The `*SAV <numeric_state>` command saves the current instrument state. The state number (0-9) is specified by the `<numeric_state>` parameter. The settings saved by this command are:

Channel relay states (open or closed)

ARM:COUNT

TRIGger:SOURce

OUTPut:STATe

INITiate:CONTinuous

The `*RCL <numeric_state>` command recalls the state when the last `*SAV` was executed for the specified `<numeric_state>` parameter (0-9). If no `*SAV` was executed for the `<numeric_state>`, `*RST` default settings are used. Refer to the `*SAV` settings list for the settings recalled by `*RCL`.

Example: Saving and Recalling State (BASIC)

This program shows how to save and recall Form C switch states.

```

10  DIM A$(150) !Dimension a string variable for 150 characters
20  OUTPUT 70915; "CLOS (@100:131)" !Close channels 00 - 31 on
                                     the Form C switch

30  OUTPUT 70915; "*SAV 5" !Save as numeric state 5
40  OUTPUT 70915; "*RST;*CLS" !Reset and clear the Form C switch
50  OUTPUT 70915; "CLOS? (@100:131)" !Query the channels closed
60  ENTER 70915;A$
70  PRINT "Channels Closed: ";A$ !Print closed channels
                                   (should print 0s)

80  OUTPUT 70915; "*RCL 5" !Recall numeric state 5
90  OUTPUT 70915; "CLOS? (100:131)" !Query to see which channels
                                   are closed

100 ENTER 70915;A$
110 PRINT "Channels Closed: ";A$ !Print closed channels
                                   (should print 1s)

120 END

```

Detecting Error Conditions

The `SYSTem:ERRor?` query requests a value from an instrument's error register. This register contains an integer in the range `[-32,768 to 32,767]`. The response takes the form `<err_number>,<err_message>` where `<err_number>` is the value of the instrument's error and `<err_message>` is a short description of the error.

Example: Detecting Error Conditions (BASIC)

This BASIC program attempts an illegal channel closure and polls for an error message.

```
10 DIM Err_num$(256) !Dimension a string variable for 256 characters
20 OUTPUT 70915; "CLOS (@135)" !Try to close an illegal channel
30 OUTPUT 70915; "SYST:ERR?" !Query for a system error
40 ENTER 70915; Err_num$
50 PRINT Err_num$ !Print error +2001, "Invalid channel number"
60 END
```

Example: Detecting Error Conditions (Turbo C)

This Turbo C program attempts an illegal channel closure and polls for an error message. If no error occurs, the switchbox responds with 0, "No error". If there has been more than one error, the instrument will respond with the first error in its error queue. Subsequent queries continue to read the error queue until it is empty. The maximum `<err_message>` string length is 255 characters.

```
#include <stdio.h>
#include <chpib.h> /*Include file for GPIB*/

#define ISC 7L
#define FORMC 70915L /*Form C default address*/
#define TASK1 "CLOSE (@135)" /*Command for illegal
switch closure*/
#define TASK2 "SYST:ERR?" /*Command for system error*/

main( )
{
    char into[257];
    int length = 256;

    /*Output commands to Form C*/
```

```

error_handler (IOTIMEOUT (7L,5.0), "TIMEOUT");
error_handler (IOOUTPUTS (FORMC, TASK1, 12), "OUTPUT command");
error_handler (IOOUTPUTS (FORMC, TASK2, 9), "OUTPUT command");

/*Enter from Form C*/

error_handler (IOENTERS (FORMC, into, &length), "ENTER command");
printf("Print the errors: %s",into);
return;
}

int error_handler (int error, char *routine)
{
    char ch;
    if (error != NOERR)
    {
        printf ("\n Error %d %s \n", error, strerror(error));
        printf (" in call to GPIB function %s \n\n", routine);
        printf ("Press 'Enter' to exit: ");
        scanf ("%c", &ch);
        exit(0);
    }
    return 0;
}

```

Synchronizing the Form C Switch

This section gives guidelines to synchronize a Form C switch module with a measurement instrument.

Example: Synchronizing the Form C Switch (BASIC)

This BASIC program shows one way to synchronize a Form C switch module with a measurement instrument. In this example, the Form C switch module switches a signal to a multimeter. The program then verifies the channel is closed before the multimeter begins its measurement.

```

10  OUTPUT 70915; "CLOS (@105)" !Close channel 5
20  OUTPUT 70915; "*OPC?" !Wait for operation complete
30  ENTER 70915; Opc_value
40  OUTPUT 70915; "CLOS? (@105)" !Check to see if channel closed
50  ENTER 70915;A
60  IF A=1 THEN
70      OUTPUT 70903;"MEAS:VOLT:DC?" !When channel is closed, measure
                                     the voltage
80      ENTER 70903; Meas_value
90      PRINT Meas_value !Print the measured voltage

```

```
100 ELSE
110     PRINT "Channel did not close"
120 END IF
130 END
```

3 E1463A Command Reference

Using This Chapter

This chapter describes Standard Commands for Programmable Instruments (SCPI) and summarizes IEEE 488.2 Common (*) commands applicable to the E1463A Form C Switch Module. This chapter contains the following sections:

Command Types	page 57
SCPI Command Reference	page 60
SCPI Commands Quick Reference	page 88
IEEE 488.2 Common Commands Reference	page 89

Command Types

Commands are separated into two types: IEEE 488.2 Common commands and SCPI commands.

Common Command Format

The IEEE 488.2 standard defines the Common commands that perform functions like reset, self-test, status byte query, etc. Common commands are four or five characters in length, always begin with the asterisk character (*), and may include one or more parameters. The command keyword is separated from the first parameter by a space character. Some examples of Common commands are shown below:

*RST *ESE <unmask> *STB?

SCPI Command Format

The SCPI commands perform functions like closing switches, opening switches, scanning channels, querying instrument states or retrieving data. A subsystem command structure is a hierarchical structure that usually consists of a top level (or root) command, one or more lower-level commands, and their parameters. The following example shows part of a typical subsystem:

```
[ROUTe:]  
  CLOSe<channel_list>  
  SCAN <channel_list>  
  :MODE?
```

[ROUTe:] is the root command, CLOSe and SCAN are second-level commands with parameters, and :MODE? is a third-level command. There must be a space between the second-level command (such as CLOSe) and the parameter (<channel_list>).

Command Separator

A colon (:) always separates one command from the next lower-level command as shown below:

```
[ROUTe:]SCAN:MODE?
```

Colons separate the root command from the second-level command ([ROUTe:]SCAN) and the second level from the third level (SCAN:MODE?).

Abbreviated Commands

The command syntax shows most commands as a mixture of upper- and lowercase letters. The uppercase letters indicate the abbreviated spelling for the command. For shorter program lines, send the abbreviated form. For better program readability, you may send the entire command. The instrument will accept either the abbreviated form or the entire command.

For example, if the command syntax shows TRIGger, then TRIG and TRIGGER are both acceptable forms. Other forms of TRIGger, such as TRIGG or TRIGGE will generate an error. You may use uppercase or lowercase letters. Therefore, TRIGGER, trigger, and TrigGeR are all acceptable.

Implied Commands

Implied commands are those that appear in square brackets ([]) in the command syntax. (*The brackets are not part of the command and are not sent to the instrument.*) Suppose you send a second-level command but do not send the preceding implied command. In this case, the instrument assumes you intend to use the implied command and it responds as if you had sent it. Examine the portion of the [ROUTe:] subsystem shown below:

```
[ROUTe:]  
  CLOSe<channel_list>
```

The root command [ROUTe:] is an implied command (indicated by square brackets ([])). To make a query about a channel's present status, you can send either of the following command statements:

```
ROUT:CLOSe? <channel_list> or CLOSe? <channel_list>
```


Variable Command Syntax

Some commands have what appears to be a variable syntax, such as `OUTPut:TTLTrgn`. In this command, the "n" is replaced by a number. No space is left between the command and the number because the number is not a parameter.

Parameters

Parameter Types. The following table contains explanations and examples of parameter types you might see later in this chapter.

Type	Explanations and Examples
Boolean	Represents a single binary condition that is either true or false (ON, OFF, 1.0). Any non-zero value is considered true.
Discrete	Selects from a finite number of values. These parameters use mnemonics to represent each valid setting. An example is the <code>TRIGger:SOURce <source></code> command where <code><source></code> can be <code>BUS</code> , <code>EXTErnal</code> , <code>HOLD</code> , <code>IMMEdiate</code> , or <code>TTLTrgn</code> .
Numeric	Commonly used decimal representations of numbers including optional signs, decimal points, and scientific notation. Examples are <code>123</code> , <code>123E2</code> , <code>-123</code> , <code>-1.23E2</code> , <code>.123</code> , <code>1.23E-2</code> , <code>1.23000E-01</code> . Special cases include <code>MINimum</code> , <code>MAXimum</code> , <code>DEFault</code> and <code>INFinity</code> .
Optional	Parameters shown within square brackets ([]) are optional parameters. <i>(The brackets are not part of the command and are not sent to the instrument.)</i> If you do not specify a value for an optional parameter, the instrument chooses a default value. For example, consider the <code>ARM:COUNT? [<MIN MAX>]</code> command. If you send the command without specifying a parameter, the present <code>ARM:COUNT</code> value is returned. If you send the <code>MIN</code> parameter, the command returns the minimum count available. If you send the <code>MAX</code> parameter, the command returns the maximum count available. Be sure to place a space between the command and the parameter.

Linking Commands

Linking IEEE 488.2 Common Commands with SCPI Commands. Use a semicolon (;) between the commands. For example, `*RST;*RCL 1` or `CLOS (@101);*SAV 1`

Linking Multiple SCPI Commands. Use both a semicolon (;) and a colon (:) between the commands, such as `CLOS (@101);:CLOS? (@101)`.

Linking Subsystem Commands. SCPI also allows several commands within the same subsystem to be linked with a semicolon, such as `ROUT:CLOS (@101);:ROUT:CLOS? (@101)` or `ROUT:CLOS (@101);CLOS? (@101)`.

SCPI Command Reference

This section describes the Standard Commands for Programmable Instruments (SCPI) commands for the E1463A. Commands are listed alphabetically by subsystem and within each subsystem.

ABORt

The ABORt command stops a scan in progress when the scan is enabled via the interface and the trigger source is TRIGger:SOURce BUS or TRIGger:SOURce HOLD.

Subsystem Syntax

ABORt

Comments

ABORt Actions: The ABORt command terminates the scan and invalidates the current channel list.

Stopping Scan Enabled Via Interface: When a scan is enabled via an interface, an interface CLEAR command can be used to stop the scan. When the scan is enabled via the interface and TRIG:SOUR BUS or HOLD is set, you can use ABORt to stop the scan.

Related Commands: ARM, INITiate:CONTinuous,[ROUTe:]SCAN, TRIGger

Example

Stopping a Scan with ABORt

This example stops a continuous scan in progress.

```
TRIG:SOUR BUS !Trigger command will be via backplane (bus) interface
               (*TRG command generates trigger)
```

```
INIT:CONT ON !Set continuous scanning
```

```
SCAN(@100:107) !Scan channels 00 to 07
```

```
INIT !Start scan, close channel 00
```

```
.
```

```
.
```

```
ABOR !Abort scan in progress
```

ARM

The ARM subsystem selects the number of scanning cycles (1 to 32,767) for each INITiate command.

Subsystem Syntax

ARM

:COUNT <number> MIN | MAX

:COUNT? [<MIN | MAX>]

ARM:COUNT

ARM:COUNT <number> MIN | MAX allows scanning to occur a multiple of times (1 to 32,767) with one INITiate command when INITiate:CONTinuous OFF | 0 is set. MIN sets 1 cycle and MAX sets 32,767 cycles.

Parameters

Name	Type	Range of Values	Default Value
<number>	numeric	1 - 32,767 MIN MAX	1

Comments

- Number of Scans: Use only numeric values between 1 and 32767, MIN, or MAX for the number of scanning cycles.
- Related Commands: ABORT, INITiate[:IMMediate]
- *RST Condition: ARM:COUNT 1

Example

Setting Ten Scanning Cycles

This example sets a Form C switch for 10 scans of channels 00 through 03. When the scan sequence completes, channels 00 through 03 (relays 00 through 03) are closed.

ARM:COUNT 10 !Set 10 scans per INIT command

SCAN(@100:103) !Scan channels 00 to 03

INIT !Start scan, close channel 00

ARM:COUNT?

ARM:COUNT? [<MIN | MAX>] returns the current number of scanning cycles set by ARM:COUNT. The current number of scan cycles is returned when MIN or MAX is not specified. With MIN or MAX as a parameter, MIN returns "1" and MAX returns "32,767".

Parameters

Name	Type	Range of Values	Default Value
MIN MAX	numeric	MIN = 1, MAX = 32,767	current cycle

Comments

Related Commands: INITiate[:IMMediate]

Example

Querying Number of Scans

This example sets a switchbox for 10 scanning cycles and queries the number of scan cycles set. The ARM:COUN? command returns 10.

ARM:COUN 10 !Set 10 scans per INIT command

ARM:COUN? !Query number of scans

DISPlay

The DISPlay subsystem monitors the channel state of the selected module in a switchbox. This subsystem operates with an E1406A Command Module when a display terminal is connected.

Subsystem Syntax

```
DISPlay
:MONitor
:CARD <number> | AUTO
[:STATe] <mode>
```

DISPlay:MONitor:CARD

DISPlay:MONitor:CARD <number> | AUTO selects the module in a switchbox to be monitored.

Parameters

Name	Type	Range of Values	Default Value
<number> AUTO	numeric	1 - 99	AUTO

Comments

Selecting a Specific Module to be Monitored: Use DISPlay:MONitor:CARD to send the card number for the switchbox to be monitored.

Selecting the Present Module to be Monitored: Use DISPlay:MONitor:CARD AUTO to select the last module addressed by a switching command (for example, [ROUTe:]CLOSe).

*RST Conditions: DISPlay:MONitor:CARD AUTO

Example

Select Module #2 in a Switchbox for Monitoring

DISP:MON:CARD 2 !Selects module #2 in a switchbox

DISPlay:MONitor[:STATe]

DISPlay:MONitor[:STATe] *<mode>* turns the monitor mode ON or OFF.

Parameters

Name	Type	Range of Values	Default Value
<i><mode></i>	boolean	ON OFF 1 0	OFF 0

Comments

Monitoring Switchbox Channels: DISPlay:MONitor:STATe ON or DISPlay:MONitor:STATe 1 turns the monitor mode ON to show the channel state of the selected module. DISPlay:MONitor:STATe OFF or DISPlay:MONitor:STATe 0 turns the channel monitor OFF.

Selecting the Module to be Monitored: Use DISPlay:MONitor:CARD *<number>* AUTO to select the module.

Monitor Mode with a Form C Switch: When monitoring mode is turned ON, decimal numbers representing the channels closed will be displayed at the bottom of the display terminal. For example, if channels 3, 7, and 12 are closed, the bottom of the display will read as follows, where the channel numbers represent channels that are closed.

Chan , , , 3 , , , , 7 , , , , , 12 , , , , ... etc.

*RST Condition: DISPlay:MONitor[:STATe]OFF | 0

Example

Enabling Monitor Mode

```
DISP:MON:CARD 2 !Select module #2 in a switchbox
```

```
DISP:MON 1 !Turn monitor mode ON
```

INITiate

The INITiate command subsystem selects continuous scanning cycles and starts the scanning cycle.

Subsystem Syntax

```
INITiate
:CONTInuous <mode>
:CONTInuous?
[:IMMediate]
```

INITiate:CONTInuous

INITiate:CONTInuous <mode> enables or disables continuous scanning cycles for the switchbox.

Parameters

Name	Type	Range of Values	Default Value
<mode>	boolean	ON OFF 1 0	OFF 0

Comments

Continuous Scanning Operation: Continuous scanning is enabled with INITiate:CONTInuous ON or INITiate:CONTInuous 1. Sending INITiate:IMMediate closes the first channel in the channel list. Each trigger from the source specified by TRIGger:SOURce advances the scan through the channel list. A trigger at the end of the channel list closes the first channel in the channel list and the scan cycle repeats.

Noncontinuous Scanning Operation: Noncontinuous scanning is enabled with INITiate:CONTInuous OFF or INITiate:CONTInuous 0. Sending INITiate:IMMediate closes the first channel in the channel list. Each trigger from the source specified by TRIGger:SOURce advances the scan through the channel list. At the end of the scanning cycle, the last channel in the channel list is opened.

Stopping Continuous Scan: See the ABORt command.

Related Commands: ABORt, ARM:COUNT, TRIGger:SOURce

*RST Condition: INITiate:CONTInuous OFF | 0

Example

Enabling Continuous Scanning

This example enables continuous scanning of channels 00 through 03 of a single-module switchbox. Since TRIGger:SOURce IMMEDIATE (default) is set, use an interface clear command (such as CLEAR) to stop the scan.

```
INIT:CONT ON !Enable continuous scanning
SCAN(@100:103) !Define channel list
INIT !Start scan cycle, close channel 00
```

INITiate:CONTinuous?

INITiate:CONTinuous? queries the scanning state. With continuous scanning enabled, the command returns "1" (ON). With continuous scanning disabled, the command returns "0" (OFF).

Example

Querying Continuous Scanning State

This example enables continuous scanning of a switchbox and queries the state. Since continuous scanning is enabled, INIT:CONT? returns "1".

```
INIT:CONT ON !Enable continuous scanning
INIT:CONT? !Query continuous scanning state
```

INITiate[:IMMEDIATE]

INITiate[:IMMEDIATE] starts the scanning process and closes the first channel in the channel list. Successive triggers from the source specified by the TRIGger:SOURce command advance the scan through the channel list.

Comments

Starting the Scanning Cycle: INITiate:IMMEDIATE starts scanning by closing the first channel in the channel list. Each trigger received advances the scan to the next channel in the channel list. An invalid channel list definition causes an error (see [ROUTE:]SCAN).

Stopping Scanning Cycles: See the ABORT command.

Example

Enabling a Single Scan

This example enables a single scan of channels 00 through 03 of a single-module switchbox. The trigger source to advance the scan is immediate (internal) triggering set with TRIGger:SOURceIMMEDIATE (default).

```
SCAN(@100:103) !Scan channels 00 - 03
INIT !Begin scan, close channel 00 (use immediate triggering)
```


OUTPut

The OUTPut command subsystem enables or disables the different trigger lines of the E1406A Command Module.

Subsystem Syntax

```
OUTPut
  :EXternal
    [:STATe] <mode>
    [:STATe]?
  [:STATe] <mode>
  [:STATe]?
  :TTLTrgn (:TTLTrg0 through :TTLTrg7)
    [:STATe] <mode>
    [:STATe]?
```

OUTPut:EXternal[:STATe]

OUTPut:EXternal[:STATe] <mode> enables or disables the "Trig Out" port on the E1406A Command Module.

Parameters

Name	Type	Range of Values	Default Value
<mode>	boolean	ON OFF 1 0	OFF 0

Comments

Enabling "Trig Out" Port: When enabled, a pulse is output from the "Trig Out" port after each scanned switchbox channel is closed. If disabled, a pulse is not output from the port after channel closures. The output pulse is a +5V negative-going pulse.

"Trig Out" Port Shared by Switchboxes: When enabled, the "Trig Out" port is pulsed by any switchbox each time a scanned channel is closed. To disable the output for a specific module send OUTPut:EXternal[:STATe] OFF or OUTPut:EXternal[:STATe] 0 for that module.

One Output Selected at a Time: Only one output (TTLTrg or EXternal) can be enabled at one time. Enabling a different output source will automatically disable the active output.

Related Commands: [ROUTe:]SCAN, TRIGger:SOURce

*RST Condition: OUTPut:EXternal[:STATe] OFF (port disabled)

Example

Enabling "Trig Out" Port

```
OUTP:EXT ON !Enable "Trig Out" port to output pulse after each scanned
channel is closed
```

OUTPut:EXternal[:STATe]?

OUTPut:EXternal[:STATe]? queries the present state of the "Trig Out" port on the E1406A Command Module. The command returns "1" if the port is enabled or "0" if the port is disabled.

Example

Query "Trig Out" Port Enable State

This example enables the "Trig Out" port and queries the enable state. OUTPut:EXternal[:STATe]? returns "1" since the port is enabled.

```
OUTP:EXT ON !Enable E1406A "Trig Out" port
OUTP:EXT? !Query port enable state
```

OUTPut[:STATe]

OUTPut[:STATe] <mode> enables or disables the "Trig Out" port on the E1406A Command Module. OUTPut[:STATe] ON | 1 enables the port and OUTPut[:STATe] OFF | 0 disables the port. This command functions the same as OUTPut:EXternal[:STATe].

Parameters

Name	Type	Range of Values	Default Value
<mode>	boolean	ON OFF 1 0	OFF 0

Comments

*RST Condition: OUTPut[:STATe] OFF (port disabled)

Example

Enabling "Trig Out" Port

```
OUTP ON !Enable "Trig Out" port to output pulse after each scanned
channel is closed
```

OUTPut[:STATe]?

OUTPut[:STATe]? queries the present state of the E1406A Command Module "Trig Out" port. The command returns "1" if the port is enabled or "0" if the port is disabled. This command functions the same as OUTPut:EXTeRnal[:STATe]?

Example

Query "Trig Out" Port Enable State

This example enables the E1406A Command Module "Trig Out" port and queries the enable state. OUTPut[:STATe]? returns "1" since the port is enabled.

```
OUTP ON !Enable "
```

```
Trig Out" port OUTP? !Query port enable state
```

OUTPut:TTLTrgn[:STATe]

OUTPut:TTLTrgn[:STATe] <mode> selects and enables which TTL Trigger bus line (0 to 7) will output a trigger when a channel is closed during a scan. This is also used to disable a selected TTL Trigger bus line. "n" specifies the TTL Trigger bus line (0 to 7) and <mode> enables (ON or 1) or disables (OFF or 0) the specified TTL Trigger bus line.

Parameters

Name	Type	Range of Values	Default Value
n	numeric	0 to 7	N/A
<mode>	boolean	ON OFF 1 0	OFF 0

Comments

Enabling TTL Trigger Bus: When enabled, a pulse is output from the selected TTL Trigger bus line (0 to 7) after each channel in the switchbox is closed during a scan. If disabled, a pulse is not output. The output is a negative-going pulse.

One Output Selected at a Time: Only one output (TTLTrg or EXTeRnal) can be enabled at one time. Enabling a different output source will automatically disable the active output. For example, if TTLTrg1 is the active output and TTLTrg4 is enabled, TTLTrg1 will become disabled and TTLTrg4 will become the active output.

Related Commands: [ROUTe:]SCAN, TRIGger:SOURce, OUTPut:TTLTrgn[:STATe]?

*RST Condition: OUTPut:TTLTrgn[:STATe] OFF (disabled)

Example

Enabling TTL Trigger Bus Line 7

```
OUTP:TTLT7:STAT 1 !Enable TTL Trigger bus line 7 to output pulse after  
each scanned channel is closed
```

OUTPut:TTLTrgn[:STATe]?

OUTPut:TTLTrgn[:STATe]? queries the present state of the specified TTL Trigger bus line. The command returns "1" if the specified TTLTrg bus line is enabled or "0" if disabled.

Example

Query TTL Trigger Bus Enable State

This example enables TTL Trigger bus line 7 and queries the enable state. OUTPut:TTLTrgn? returns "1" since the port is enabled.

```
OUTP:TTLT7:STAT 1 !Enable TTL Trigger bus line 7
```

```
OUTP:TTLT 7? !Query bus enable state
```

[ROUTe:]

The [ROUTe:] command subsystem controls switching and scanning operations for Form C switch modules in a switchbox.

Subsystem Syntax

```
[ROUTe:]
  CLOSe <channel_list>
  CLOSe? <channel_list>
  OPEN <channel_list>
  OPEN? <channel_list>
  SCAN <channel_list>
```

NOTE

There must be a space between the second level command (CLOS, for example) and the parameter <channel_list>.

[ROUTe:]CLOSe

[ROUTe:]CLOSe <channel_list> closes the Form C switch channels specified by <channel_list>. <channel_list> has the form (@ccnn) where cc = card number (01-99) and nn = channel number (00-31).

Parameters

Name	Type	Range of Values	Default Value
<channel_list>	numeric	cc00 - cc31	N/A

Comments

Closing Channels:

- To close a single channel use ROUT:CLOS (@ccnn)
- To close multiple channels use ROUT:CLOS (@ccnn,ccnn,...)
- To close sequential channels use ROUT:CLOS (@ccnn:ccnn)
- To close groups of sequential channels use ROUT:CLOS (@ccnn:ccnn,ccnn:ccnn)
- or any combination of the above

NOTE

Closure order for multiple channels with a single command is not guaranteed. Channel numbers can be in the <channel_list> in any random order.

Related Commands: [ROUTe:]OPEN, [ROUTe:]CLOSe?

*RST Condition: All channels open.

Example

Closing Form C Switch Channels

This example closes channels 100 and 213 of a two-module switchbox (card numbers 01 and 02).

```
CLOS(@100,213) !Close channels 100 and 213. 100 closes channel 00 of
card #1 and 213 closes channel 13 of card #2.
```

[ROUTe:]CLOSe?

[ROUTe:]CLOSe? <channel_list> returns the current state of the channel(s) queried. <channel_list> has the form (@ccnn) where cc = card number (01-99) and nn = channel number (00-31). The command returns "1" if channel(s) are closed or returns "0" if channel(s) are open.

Comments

Query is Software Readback: ROUTe:CLOSe? returns the current software state of the channel(s) specified. It does not account for relay hardware failures.

A maximum of 128 channels can be queried at one time. If you want to query more than 128 channels, you must enter the query data in two separate commands.

Example

Querying Channel Closure

This example closes channels 100 and 213 of a two-module switchbox and queries channel closure. Since the channels are programmed to be closed "1,1" is returned as a string.

```
CLOS(@100,213) !Close channels 100 and 213
```

```
CLOS?(@100,213) !Query channels 100 and 213 state
```

[ROUTe:]OPEN

[ROUTe:]OPEN *<channel_list>* opens the Form C switch channels specified by *<channel_list>*. *<channel_list>* has the form (@*ccnn*) where *cc* = card number (01-99) and *nn* = channel number (00-31).

Parameters

Name	Type	Range of Values	Default Value
<i><channel_list></i>	numeric	cc00 - cc31	N/A

Comments

- Opening Channels:
- To open a single channel use ROUT:OPEN (@*ccnn*)
- To open multiple channels use ROUT:OPEN (@*ccnn*,*ccnn*,...)
- To open sequential channels use ROUT:OPEN (@*ccnn*:*ccnn*)
- To open groups of sequential channels use ROUT:OPEN (@*ccnn*:*ccnn*,*ccnn*:*ccnn*)
- or any combination of the above

Opening Order: Opening order for multiple channels with a single command is not guaranteed.

Related Commands: [ROUTe:]CLOSe, [ROUTe:]OPEN?

*RST Condition: All channels open.

Example

Opening Form C Switch Channels

This example opens channels 100 and 213 of a two-module switchbox (card numbers 01 and 02).

```
OPEN(@100,213) !Open channels 100 and 213. 100 opens channel 00 of
card #1 and 213 opens channel 13 of card #2.
```

[ROUTe:]OPEN?

[ROUTe:]OPEN? <channel_list> returns the current state of the channel(s) queried. <channel_list> has the form (@ccnn) where cc = card number (01-99) and nn = channel number (00-31). The command returns "1" if channel(s) are open or returns "0" if channel(s) are closed.

Comments

Query is Software Readback: ROUTe:OPEN? returns the current software state of the channel(s) specified. It does not account for relay hardware failures.

A maximum of 128 channels can be queried at one time: If you want to query more than 128 channels, you must enter the query data in two separate commands.

Example

Querying Channel Open State

This example opens channels 100 and 213 of a two-module switchbox and queries channel 213 state. Since channel 213 is programmed to be open, "1" is returned.

OPEN(@100,213)	<i>!Open channels 100 and 213</i>
OPEN?(@213)	<i>!Query channel 213 state</i>

[ROUTe:]SCAN

[ROUTE:]SCAN *<channel_list>* defines the channels to be scanned. *<channel_list>* has the form (@*ccnn*) where *cc* = card number 01-99) and *nn* = channel number (00-31).

Parameters

Name	Type	Range of Values	Default Value
<channel_list>	numeric	cc00 - cc31	N/A

Comments

Defining Scan List: When ROUTe:SCAN is executed, the channel list is checked for valid card and channel numbers. An error is generated for an invalid channel list.

Scanning Channels:

- To scan a single channel use ROUT:SCAN (@ccnn)
- To scan multiple channels use ROUT:SCAN (@ccnn,ccnn,...)
- To scan sequential channels use ROUT:SCAN (@ccnn:ccnn)

- To scan groups of sequential channels use ROUT:SCAN (@ccnn:ccnn,ccnn:ccnn)
- or any combination of the above

NOTE

Channel numbers can be in the <channel_list> in any random order.

Scanning Operation: When a valid channel list is defined, INITiate[:IMMediate] begins the scan and closes the first channel in the <channel_list>. Successive triggers from the source specified by TRIGger:SOURce advance the scan through the <channel list>. At the end of the scan, the last trigger opens the last channel.

Stopping Scan: See ABORT

Related Commands: TRIGger, TRIGger:SOURce

*RST Condition: All channels open.

Example

Scanning Using External Device

See "Scanning Channels" in Chapter 2 for examples of scanning programs using external instruments.

STATus

The STATus subsystem reports the bit values of the OPERation Status Register. It also allows you to unmask the bits you want reported from the Standard Event Status Register and to read the summary bits from the Status Byte Register.

Subsystem Syntax

```

STATus
  :OPERation
    :CONDition?
    :ENABle <unmask>
    :ENABle?
    [:EVENT?]
  :PRESet

```

As shown in Figure 3-1, the STATus subsystem for the E1463A Form C Switch includes the Status Byte Register, the Standard Event Status Register, OPERation Status Register, and Output Queue. The Standard Event Status Register (*ESE?) and the Status Byte Register (*STB?) are under IEEE 488.2 control.

Status Byte Register

In the Status Byte register, the Operation Status bit (OPR), Request Service bit (RQS), Standard Event bit (ESB), Message Available bit (MAV) and Questionable Data bit (QUE) (bits 7, 6, 5, 4 and 3 respectively) can be queried with the *STB? command.

Standard Event Status Register

In the Standard Event Status Register, you can use *ESE? to query the "unmask" value (the bits to be logically ORed into the Summary bit).

The registers are queried using decimal-weighted bit values. Decimal equivalents for bits 0 through 15 are shown in Figure 3-1.

OPERation Status Register

Using STATus:OPERation:ENABle 256 allows only bit 8 to generate a Summary bit from the OPERation Status Register, since the decimal value for bit 8 is 256. The decimal values can also be used in the inverse manner to determine the bits set from the value returned by STATus:OPERation:EVENT? or STATus:OPERation:CONDition?.

The Form C switch driver uses only bit 8 of OPERation Status Register. This bit is called the *Scan Complete* bit and is set whenever a scan operation completes. Since completion of a scan operation is an event in time, bit 8 will never appear set when STATus:OPERation:CONDition? is queried. However, you can find bit 8 set by using STATus:OPERation:EVENT?.




Figure 3-7 E1463A Status System Register Diagram

STATus:OPERation:CONDition?

STATus:OPERation:CONDition? returns the state of the Condition Register in the OPERation Status Register. The state represents conditions that are part of the instrument's operation. The switch driver does not set bit 8 in the OPERation Status Register (see STATus:OPERation[:EVENT]?).

STATus:OPERation:ENABle

STATus:OPERation:ENABle <unmask> sets an enable mask to allow events recorded in the Event Register of the OPERation Status Register to send a Summary bit to the Status Byte Register (bit 7). For switch modules, when bit 8 in the OPERation Status Register is set to 1 and bit 8 is enabled by STATus:OPERation:ENABle, bit 7 in the Status Byte Register is set to 1.

Parameters

Name	Type	Range of Values	Default Value
<unmask>	numeric	0 through 65,535	N/A

Comments

Setting Bit 7 of the Status Byte Register: STATus:OPERation:ENABle 256 sets bit 7 (OPR) of the Status Byte Register to 1 after bit 8 (Scan Complete) of the OPERation Status Register is set to 1.

Related Commands: [ROUTe:]SCAN

Example

Enabling Operation Status Register Bit 8

STAT:OPER:ENAB 256 !Enable bit 8 of the OPERation Status Register to be reported to bit 7 (OPR) in the Status Byte Register

STATus:OPERation:ENABle?

STATus:OPERation:ENABle? returns the bit value of the Enable Register within the OPERation Status Register.

Comments

Output Format: STATus:OPERation:ENABle? returns a decimal-weighted value from 0 to 65,535 indicating the bits set to true.

Maximum Value Returned: The value returned is the value set by STATUS:OPERation:ENABLE <unmask>. However, the maximum decimal-weighted value used in this module is 256 (bit 8 in the Condition Register within the OPERation Status Register is set to true).

Example

Querying the Enable Register in the OPERation Status Register

```
STAT:OPER:ENAB? ! Query the Enable Register in the OPERation Status
                  Register
```

STATus:OPERation[:EVENT]?

STATus:OPERation[:EVENT]? returns which bits in the Event Register within the OPERation Status Register are set. The Event Register indicates that a time-related instrument event has occurred.

Comments

Setting Bit 8 of the OPERation Status Register: Bit 8 (Scan Complete) is set to 1 after a scanning cycle completes. Bit 8 returns to 0 (zero) after sending STATUS:OPERation[:EVENT]?

Returned Data after sending STATus:OPERation[:EVENT]?: The command returns "+256" if bit 8 of the OPERation Status Register is set to 1. The command returns "+0" if bit 8 of the OPERation Status Register is set to 0.

Event Register Cleared: Reading the Event Register within the OPERation Status Register with STATus:OPERation:EVENT? clears the Event Register.

Aborting a Scan: Aborting a scan will leave bit 8 set to 0.

Related Commands: [ROUTE:]SCAN

Example

Reading the OPERation Status Register After a Scanning Cycle

```
STAT:OPER? !Return the bit values of the Event Register within the
            OPERation Status Register
```

```
read the register value +256 shows bit 8 is set to 1.
                        +0 shows bit 8 is set to 0.
```

STATus:PRESet

STATus:PRESet affects only the Enable Register within the OPERation Status Register by setting all Enable Register bits to 0. It does not affect either the Status Byte Register or the Standard Event Status Register. STATus:PRESet does not clear any of the Event Registers.

SYSTem

The SYSTem subsystem returns the error numbers and error messages in the error queue of a switchbox. It can also return the types and descriptions of modules (cards) in a switchbox.

Subsystem Syntax

```
SYSTem
:CDescription? <number>
:CPON <number> | ALL
:CTYPE? <number>
:ERRor?
```

SYSTem:CDescription?

SYSTem:CDescription? <number> returns the description of a selected module (card) in a switchbox.

Parameters

Name	Type	Range of Values	Default Value
<number>	numeric	1 through 99	N/A

Comments

Form C Switch Module Description: SYSTem:CDescription? returns:
"32 Channel General Purpose Relay"

Example

Reading the Description of a Module

```
SYST:CDES? 1 !Return description of module card #1
```

SYSTem:CPON

SYSTem:CPON <number> | ALL sets the selected module (card) in a switchbox to its power-on state.

Parameters

Name	Type	Range of Values	Default Value
<number>	numeric	1 through 99	N/A

Comments

Form C Switch Power-on State: The power-on state is all channels (relays) open. SYSTem:CPON ALL and *RST open all channels of all modules in a switchbox, while SYSTem:CPON <number> opens the channels in only the module (card) specified in the command.

Example

Setting Module to Power-on State

```
SYST:CPON 1 !Set card #1 to power-on state
```

SYSTem:CTYPe?

SYSTem:CTYPe? <number> returns the module (card) type of a selected module in a switchbox.

Parameters

Name	Type	Range of Values	Default Value
<number>	numeric	1 through 99	N/A

Comments

E1463A Form C Switch Model Number: SYSTem:CTYPe? <number> returns

HEWLETT-PACKARD,E1463A,0,A.04.00

where the 0 after E1463A is the module serial number (always 0) and A.04.00 is an example of the module revision code number.

Example

Reading the Model Number of a Module

```
SYST:CTYP? 1 !Return the model number
```


SYSTem:ERRor?

SYSTem:ERRor? returns the error numbers and corresponding error messages in the error queue of a switchbox. See Appendix C for a listing of switchbox error numbers and messages.

Comments

Error Numbers/Messages in the Error Queue: Each error generated by a switchbox stores an error number and corresponding error message in the error queue. The error message can be up to 255 characters long.

Clearing the Error Queue: An error number/message is removed from the queue each time SYSTem:ERRor? is sent. The errors are cleared first-in, first-out. When the queue is empty, each following SYSTem:ERRor? command returns **+0, "No error"**. To clear all error numbers/messages in the queue, execute *CLS.

Maximum Error Numbers/Messages in the Error Queue: The queue holds a maximum of 30 error numbers/messages for each switchbox. If the queue overflows, the last error number/message in the queue is replaced by **-350, "Too many errors"**. The least recent error numbers/messages remain in the queue and the most recent errors are discarded.

Example

Reading the Error Queue

```
SYST:ERR? !Query the error queue
```

TRIGger

The TRIGger command subsystem controls the triggering operation of Form C switch modules in a switchbox.

Subsystem Syntax

```
TRIGger
[:IMMediate]
:SOURce <source>
:SOURce?
```

TRIGger[:IMMediate]

TRIGger[:IMMediate] causes a trigger event to occur when the defined trigger source is TRIGger:SOURce BUS or TRIGger:SOURce HOLD.

Comments

Executing TRIGger[:IMMediate]: Before TRIGger[:IMMediate] will execute, a channel list must be defined with [ROUTe:]SCAN <channel_list> and an INITiate[:IMMediate] must be executed

BUS or HOLD Source Remains: If selected, TRIGger:SOURce BUS or TRIGger:SOURce HOLD remains in effect after triggering a switchbox with TRIGger[:IMMediate].

Related Commands: INITiate, [ROUTe:]SCAN

Example

Advancing Scan Using TRIGger

This example uses TRIGger[:IMMediate] to advance the scan of a single-module switchbox from channel 00 through 03. Since TRIGger:SOURce HOLD is set, the scan is advanced one channel each time TRIGger is executed.

```
TRIG:SOUR HOLD !Set trigger source to HOLD
SCAN(@100:103) !Define channel list
INIT !Begin scan, close channel 00
loop statement !Start count loop
TRIG !Advance scan to next channel
increment loop !Increment loop count
```

TRIGger:SOURce

TRIGger:SOURce <source> specifies the trigger source to advance the <channel_list> during scanning.

Parameters

Parameter Name	Parameter Type	Parameter Description	Default Value
BUS	discrete	*TRG or GET command	IMM
EXternal	discrete	"Trig In" port	IMM
HOLD	discrete	Hold Triggering	IMM
IMMEDIATE	discrete	Immediate Triggering	IMM
TTLTrgn	numeric	TTL Trigger Bus Line 0 - 7	IMM

Comments

Enabling the Trigger Source: TRIGger:SOURce only selects the trigger source. INITiate[:IMMEDIATE] enables the trigger source.

Using the TRIGger Command: You can use TRIGger[:IMMEDIATE] to advance the scan when TRIGger:SOURce BUS or TRIGger:SOURce HOLD is selected.

Using External Trigger Inputs: With TRIGger:SOURce EXTERNAL selected, only one switchbox at a time can use the external trigger input at the E1406A "Trig In" port. The trigger input is assigned to the first switchbox requesting the external trigger source (with a TRIGger:SOURce EXTERNAL command).

Assigning External Trigger: A switchbox assigned with TRIGger:SOURce EXTERNAL remains assigned to that source until the switchbox trigger source is changed to BUS, HOLD, or IMMEDIATE. When the source is changed, the external trigger source is available to the next switchbox requesting it (with a TRIGger:SOURce EXTERNAL command). If a switchbox requests an external trigger input already assigned to another switchbox, an error is generated.

Using Bus Triggers: To trigger the switchbox with bus triggers when TRIGger:SOURce BUS selected, use the IEEE 488.2 common command *TRG or the GPIB Group Execute Trigger (GET) command.

"Trig Out" Port Shared by Switchboxes: When enabled, the E1406A Command Module "Trig Out" port is pulsed by any switchbox each time a scanned channel is closed. To disable the output for a specific module send OUTPUT:EXTERNAL[:STATE] OFF or OUTPUT:EXTERNAL[:STATE] 0 for that module.

One Output Selected at a Time: Only one output (TTLTrg or EXTeRnal) can be enabled at one time. Enabling a different output source will automatically disable the active output.

Related Commands: ABORt, [ROUTe:]SCAN, OUTPut

*RST Condition: TRIGger:SOURce IMMEDIATE

Example

Scanning Using External Triggers

This example uses external triggering (TRIGger:SOURce EXTeRnal) to scan channels 00 through 03 of a single-module switchbox. The trigger source to advance the scan is the input to the "Trig In" port on the E1406A Command Module. When INIT is executed, the scan is started and channel 00 is closed. Then, each trigger received at the "Trig In" port advances the scan to the next channel.

```
TRIG:SOUR EXT !Select external triggering
SCAN(@100:103) !Scan channels 00 through 03
INIT !Begin scan, close channel 00
trigger externally !Advance scan to next channel
```

Example

Scanning Using Bus Triggers

This example uses bus triggering (TRIG:SOUR BUS) to scan channels 00 through 03 of a single-module switchbox. The trigger source to advance the scan is the *TRG command (as set with TRIGger:SOURce BUS). When INIT is executed, the scan is started and channel 00 is closed. Then, each *TRG command advances the scan to the next channel.

```
TRIG:SOUR BUS !Select interface (bus) triggering
SCAN(@100:103) !Scan channels 00 through 03
INIT !Begin scan, close channel 00
loop statement !Loop to scan all channels
*TRG !Advance scan using bus triggering
increment loop !Increment loop count
```

TRIGger:SOURce?

TRIGger:SOURce? returns the current trigger source for the switchbox. The command returns BUS, EXT, HOLD, IMM, or TTLTfor sources BUS, EXTernal, HOLD, IMMEDIATE, or TTLTrgn, respectively.

Example

Querying the Trigger Source

This example sets external triggering and queries the trigger source. Since external triggering is set, TRIG:SOUR? returns "EXT".

```
TRIG:SOUR EXT !Set external trigger source
```

```
TRIG:SOUR? !Query trigger source
```

SCPI Commands Quick Reference

The following table summarizes the SCPI Commands for the E1463A Form C Switch module.

Command	Description
ABORt ABORt	Aborts a scan in progress
ARM :COUNT <number> MIN MAX :COUNT? [MIN MAX]	Multiple scans per INIT command Queries number of scans
DISPlay :MONitor:CARD <number> AUTO :MONitor[:STATe] <mode>	Selects module to be monitored Selects monitor mode
INITiate :CONTInuous <mode> :CONTInuous? [:IMMediate]	Enables/disables continuous scanning Queries continuous scan state Starts a scanning cycle
OUTPut [:EXTeRnal[:STATe] <mode> [:EXTeRnal[:STATe]? [:STATe] <mode> [:STATe]? :TTLTrgn[:STATe] <mode> :TTLTrgn[:STATe]?]	Enables/disables the Trig Out port on the E1406 Queries the external state Enables/disables the Trig Out port on the E1406 Queries port enable state Enables/disables the specified TTL trigger line Queries the specified TTL trigger line
[ROUTe:] CLOSe <channel_list> CLOSe? <channel_list> OPEN <channel_list> OPEN? <channel_list> SCAN <channel_list>	Closes channel(s) Queries channel(s) closed Opens channel(s) Queries channel(s) opened Defines channels for scanning
STATus :OPERation:CONDition? :OPERation:ENABle <unmask> :OPERation:ENABle? :OPERation[:EVENT]? :PRESet	Returns status of the Condition Register Enables the Operation Event Register to set a bit in the Status Register Query the contents in the Operation Status Register Returns status of the Operation Status Register Sets Enable Register to 0
SYSTem :CDEscription? <number> :CTYPe? <number> :CPON <number> ALL :ERRor?	Returns description of module in a switchbox Returns the module type Sets specified module to its power-on state Returns error number/message to error queue
TRIGger [:IMMediate] :SOURce BUS :SOURce EXTeRnal :SOURce HOLD :SOURce IMMediate :SOURce?	Causes a trigger to occur Trigger source is *TRG Trigger source is Trig In (on the E1406) Hold off triggering Continuous (internal) triggering Query scan trigger source

IEEE 488.2 Common Commands Reference

The following table lists the IEEE 488.2 Common (*) commands accepted by the E1463A Form C Switch module. The operation of some of these commands is described in Chapter 2 of this manual. For more information on Common commands, refer to the user's manual for your mainframe or to the ANSI/IEEE Standard 488.2-1987.

Command	Title	Command Description
*CLS	Clear Status Register	Clears all status registers (see STATus:OPERation[:EVENT]?).
*ESE	Event Status Enable	Enables Status Register bits.
*ESE?	Event Status Enable Query	Queries the current contents in the Standard Event Status Register
*ESR?	Event Status Register Query	Queries and clears the current contents in the Standard Event Status Register
*IDN?	Identification Query	Returns identification string of the Switchbox.
*OPC	Operation Complete	Sets the Request for OPC flag when all pending operations have completed. Also, sets OPC bit in the Standard Event Status Register.
*OPC?	Operation Complete Query	Returns a "1" to the output queue when all pending operations have completed. Used to synchronize between multiple instruments.
*RCL	Recall Instrument State	Recalls previously stored configuration.
*RST	Reset	Opens all channels and sets the module to a known state.
*SAV	Save Instrument State	Stores the current configuration in specified memory.
*SRE	Service Request Enable	Sets the Service Request Enable Register bits and corresponding Serial Poll Status Register bits to generate a service request.
*SRE?	Service Request Enable Query	Queries the current contents in the Service Request Enable Register.
*STB?	Read Status Byte Query	Queries the current contents in the Status Byte Register.
*TRG	Trigger	Triggers the module to advance the scan when scan is enabled and trigger source is TRIGger:SOURce BUS.
*TST?	Self-Test Query	Returns +0 if self-test passes. Returns +cc01 for firmware error. Returns +cc02 for bus error. Returns +cc10 if an interrupt was expected but not received. Returns +cc11 if the busy bit was not held for 10 msec.
*WAI	Wait to Continue	Prevents an instrument from executing another command until the operation caused by the previous command is finished. Since all instruments normally perform sequential operations, executing this command causes no change.

A Form C Switch Specifications

General				
Module Size / Device Type: C-size VXIbus, Register based, A16/D16, Interrupter (levels 1-7, jumper selectable)		Relay Life (Typical):*		
		Condition	Number of Operations	
Power Requirements: Voltage:				

* Relays are subject to normal wearout based on the number of operations.

** Absolute worst case when all relays are closed simultaneously.

B Register-Based Programming

About This Appendix

This appendix contains the information you can use for register-based programming of the E1463A Form C Switch. The contents include:

Register Programming vs. SCPI Programming [page 93](#)

Addressing the Registers [page 93](#)

Register Descriptions [page 96](#)

Programming Examples [page 99](#)

Register Programming vs. SCPI Programming

The E1463A Form C Switch is a register-based module that does not support the VXIbus word serial protocol. When a SCPI command is sent to the Form C switch, the E1406 Command Module parses the command and programs the switch at the register level.

NOTE

If SCPI is used to control this module, register programming is not recommended. The SCPI driver maintains an image of the card state. The driver will be unaware of changes to the card state if you alter the card state by using register writes.

Register-based programming is a series of reads and writes directly to the Form C switch registers. This increases throughput speed since it eliminates command parsing and allows the use of an embedded controller. Also, if slot 0, the resource manager, and the computer GPIB interface are provided by other devices, a C-size system can be downsized by removing the command module.

Addressing the Registers

Register addresses for register-based devices are located in the upper 25% of VXI A16 address space. Every VXI device (up to 256 devices) is allocated a 32-word (64-byte) block of addresses. With five registers, the E1463A Form C Switch uses five of the 64 addresses allocated.

The Base Address

When reading or writing to a switch register, a hexadecimal or decimal *register address* is specified. This address consists of a *base address* plus a *register offset*. The base address used in register-based programming depends on whether the A16 address space is outside or inside the E1406 Command Module.

Figure B-1 shows the register address location within A16 as it might be mapped by an embedded controller. Figure B-2 shows the location of A16 address space in the E1406 Command Module.

A16 Address Space Outside the Command Module

When the E1406 Command Module is not part of your VXIbus system (see Figure B-1), the switch's base address is computed as:

$$C000_{16} + (LADDR * 64)_{16} \text{ or } 49,152 + (LADDR * 64)$$

where $C000_{16}$ (49,152) is the starting location of the register addresses, LADDR is the switch's logical address, and 64 is the number of address bytes per VXI device. For example, the switch's factory-set logical address is 120 (78_{16}). If this address is not changed, the switch will have a base address of:

$$C000_{16} + (120 * 64)_{16} = C000_{16} + 1E00_{16} = DE00_{16}$$

or (decimal)

$$49,152 + (120 * 64) = 49,152 + 7680 = 56,832$$

A16 Address Space Inside the Command Module or Mainframe

When the A16 address space is inside the E1406 Command Module (see Figure B-2), the switch's base address is computed as:

$$1FC000_{16} + (LADDR * 64)_{16} \text{ or } 2,080,768 + (LADDR * 64)$$

where $1FC000_{16}$ (2,080,768) is the starting location of the VXI A16 addresses, LADDR is the switch's logical address, and 64 is the number of address bytes per register-based device. Again, the switch's factory-set logical address is 120. If this address is not changed, the switch module will have a base address of:

$$1FC000_{16} + (120 * 64)_{16} = 1FC000_{16} + 1E00_{16} = 1FDE00_{16}$$

or

$$2,080,768 + (120 * 64) = 2,080,768 + 7680 = 2,088,448$$

Register Offset

The register offset is the register’s location in the block of 64 address bytes. For example, the switch’s Status Register has an offset of 04₁₆. When you write a command to this register, the offset is added to the base address to form the register address:

$1FDE00_{16} + 04_{16} = 1FDE04_{16}$ or $2,088,448 + 4 = 2,088,452$




Figure B-1 Registers Within A16 Address Space




Figure B-2 Registers Within the E1406 A16 Address Space

Register Descriptions

The Form C switch module contains two read registers, one read/write register, and two write registers. This section describes each Form C module register.

Reading and Writing to the Registers

Example programs are provided at the end of this appendix that show how to read and write to these registers. You can read or write to the following Form C switch module registers.

- Manufacturer Identification Register (base + 00₁₆) (read)
- Device Type Register (base + 02₁₆) (read)
- Status/Control Register (base + 04₁₆) (read or write)
- Relay Control Register for Channels 00 - 15 (base + 06₁₆) (write)
- Relay Control Register for Channels 16 - 31 (base + 08₁₆) (write)

Manufacturer Identification Register

The Manufacturer Identification Register is at offset address 00₁₆ and returns FFFF₁₆. This shows that Keysight Technologies is the manufacturer and the module is an A16 register-based module. This register is read only.

b+00 ₁₆	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Write	Undefined															
Read	Manufacturer ID - Returns FFFF ₁₆ = Keysight Technologies A16 only register-based device.															

Device Type Register

The Device Type Register is at offset address 02₁₆ and returns 0121₁₆ for an E1463A Form C Switch module. This register is read only.

b+02 ₁₆	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Write	Undefined															
Read	0121 ₁₆															

Status/Control Register

The Status/Control Register is at offset address 04₁₆ and informs the user about the module's status and configuration. This register is read and write.

b+04 ₁₆	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Write	Not Used									E	Not Used					R
Read	X	MS	Not Used					B	E	X	X	1	1	X	X	X

Reading the Status/Control Register

For Status/Control register reads, three bits are defined as follows.

- MODID Select (bit 14): 0 indicates the module has been selected by MODID (module ID) and a 1 indicates the module has not been selected.
- Busy (bit 7): 0 indicates the module is busy. Each relay requires about 10 ms execution time during which the Form C switch is busy. Bit 7 of this register is used to inform the user of a busy condition.
- Enable (bit 6): 0 indicates the interrupt is enabled. The interrupt generated after a channel has been closed can be disabled. Bit 6 of this register is used to inform the user of the interrupt status.

For example, if the Form C switch module is not busy (bit 7 = 1) and the interrupt is enabled (bit 6 = 0), a read of the Status/Control Register (base + 04₁₆) returns FFBF.

Writing to the Status/Control Register

You can only write to bits 0 and 6 of the Status/Control Register.

- Enable (bit 6): Writing a "1" to this bit disables the interrupt function of the module.
- Soft Reset (bit 0): Writing a "1" to this bit soft resets the module.

NOTE

When writing to the registers it is necessary to write "0" to bit 0 after the reset has been performed before any other commands can be programmed and executed. SCPI commands take care of this automatically.

Typically, interrupts are only disabled to "peek-poke" a module. See the appropriate command module operating manual before disabling the interrupt. Writing a "1" to bit 0 resets the switch (all channels open).

Relay Control Register

There are two relay control registers: Relay Control Register 1 (base + 06₁₆) and Relay Control Register 2 (base + 08₁₆). These registers are used to connect the common (C) to the normally open (NO) terminal. Reading any Relay Control Register will always return FFFF₁₆ regardless of the channel states.

The numbers in the register maps indicate the channel number to be written to. Writes to the Relay Control Registers enable you to open or close the desired channel. For example, write a "1" to bit 2 of Relay Control Register 1 to close channel 02.

Relay Control Register Channels 00 - 15

b+06 ₁₆	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Write	CH15	CH14	CH13	CH12	CH11	CH10	CH09	CH08	CH07	CH06	CH05	CH04	CH03	CH02	CH01	CH00
Read	Always returns FFFF ₁₆															

Relay Control Register Channels 16 - 31

b+08 ₁₆	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Write	CH31	CH30	CH29	CH28	CH27	CH26	CH25	CH24	CH23	CH22	CH21	CH20	CH19	CH18	CH17	CH16
Read	Always returns FFFF ₁₆															

Programming Examples

This section provides example programs in BASIC and C/HP-UX, including:

- Example: Reading the Registers (BASIC)
- Example: Reading the Registers (C/HP-UX)
- Example: Making Measurements (BASIC)
- Example: Making Measurements (C/HP-UX)
- Example: Scanning Channels (BASIC)
- Example: Scanning Channels (C/HP-UX)

Example: Reading the Registers (BASIC)

This BASIC programming example reads the Manufacturer ID Register, Device Type Register and Status Register on the Form C switch.

```

10  !*****
20  ! *****                                READREG
    *****
30  !*****
40  OPTION BASE 1
50  !Set up arrays to store register names and addresses
60  DIM Reg_name$(1:3)[32], Reg_addr(1:3)
70  !
80  !Read register names and addresses into the arrays
90  READ Reg_name$(*)
100 READ Reg_addr(*)
110 !
120 !Set base address variable
130 Base_addr = DVAL("DE00",16)
140 !
150 !Map the A16 address space in the controller
160 !
170 CONTROL 16,25;2
180 !Call the subprogram Read_regs
190 Read_regs(Base_addr, Reg_name$(*), Reg_addr(*))
200 !
210 DATA Identification register, Device register, Status register
220 DATA 00, 02, 04
230 END
    .
    .
    .
300 !This subprogram steps through a loop that reads each register
310 !and prints its contents
320 SUB Read_regs(Base_addr, Reg_name$(*), Reg_addr(*))
330 !
340     For Number = 1 to 3

```

```

350      Register = READIO(-16,Base_addr + Reg_addr(number))
360      PRINT Reg_name$(number); " = "; IVAL$(Register,16)
370      Next Number
380  SUBEND

```

Example: Reading the Registers (C/HP-UX)

This C/HP-UX programming example reads the Manufacturer ID Register, Device Type Register and Status Register on the Form C switch.

```

/*****
/*****                               readreg.c
*****/ *****/ *****/ *****/ *****/ *****/ *****/ *****/ *****/ *****/ *****/

#include      <sys/vxi.h>      /*source file for controller VXI
drivers*/
#include      <fcntl.h>
#include      <stdio.h>

#define logical_address 120  /*logical address of the Form C module*/

int fd;
typedef unsigned short word;
typedef struct dev_regs{      /*set up pointers*/
    unsigned short id_reg;
    unsigned short device_type;
    unsigned short status_reg;
    unsigned short bank0_channels;

} DEV_REGS;

main( )
{
/*open the controller VXI interface*/
fd=open("/dev/vxi/primary",O_RDWR);
if (fd){
    perror("open");
    exit(1);
}

/*retrieve the A16 pointers*/
dev=(struct dev_regs *)vxi_get_a16_addr(fd,logical_address);

/*sub to read the registers*/
read_reg(dev);
/*END of main program*/
}

/*SUB READ_REG*/

int read_reg(reg_ptr)
DEV_REGS *reg_ptr;
{
/*read the ID register*/
printf("\n ID Register = 0x%x\n",reg_ptr->id_reg);
/*read the Device Type register*/

```

```

printf("\n Device Type Register = 0x%x\n",reg_ptr->device_type);
/*read the Status register*/
printf("\n Status Register = 0x%x\n",reg_ptr->status_reg);
return;
}

```

Example: Making Measurements (BASIC)

This BASIC programming example closes bit 1 on bank 0, waits for a measurement to be made, and then opens the channel. You must insert your own programming code for the measurement part of this program. For example, if you are using the E1411B, see the *E1326B/E1411B Multimeter User's Manual* for programming examples.

```

10  !*****
20  !*****                                MAKEMEAS
****
30  !*****
40  OPTION BASE 1
50  !Set up arrays to store register names and addresses
60  DIM Reg_name$(1:1)[32], Reg_addr(1:1)
70  !
80  !Read register names and address into the arrays
90  READ Reg_name$(*)
100 READ Reg_addr(*)
110 !
120 !Set base address variable
130 Base_addr = DVAL("DE00",16)
140 !
150 !Map the A16 address space in the controller
160 CONTROL 16,25;2
170 !Call the subprogram Make_meas
180 Make_meas(Base_addr, Reg_addr(*))
190 !
200 DATA Bank0 channels register
210 DATA 06
220 END
.
.
.
280 !This subprogram closes bit 1 of bank0 channels, waits for the
290 !channel to be closed, makes a measurement, and then opens
300 !the relay.
310 SUB Make_meas(Base_addr, Reg_addr(*))
320 !
330   WRITEIO -16, Base_addr + Reg_addr(1); 1
340   REPEAT
350     UNTIL BIT(READIO(-16,Base_addr+4),7)
.
.   !Make Measurements

```

```

380     WRITEIO -16, Base_addr + Reg_addr(1);0
390 SUBEND

```

Example: Making Measurements (C/HP-UX)

This C/HP-UX programming example closes bit 1 on bank 0, waits for a measurement to be made, and then opens the channel. You must insert your own programming code for the measurement part of this program. For example, if you are using the E1411B, see the *E1326B/E1411B Multimeter User's Manual* for programming examples.

The sub *ver_time* allows time for switch closures. This sub should print a time around 10 ms. If the time is less, you must change the value of *j* in the for loop. For example, instead of 10000, you might need to use 12000.

```

/*****
***                               makemeas.c                               ***
*****/
#include    <time.h>
#include    <sys/vxi.h>             /*source file for controller VXI
drivers*/
#include    <fcntl.h>
#include    <stdio.h>

#define logical_address 120        /*logical address of Form C Switch*/

int fd;
typedef unsigned short word;
typedef struct dev_regs{           /*set up pointers*/
    unsigned short id_reg;
    unsigned short device_type;
    unsigned short status_reg;
    unsigned short bank0_channels;

} DEV_REGS;

main( )
{
    /*open the controller VXI interface*/
    fd=open("/dev/vxi/primary",O_RDWR);
    if (fd){
        perror("open");
        exit(1);
    }
    /*retrieve the A16 pointers*/
    dev=(struct dev_regs *)vxi_get_a16_addr(fd,logical_address);

    /*sub to verify the time to close the switch*/
    ver_time( );
    /*sub to close switch and make measurement*/
    make_meas(dev);
} /* *END of main program*/

```

```

/*SUB VER_TIME*/
ver_time( )
{
    struct timeval first,
                second,
                lapsed;

    struct timezone tzp;
    gettimeofday(&first,&tzp);
    for (j=0; j<=10000; j ++);
    gettimeofday ($second,&tzp);
    if (first.tv_usec > second.tv_usec)
    {
        second.tv_usec +=1000000;
        second.tv_sec--;
    }

    lapsed.tv_usec = second.tv_usec - first.tv_usec;
    lapsed.tv_sec = second.tv_sec - first.tv_sec;

    printf("Elapsed time for closing a channel is:  %ld sec %ld usec \n",
    lapsed.tv_sec, lapsed.tv_usec);
}

/*SUB MAKE_MEAS*/
int make_meas(reg_ptr)
DEV_REGS *reg_ptr;
{
    /*close bit 1 of bank0 */
    reg_ptr->bank0_channels=0x0001;
    for (j=0; j<=10000; j ++);          /*wait for switch to close*/
    printf("\n Making Measurement");
        .
        .
        .
        /*make measurements*/
        .
        .
        .
    /*open bit 1 of bank0*/
    reg_ptr->bank0_channels=0x0000;
    return;
}

```

Example: Scanning Channels (BASIC)

This BASIC programming example scans through the bank 0 channels (closing one switch at a time) and makes measurements between switch closures. You must insert your own programming code for the measurement part of this program. For example, if you are using the E1411B, see the *E1326B/E1411B Multimeter User's Manual* for programming examples.

```

10  !*****
20  !*****                                SCANNING
    *****
30  !*****
40  OPTION BASE 1
50  !Set up arrays to store register names and addresses
60  DIM Reg_name$(1:1)[32], Reg_addr(1:1)
70  !
80  !Read register names and addresses into the arrays
90  READ Reg_name$(*)
100 READ Reg_addr(*)
110 !Set base address variable
120 Base_addr = DVAL("DE00",16)
130 !
140 !Map the A16 address space in the controller
150 CONTROL 16,25;2
160 !Call the subprogram Scan_meas
170 Scan_meas(Base_addr, Reg_addr(*))
180 !
190 DATA Bank0 channels register
200 DATA 06
210 END
    .
    .
    .
270 !This subprogram sets all bits in bank0 open then scans through
280 !bank 0, closing one channel at a time (waits for the channel to
290 !be closed) so a measurement can be made.
300 SUB Scan_meas(Base_addr, Reg_addr(*))
310 !
320 WRITEIO -16, Base_addr + Reg_addr(1);0
330 FOR I= 0 to 15
340     WRITEIO -16, Base_addr + Reg_addr(1);2^I
350     REPEAT
360     UNTIL BIT(READIO(-16,Base_addr+4),7)
370     PRINT "Making Measurements"
    .
    .                                !Make Measurements
    .
420 NEXT I
430 WRITEIO -16,Base_addr + Reg_addr(1);0
440 SUBEND

```

Example: Scanning Channels (C/HP-UX)

This C/HP-UX programming example scans through the bank 0 channels (closing one switch at a time) and makes measurements between switch closures. You must insert your own programming code for the measurement part of this program. For example, if you are using the E1411B, see the *E1326B/E1411B Multimeter User's Manual* for programming examples.

NOTE

The sub `ver_time` allows time for the switches to close. The program should print a time around 10 ms. If the time is less, you must change the value of `j` in the for loop. For example, instead of 10000, you might need to use 12000.

The `math.h` include file requires a `-lm` option when compiling this program.

```

/*****
/**                               scanning.c                               ***/
*****/
#include    <time.h>
#include    <math.h>                /*file to perform math functions*/
#include    <sys/vxi.h>              /*source file for controller VXI
drivers*/
#include    <fcntl.h>
#include    <stdio.h>

#define logical_address 120          /*logical address of Form C
Switch*/
#define lastch15

int fd, i, reg;
double y;
typedef unsigned short word;
typedef struct dev_regs{              /*set up pointers*/
    unsigned short id_reg;
    unsigned short device_type;
    unsigned short status_reg;
    unsigned short bank0_channels;

} DEV_REGS;
main( )
{
    /*open the controller VXI interface*/
    fd=open("/dev/vxi/primary",O_RDWR);
    if (fd){
        perror("open");
        exit(1);
    }
    /*retrieve the A16 pointers*/
    dev=(struct dev_regs *)vxi_get_a16_addr(fd,logical_address);

```

```

/*sub to verify the time to close the switch*/
ver_time( );
/*sub to close a set of switches and make measurements*/
scan_meas(dev);
}                                /*END of main program*/

/*SUB VER_TIME*/
ver_time( )
{
    struct timeval first,
                  second,
                  lapsed;

    struct timezone tzp;
    gettimeofday(&first,&tzp);
    for (j=0; j<=10000; j ++);
    gettimeofday ($second,&tzp);
    if (first.tv_usec > second.tv_usec)
    {
        second.tv_usec +=1000000;
        second.tv_sec--;
    }

    lapsed.tv_usec = second.tv_usec - first.tv_usec;
    lapsed.tv_sec = second.tv_sec - first.tv_sec;

    printf("Elapsed time for closing a channel is:  %ld sec %ld usec \n",
    lapsed.tv_sec, lapsed.tv_usec);
}

/*SUB SCAN_MEAS*/
int scan_meas(reg_ptr)
DEV_REGS *reg_ptr;
{
    /*set bank0 to 000 */
    reg_ptr->bank0_channels=0x000;
    i=0;
    for (i=0;i=lastch;i ++)
    {
        y=i;
        reg=pow(2.0,y);
        reg_ptr->bank0_channels=reg;
        for (j=0; j<=10000; j ++);          /*wait for switch to be closed*/
        printf("\n Making Measurement");

        .
        .
        .
    }
    return;
}

```


C E1463A Error Messages

Error Types

Table C-2 lists the error messages generated by the E1463A Form C Switch module firmware when programmed by SCPI. Errors with negative values are governed by the SCPI standard and are categorized in Table C-1. Error numbers with positive values are not governed by the SCPI standard. See the *E1406A Command Module User's Manual* for further details on these errors.

Table C-4 Error Types

Range	Error Types Description
-199 to -100	Command Errors (syntax and parameter errors).
-299 to -200	Execution Errors (instrument driver detected errors)
-399 to -300	Device Specific Errors (instrument driver errors that are not command nor execution errors).
-499 to -400	Query Errors (problem in querying an instrument)

Error Messages

Table 2-5 Error Messages

Code	Error Message	Potential Cause(s)
-109	Missing Parameter	Sending a command requiring a channel list without the channel list.
-211	Trigger Ignored	Trigger received when scan not enabled. Trigger received after scan complete. Trigger too fast.
-213	INIT Ignored	Attempting to execute an INIT command when a scan is already in progress.
-224	Illegal Parameter Value	Attempting to execute a command with a parameter not applicable to the command.
-310	System Error, Internal Driver Error.	This error can result if an excessively long parameter list is entered.
+1500	External Trigger Source Already Allocated	Assigning an external trigger source to a switchbox when the trigger source has already been assigned to another switchbox.
+2000	Invalid Card Number	Addressing a module (card) in a switchbox that is not part of the switchbox.
+2001	Invalid Channel Number	Attempting to address a channel of a module in a switchbox that is not supported by the module (e.g., channel 99 of a multiplexer module).
+2006	Command Not Supported On This Card	Sending a command to a module (card) in a switchbox that is unsupported by the module.
+2008	Scan List Not Initialized	Executing a scan without the INIT command.
+2009	Too Many Channels In Channel List	Attempting to address more channels than available in the switchbox.
+2011	Empty Channel List	No valid channels are specified in the <i><channel_list></i> .
+2012	Invalid Channel Range	Invalid channel(s) specified in SCAN <i><channel_list></i> command. Attempting to begin scanning when no valid <i><channel_list></i> is defined.
+2600	Function Not Supported On This Card	Sending a command to a module (card) in a switchbox that is not supported by the module or switchbox.

