
Keysight
E5045A PN3, E5046A PN3,
E5047A PN3

Signal Source Analyzer

Notices

© Keysight Technologies, Inc. 2024

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Trademark Acknowledgments

Manual Part Number

E5045-90003

Edition

Edition 1, January 2025

Published by:
Keysight Technologies
1400 Fountaingrove Parkway
Santa Rosa, CA 95403

Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED “AS IS,” AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS

COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

U.S. Government Rights

The Software is “commercial computer software,” as defined by Federal Acquisition Regulation (“FAR”) 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement (“DFARS”) 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at <http://www.keysight.com/find/swe-ula>. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond

those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

Where to Find the Latest Information

Documentation is updated periodically. For the latest information about these products, including instrument software upgrades, application information, and product information, browse to one of the following URLs, according to the name of your product:

<http://www.keysight.com/us/en/product/E5045A>

<https://www.keysight.com/us/en/support/E5046A>

<https://www.keysight.com/us/en/support/E5047A>

To receive the latest updates by email, subscribe to Keysight Email Updates at the following URL:

<https://support.keysight.com>

Information on preventing instrument damage can be found at:

<http://www.keysight.com/find/PreventingInstrumentRepair>

Is your product software up-to-date?

Periodically, Keysight releases software updates to fix known defects and incorporate product enhancements. To search for software updates for your product, go to the Keysight Technical Support website at:

<http://www.keysight.com/find/techsupport>

Product and Solution Cybersecurity

Keysight complies with multinational regulations for the cybersecurity of its own products and is committed to providing information to assist you in protecting your products and solutions from external cyber threats. For more information, see:

<https://www.keysight.com/us/en/about/quality-and-security/security/product-and-solution-cyber-security.html>

Keysight also recommends that you secure your IT environments using appropriate third-party tools. For instruments that run the Microsoft Windows operating system, Keysight concurs with Microsoft's recommendations for ensuring that the instrument is protected:

- Get the latest critical Windows updates
- For network-connected instruments, use an Internet firewall (in Keysight instruments, Windows Firewall is enabled by default)
- For network-connected instruments, use up-to-date antivirus and anti-spyware software

Responsible Disclosure Program

Keysight recommends that security researchers share the details of any suspected vulnerabilities across any asset owned, controlled, or operated by Keysight (or that would reasonably impact the security of Keysight and our users) using this form:

<https://www.keysight.com/us/en/contact/responsible-disclosure-program.html>

Report a Product Cybersecurity Issue

If you discover a cybersecurity issue that you suspect may involve Keysight's proprietary software, or third-party software supplied by Keysight as part of a product, or that may affect the operation of Keysight products, we encourage you to report it to us using this form:

<https://www.keysight.com/us/en/about/quality-and-security/security/product-and-solution-cyber-security/report-a-product-cybersecurity-issue>

Contents

1. Programming the Instrument

Introduction	10
Programming the instrument	10
Ethernet LAN	11
Ethernet Interface Connection and Setup	11
Using Sockets LAN	13
Using and Configuring VXI-11 (VISA)	13
Using Telnet LAN (Port 18)	14
USB (USBTMC)	15
USB-TMC Interface Connection and Setup using VISA	15
USB-TMC Interface Connection and Setup using Keysight API	15
GPIOB Interface Connection and Setup	16
General GPIOB information	16
SCPI Commands	17

2. IEEE-488 Interface Commands

IEEE Mandated and Optional Common Commands	20
*CLS	20
*ESE<data>	21
*ESE?	21
ESR?	21
*IDN?	21
*OPC	21
*OPC?	21
*OPT?	22
*RCL<reg>	22
*RST	22
*SAV <reg>	22
*SRE<data>	22
*SRE?	23
*STB?	23
*TRG	23
*TST?	23
*WAI	23

3. SCPI Commands

Introduction	26
SCPI Command Types	27
SCPI Command Syntax	28
Structure of a Command Line	28
Responses to Queries	28
Parameters	28
Hierarchical Command Structure	30
Status System Programming	31
Status Registers	32
Condition Register	32
Transition Filter	32
Event Register	32

Contents

Enable Register	32
Status Group Reporting	33
Summary Status Byte Group	33
Operation Status Group	33
Standard Event Status Group	34
Questionable Status Group	35
4. SCPI Command Descriptions	
:ABORt Subsystem	38
ABORt	38
:CALCulate Subsystem	39
:CALCulate:AN Branch	39
:CALCulate:FN Branch	40
:CALCulate:FREQuency?	42
:CALCulate:PN Branch	42
:CALCulate:POWER?	45
:CALCulate:WAIT:AVERage	46
:CALCulate:VCO Branch	46
:INITiate Subsystem	49
INITiate	49
:SENSe Subsystem	50
:SENSe:AN Branch	50
:SENSe:FN Branch	51
:SENSe:FREQuency:EXECute?	53
:SENSe:MODE	53
:SENSe:PN Branch	53
:SENSe:POWER:EXECute?	59
:SENSe:VCO Branch	59
:SOURce Subsystem	63
Channel selection for multi-channel devices	63
[:SOURce]:TUNE:DUT:STAT	63
[:SOURce]:TUNE:DUT:VOLT	63
:SYSTem Subsystem	64
:SYSTem:COMMunicate Branch	64
System:ERRor Branch	67
5. Programming Examples	
Absolute Phase Noise	70
VCO Characterization	72
Amplitude Noise	74
Absolute Phase Noise (Mode FN)	76
Block Data Format	78

1 Programming the Instrument

This section describes the following features:

“Introduction” on page 10

“Ethernet LAN” on page 11

“USB (USBTMC)” on page 15

“GPIB Interface Connection and Setup” on page 16

“SCPI Commands” on page 17

Introduction

This manual provides information for remote operation of the Keysight Signal Source Analyzers (PN3) using commands sent from an external controller via Ethernet, USB, or GPIB. It includes the following:

- A general description of the LAN and the bus data transfer and control functions.
- A general description of how to establish connection via LAN, USB, or GPIB.
- A listing of the IEEE-488 Interface Function Messages recognized by the signal source analyzer with a description of its response.
- A complete listing and description of all the Standard Commands for Programmable Instruments (SCPI) commands that can be used to control signal source analyzer operation with examples of command usage

Programming the instrument

All instruments described in this manual can be accessed through LAN, USB or GPIB interface. All interfaces use standard SCPI command set to pass commands to the device.

While LAN is the preferred interface for Keysight instruments, GPIB is only optionally available for some models.

Ethernet LAN

All Keysight PN3 signal source analyzers are preferably remotely programmed via a 10/100/1000Base-T LAN interface and LAN-connected computer using one of several LAN interface protocols. The LAN allows instruments to be connected together and controlled by a LAN based computer. LAN and its associated interface operations are defined in the IEEE 802.2 standard.

All instruments support the following LAN interface protocols:

- **Socket based LAN:** The application programming interface (API) provided with the instrument supports general programming using the LAN interface under Windows operating system.
- **VXI-1:** is a TCP/IP instrument protocol specification for LXI instruments based on Ethernet.
- **Telephone Network (TELNET):** TELNET is used for interactive, one command at a time instrument control.
- **Internet protocol** optionally supported

For LAN operation, the signal source analyzer must be connected to the LAN, and an IP address must be assigned to the signal source analyzer either manually or by using the DHCP client service. Your system administrator can tell you which method to use. Most current LAN networks use DHCP.

DHCP Configuration

If the DHCP server uses dynamic DNS to link the hostname with the assigned IP address, the hostname may be used in place of the IP address. Otherwise, the hostname is not usable.

Ethernet Interface Connection and Setup

The instrument fully supports the IEEE-802.3 standard. All functions (except power on/off and the Optional LO RF jumper configuration) can be remotely controlled via a network server and an Ethernet connection. The instrument firmware supports the TCP/IP network protocol.

Ethernet uses a bus or star topologies where all of the interfacing devices are connected to a central cable called the bus or are connected to a hub. Ethernet uses the CSMA/CD access method to handle simultaneous transmissions over the bus. CSMA/CD stands for Carrier Sense Multiple Access/Collision Detection. This standard enables network devices to detect simultaneous data channel usage, called a collision, and provides for a contention protocol. When a network device detects a collision, the CSMA/CD standard dictates that the data will be retransmitted after waiting a random amount of time. If a second collision is detected, the data is again retransmitted after waiting twice as long. This is known as exponential back off.

The TCP/IP setup requires the following:

- IP Address: Every computer/electronic device in a TCP/IP network requires an IP address. An IP address has four numbers (each between 0 and 255) separated by periods.

For example: 192.168.1.50 is a valid IP address.

- Subnet Mask: The subnet mask distinguishes the portion of the IP address that is the network ID from the portion that is the station ID. The subnet mask 255.255.0.0, when applied to the IP address given above, would identify the network ID as 192.168 and the station ID as 1.50. All stations in the same local area network should have the same network ID, but different station IDs.
- Default Gateway: A TCP/IP network can have a gateway to communicate beyond the LAN identified by the network ID. A gateway is a computer or electronic device that is connected to two different networks and can move TCP/IP data from one network to the other. A single LAN that is not connected to other LANs requires a default gateway setting of 0.0.0.0. If you have a gateway, then the default gateway would be set to the appropriate value of your gateway.
- MAC Address: A MAC address is a unique 48-bit value that identifies a network interface card to the rest of the network. Every network card has a unique MAC address permanently stored into its memory.

Interface between the instrument and other devices on the network is connected to a network via a category five (CAT-5) interface cable. This cable uses four twisted pairs of copper insulators terminated into an RJ45 connector. CAT-5 cabling is capable of supporting frequencies up to 100 MHz and data transfer speeds up to 1 Gbps, which accommodates 1000Base-T, 100Base-T, and 10Base-T networks.

Generally, a VISA I/O library (like NI-VISA) is used on the server side to facilitate the communications. A VISA installation on the controller is a prerequisite for remote control over LAN interface. VISA is a standardized software interface library providing input and output functions to communicate with instruments. For more information about VISA refer to the VISA library supplier's documentation.

Only the IP address or the device name is required for link setup. The IP address/device name is part of the "visa resource string" used by the programs for identification and control of the instrument. The visa resource string has the form:

`TCPIP::ipaddr::inst0::INSTR`

ipaddr must be replaced by the IP address or the computer name of the instrument.

For instance, if the instrument has the IP address 192.168.1.50, TCPIP::192.168.1.50::inst0::INSTR is the valid resource name. Specification of inst0 in the resource name is optional. In this example, also TCPIP::192.168.1.50::INSTR is therefore a valid resource name.

TCPIP designates the network protocol used and **INSTR** indicates that the VXI-11 protocol is used. If several instruments are connected to the network, each instrument has its own IP address and associated resource name. The controller identifies these instruments by means of the resource name.

Using Sockets LAN

Sockets LAN is a method used to communicate with the signal source analyzer over the LAN interface using the Transmission Control Protocol/Internet Protocol (TCP/IP). A socket is a fundamental technology used for computer networking and allows applications to communicate using standard mechanisms built into network hardware and operating systems. The method accesses a port on the signal source analyzer from which bidirectional communication with a network computer can be established.

Sockets LAN can be described as an Internet address that combines Internet Protocol (IP) with a device port number and represents a single connection between two pieces of software. The socket can be accessed using code libraries packaged with the computer operating system. Two common versions of socket libraries are the Berkeley Sockets Library for UNIX systems and Winsock for Microsoft operating systems.

Your signal source analyzer implements a socket Applications Programming Interface (API) that is compatible with Berkeley socket for UNIX systems and Winsock for Microsoft systems. The signal source analyzer is also compatible with other standard sockets APIs. The signal source analyzer can be controlled using predefined SCPI functions once the socket connection is established in your program. Socket connection is available on port 18.

Using and Configuring VXI-11 (VISA)

The signal source analyzer supports the LAN interface protocol described in the VXI-11 standard. VXI-11 is an instrument control protocol based on Open Network Computing/Remote Procedure Call (ONC/RPC) interfaces running over TCP/IP.

A range of standard software such as NI-VISA or Keysight IO Config is available to setup the computer/signal source analyzer interface for the VXI-11 protocol. Refer to the applicable software user manual and documentation for information on running the program and configuring the VXI-11 interface. The program is used to configure the LAN client. Once the computer is configured for a LAN client, you can use the VXI-11 protocol and the VISA library to send SCPI commands to the signal source analyzer over the LAN interface. Example programs are available on request under support@keysight.com.

VISA is an IO library used to develop IO applications and instrument drivers that comply with industry standards. It is recommended to use the VISA library for programming the signal source analyzer. The NI-VISA and Keysight VISA libraries are similar implementations of VISA and have the same commands, syntax, and functions.

Using Telnet LAN (Port 18)

Telnet provides a means of communicating with the signal source analyzer over the LAN. The Telnet client, runs on a LAN connected computer and will create a session on the signal source analyzer. A connection, established between computer and signal source analyzer, generates a command line. prompts on the command line.

Telnet service uses newline '\n' (0x0D hex) as line (and command) termination character.

Using the Telnet protocol to send commands to the signal source analyzer is similar to communicating with the signal source analyzer over LAN. You establish a connection with the signal source analyzer and then send or receive information using predefined commands. Communication is interactive: one command at a time. The telnet service is available on port 18.

USB (USBTMC)

All instruments support the following USB interface protocols:

- **USBTMC class device via VISA: USBTMC** stands for **USB Test & Measurement Class**. USBTMC is a protocol built on top of USB that allows GPIB-like communication with USB devices. From the user's point of view, the USB device behaves just like a GPIB device. USBTMC allows instrument manufacturers to upgrade the physical layer from GPIB to USB while maintaining software compatibility with existing software such as instrument drivers and any application that uses VISA. This is also what the VXI-11 protocol provides for TCP/IP.
- **USBTMC with IVI drivers:** the application programming interface (API) provided with the instrument supports general programming using the USB interface under the Windows operating system using the IVI drivers.

USB-TMC Interface Connection and Setup using VISA

From the user's point of view, the USB device behaves just like a GPIB device. For example, you can use VISA Write to send the *IDN? query and use VISA Read to get the response. The USBTMC protocol supports service request, triggers and other GPIB specific operations.

USBTMC upgrades the physical layer from GPIB to USB while maintaining software compatibility with existing software such as instrument drivers and any application that uses VISA. This is also what the VXI-11 protocol provides for TCP/IP.

NI-VISA 3.0 or later allows you to communicate as a controller to PN3 devices. NI-VISA is configured to detect USBTMC compliant instruments such as the PN3. To use such a device, plug it in and Windows should detect the new hardware and launch the New Hardware Wizard. Instruct the wizard to search for the driver, which in this case is NI-VISA. If NI-VISA is properly installed, the device will be installed as a USB Test & Measurement Class Device. Open Measurement & Automation Explorer (MAX). The new device will appear in MAX under Device and Interfaces > USB Devices. You can then use this resource name as you would use any GPIB resource.

USB-TMC Interface Connection and Setup using Keysight API

Keysight API programming interface supports direct communication to instruments using Keysight's proprietary DLL driver libraries.

Please contact Keysight for more detailed documentation, programming samples, and updates on the DLL library.

GPIB Interface Connection and Setup

General GPIB information

GPIB (General Purpose Interface Bus) is an interface standard for connecting computers and peripherals, which supports the following international standards: IEEE 488.1, IEC-625, IEEE 488.2, and JIS-C1901. The GPIB interface allows you to control the PN3 from an external computer. The computer sends commands and instructions to the PN3 and receives data sent from the PN3 via GPIB.

You can connect up to 15 devices in a single GPIB system.

The length of cables to connect between devices must be 4 m or less. The total length of connecting cables in a single GPIB system must be 2 m x the number of connected devices (including the controller) or less. You cannot construct the system in which the total cable length exceeds 20 m.

The number of connectors connected to an individual device must be 4 or less. If you connect 5 or more connectors, excessive force is applied to the connector part, which may result in failure.

You can choose the device connection topology from star, linear, and combined. Loop connection is not allowed.

SCPI Commands

The Standard Commands for Programmable Instrumentation (SCPI) provides a uniform and consistent language to control programmable test and measurement devices in instrumentation systems. The SCPI standard is built on the foundation of IEEE-488.2, Standard Codes and Formats. It requires conformance to IEEE-488.2, but is a pure software standard. SCPI syntax is ASCII text, and therefore can be attached to any computer test language such as BASIC, C, or C++. It can also be used with Test Application Environments such as LabWindows/CVI, LabVIEW™, or Matlab®. SCPI is hardware independent. SCPI strings can be sent over any instrument interface. It works equally well over USB-TMC, GPIB, RS-232, VXIbus or LAN networks.

Please see the **Chapter 3, “SCPI Commands,”** for detailed description of supported SCPI commands.

2 IEEE-488 Interface Commands

The following topics can be found in this chapter:

“IEEE Mandated and Optional Common Commands” on page 20

IEEE Mandated and Optional Common Commands

The required common commands are IEEE-488.2 mandated commands that are defined in the IEEE-488.2 standard and must be implemented by all SCPI compatible instruments. These commands are identified by the asterisk (*) at the beginning of the command keyword. These commands are used to control instrument status registers, status reporting, synchronization, and other common functions.

Commands declared mandatory by IEEE 488.2.

- *CLS Clear Status Command
- *ESE Standard Event Status Enable Command
- *ESE? Standard Event Status Enable Query
- *ESR? Standard Event Status Register Query
- *IDN? Identification Query
- *OPC Operation Complete Command
- *OPC? Operation Complete Query
- *RST Reset Command
- *SRE Service Request Enable Command
- *SRE? Service Request Enable Query
- *STB? Read Status Byte Query
- *TST? Self-Test Query
- *WAI Wait-to-Continue Command

Optional common commands described by IEEE 488.2

- *OPT? Option Identification Query

*CLS

The Clear Status (CLS) command clears the status byte by emptying the error queue and clearing all the event registers including the Data Questionable Event Register, the Standard Event Status Register, the Standard Operation Status Register, and any other registers that are summarized in the status byte.

*ESE<data>

The Standard Event Status Enable (ESE) command sets the Standard Event Status Enable Register. The variable <data> represents the sum of the bits that will be enabled.

Range: 0–255

Remarks: The setting enabled by this command is not affected by signal source analyzer preset or *RST. However, cycling the signal source analyzer power will reset this register to zero.

*ESE?

The Standard Event Status Enable (ESE) query returns the value of the Standard Event Status Enable Register.

Range: 0–255

ESR?

The Standard Event Status Register (ESR) query returns the value of the Standard Event Status Register.

*IDN?

The Identification (IDN) query outputs an identifying string. The response will show the following information: <company name>, <model number>, <serial number>, <firmware revision>

*OPC

The Operation Complete (OPC) command sets bit 0 in the Standard Event Status Register when all pending operations have finished.

The Operation Complete command causes the device to set the operation complete bit (bit 0) in the Standard Event Status Register when all pending operations have been finished.

*OPC?

The Operation Complete (OPC) query returns the ASCII character 1 in the Standard Event Status Register when all pending operations have finished.

This query stops any new commands from being processed until the current processing is complete. This command blocks the communication until all operations are complete (i.e. the timeout setting should be longer than the longest sweep).

*OPT?

The options (OPT) query returns a comma-separated list of all currently installed instrument options on the signal source analyzer.

Common returned option strings are:

0	Basic device
B3	Rechargeable battery pack
PE PE2 PE3 PE4	Extended power range
GPB	GPIB (IEEE 488) programming interface

*RCL<reg>

The Recall (RCL) command recalls the state from the specified memory register <reg>.

*RST

The Reset (RST) command resets most signal source analyzer functions to factory- defined conditions.

Remarks: Each command shows the [*RST] default value if the setting is affected.

*SAV <reg>

The Save (SAV) command saves signal source analyzer settings to the specified memory register <reg>.

Remarks: The save function does not save all signal source analyzer settings. Refer to the User's Guide for more information on the save function.

*SRE<data>

The Service Request Enable (SRE) command sets the value of the Service Request Enable Register. The variable <data> is the decimal sum of the bits that will be enabled. Bit 6 (value 64) is ignored and cannot be set by this command.

Range: 0–255

The setting enabled by this command is not affected by signal source analyzer preset or *RST. However, cycling the signal source analyzer power will reset it to zero.

***SRE?**

The Service Request Enable (SRE) query returns the value of the Service Request Enable Register.

Range: 0-63 & 128-191

***STB?**

The Read Status Byte (STB) query returns the value of the status byte including the master summary status (MSS) bit.

Range: 0-255

***TRG**

The Trigger (TRG) command triggers the device if bus trigger is the selected trigger source, otherwise, *TRG is ignored.

***TST?**

The Self-Test (TST) query initiates the internal self- test and returns one of the following results:

0 - This shows that all tests passed.

1 - This shows that one or more tests failed.

***WAI**

The Wait-to-Continue (WAI) command causes the signal source analyzer to wait until all pending commands are completed, before executing any other commands.

3 SCPI Commands

This chapter introduces SCPI programming that includes descriptions of the command types, hierarchical command structure, data parameters, and notational conventions. Information on PN3 status system and trigger system programming is also provided.

The following topics can be found in this chapter:

“Introduction” on page 26

“SCPI Command Types” on page 27

“SCPI Command Syntax” on page 28

“Hierarchical Command Structure” on page 30

“Status System Programming” on page 31

“Status Registers” on page 32

“Status Group Reporting” on page 33

“Standard Event Status Group” on page 34

“Questionable Status Group” on page 35

Introduction

Standard Commands for Programmable Instruments (SCPI) is a instrument command language for controlling instruments that goes beyond IEEE 488.2 to address a wide variety of instrument functions in a standard manner. SCPI promotes consistency, from the remote programming standpoint, between instruments of the same class and between instruments with the same functional capability. For a given measurement function such as frequency or voltage, SCPI defines the specific command set that is available for that function. Thus, two oscilloscopes made by different manufacturers could be used to make frequency measurements in the same way. It is also possible for a SCPI counter to make a frequency measurement using the same commands as an oscilloscope. SCPI commands are easy to learn, self-explanatory and account for both novice and expert programmer's usage. Once familiar with the organization and structure of SCPI, considerable efficiency gains can be achieved during control program development, independent of the control program language selected.

A key to consistent programming is the reduction of multiple ways to control similar instrument functions. The philosophy of SCPI is for the same instrument functions to be controlled by the same SCPI commands. To simplify learning, SCPI uses industry-standard names and terms that are manufacturer and customer supported.

The advantage of SCPI for the ATE system programmer is reducing the time learning how to program new SCPI instruments after programming their first SCPI instrument.

Programmers who use programming languages such as BASIC, C, FORTRAN, etc., to send instrument commands to instruments will benefit from SCPI. Also, programmers who implement instrument device drivers for ATE program source analyzers and/or software instrument front panels will benefit by SCPI's advantages. SCPI defines instrument commands, parameters, data, and status. It is not an application package, programming language or software intended for instrument front panel control.

SCPI is designed to be layered on top of the hardware-independent portion of IEEE 488.2.

SCPI Command Types

SCPI commands, which are also referred to as SCPI instructions, are messages to the instrument to perform specific tasks. The PN3 command set includes:

- “Common” commands (IEE488.2 mandated commands)
- SCPI required commands
- SCPI optional commands (per SCPI 1999.0)
- SCPI compliant commands that are unique to the PN3. Not all of the commands supported by the instrument are taken from the SCPI standard; however, their syntax follows SCPI rules.

SCPI Command Syntax

Typical SCPI commands consist of one or more keywords, parameters, and punctuation. SCPI command keywords can be a mixture of upper- and lower-case characters. Except for common commands, each keyword has a long and a short form. In this manual, the long form is presented with the short form in upper case and the remainder in lower case. Unrecognized versions of long form or short form commands, or improper syntax, will generate an error.

Structure of a Command Line

A command line may consist of one or several commands. It is terminated by an EOI together with the last data byte.

Several commands in a command line must be separated by a semicolon ";". If the next command belongs to a different command system, the semicolon is followed by a colon. A colon ":" at the beginning of a command marks the root node of the command tree.

If the successive commands belong to the same system, having one or several levels in common, the command line can be abbreviated. To this end, the second command after the semicolon starts with the level that lies below the common levels. The colon following the semicolon must be omitted in this case.

Responses to Queries

A query is defined for each setting command unless explicitly specified otherwise. It is formed by adding a question mark to the associated setting command. According to SCPI, the responses to queries are partly subject to stricter rules than in standard IEEE 488.2.

Parameters

Most commands require a parameter to be specified. The parameters must be separated from the header by a "white space". Permissible parameters are numerical values, Boolean parameters, text, character strings and block data. The type of parameter required for the respective command and the permissible range of values are specified in the command description.

Numerical values

Numerical values can be entered in any form, i.e. with sign, decimal point and exponent. Values exceeding the resolution of the instrument are rounded up or down. The mantissa may comprise up to 255 characters, the values must be in the value range $-9.9\text{E}37$ to $9.9\text{E}37$. The exponent is introduced by an "E" or "e". Entry of the exponent alone is not allowed.

Units

In the case of physical quantities, the unit can be entered. Permissible unit prefixes are G (giga), MA (mega), MHz are also permissible), K (kilo), M (milli), U (micro) and N (nano). If the unit is missing, the basic unit is used.

Boolean Parameters

Boolean parameters represent two states. The ON state (logically true) is represented by ON or a numerical value unequal to 0. The OFF state (logically false) is represented by OFF or the numerical value 0. ON or OFF is returned by a query.

Hierarchical Command Structure

All SCPI commands, except the common commands, are organized in a hierarchical structure similar to the inverted tree file structure used in most computers. The SCPI standard refers to this structure as “the Command Tree.” The command keywords that correspond to the major instrument control functions are located at the top of the command tree. The command keywords for the PN3 SCPI command set are shown below.

:ABORt
:CALCulate
:INITiate
:SENSe
:SOURce
:SYSTem

All PN3 SCPI commands, except the “**ABORt**” command, have one or more subcommands (keywords) associated with them to further define the instrument function to be controlled. The subcommand keywords may also have one or more associated subcommands (keywords). Each subcommand level adds another layer to the command tree. The command keyword and its associated subcommand keywords form a portion of the command tree called a command subsystem.

Status System Programming

The PN3 implements the Status Byte Register, the Service Request Enable Register, the Standard Event Status Register, and the Standard Event Status Enable Register.

The PN3 status system consists of the following SCPI-defined status reporting structures:

- The Instrument Summary Status Byte
- The Standard Event Status Group
- The Operation Status Group
- The Questionable Status Group

Status Registers

In general, a status group consists of a condition register, a transition filter, an event register, and an enable register. Each component is briefly described in the following paragraphs.

Condition Register

The condition register is continuously updated to reflect the current status of the signal source analyzer. There is no latching or buffering for this register, it is updated in real time. Reading the contents of a condition register does not change its contents.

Transition Filter

The transition filter is a special register that specifies which types of bit state changes in the condition register will set corresponding bits in the event register. Negative transition filters (NTR) are used to detect condition changes from True (1) to False (0); positive transition filters (PTR) are used to detect condition changes from False (0) to True (1). Setting both positive and negative filters True allows an event to be reported anytime the condition changes. Transition filters are read-write. Transition filters are unaffected by queries or *CLS (clear status) and *RST commands. The command `Status:Preset` sets all negative and positive transition filters to all 0's.

Event Register

The event register latches transition events from the condition register as specified by the transition filter. Bits in the event register are latched, and once set they remain set until cleared by a query or a *CLS command. Event registers are read only.

Enable Register

The enable register specifies the bits in the event register that can produce a summary bit. The PN3 logically ANDs corresponding bits in the event and enable registers, and ORs all the resulting bits to obtain a summary bit. Summary bits are recorded in the Summary Status Byte. Enable registers are read-write. Querying an enable register does not affect it. The command `Status:Preset` sets the Operation Status Enable register and the Questionable Status Enable register to all 0's.

Status Group Reporting

The state of certain PN3 hardware and operational events and conditions can be determined by programming the status system. Three lower status groups provide status information to the Summary Status Byte group. The Summary Status Byte group is used to determine the general nature of an event or condition and the other status groups are used to determine the specific nature of the event or condition.

Summary Status Byte Group

The Summary Status Byte group, consisting of the Summary Status Byte Enable register and the Summary Status Byte, is used to determine the general nature of an PN3 event or condition. The bits in the Summary Status Byte provide the following:

Operation Status Group

The Operation Status group, consisting of the Operation Condition register, the Operation Positive Transition register, the Operation Negative Transition register, the Operation Event register and the Operation Event Enable register.

Standard Event Status Group

The Standard Event Status group, consisting of the Standard Event Status register (an Event register) and the Standard Event Status Enable register, is used to determine the specific event that set bit 5 of the Summary Status Byte.

The bits in the Standard Event Status register provide the following:

Bit	Description
0	Set to indicate that all pending PN3 operations were completed following execution of the “*OPC” command.
1	Request control
2	Set to indicate that a query error has occurred. Query errors have SCPI error codes from –499 to –400.
3	Set to indicate that a device-dependent error has occurred. Device-dependent errors have SCPI error codes from –399 to –300 and 1 to 32767.
4	Set to indicate that an execution error has occurred. Execution errors have SCPI error codes from –299 to –200.
5	Set to indicate that a command error has occurred. Command errors have SCPI error codes from –199 to –100.
6	User request
7	Power on

Questionable Status Group

The Questionable Status group, consisting of the Questionable Condition register, the Questionable Positive Transition register, the Questionable Negative Transition register, the Questionable Event register, and the Questionable Event Enable register, is used to determine the specific condition that set bit 3 in the Summary Status Byte.

The bits in the Questionable Status register provide the following:

Bit	Description
0	NOT USED
1	NOT USED
2	NOT USED
3	Output power level inaccurate or out of range.
4	Device temperature out of operating range.
5	Output frequency inaccurate or out of range.
6	NOT USED
7	Modulation inaccurate or out of range.
8	NOT USED
9	NOT USED
10	NOT USED
11	NOT USED
12	NOT USED
13	NOT USED
14	NOT USED
15	NOT USED

4 SCPI Command Descriptions

“:ABORt Subsystem” on page 38

“:CALCulate Subsystem” on page 39

“:INITiate Subsystem” on page 49

“:SENSe Subsystem” on page 50

“:SOURce Subsystem” on page 63

“:SYSTem Subsystem” on page 64

:ABORt Subsystem

The :ABORt command is a single command subsystem. There are no subcommands or associated data parameters, as shown below. The :ABORt command, along with the :TRIGger and :INITiate commands, comprise the Trigger group of commands.

ABORt

ABOR

Aborts measurements in progress.

:CALCulate Subsystem

The CALCulate subsystem performs post acquisition data processing. Functions in the SENSE subsystem are related to data acquisition, the CALCulate subsystem operates on the data acquired by a SENSE function.

:CALCulate:AN Branch

The CALC:AN branch handles amplitude noise measurements.

Command	Parameters	Unit
:CALCulate:AN:TRACe:FREQuency?		Hz
:CALCulate:AN:TRACe:NOISe?		dBc/Hz
:CALCulate:AN:TRACe:SPOT?	<float>	dBc/Hz
:CALCulate:AN:TRACe:SPURious:FREQuency?		Hz
:CALCulate:AN:TRACe:SPURious:POWer?		dBc
:CALCulate:AN:PRELiminary:AVERage?		
:CALCulate:AN:PRELiminary:AVERage:CORRelation?		

:AN:TRACe:FREQuency?

:CALCulate:AN:TRACe:FREQuency?

Returns a list of offset frequency values of the current measurement as block data. (Block data according to IEEE 488.2. See section 7 for more details.)

Unit: Hz

*RST: empty list

:AN:TRACe:NOISe?

:CALCulate:AN:TRACe:NOISe?

Returns a list of amplitude noise spectrum values of the current measurement as block data.

Unit: dBc/Hz

*RST: empty list

:AN:TRACe:SPOT?

:CALCulate:AN:TRACe:SPOT? <float>

Returns the spot noise value at the specified offset frequency. The parameters defines the spot noise offset frequency in [Hz].

Unit: dBc/Hz

*RST: -1000.0

:AN:TRACe:SPURious:FREQuency?

:CALCulate:AN:TRACe:SPURious:FREQuency?

Returns a list of offset frequencies of the spurs in the active trace as block data. The order of the list corresponds to the values retrieved by CALC:AN:TRAC:SPUR:POW?.

Unit: Hz

*RST: empty list

:AN:TRACe:SPURious:POWer?

:CALCulate:AN:TRACe:SPURious:POWer?

Returns a list of power values of the spurs in the active trace as block data. The order of the list corresponds to the values retrieved by CALC:AN:TRAC:SPUR:FREQ?.

Unit: dBc

*RST: empty list

:AN:PRELiminary:AVERage?

:CALCulate:AN:PRELiminary:AVERage?

Returns the number of averages of the current preliminary result.

*RST: 0

:AN:PRELiminary:CORRelation?

:CALCulate:AN:PRELiminary:CORRelation?

Returns the number of cross correlations of the current preliminary result.

*RST: 0

:CALCulate:FN Branch

The CALC:FN branch handles phase noise measurements. This is an alternative method to measure phase noise, that doesn't depend on a locking mechanism (and is therefore suitable for signals that are too unstable to be measured with the CALC:PN branch).

Command	Parameters	Unit
:CALCulate:FN:PRELiminary:AVERage?		
:CALCulate:FN:PRELiminary:CORRelation?		
:CALCulate:FN:TRACe:FREQuency?		Hz

Command	Parameters	Unit
:CALCulate:FN:TRACe:NOISe?		dBc/Hz
:CALCulate:FN:TRACe:SPOT?	<float>	dBc/Hz
:CALCulate:FN:TRACe:SPURious:FREQuency?		Hz
:CALCulate:FN:TRACe:SPURious:POWer?		dBc

:FN:PRELiminary: AVERage?

:CALCulate:FN:PRELiminary:AVERage?

Returns the number of averages of the current preliminary result.

*RST: 0

:FN:PRELiminary: CORRelation?

:CALCulate:FN:PRELiminary:CORRelation?

Returns the number of cross correlations of the current preliminary result.

*RST: 0

:FN:TRACe:FREQuency?

:CALCulate:FN:TRACe:FREQuency?

Returns a list of offset frequency values of the current measurement as block data. (Block data according to IEEE 488.2. See section 7 for more details.)

Unit: Hz

*RST: empty list

:FN:TRACe:NOISe?

:CALCulate:FN:TRACe:NOISe?

Returns a list of phase noise spectrum values of the current measurement as block data.

Unit: dBc/Hz

*RST: empty list

:FN:TRACe:SPOT?

:CALCulate:FN:TRACe:SPOT? <float>

Returns the spot noise value at the specified offset frequency. The parameters defines the spot noise offset frequency in [Hz].

Unit: dBc/Hz

*RST: -1000

:FN:TRACe:SPURious:FREQuency?

:CALCulate:FN:TRACe:SPURious:FREQuency?

Returns a list of offset frequencies of the spurs in the active trace as block data. The order of the list corresponds to the values retrieved by CALC:FN:TRAC:SPUR:POW?.

Unit: Hz

*RST: empty list

:FN:TRACe:SPURious:POWEr?

:CALCulate:FN:TRACe:SPURious:POWEr?

Returns a list of power values of spurs in the active trace as block data. The order corresponds to the values retrieved by CALC:FN:TRAC:SPUR:FREQ?.

Unit: dBc

*RST: empty list

:CALCulate:FREQuency?

:CALCulate:FREQuency?

Reads back the detected frequency from a frequency search (that was initiated by SENS:FREQ:EXEC). Units are in Hz.

:CALCulate:PN Branch

The CALC:PN branch handles absolute phase noise measurements.

Command	Parameters	Unit
:CALCulate:PN:PRELiminary:AVERage?		
:CALCulate:PN:PRELiminary:CORRelation?		
:CALCulate:PN:TEST?		
:CALCulate:PN:TRACe:FREQuency?		Hz
:CALCulate:PN:TRACe:NOISE?		dBc/Hz
:CALCulate:PN:TRACe:SPOT?	<float>	dBc/Hz
:CALCulate:PN:TRACe:FUNCTion:AVARiance		
:CALCulate:PN:TRACe:FUNCTion:AVARiance:SIGMa?		□
:CALCulate:PN:TRACe:FUNCTion:AVARiance:TAU?		s
:CALCulate:PN:TRACe:FUNCTion:INTegral?		dBc
:CALCulate:PN:TRACe:FUNCTion:JITTer?		s

Command	Parameters	Unit
:CALCulate:PN:TRACe:SPURious:FREQuency?		Hz
:CALCulate:PN:TRACe:SPURious:POWer?		dBc

:PN:PRELiminary:AVERage?

:CALCulate:PN:PRELiminary:AVERage?

Returns the number of averages for the current data saved on the device.

*RST: 0

:PN:PRELiminary:CORRelation?

:CALCulate:PN:PRELiminary:CORRelation?

Returns the number of cross correlations for the current data saved on the device.

*RST: 0

:PN:TEST?

:CALCulate:PN:TEST?

Returns a comma separated list of values defined by the test set command SENS:PN:TEST<definition>.

*RST: empty list

Remarks: The elements of the test set are stored during a measurement that is performed after the test set has been defined.

:PN:TRACe:FREQuency?

:CALCulate:PN:TRACe:FREQuency?

Returns a list of offset frequency points of the most recent measurement as block data. (Block data according to IEEE 488.2. See section 7 for more details.)

Unit: Hz

*RST: empty list

:PN:TRACe:NOISe?

:CALCulate:PN:TRACe:NOISe?

Returns a list of phase noise points of the most recent measurement as block data. The measurement points correspond to the frequency points returned by CALC:PN:TRAC:FREQ?.

Unit: dBc/Hz

*RST: empty list

:PN:TRACe:SPOT? <float>

:CALCulate:PN:TRACe:SPOT? <float>

Returns the phase noise value of the last measurement at the offset frequency defined in <value>. The parameter is given as offset frequency in [Hz].

Unit: dBc/Hz

*RST: -1000.0

:PN:TRACe:FUNCtion:AVARiance

:CALCulate:PN:TRACe:FUNCtion:AVARiance

Calculates the Allan variance for the current trace.

Remark: The offset frequency range used to calculate the Allan variance from the phase noise trace, is defined with the command SENS:PN:FUNC:RANG <min>,<max>.

:PN:TRACe:FUNCtion:AVARiance:SIGMa?

:CALCulate:PN:TRACe:FUNCtion:AVARiance:SIGMa?

Returns a list of sigma values of the Allan variance for the current trace as block data.

Unit: []

*RST: empty list

Remark: The offset frequency range used to calculate the Allan variance from the phase noise trace, is defined with the command SENS:PN:FUNC:RANG <min>,<max>. The Allan variance must be calculated before reading the values using the command CALC:PN:TRAC:FUNC:AVAR.

:PN:TRACe:FUNCtion:AVARiance:TAU?

:CALCulate:PN:TRACe:FUNCtion:AVARiance:TAU?

Returns a list of tau values of the Allan variance for the current trace as block data.

Unit: s

*RST: empty list

Remark: The offset frequency range used to calculate the Allan variance from the phase noise trace is defined with the command SENS:PN:FUNC:RANG <min>,<max>. The Allan variance must be calculated before reading the values using the command CALC:PN:TRAC:FUNC:AVAR.

:PN:TRACe:FUNCtion:INTegral?

:CALCulate:PN:TRACe:FUNCtion:INTegral?

Returns the integral noise of the current trace.

Unit: dBc

*RST: -1.0

Remark: The offset frequency range used to calculate the integral from the phase noise trace, is defined with the command SENS:PN:FUNC:RANG <min>,<max>.

:PN:TRACe:FUNCtion:JITTer?

:CALCulate:PN:TRACe:FUNCtion:JITTer?

Returns the RMS jitter of the current trace.

Unit: s

*RST: -1.0

Remark: The offset frequency range used to calculate the jitter from the phase noise trace, is defined with the command SENS:PN:FUNC:RANG <min>,<max>.

:PN:TRACe:SPURious:FREQuency?

:CALCulate:PN:TRACe:SPURious:FREQuency?

Returns a list of offset frequencies of the spurious in the active trace as block data.

Unit: Hz

*RST: empty list

Remark: The spurs are ordered by increasing offset frequencies. The ordering corresponds with the power value list returned by CALC:PN:TRAC:SPUR:POW?.

:PN:TRACe:FUNCtion:POWer?

:CALCulate:PN:TRACe:SPURious:POWer?

Returns a list of power values of the spurious in the active trace as block data.

Unit: dBc

*RST: empty list

Remark: The spurs are ordered by increasing offset frequencies. The ordering corresponds with the offset frequency list returned by CALC:PN:TRAC:SPUR:FREQ?.

:CALCulate:POWer?

:CALCulate:POWer?

Reads back the detected power level from a frequency search (that was initiated by SENS:FREQ:EXEC). Units are in dBm.

:CALCulate:WAIT:AVERage

:CALCulate:WAIT:AVERage NEXT | ALL | <integer>[, <integer>]

Waits for the defined event (NEXT: next iteration complete, ALL: measurement complete, <value>: specified iteration complete). Optionally, a timeout in milliseconds can be specified as a second parameter. This command will block further SCPI requests until the specified event or the specified timeout has occurred. If no timeout is specified, the timeout will be infinite.

:CALCulate:VCO Branch

The CALC:VCO branch handles VCO characterization measurements.

Command	Parameters	Unit
:CALCulate:VCO:ITERation?		
:CALCulate:VCO:TRACe:FREQuency?		Hz
:CALCulate:VCO:TRACe:ISupply?		A
:CALCulate:VCO:TRACe:KPUSH?		Hz/V
:CALCulate:VCO:TRACe:KVCO?		Hz/V
:CALCulate:VCO:TRACe:PNOise?	1 2 3 4	dBc/Hz
:CALCulate:VCO:TRACe:POWer?		dBm
:CALCulate:VCO:TRACe:VOLTage?		V
:CALCulate:VCO:WAIT	NEXT ALL[, <integer>]	

:VCO:ITERation?

:CALCulate:VCO:ITERation?

Returns the iteration of the current VCO characterization measurement.

*RST: 0

Remarks: CALC:VCO:WAIT must have been called before using this command.

:VCO:TRACe:FREQuency?

:CALCulate:VCO:TRACe:FREQuency?

Returns a list of offset frequency points of the most recent measurement as block data. (Block data according to IEEE 488.2. See section 7 for more details.)

Unit: Hz

*RST: empty list

:VCO:TRACe:ISupply?

:CALCulate:VCO:TRACe:ISupply?

Returns a list of supply current values measured at each tune voltage point of the current measurement as block data.

Unit: A

*RST empty list

:VCO:TRACe:KPUSH?

:CALCulate:VCO:TRACe:KPUSH?

Returns a list of pushing values measured at each tune voltage point of the current measurement as block data.

Unit: Hz/V

*RST: empty list

:VCO:TRACe:KVCO?

:CALCulate:VCO:TRACe:KVCO?

Returns a list of Kv values measured at each tune voltage point of the current measurement as block data.

Unit: Hz/V

*RST: empty list

:VCO:TRACe:PNoise?

:CALCulate:VCO:TRACe:PNoise? 1|2|3|4

Returns a list of phase noise values measured at each tune voltage point of the current measurement as block data. The parameter 1 - 4 selects the offset frequency from the set defined by the SENS:VCO:TEST:PN:OFFS <list> command.

Unit: dBc/Hz

*RST: empty list

:VCO:TRACe:POWer?

:CALCulate:VCO:TRACe:POWer?

Returns a list of power values measured at each tune voltage point of the current measurement as block data.

Unit: dBm

*RST: empty list

:VCO:TRACe:VOLTage?

:CALCulate:VCO:TRACe:VOLTage?

Returns a list of tune voltage values measured at each tune voltage point of the current measurement as block data.

Unit: V

*RST: empty list

:VCO:WAIT

:CALCulate:VCO:WAIT NEXT|ALL[,<integer>]

Requests a preliminary result during the measurement and blocks until the result is ready. The first parameter (required) specifies the target iteration to be saved. NEXT specifies the next possible iteration, ALL specifies the last iteration of the measurement (i.e. waits for the measurement to finish) and an integer specifies the specific iteration requested. The second parameter (optional) defines a timeout in milliseconds. If the command terminates without generating a preliminary result. It will produce an error. This error can be queried with SYST:ERR? or SYST:ERR:ALL?.

:INITiate Subsystem

The :INITiate subsystem controls the state of the trigger system. The subsystem commands and parameters are described below. The :INITiate commands, along with the :ABORt and :TRIGger commands, comprise the Trigger Group of commands.

INITiate

:INITiate[:IMMediate]

Sets the trigger to an armed state.

:SENSe Subsystem

The SENSe command subsystem directly affects device specific setting used to make measurements.

:SENSe:AN Branch

The SENSe:AN branch is used to configure the amplitude noise measurement.

Command	Parameters	Unit	Default
:SENSe:AN:PRELIminary:AVERage?			
:SENSe:AN:PRELIminary:CORRelation?			
:SENSe:AN:TRACe:FREQuency?		Hz	
:SENSe:AN:TRACe:NOISe?		dBc/Hz	
:SENSe:AN:TRACe:SPOT?	<float>	dBc/Hz	
:SENSe:AN:TRACe:SPURious:FREQuency?		Hz	
:SENSe:AN:TRACe:SPURious:POWer?		dBc	

:AN:PRELIminary:AVERage?

:SENSe:AN:PRELIminary:AVERage?

Returns the number of averages of the current preliminary result.

*RST: 0

:AN:PRELIminary:CORRelation?

:SENSe:AN:PRELIminary:CORRelation?

Returns the number of cross correlations of the current preliminary result.

*RST: 0

:AN:TRACe:FREQuency?

:SENSe:AN:TRACe:FREQuency?

Returns a list of offset frequency values of the current measurement as block data.

Unit: Hz

*RST: empty list

:AN:TRACe:NOISe?

:SENSe:AN:TRACe:NOISe?

Returns a list of amplitude noise spectrum values of the current measurement as block data.

Unit: dBc/Hz

*RST: empty list

:AN:TRACe:SPOT?

:SENSe:AN:TRACe:SPOT? <float>

Returns the spot noise value at the specified offset frequency. The parameters defines the spot noise offset frequency in [Hz].

Unit: dBc/Hz

*RST: -1000.0

:AN:TRACe:SPURious:FREQuency?

:SENSe:AN:TRACe:SPURious:FREQuency?

Returns a list of offset frequencies of the spurs in the active trace as block data.

Unit: Hz

*RST: empty list

:AN:TRACe:SPURious:POWer?

:SENSe:AN:TRACe:SPURious:POWer?

Returns a list of power values of the spurs in the active trace as block data.

Unit: dBc

*RST: empty list

:SENSe:FN Branch

The SENSe:FN branch handles phase noise measurements.

Command	Parameters	Unit
:SENSe:FN:PRELIminary:AVERAge?		
:SENSe:FN:PRELIminary:CORReLation?		
:SENSe:FN:TRACe:FREQuency?		Hz
:SENSe:FN:TRACe:NOISe?		dBc/Hz
:SENSe:FN:TRACe:SPOT?	<float>	dBc/Hz
:SENSe:FN:TRACe:SPURious:FREQuency?		Hz
:SENSe:FN:TRACe:SPURious:POWer?		dBc

:FN:PRELIminary: AVERAge?

:SENSe:FN:PRELIminary:AVERAge?

Returns the number of averages of the current preliminary result.

*RST: 0

:FN:PRELIminary: CORReLation?

:SENSe:FN:PRELIminary:CORReLation?

Returns the number of cross correlations of the current preliminary result.

*RST: 0

:FN:TRACe:FREQuency?

:SENSe:FN:TRACe:FREQuency?

Returns a list of offset frequency values of the current measurement as block data.

Unit: Hz

*RST: empty list

:FN:TRACe:NOISe?

:SENSe:FN:TRACe:NOISe?

Returns a list of phase noise spectrum values of the current measurement as block data.

Unit: dBc/Hz

*RST: empty list

:FN:TRACe:SPOT?

:SENSe:FN:TRACe:SPOT? <float>

Returns the spot noise value at the specified offset frequency. The parameters defines the spot noise offset frequency in [Hz].

Unit: dBc/Hz

*RST: -1000

:FN:TRACe:SPURious:FREQuency?

:SENSe:FN:TRACe:SPURious:FREQuency?

Returns a list of offset frequencies of the spurs in the active trace as block data.

Unit: Hz

*RST: empty list

:FN:TRACe:SPURious:POWEr?

:SENSe:FN:TRACe:SPURious:POWEr?

Returns a list of power values of spurs in the active trace as block data.

Unit: dBc

*RST: empty list

:SENSe:FREQuency:EXECute?

:SENSe:FREQuency:EXECute?

Starts the frequency search. See the “:CALCulate Subsystem” on page 39 on how to read the result.

:SENSe:MODE

:MODE PN | VCO | AN | FN | BB | TRAN

:MODE?

Sets or gets the active measurement mode.

- PN: phase noise measurement
- AN: amplitude noise measurement
- FN: frequency noise measurement
- BB: baseband measurement (not yet available)
- TRAN: transient analysis (not yet available)
- VCO: voltage controlled oscillator characterization

*RST: PN

:Sense:PN Branch

The SENSe:PN branch is used to configure the phase noise measurement.

Command	Parameters	Unit	Default
:SENSe:PN:AVERage	<integer>		1
:SENSe:PN:CORRelation	<integer>		1
:SENSe:PN:FREQuency	<float>	Hz	100e6
:SENSe:PN:FREQuency:AUTO	ON OFF		ON
:SENSe:PN:FREQuency:DETEct	ALWays NEVer		ALWays
:SENSe:PN:FREQuency:STARt	0.1 0.5 1 10 100 1k 10k 100k	Hz	100
:SENSe:PN:FREQuency:STOP	1k 10k 100k 1M 10M 50M	Hz	50e6

SCPI Command Descriptions
:SENSe Subsystem

Command	Parameters	Unit	Default
:SENSe:PN:FUNCTION:RANGe	<float>	Hz,Hz	10,50e6
:SENSe:PN:IF:GAIN	<integer>	dB	0
:SENSe:PN:IF:GAIN:AUTO	ON OFF		ON
:SENSe:PN:IF:GAIN:DETEct	ALWays ONCe NEVer		ALWays
:SENSe:PN:KPHI	<float>	rad/V	
:SENSe:PN:KPHI:AUTO	ON OFF		ON
:SENSe:PN:LOBandwidth	<float>	Hz	10
:SENSe:PN:LOBandwidth:AUTO	ON OFF		ON
:SENSe:PN:PPD	<integer>		250
:SENSe:PN:REFErences	LN NORN EXT		NORM
:SENSe:PN:REFErences<ch>:SENSitivity	<float>	Hz/V	1
:SENSe:PN:REFErences:SENSitivity:EXECute			
:SENSe:PN:RESet			
:SENSe:PN:SMOothing:APERture	<float>	%	0.05
:SENSe:PN:SMOothing:STATe	ON OFF		OFF
:SENSe:PN:SPURious:OMISSion	ON OFF		ON
:SENSe:PN:TEST	<string>		OFF

:PN:AVERage

:SENSe:PN:AVERage <integer>

:SENSe:PN:AVERage?

Sets or gets the average count of the measurement.

Range: 1 - 10000

*RST: 1

:PN:CORRelation

:SENSe:PN:CORRelation <integer>

:SENSe:PN:CORRelation?

Sets or gets the number of cross correlations of the current preliminary result.

Range: 1 - 10000

*RST: 1

:PN:FREQuency

:SENSe:PN:FREQuency <float>

:SENSe:PN:FREQuency?

Sets or gets the DUT frequency.

ALWays: Perform it for every measurement

ONCe: Perform it only if it hasn't been performed since startup of the instrument.

Unit: Hz

*RST: 100000000.0

:PN:FREQuency:AUTO

:SENSe:PN:FREQuency:AUTO ON | OFF

:SENSe:PN:FREQuency:AUTO?

Enables or disables the automatic frequency search at the start of the measurement.

*RST: ON

:PN:FREQuency:DETECT

:SENSe:PN:FREQuency:DETECT ALWays | ONCE | NEVer

:SENSe:PN:FREQuency:DETECT?

Sets how often the automatic frequency search should be performed (if activated via SENS:PN:FREQ:AUTO).

ALWays: Perform it for every measurement

ONCe: Perform it only if it hasn't been performed since startup of the instrument.

NEVer: Always skip it

*RST: ALWays

:PN:FREQuency:STArT

:SENSe:PN:FREQuency:STArT ><float>

:SENSe:PN:FREQuencySTArT?

Sets or gets the start offset frequency.

Unit: Hz

*RST: 10

:PN:FREQuency:STOP

:SENSe:PN:FREQuency:STOP ><float>

:SENSe:PN:FREQuencySTOP?

Sets or gets the stop offset frequency.

Unit: Hz

*RST: 100000000.0

:PN:FUNction:RANGe

:SENSe:PN:FUNction:RANGe <float>,<float>

Sets or gets the frequency offset range for the FUNction subsystem. The first parameter represents the minimum offset frequency, the second parameter represents the maximum offset frequency of the range. This system offers statistical analysis of the measurement data.

Unit: Hz,Hz

Range: 0.1 -50e6,01 - 50e6

:PN:IFGain

:SENSe:PN:IFGain <integer>

:SENSe:PN:IFGain?

Sets or gets the gain for the measurement.

Range: 0 - 60

*RST: 0

:PN:IFGain:AUTO

:SENSe:PN:IFGain:AUTO ON | OFF

:SENSe:PN:IFGain:AUTO?

Enables or disables the automatic IF gain setting.

*RST: ON

:PN:IFGain:DETect

:SENSe:PN:IFGain:DETect ALWays | ONCe | NEVer

:SENSe:PN:IFGain:DETect?

Sets how often the IF gain should be automatically determined.

ALWays: Perform it for every measurement

ONCe: Perform it only if it hasn't been performed since startup of the instrument.

NEVer: Always skip it

*RST: ALWays

:PN:KPHI

:SENSe:PN:KPHI <float>

:SENSe:PN:KPHI?

Sets or gets Kphi.

Unit: rad/V

*RST: 0.0

:PN:KPHI:AUTO

:SENSe:PN:KPHI:AUTO ON|OFF

:SENSe:PN:KPHI:AUTO?

Enables/disables the automatic Kphi detection at the start of the measurement.

*RST: On

:PN:LOBandwidth

:SENSe:PN:LOBandwidth <float>

:SENSe:PN:LOBandwidth?

Sets or gets the PLL bandwidth for the selected channel.

Unit: Hz

Range: 0.1 - 10000

*RST: 1.0

:PN:PPD

:SENSe:PN:PDD <integer>

:SENSe:PN:PDD?

Sets or gets the number of points per decade for the resulting trace.

Range: 1 - 500

*RST: 250

:PN:REReferences

:SENSe:PN:REReferences LN | NORM | EXT

:SENSe:PN:REReferences?

Selects the reference used for the measurement. The options are NORM for standard internal references, LN for low noise internal references (only available with option LN) and EXT for external references.

*RST: NORM

:PN:REferences<ch>:SENSitivity

:SENSe:PN:REferences<ch>:SENSitivity <float>

:SENSe:PN:REferences?

Sets or gets the sensitivity for the specified reference. The reference can be specified with <ch> selector to select channel 1 or 2.

Unit: Hz/V

Range: 0.1 - 500

*RST: 10.0

:PN:RESet

:SENSe:PN:RESet

Resets the measurement. The measurement configuration will remain, but the detect will be reset (ONCe will activate again).

:PN:SMOothing:APERture

:SENSe:PN:SMOothing:APERture <float>

:SENSe:PN:SMOothing:APERture?

Enables or disables the smoothing aperture of the trace.

Unit: %

Range: 0.05 - 20

*RST: ON

:PN:SMOothing:STATe

:SENSe:PN:SMOothing:STATe ON | OFF

:SENSe:PN:SMOothing:STATe?

Enables or disables trace smoothing.

*RST: ON

:PN:SPURious:OMISSion

:SENSe:PN:SPURious:OMISSion ON | OFF

:SENSe:PN:SPURious:OMISSion?

Enables or disables spur omission for the trace and statistical analysis.

*RST: ON

:PN:TEST

:SENSe:PN:TEST <string>

:SENSe:PN:TEST?

Sets or gets the test set definition. The test set definition is a comma separated list of keywords from the following list.

O<float>	phase noise in [dBc/Hz] at offset <float> specified in [Hz]
F	detected frequency in [Hz]
P	detected power level in [dBm]
J	jitter value in [fs], offset rant is defined with the command SENS:PN:FUNC:RANG <float>,<float>
I	integrated phase noise in [dBc] (same offset range as jitter)
D	residual PM in [udeg] (same offset range as jitter)
R	residual PM in [urad] (same offset range as jitter)
M	residual FM in [Hz] (same offset range as jitter)
Example	SENS:PN:TEST 01e3,01e5,01e6,05e6,F,P,J This test set contains the phase noise values (in this order) at 1kHz, 100kHz, 1MHz, 5MHz, the detected frequency, the detected power level and the calculated jitter.
Remarks	The query retrieves the test set definition, not the resulting test set from a measurement. To retrieve the resulting test set from the previous measurement, use CALC:PN:TEST?.

:SENSe:POWEr:EXECute?

:SENSe:POWEr:EXECute?

Starts the power measurement. When performing SENS:FREQ:EXEC, this measurement will be automatically run at the end (if a signal is detected). See the **“:CALCulate Subsystem” on page 39** on how to read out the result.

:SENSe:VCO Branch

The SENSe:VCO branch is used to configure the VCO characterization measurement.

Command	Parameters	Unit	Default
:SENSe:VCO:TEST:FREQuency	ON OFF		ON
:SENSe:VCO:TEST:ISUPply	ON OFF	ON	ON

Command	Parameters	Unit	Default
:SENSe:VCO:TEST:KPUShing	ON OFF	ON	ON
:SENSe:VCO:TEST:KVCO	ON OFF	ON	ON
:SENSe:VCO:TEST:PNoise	ON OFF	OFF	OFF
:SENSe:VCO:TEST:PNoise:COUNT?			0
:SENSe:VCO:TEST:PNoise:OFFSet	<float>,<float>,<float>,<float>	Hz	10k, 100k, 1M, 10M
:SENSe:VCO:TEST:PNoise:OFFSet<sel>?			
:SENSe:VCO:TEST:POWer	ON OFF		ON
:SENSe:VCO:TYPE	VCO/VCXO		VCO
:SENSe:VCO:VOLTage:POINts	<integer>		10
:SENSe:VCO:VOLTage:START	<float>	V	0.0
:SENSe:VCO:VOLTage:STOP	<float>	V	5.0

:VCO:TEST:FREQuency

:SENSe:VCO:TEST:FREQuency ON | OFF

:SENSe:VCO:TEST:FREQuency?

Enables or disables the frequency parameter for the measurement.

*RST: ON

:VCO:TEST:ISUPply

:SENSe:VCO:TEST:ISUPply ON | OFF

:SENSe:VCO:TEST:ISUPply?

Enables or disables the supply current for the measurement.

*RST: ON

:VCO:TEST:IKPUShing

:SENSe:VCO:TEST:KPUShing ON | OFF

:SENSe:VCO:TEST:KPUShing?

Enables or disables the pushing parameter for the measurement.

*RST: ON

:VCO:TEST:KVCO

:SENSe:VCO:TEST:KVCO ON | OFF

:SENSe:VCO:TEST:KVCO?

Enables or disables the sensitivity parameter for the measurement.

*RST: ON

:VCO:TEST:PNoise

:SENSe:VCO:TEST:PNoise ON | OFF

:SENSe:VCO:TEST:PNoise?

Enables or disables the phase noise parameter for the measurement.

*RST: ON

:VCO:TEST:PNoise:COUNt

:SENSe:VCO:TEST:PNoise:COUNt?

Returns the number of offsets that are set.

*RST: 4

:VCO:TEST:PNoise:OFFSet

:SENSe:VCO:TEST:PNoise:OFFSet <float>,<float>,<float>,<float>

:SENSe:VCO:TEST:PNoise<sel>?

Sets up to four offset frequencies at which the phase noise is measured. At least one parameter is required. Blank parameters are set to 0 (disabled).

The query returns the set frequency for the specified offset. The offset can be specified with the <set> parameter and can be chosen from 1 | 2 | 3 | 4.

Unit: Hz

*RST: 10000.0,100000.0,1000000.0,10000000.0

:VCO:TEST:POWer

:SENSe:VCO:TEST:POWer ON | OFF

:SENSe:VCO:TEST:POWer?

Enables or disables the power parameter for the measurement.

*RST: ON

:VCO:TYPE

:SENSe:VCO:TYPE VCO | VCXO

:SENSe:VCO:TYPE?

Sets the DUT type for the measurement. VCXO is used for slow tuning sensitivities and VCO is used for fast tuning sensitivities.

*RST: VCO

:VCO:VOLTage:POINts

:SENSe:VCO:VOLTage:POINts <integer>

:SENSe:VCO:VOLTAge:POINTs?

Sets or gets the number of voltage points for the measurement.

*RST: 10

:VCO:VOLTage:START

:SENSe:VCO:VOLTage:START <float>

:SENSe:VCO:VOLTage:START?

Sets or gets the start tuning voltage for the measurement.

Unit: V

*RST: 0

:VCO:VOLTage:STOP

:SENSe:VCO:VOLTage:STOP <float>

:SENSe:VCO:VOLTage:STOP?

Sets or gets the stop tuning voltage for the measurement.

Unit: V

*RST: 5

:SOURce Subsystem

Channel selection for multi-channel devices

The SOURce subsystem allows you to set the tuning voltages of the reference and supply ports.

Command	Parameters	Unit	Default
[:SOURce] :TUNE :DUT :STAT	ON OFF		OFF
[:SOURce] :TUNE :DUT :VOLT	<float>	V	0

[:SOURce] :TUNE :DUT :STAT

:SOURce:TUNE:DUT:STAT ON | OFF

:SOURce:TUNE:DUT:STAT?

Enables or disables the DUT TUNE port

*RST: 0

[:SOURce] :TUNE :DUT :VOLT

:SOURce:TUNE:DUT:VOLT <float>

[:SOURce] :SElect?

Sets the voltage at the DUT TUNE port or returns the configured value. If the output is turned off, it doesn't necessarily return 0, as an internal voltage may be configured.

Unit: V

*RST: 0

:SYSTem Subsystem

The SYSTem subsystem allows access to system functions.

:SYSTem:COMMunicate Branch

This branch gives access to system functions to communicate with the instrument.

Command	Parameters	Unit	Default
:SYSTem:COMMunicate:GPIB:ADDRes	<integer>		1
:SYSTem:COMMunicate:LAN:CONFig	DHCP MANual AUTO		AUTO
:SYSTem:COMMunicate:LAN:DEFaults			OFF
:SYSTem:COMMunicate:LAN:GATEway	<ipv4string>		automatic
:SYSTem:COMMunicate:LAN:IP	<ipv4string>		automatic
:SYSTem:COMMunicate:LAN:REStart			
:SYSTem:COMMunicate:LAN:RTMO	INFinite <float>		INFinite
:SYSTem:COMMunicate:LAN:SUBNet	<ipv4string>		automatic
:SYSTem:COMMunicate:VXI:RTMO	INFinite <float>		INFinite

:COMMunicate:GPIB:ADDRes <integer>

:SYSTem:COMMunicate:GPIB:ADDRes <integer>

:SYSTem:COMMunicate:GPIB:ADDRes?

Sets or gets the instruments GPIB address.

Range: 1 to 30

*RST: unchanged, 1 on factory preset

:COMMunicate:LAN:CONFig

:SYSTem:COMMunicate:LAN:CONFig DHCP | MANual | AUTO

:SYSTem:COMMunicate:LAN:CONFig?

Sets or gets the Internet protocol (IP) address.

- **MANual:** The user assigns an IP address to the instrument.
- **DHCP:** The network assigns an IP address to the instrument. Requests will be repeated continuously with infinite timeout until a valid address has been assigned.
- **AUTO:** The network assigns an IP address to the instrument with a fallback to AUTO-IP if DHCP request continues to fail for more than 10 seconds.

*RST: unchanged, auto on factory preset

:COMMunicate:LAN:DEFaults

:SYSTem:COMMunicate:LAN:DEFaults?

Restores the instrument's LAN settings to their factory default values. The default mode is SYST:COMM:LAN:CONF AUTO. In this mode the instrument uses DHCP to retrieve an IP address and falls back to Auto-IP if DHCP fails.

:COMMunicate:LAN:GATEway

:SYSTem:COMMunicate:LAN:GATEway <"ipv4string">

:SYSTem:COMMunicate:LAN:GATEway?

Sets the gateway for local area network (LAN) access to the device from outside the current sub-network. The query returns the current setting, not the saved setting. The expected format for <ipv4string> is four decimal octets separated by periods, surrounded by quotation marks. Example command: SYST:COMM:LAN:GATE "192.168.1.1". In SYST:COMM:LAN:CONF DHCP|AUTO mode this setting is configured automatically.

Range: 0.0.0.0 to 255.255.255.255

*RST: unchanged, automatic in DHCP/AUTO mode

:COMMunicate:LAN:IP

:SYSTem:COMMunicate:LAN:IP <ipv4string>

:SYSTem:COMMunicate:LAN:IP?

Sets the internet protocol (IP) address for the local area network (LAN) access to the device from outside the current sub-network. The query returns the current setting, not the saved setting. The expected format for <ipv4string> is four decimal octets separated by periods, surrounded by quotation marks. Example command: SYST:COMM:LAN:IP "192.168.1.100". In SYST:COMM:LAN:CONF DHCP|AUTO mode this setting is configured automatically.

Range: 0.0.0.0 to 255.255.255.255

*RST: unchanged, automatic in DHCP/AUTO mode

:COMMunicate:LAN:REStart

:SYSTem:COMMunicate:LAN:REStart

Restarts the network to enable changes that have been made to the LAN setup.

:COMMunicate:LAN:RTMO

:SYSTem:COMMunicate:LAN:RTMO INFinite | <float>

:SYSTem:COMMunicate:LAN:RTMO?

Sets the LAN reconnect timeout in seconds or INFinite timeout. After the LAN connection is inactive for the configured timeout, a new connection can be established (reconnected). INFinite timeout disables reconnect. Finite or zero timeout enables reconnect. Non-zero finite timeout protects against undesired connection attempts.

Unit: s

Range: INFinite|0 to 1e6

*RST: unchanged, infinite on power up

:COMMunicate:LAN:SUBNet

:SYSTem:COMMunicate:LAN:SUBNet <ipv4string>

:SYSTem:COMMunicate:LAN:SUBNet?

Sets the instrument's local area network (LAN) subnet mask address for the internet protocol (IP) network connection. The query returns the current setting, not the saved setting. The expected format for <ipv4string> is four decimal octets separated by periods, surrounded by quotation marks. Example command: SYST:COMM:LAN:SUBN "255.255.255.0". In SYST:COMM:LAN:CONF DHCP|AUTO mode this setting is configured automatically.

Range: 0.0.0.0 to 255.255.255.255

*RST: unchanged, automatic in DHCP/AUTOMode

:COMMunicate:VXI:RTMO

:SYSTem:COMMunicate:VXI:RTMO INFinite | <float>

:SYSTem:COMMunicate:VXI:RTMO?

Sets the VXI-11 reconnect timeout in seconds or INFinite timeout. After the VXI connection is inactive for the configured timeout, a new connection can be established (reconnected). INFinite timeout disables reconnect. Finite or zero timeout enables reconnect. Non-zero finite timeout protects against undesired connection attempts.

Unit: s

Range: INFinite|0 to 1e6

*RST: unchanged, INFinite on power up

System:ERRor Branch

Command	Parameters	Unit	Default
:SYSTem:ERRor:All?			0, "No error"
:SYSTem:ERRor[:NEXT]?			0, "No error"
::SYSTem:ERRor:REStart			

:ERRor:ALL?

:SYSTem:ERRor:ALL?

Returns a list of integer error numbers. This query is a request for all entries in the instrument's error queue. Error messages in the queue contain an integer in the range [-32768,32768] denoting an error code and associated descriptive text. The query clears the instrument's error queue.

*RST: 0, "No error"

:ERRor[:NEXT]?

:SYSTem:ERRor[:NEXT]?

Returns the integer error number. This query is a request for the next entry in the instrument's error queue. Error messages in the queue contain an integer in the range [-32768,32768] denoting an error code and associated descriptive text.

*RST: 0, "No error"

:ERRor:REStart

:SYSTem:ERRor:REStart

Restarts the system. This will terminate the connection, shutdown the operating system, and perform a restart. On a software level, this has the same effect as power cycling the unit.

5 Programming Examples

This chapter contains various commented command sequences that showcase the usage of the SCPI Interface.

[“Absolute Phase Noise” on page 70](#)

[“VCO Characterization” on page 72](#)

[“Amplitude Noise” on page 74](#)

[“Absolute Phase Noise \(Mode FN\)” on page 76](#)

[“Block Data Format” on page 78](#)

Absolute Phase Noise

Comprehensive configuration example:

```
// configuration
> SENS:MODE PN // set phase noise measurement
> SENS:PN:REF NORM // select standard internal references
> SENS:PN:LOB:AUTO ON // enable automatic bandwidth selection
> SENS:PN:FREQ:AUTO ON // enable frequency search
> SENS:PN:FREQ:DET ALW // ^ every time
> SENS:PN:KPHI:AUTO ON // enable Kphi detection
> SENS:PN:KPHI:DET ALW // ^ every time
> SENS:PN:IFG:AUTO ON // enable automatic gain selection
> SENS:PN:IFG:DET ALW // ^ every time
> SENS:PN:TEST 01e3,01e6,F,J // define test set (PN@1kHz, PN@1MHz, freq, jitter)
> SENS:PN:RES // reset measurement configuration

// measurement
> SENS:PN:AVER 1 // 1 averages
> SENS:PN:CORR 10 // 10 correlations
> SENS:PN:PPD 150 // 150 points per decade
> SENS:PN:FREQ:STAR 10 // minimum offset frequency 10Hz
> SENS:PN:FREQ:STOP 50E6 // maximum offset frequency 50MHz
> SENS:PN:FUNC:RANG 12E3,5E6 // set integration interval to [12kHz - 5MHz]
> SENS:PN:SPUR:OMIS ON // disable spurs (enable omission of spurs)
> SENS:PN:SMO:STAT 0 // disable smoothing
> INIT // trigger measurement start

loop
> CALC:WAIT:AVER ALL,500 // wait for the measurement to finish
< SYST:ERR:ALL? // check if measurement was successful
end loop

// retrieve full trace
> CALC:PN:TRAC:FREQ? // request frequency data
< read list // binary format of list explained below
> CALC:PN:TRAC:NOIS? // request phase noise data
< read list // binary format of list explained below

// retrieve test set
< CALC:TEST? // retrieve test set
```

Simplified configuration example:

```
// measurement
> SENS:MODE PN // select phase noise measurement
> INIT // start measurement
> CALC:WAIT:AVER ALL // wait for the measurement to finish
> SYST:ERR:ALL? // check if measurement was successful
< read error queue // 0: ok, <0: fail (error code)
> CALC:PN:TRAC:SPOT? 1E6 // request spot noise value at 1MHz offset
< read value // value is in dBc/Hz
```

VCO Characterization

Comprehensive configuration example:

```
// configuration
> SENS:MODE VCO // select VCO characterization
> SENS:VCO:TEST:FREQ ON // enable frequency parameter
> SENS:VCO:TEST:ISUP ON // enable supply current parameter
> SENS:VCO:TEST:KPUS ON // enable pushing parameter
> SENS:VCO:TEST:KVCO ON // enable Kvco parameter
> SENS:VCO:TEST:PN ON // enable spot noise parameter
> SENS:VCO:TEST:PN:OFFS 1.2E3,1E5 // set two spot noise offsets: 1.2kHz, 100kHz
> SENS:VCO:TEST:POW ON // enable power parameter

// measurement
> SENS:VCO:TYPE VCO // set DUT Type (VCO or VCXO)
> SENS:VCO:VOLT:POIN 11 // set 11 measurement points
> SENS:VCO:VOLT:STAR 0.5 // set tuning range minimum to 0.5V
> SENS:VCO:VOLT:STOP 4.5 // set tuning range maximum to 10V
> SOUR:SUPP1:VOLT 5 // set supply voltage to 6V
> SOUR:SUPP1:STAT ON // enable supply voltage
> INIT // trigger measurement start

loop
> CALC:VCO:WAIT ALL,500 // wait for the measurement to finish
> SYST:ERR:ALL? // check if measurement was successful
< read error queue // 0: ok, <0: fail (or timeout -393416 -> loop)
end loop

// retrieve results
> CALC:VCO:TRAC:VOLT? // request control voltage data array
< read list // binary format of list explained below
> CALC:VCO:TRAC:FREQ? // request frequency data array
< read list // binary format of list explained below
> CALC:VCO:TRAC:KVCO? // request Kvco data array
< read list // binary format of list explained below
> CALC:VCO:TRAC:KPUS? // request pushing data array
< read list // binary format of list explained below
> CALC:VCO:TRAC:ISUP? // request supply current data array
< read list // binary format of list explained below
```


Programming Examples

VCO Characterization

```
> CALC:VCO:TRAC:POW? // request power level data array
< read list // binary format of list explained below
> CALC:VCO:TRAC:PN? 1 // request spot noise data array @offset #1 (1.2kHz)
< read list // binary format of list explained below
```

Amplitude Noise

Comprehensive configuration example:

```
// configuration
> SENS:MODE AN // set amplitude noise measurement
> SENS:AN:FREQ:AUTO ON // enable frequency search
> SENS:AN:FREQ:DET ALW // ^ every time
> SENS:AN:RES // reset measurement configuration
// measurement
> SENS:AN:AVER 1 // 1 averages
> SENS:AN:CORR 10 // 10 correlations
> SENS:AN:PPD 150 // 150 points per decade
> SENS:AN:FREQ:STAR 10 // minimum offset frequency 10Hz
> SENS:AN:FREQ:STOP 40E6 // maximum offset frequency 40MHz
> SENS:AN:SPUR:THR 15 // spur threshold 15dB
> SENS:AN:SPUR:OMIS ON // enable omission of spurs (don't show spurs)
> SENS:AN:SMO:APER 5 // smoothing aperture 5%
> SENS:AN:SMO:STAT ON // enable smoothing
> INIT // trigger measurement start
loop
> CALC:WAIT:AVER ALL,500 // wait for the measurement to finish
> SYST:ERR:ALL? // check if measurement was successful
< read error queue // 0: ok, <0: fail (or timeout -393416 -> loop)
end loop
// retrieve full trace
> CALC:AN:TRAC:FREQ? // request frequency data
< read list // binary format of list explained below
> CALC:AN:TRAC:NOIS? // request amplitude noise data
< read list // binary format of list explained below
// retrieve spot noise values
> CALC:AN:TRAC:SPOT? 1E3 // get spot noise value at 1kHz offset
```

Simplified configuration example:

```
// measurement
> SENS:MODE AN // select amplitude noise measurement
> INIT // start measurement
> CALC:WAIT:AVER ALL // wait for the measurement to finish
> SYST:ERR:ALL? // check if measurement was successful
< read error queue // 0: success, <0: failed
> CALC:AN:TRAC:SPOT? 1E6 // request spot noise value at 1MHz offset
<read value // value is in dBc/Hz
```

Absolute Phase Noise (Mode FN)

Comprehensive configuration example:

```
// configuration
> SENS:MODE FN // enable frequency search
> SENS:FN:FREQ:AUTO ON // enable frequency search
> SENS:FN:FREQ:DET ALW // ^ every time
> SENS:FN:RES // reset measurement configuration

// measurement
> SENS:FN:AVER 1 // 1 average
> SENS:FN:CORR 10 // 10 correlations
> SENS:FN:PPD 150 // 150 points per decade
> SENS:FN:FREQ:STAR 10 // minimum offset frequency 10Hz
> SENS:FN:FREQ:STOP 40E6 // maximum offset frequency 40MHz
> SENS:FN:SPUR:THR 15 // spur threshold 15 dB
> SENS:FN:SPUR:OMIS ON // enable omission of spurs (don't show spurs)
> SENS:FN:SMO:APER 5 // smoothing aperture 5%
> SENS:FN:SMO:STAT ON // enable smoothing
> INIT // trigger measurement start

loop
> CALC:WAIT:AVER ALL,500 // wait for the measurement to finish
> SYST:ERR:ALL? // check if measurement was successful
< read error queue // 0: ok, <0: fail (or timeout -393416 -> loop)
end loop

// retrieve full trace
> CALC:FN:TRAC:FREQ? // request frequency data
< read list // binary format of list explained below
> CALC:FN:TRAC:NOIS? // request phase noise data
< read list // binary format of list explained below


// retrieve spot noise values
> CALC:FN:TRAC:SPOT? 1E3 // get spot noise value at 1kHz
```

Simplified configuration example:

```
// measurement
> SENS:MODE FN // select FN mode phase noise measurement
> INIT // start measurement
> CALC:WAIT:AVER ALL // wait for the measurement to finish
> SYST:ERR:ALL? // check if measurement was successful
< read error queue // 0: success, <0: failed
CALC:FN:TRAC:SPOT? 1E6 // request spot noise value at 1 MHz offset
< read value // value is in dBc/Hz
```

Block Data Format

The block data format is used to transfer an array of floating point values via the SCPI protocol. It follows the definition of block data according to IEEE 488.2. It contains a header and a block of 32bit floats. The header contains a start byte, a byte containing the number n defining the number of 1-byte digits following in the header. The n following 1-byte digits define the number of 4-byte floats following in the body of the package. See the color coded example below.



Example: 0x233231320050C34779689A4800247449

0x23: ASCII code for # -> start

0x32: ASCII code for 2 -> n=2

0x3132: ASCII code for 1 (0x31) and 2 (0x32) -> N=12 (3x 32bit float values)

0x0050C347: 32bit float -> 100000.0

0x79689A48: 32bit float -> 316227.78125

0x00247449: 32bit float -> 1000000.0

