

Installation Note

Option 010 Time Domain Upgrade Kit

For All PNA Series Network Analyzers

Network Analyzer Model Number	Upgrade Kit Part Number
All PNA series	E8356-60101



Agilent Technologies

Agilent Part Number: E8356-90022

Printed in USA December 2002

Supersedes Print Date: June 2001

© Copyright 2000-2002 Agilent Technologies, Inc. All rights reserved.



E8356-90022

Notice

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED “AS IS,” AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AGILENT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. AGILENT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD AGILENT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

Getting Assistance from Agilent

By internet, phone, or fax, get assistance with all your test and measurement needs.

Online assistance: www.agilent.com/find/assist		
United States (tel) 1 800 452 4844	Latin America (tel) (305) 269 7500 (fax) (305) 269 7599	Canada (tel) 1 877 894 4414 (fax) (905) 282-6495
Europe (tel) (+31) 20 547 2323 (fax) (+31) 20 547 2390	Australia (tel) 1 800 629 485 (fax) (+61) 3 9210 5947	New Zealand (tel) 0 800 738 378 (fax) (+64) 4 495 8950
Japan (tel) (+81) 426 56 7832 (fax) (+81) 426 56 7840	Singapore (tel) 1 800 375 8100 (fax) (65) 836 0252	Malaysia (tel) 1 800 828 848 (fax) 1 800 801 664
India (tel) 1 600 11 2929 (fax) 000 800 650 1101	Hong Kong (tel) 800 930 871 (fax) (852) 2506 9233	Taiwan (tel) 0800 047 866 (fax) (886) 2 25456723
Philippines (tel) (632) 8426802 (tel) (PLDT subscriber only) 1 800 16510170 (fax) (632) 8426809 (fax) (PLDT subscriber only) 1 800 16510288	Thailand (tel) (outside Bangkok) (088) 226 008 (tel) (within Bangkok) (662) 661 3999 (fax) (66) 1 661 3714	People's Republic of China (tel) (preferred) 800 810 0189 (tel) (alternate) 10800 650 0021 (fax) 10800 650 0121

Help

For additional help with configuring the network analyzer and PC system, mapping and sharing disk drives, and connecting external disk drives, refer to Agilent product note, “Introduction to Application Development with the Agilent PNA Series of Network Analyzers”, literature part number, 5980-2666ENUS.

Help is also available as Embedded Help in the network analyzer. This is accessed from within the network analyzer function.

If you have access to the Internet, information specific to PNA series network analyzers is available at: <http://www.agilent.com/find/pna>.

About Installing the Upgrade Kit

Products affected.	All PNA series analyzers and all options
Installation to be performed by	Agilent service center, personnel qualified by Agilent, or customer
Estimated installation time	5 minutes
Estimated verification time	5 minutes

Description of the Option 010 Upgrade Kit

This Option 010 upgrade kit provides the network analyzer with time domain operation. The upgrade kit is keyed to the model number and serial number of a specific network analyzer and cannot be used to upgrade any other analyzer.

Items Included in the Upgrade Kit

Check the contents of your kit against the following list. If any item is missing, contact Agilent Technologies. Refer to “[Getting Assistance from Agilent](#)” on page 2.

Table 1 Contents of Option 010 Upgrade Kit (E8356-60101)

Quantity	Description	Part Number
1	Installation note (this document)	E8356-90022
1	License key certificate	5964-5136
1	Cover letter	5964-5139

Installation Procedure for the Upgrade Kit

Installation Requirements

- The network analyzer must be in proper working condition prior to installing this option. Any necessary repairs must be made before proceeding with this installation.
- This installation does not require removal of the analyzer's protective outer covers.
- The analyzer must be powered up and operating to perform this installation. The Network Analyzer program must be running.
- This installation requires that a keyboard be connected to the network analyzer. A mouse is not required but is recommended.

Verify the Serial and Option Numbers

Refer to the License Key Certificate supplied with the kit:

- Verify that the analyzer's model and serial numbers match those on the certificate.
- Verify that the option number on the certificate matches the option number described in this installation note.

If the model number, serial number, or option number do not match the expected results, you will not be able to install the option. If this is the case, contact Agilent for assistance. Refer to [“Getting Assistance from Agilent” on page 2](#).

Enable Option 010

Mouse Procedure

1. On the analyzer's **System** menu, point to **Service**, and then click **Option Enable**.
2. In the **Select Desired Option** list, click **010 - Time Domain**.
3. Using the keyboard, enter the keyword in the box provided. The keyword is printed on the License Key Certificate. Enter this keyword *exactly* as it is printed on the certificate.
4. Click **Install**.
5. When the installation is complete, click **Exit**.

Front Panel Keys Procedure

1. In the **COMMAND** block, press **Menu/Dialog**.
2. In the **NAVIGATION** block, press the Right Tab and Arrows to move over to the **System** menu and down to the **Service** selection. Press the Right Tab to display the extended menu and the Arrows to select **Option Enable**. Press **Click**.
3. Tab to the **Select Desired Option** list, and press Arrows to select **010 - Time Domain**.
4. Using the keyboard, enter the keyword in the box provided. The keyword is printed on the License Key Certificate. Enter this keyword *exactly* as it is printed on the certificate.
5. Tab to **Install**. Press **Click**.
6. When the installation is complete, Tab to **Exit**. Press **Click**.

Verify that Option 010 Is Enabled

Mouse Procedure

1. On the analyzer's **Help** menu, click **About Network Analyzer**.
2. Verify that "010" is listed after "Options:" in the display. Click **OK**.
3. On the analyzers **Trace** menu, verify that the **Transform** menu item is present. This is an indication that Option 010 is enabled.

NOTE	If Option 010 has not been enabled, perform this installation procedure again. If the option is still not enabled, contact Agilent Technologies. Refer to "Getting Assistance from Agilent" on page 2 .
-------------	---

Front Panel Keys Procedure

1. In the **COMMAND** block, press **Menu/Dialog**.
2. In the **NAVIGATION** block, press the Right Tab and Arrows to move over to the **Help** menu, and down to the **About Network Analyzer** selection. Press **Click**.
3. Verify that "010" is listed after "Options:" in the display. Tab to **OK**. Press **Click**.
4. In the **COMMAND** block, press **Menu/Dialog**.
5. In the **NAVIGATION** block, press the Right Tab and Arrows to move over to the **Trace** menu. Verify that the **Transform** menu item is present. This is an indication that Option 010 is enabled.

NOTE	If Option 010 has not been enabled, perform this installation procedure again. If the option is still not enabled, contact Agilent Technologies. Refer to "Getting Assistance from Agilent" on page 2 .
-------------	---
