

# Keysight OIF-CEI 28G VSR/SR Compliance Test Plugin

This document contains latest information on the Keysight OIF-CEI 28G VSR/SR Plugin.

## Related Document

For detailed information, refer to the following document for this application:

- “OIF-CEI-28G User Guide.pdf”

This document can be found at the following location after you install the plugin:

*C:\Program Files\Keysight\M8070A\Plugins\OIFPlugin\doc*

The M8070A documents can be located by clicking *Start > All Programs > Keysight M8070A > Keysight M8070A Documentation*. Alternatively, you can also visit

[www.keysight.com/find/m8070a](http://www.keysight.com/find/m8070a) to find the latest versions of M8070A documents.

## Installation Steps

To install the Keysight OIF-CEI 28G VSR/SR plugin, perform the following steps:

- Start the M8070A software. To do so, go to *Start Menu > All Programs > Keysight M8070A*.
- Click *Utilities > Plugin Manager*.
- Click on the Install Plug-in from File button. A File Open dialog is displayed.
- Locate the OIF-CEI plug-in file (\*.M8KP) to install and click OK. On the successful installation of OIF-CEI plug-in, a message is displayed.

- Install the required licenses via the Keysight License Manager (if not done before). To know about the required licenses, refer to the release information in the last section of this document or see the OIF-CEI-28G User Guide.
- Restart the M8070A software. You should now find the new plugin in the *Applications* menu of the M8070A software.

## Getting Started

To access the installed OIF-CEI 28G VSR/SR plug-in, perform the following steps:

1. Click *Start > All Programs > Keysight M8070A > Keysight M8070A*.
2. From the M8070A user interface menu, click *Application* to view the list of all installed plug-ins.
3. Select the OIF-CEI-03.1 plug-in. The OIF-CEI user interface is displayed.
4. After starting the application, you must set up the system for VSR Host Testing or SR Testing. Refer to the OIF-CEI-28G User Guide for detailed instructions.

# OIF-CEI 28G VSR/SR Compliance Test Plugin

## Release V1.0.0.0

Released Date:	July 7, 2017
Operating System:	Microsoft Windows 7 (64 bit) SP1, Microsoft Windows 8 (64 bit) Microsoft Windows 8.1 (64 bit)
Display resolution:	Minimum requirement 1024 x 768
MATLAB Runtime Required:	R2015b (9.0), 64-bit Download from <a href="#">here</a> .
Oscilloscope Required:	86100D with 86108B plugin. FlexDCA Software Version 5.61 or above
Noise Source Required for SR Testing:	M8195A with Software Version 3.0.4.3 or above
Software Pre-requisites:	Keysight IO Library rev. 17.2 or above AXIe Chassis Firmware (Embedded System Module (ESM) from Keysight Technologies) greater than or equal version 1.3.41
Plugin Requirements:	Keysight M8070A System Software Version: 3.6 and above with options OTP Keysight M8041A with options G16, C16, OG2, OA2, and OG3 Keysight M8062A with options G32, C32, OG4, and OA4 Keysight M8045A with options G32, OG2, OG3, and OG4 Keysight M8046A with option A32 Keysight 86100D with options ETR, 200, 201, and SIM Keysight 86108B with options HBW, 232, JSA, PT2, CA2, and DC2 Keysight OIF-CEI 28G VSR/SR Plugin options M809228XA-1FP or M809228XA-1FT
File Name:	OIFPlugin.m8kp

## Features

- First release of Keysight OIF-CEI 28G VSR/SR Plugin. The plugin provides the following calibrations and tests for 28G-SR and 28G-VSR Host compliance.

### VSR Host Testing

Calibrations	Crosstalk Amplitude Crosstalk Transition Time Amplitude UUGJ UBHPJ SJ Stressed Eye
--------------	--

Tests	Stressed Input Voltage Tolerance
SR Testing	
Calibrations	Amplitude Direct Connection Amplitude UUGJ UBHPJ SJ Transmitter Common Mode Noise Integrated Crosstalk Noise
Tests	Stressed Input Voltage Tolerance