

# Understanding the 5G NR Physical Layer

November 1<sup>st</sup>, 2017

**Javier Campos**  
NR Physical Layer Architect  
RAN1 Delegate

# You Will Learn...

## Understanding the 5G NR Physical Layer

- 3GPP NR roadmap and releases
- Key differences between the physical layers of LTE and NR
- Key new technologies in NR physical layer
- Overview of the NR physical channels
- Most important new NR physical layer procedures
  - Initial access and beamforming
  - Beam management
  - MIMO
  - Bandwidth Parts
  - ...

# NR Key Technologies

## Understanding the 5G NR Physical Layer

### Waveforms and Frame Structure

Scalable Numerology

Numerology Multiplexing

Dynamic TDD

### Low Latency

Mini-Slots

CBG Retransmissions

Front-Loaded DMRS

### Millimeter Wave

Beam-Sweeping

Beam Management

Massive MIMO

### Future Proof – Forward Compatible

Bandwidth Parts

Reduced Always-On Signals

No Fixed Time Relationship Between Channels

# Contents

## Understanding the 5G NR Physical Layer

- 3GPP NR Introduction & Roadmap
- Waveform, Numerology and Frame Structure
- Initial Access and Beam Management
- Downlink and Uplink Channels
- Bandwidth Parts
- Summary

# Contents

Understanding the 5G NR Physical  
Layer

Page 5

## – 3GPP NR Introduction & Roadmap

- Waveform, Numerology and Frame Structure
- Initial Access and Beam Management
- Downlink and Uplink Channels
- Bandwidth Parts
- Summary

# 3GPP NR Use Cases

## 3GPP NR Roadmap & Introduction



### Enhanced Mobile Broadband (eMBB)

- 10-20 Gbps peak
- 100 Mbps whenever needed
- 10000x more traffic
- Macro and small cells
- Support for high mobility (500 km/h)
- Network energy saving by 100 times



### Massive Machine Communication (mMTC)

- High density of devices ( $2 \times 10^5$  -  $10^6/\text{km}^2$ )
- Long range
- Low data rate (1 - 100 kbps)
- M2M ultra low cost
- 10 years battery
- Asynchronous access




### Ultra Reliability and Low Latency (URLLC)

- Ultra responsive
  - <1 ms air interface latency
  - 5 ms E2E latency
- Ultra reliable and available (99.9999%)
- Low to medium data rates (50 kbps - 10 Mbps)
- High speed mobility

# 3GPP NR Roadmap

## 3GPP NR Roadmap & Introduction



# 3GPP NR Rel-15 Scope

## 3GPP NR Roadmap & Introduction

- Acceleration of eMBB Non-Standalone mode by **December'17**
  - Standalone standardization dates as expected (June'18)
- Use cases:
  - Enhanced Mobile Broadband (eMBB)
  - Ultra Reliable Low Latency Communications (URLLC)
- Carrier aggregation operation
- Inter-RAT mobility between NR and E-UTRA

✓ **IN SCOPE**

- Frequencies beyond 52.6 GHz
  - Other types of waveforms
- mMTC – Machine type communications
- Internetworking with non-3GPP systems (e.g. WiFi)
- Vehicular communications
- Multicast services and multimedia broadcast
- Unlicensed spectrum access


⊘ **OUT OF SCOPE**



# NR Non-Stand Alone Mode

## 3GPP NR Roadmap & Introduction

- Specified by **December'17**
- Using LTE core network
- LTE eNB always acts as a master
- NR gNB always acts as a slave




# 3GPP NR Rel-15 Roadmap

## 3GPP NR Roadmap & Introduction




### 3GPP Release 15 Roadmap



# 3GPP RAN1 Rel-15 Roadmap

## 3GPP NR Roadmap & Introduction



# Feature Down-Scoping

## 3GPP NR Roadmap & Introduction

- In the latest RAN #77 plenary meeting it was agreed to down-scope some of NR features for the **December'17** release
- This is the complete list of dropped functionality:
  - **Duplexing**
    - FDD half duplex
  - **MIMO**
    - RS design for mini-slot beyond what is covered in December'17
    - Multi-TRP/panel/beam transmission/reception at gNB for PDSCH/PUSCH
  - **Scheduling**
    - Mini-slot based scheduling beyond what is covered in December'17
    - Multi-TRP/panel/beam PDCCH
    - Transmit diversity for PUCCH (postponed to Release-16)
    - Simultaneous transmission of PUSCH and PUCCH
  - **NR CA/DC**
    - NR-NR DC

# NR L1 Specification Drafts

## 3GPP NR Roadmap & Introduction

Spec Number	Title	Current Draft
<b>38.201</b>	General Description	R1-1715069
<b>38.202</b>	Services Provided by the Physical Layer	R1-1714655
<b>38.211</b>	Physical Channels and Modulation	R1-1718318
<b>38.212</b>	Multiplexing and Channel Coding	R1-1719106
<b>38.213</b>	Physical Layer Procedures for Control	R1-1718782
<b>38.214</b>	Physical Layer Procedures for Data	R1-1718808
<b>38.215</b>	Physical Layer Measurements	R1-1719108

# Study Items for Rel-16

## 3GPP NR Roadmap & Introduction

– Study items starting in **2018**:

- NR-based access to unlicensed spectrum
- Non-orthogonal multiple access for NR
- Evaluation methodology of new V2X use cases for LTE and NR
- NR to support non-terrestrial networks
- Integrated access and backhaul for NR

# Contents

Understanding the 5G NR Physical  
Layer

Page 15

- 3GPP NR Introduction & Roadmap
- **Waveform, Numerology and Frame Structure**
- Initial Access and Beam Management
- Downlink and Uplink Channels
- Bandwidth Parts
- Summary

# Key Things to Learn...

## Waveform, Numerology and Frame Structure

### – Scalable numerology

- Implications to slot duration
- Implications to multiplexing of numerologies
- Inter-subcarrier spacing interference

### – Slot based vs. non-slot based scheduling

- Use cases for non-slot (i.e. mini-slot) based scheduling

### – Dynamic TDD

- How to indicate link direction?



# Waveform

## Waveform, Numerology and Frame Structure

- **Waveform** (for eMBB/URLLC and  $< 52.6$  GHz)

- DL Waveform: CP-OFDM
- UL Waveform: CP-OFDM + DFT-s-OFDM
  - CP-OFDM targeted at high throughput scenarios
  - DFT-s-OFDM targeted at power limited scenarios

- **Multiple Access**

- Orthogonal Multiple Access
- Non-Orthogonal Multiple Access (NOMA) not supported in Rel-15

- **Bandwidth**

- Maximum CC bandwidth is 400 MHz
- Maximum number of subcarriers is 3300
  - 4096-FFT is needed
- Maximum number of CCs is 16

This is from signaling point of view  
Allowed combinations to be decided by RAN4

# Numerology Definition

## Waveform, Numerology and Frame Structure

- Scalable subcarrier spacing

$$\Delta f = 2^{\mu} \cdot 15 \text{ kHz}$$


- Parameters defining a numerology:

- Subcarrier spacing (i.e.  $\mu$  parameter)
- Cyclic prefix (i.e. Normal/Extended)

	$\mu$	$\Delta f = 2^{\mu} \cdot 15 \text{ kHz}$	Cyclic Prefix	
Sync < 6 GHz	0	15 kHz	Normal	Data < 6 GHz
	1	30 kHz	Normal	
	2	60 kHz	Normal, Extended	
Sync > 6 GHz	3	120 kHz	Normal	Data > 6 GHz
	4	240 kHz	Normal	
	5	480 kHz	Normal	

Specified but not supported in Rel- 15

# Numerology Example (Normal CP)



- Each symbol length (including CP) of 15 kHz equals the sum of the corresponding  $2^{\mu}$  symbols at  $F_s$
- Other than the first OFMD symbol in every 0.5 ms, all symbols within 0.5 ms have the same length

# Mixed Numerology


## Waveform, Numerology and Frame Structure

- Multiplexing different numerologies
  - TDM and/or FDM for downlink and uplink
  - Rel-15 NR UEs are not mandated to support simultaneous DL reception or UL transmission of multiple FDM physical channels (e.g. PDSCH, PDCCH, PUSCH, PUCCH) with different numerologies at the same time
- Two FDM use cases
  - **Use Case #1: Data/Data**
    - Not supported in DL (for Rel-15)
    - Not supported in UL (for Rel-15)
    - Supported between DL and UL (i.e. different numerologies in DL and UL)
  - **Use Case #2: Data/Synchronization**
    - Optional from UE point of view

# Frame Structure

## Waveform, Numerology and Frame Structure

- Frame: 10 ms
- Subframe: Reference period of 1 ms
- Slot (slot based scheduling)
  - **14 OFDM symbols**
  - One possible scheduling unit
    - Slot aggregation allowed
  - Slot length scales with the subcarrier spacing
    - $\text{Slot length} = 1 \text{ ms} / 2^\mu$
- Mini-Slot (non-slot based scheduling)
  - **7, 4 or 2 OFDM symbols**
  - Minimum scheduling unit



# Mini-Slot Use Cases

## Waveform, Numerology and Frame Structure


- Support of very low latency (i.e. part of URLLC)
- Support of finer TDM granularity of scheduling for the same/different UEs within a slot
  - Especially if TRxP uses beam-sweeping (e.g. above 6GHz)
- NR-LTE co-existence (e.g. using LTE MBSFN subframes for NR)
- Forward compatibility towards unlicensed spectrum operation

# Frame Structure

## Waveform, Numerology and Frame Structure

– Slots are numbered:

- $n_s^\mu \in \{0, \dots, N_{slot}^{subframe,\mu} - 1\}$  within a subframe
- $n_{s,f}^\mu \in \{0, \dots, N_{slot}^{frame,\mu} - 1\}$  within a frame



# Frame Structure

## Waveform, Numerology and Frame Structure

Subcarrier Spacing ( $\mu$ )	Number of OFDM Symbols per Slot ( $N_{\text{slot}}^{\text{slot}}$ )	Number of Slots per Subframe ( $N_{\text{slot}}^{\text{subframe},\mu}$ )	Number of Slots per Frame ( $N_{\text{slot}}^{\text{frame},\mu}$ )
<b>0</b> 15 kHz	14 1 ms	1 1 slot x 1 ms = 1 ms	10 10 ms
<b>1</b> 30 kHz	14 500 $\mu$ s	2 2 slots x 500 $\mu$ s = 1 ms	20 10 ms
<b>2</b> 60 kHz (normal CP)	14 250 $\mu$ s	4 4 slots x 250 $\mu$ s = 1 ms	40 10 ms
<b>2</b> 60 kHz (extended CP)	12 250 $\mu$ s	4 4 slots x 250 $\mu$ s = 1 ms	40 10 ms
<b>3</b> 120 kHz	14 125 $\mu$ s	8 8 slots x 125 $\mu$ s = 1 ms	80 10 ms
<b>4</b> 240 kHz	14 62.5 $\mu$ s	16 16 slots x 62.5 $\mu$ s = 1 ms	160 10 ms
<b>5</b> 480 kHz	14 31.25 $\mu$ s	32 32 slots x 31.25 $\mu$ s = 1 ms	320 10 ms



# Resource Grid

## Waveform, Numerology and Frame Structure



- Resource elements are grouped into Physical Resource Blocks (**PRB**)
- Each PRB consists of **12 subcarriers**

$\mu$	$\Delta f$	$N_{RB}^{min,\mu}$	$N_{RB}^{max,\mu}$
0	15 kHz	20	275
1	30 kHz	20	275
2	60 kHz	20	275
3	120 kHz	20	275
4	240 kHz	20	138
5	480 kHz	20	69

# Resource Grid

## Waveform, Numerology and Frame Structure


- For each numerology and carrier, a resource grid of  $N_{RB}^{max,\mu} \cdot N_{sc}^{RB}$  subcarriers and  $N_{symb}^{subframe,\mu}$  OFDM symbols is defined
- The resource grids for all subcarrier spacing are overlapped



# Slot Structure

## Waveform, Numerology and Frame Structure

- A slot can be:
  - All downlink
  - All uplink
  - Mixed downlink and uplink
    - Static, semi-static or dynamic
- Slot aggregation is supported
  - Data transmission can be scheduled to span one or multiple slots



# Slot Format Indication

## Waveform, Numerology and Frame Structure

- Slot Format Indication informs the UE whether an OFDM symbol is **Downlink**, **Uplink** or **Flexible**
- SFI can indicate link direction over one or many slots (configured through RRC)
- The SFI carries an index to a pre-configured UE-specific table (configured through RRC)
- SFI can be either:
  - **Dynamic** (i.e. through a DCI)
    - UE assumes there is no conflict between dynamic SFI and DCI DL/UL assignments
  - **Static** or **semi-static** (i.e. through RRC)

# Key Things to Learn...

## Waveform, Numerology and Frame Structure

### – Scalable numerology

- Implications to slot duration
- Implications to multiplexing of numerologies
- Inter-subcarrier spacing interference

### – Slot based vs. non-slot based scheduling

- Use cases for non-slot (i.e. mini-slot) based scheduling

### – Dynamic TDD

- How to indicate link direction?

# Contents

Understanding the 5G NR Physical  
Layer

Page 30

- 3GPP NR Introduction & Roadmap
- Waveform, Numerology and Frame Structure
- **Initial Access and Beam Management**
- Downlink and Uplink Channels
- Bandwidth Parts
- Summary

# Key Things to Learn...

## Initial Access and Beam Management

### – Beam-sweeping

- How does the UE identifies the best beam to receive from the gNB?
- How does the gNB identifies the best beam to receive from the UE?


### – Initial access

- How does beamforming affect the initial access procedure?
- Implications of beam-sweeping in the design of the initial access related signals
- Implications of the initial access design to NR-LTE coexistence

# Initial Access Procedure


## Initial Access and Beam Management

TRxP-Wide Coverage




*Beam-sweeping  
transmission*

*Beam-sweeping  
transmission*




UE-Specific Coverage



*Beam-sweeping  
reception*

*UE-specific  
selected beam*



*UE-specific  
beamforming*

Synchronization Signals

System Information

*Basic information for all UEs*

Random Access Channel

Random Access Response & System  
Information

*Required only for UEs after random access*


Data and control channels

*Single-beam or  
Beam-sweeping*



# Beam-Sweeping and Initial Access

## Initial Access and Beam Management




# Beam-Sweeping and Initial Access

## Initial Access and Beam Management

- The UE identifies the SSB within the SS Burst Set by using:
  - Part of the time index carried by the PBCH DMRS
  - The rest of the SSB time index carried by the PBCH data
- The UE identifies the best SSB
- The UE transmits PRACH on a set of resources depending on the best SSB time index
  - An association between an SSB in the SS Burst Set and a subset of PRACH resources and/or preamble indices is configured by a set of parameters in the system information
  - The UE notifies the gNB with the best SSB by using the corresponding PRACH resource for that SSB

# Beam-Sweeping and Initial Access

## Initial Access and Beam Management



# Remaining and Other System Information

## Initial Access and Beam Management

### – Remaining Minimum System Information


- Minimum system information is carried onto PBCH
- The rest of the Remaining Minimum System Information (RMSI) is carried onto PDSCH
- The numerology used for RMSI is indicated in PBCH payload
  - < 6 GHz: 15 or 30 kHz (60 kHz cannot be used because it is optional for the UEs)
  - > 6 GHz: 60 or 120 kHz
- A CORESET is dedicated for RMSI scheduling
  - Not necessarily confined within PBCH bandwidth
  - There is an RMSI PDCCH monitoring window associated with an SS/PBCH block, which recurs periodically.

### – Other System Information

- On-Demand system information delivery
- Carried on PDSCH using the same numerology as the RMSI

# Messages 1, 2, 3 and 4 Transmission

## Initial Access and Beam Management



# Messages 1, 2, 3 and 4 Transmission

## Initial Access and Beam Management

Message	Subcarrier Spacing	Beam
<b>Message 1</b> UE -> gNB	<ul style="list-style-type: none"><li>Indicated in the RACH configuration</li></ul>	<ul style="list-style-type: none"><li>Beam for preamble transmission is selected by the UE</li><li>UE uses the same beam during a RACH transmission occasion</li></ul>

# Messages 1, 2, 3 and 4 Transmission

## Initial Access and Beam Management

Message	Subcarrier Spacing	Beam
<b>Message 1</b> UE -> gNB	<ul style="list-style-type: none"><li>Indicated in the RACH configuration</li></ul>	<ul style="list-style-type: none"><li>Beam for preamble transmission is selected by the UE</li><li>UE uses the same beam during a RACH transmission occasion</li></ul>
<b>Message 2</b> gNB -> UE	<ul style="list-style-type: none"><li>The same as the numerology of RMSI</li></ul>	<ul style="list-style-type: none"><li>Obtained based on the detected RACH preamble/resource and the corresponding association</li></ul>

# Messages 1, 2, 3 and 4 Transmission

## Initial Access and Beam Management

Message	Subcarrier Spacing	Beam
<b>Message 1</b> UE -> gNB	<ul style="list-style-type: none"><li>Indicated in the RACH configuration</li></ul>	<ul style="list-style-type: none"><li>Beam for preamble transmission is selected by the UE</li><li>UE uses the same beam during a RACH transmission occasion</li></ul>
<b>Message 2</b> gNB -> UE	<ul style="list-style-type: none"><li>The same as the numerology of RMSI</li></ul>	<ul style="list-style-type: none"><li>Obtained based on the detected RACH preamble/resource and the corresponding association</li></ul>
<b>Message 3</b> UE -> gNB	<ul style="list-style-type: none"><li>Indicated in the RACH configuration separately from subcarrier spacing for message 1</li></ul>	<ul style="list-style-type: none"><li>Determined by UE (same as message 1)</li></ul>



# Messages 1, 2, 3 and 4 Transmission

## Initial Access and Beam Management

Message	Subcarrier Spacing	Beam
<b>Message 1</b> UE -> gNB	<ul style="list-style-type: none"><li>Indicated in the RACH configuration</li></ul>	<ul style="list-style-type: none"><li>Beam for preamble transmission is selected by the UE</li><li>UE uses the same beam during a RACH transmission occasion</li></ul>
<b>Message 2</b> gNB -> UE	<ul style="list-style-type: none"><li>The same as the numerology of RMSI</li></ul>	<ul style="list-style-type: none"><li>Obtained based on the detected RACH preamble/resource and the corresponding association</li></ul>
<b>Message 3</b> UE -> gNB	<ul style="list-style-type: none"><li>Indicated in the RACH configuration separately from subcarrier spacing for message 1</li></ul>	<ul style="list-style-type: none"><li>Determined by UE (same as message 1)</li></ul>
<b>Message 4</b> gNB -> UE	<ul style="list-style-type: none"><li>The same as message 2</li></ul>	<ul style="list-style-type: none"><li><u>No beam reporting</u> in message 3: Same as message 2</li><li><u>Beam reporting</u> in message 3: FFS</li></ul>

# Beam Management

## Initial Access and Beam Management

- **Beam management:** acquire and maintain a set of TRxP(s) and/or UE beams that can be used for DL and UL transmission/reception
  - **Beam determination:** for TRxP(s) or UE to select its own Tx/Rx beam(s)
  - **Beam measurement:** for TRxP(s) or UE to measure characteristics of received beamformed signals
  - **Beam reporting:** for UE to report information of beamformed signal(s) based on beam measurement
  - **Beam sweeping:** operation of covering a spatial area, with beams transmitted and/or received during a time interval in a predetermined way
- Reference signals used for beam management:
  - IDLE mode: **PSS**, **SSS** and **PBCH DMRS** (i.e. SSB)
  - CONNECTED mode: **CSI-RS** (DL) and **SRS** (UL)

# Multi-Beam Operation and FDM

## Initial Access and Beam Management

- Multiplexing of signals/channels using different beams (e.g. SS-Block and PDSCH) in multi-beam systems is not possible
  - They may use different beams and the UE can only receive with a single beam at a given time (i.e. if the UE needs to measure a SSB it will not be able to receive PDSCH)
- **UEs will not be mandated to support two simultaneous beams for release 15**
  - Typical UE implementation in release 15 will have a single panel

# Physical Channels and Signals

## Initial Access and Beam Management

- Initial access is composed of the following physical channels and signals:
  - Downlink
    - Primary Synchronization Signal (PSS)
    - Secondary Synchronization Signal (SSS)
    - Physical Broadcast Channel (PBCH)
  - Uplink
    - Physical Random Access Channel (PRACH)
- PSS, SSS and PBCH are the only ***always-on*** signals in New Radio
  - Even them can be turned off by the network

# General Definitions

## Initial Access and Beam Management

### SS Block


- 1 symbol PSS
- 1 symbol SSS
- 2 symbols PBCH

### SS Burst

- One or multiple SS Block(s)

### SS Burst Set

- One or multiple SS Burst(s)
- Transmission is periodic (20 ms by default)
- Confined within a 5 ms window




# SS Burst Set Definition

## Initial Access and Beam Management

- The transmission of SSBs within SS Burst Set is confined to a **5 ms window**
- SS Burst Set transmission is periodic
  - An *IDLE* UE assumes a default periodicity of 20 ms
- Multiple SSBs frequency locations can be defined within a wideband carrier
  - The frequency location of a SSB does not need to be aligned to a PRB
- Number of possible candidate SSB locations ( $L$ ) within SS Burst Set:
  - Up to 3 GHz:  $L = 4$
  - From 3 GHz to 6 GHz:  $L = 8$
  - From 6 GHz to 52.6 GHz:  $L = 64$

# SS Block Composition


## Initial Access and Beam Management



# SS Block Mapping Location

## Initial Access and Beam Management

- SSB mapping locations for **< 6 GHz**:
  - Each slot contains 2 SS block locations






# SS Block for LTE-NR Coexistence

## Initial Access and Beam Management


- For **LTE-NR coexistence**, **30 kHz is mandatory** to avoid collisions with the LTE C-RS
  - LTE-NR coexistence **requires minimum 10 MHz bandwidth**
  - The SS blocks which collide with LTE C-RS are not transmitted by gNB



# SS Block Mapping Location

## Initial Access and Beam Management

– SSB mapping locations for **> 6 GHz**:




**2 SS block locations** in each slot

**4 SS block locations** in each two slots

# SS Burst Set Composition

## Initial Access and Beam Management



# SS Block Time Index Indication

## Initial Access and Beam Management

- 3 bits ( $b_2, b_1, b_0$ ) of SSB time index are carried by changing the DMRS sequence within each 5 ms period
- Two cases for the rest of the SSB time index indication:
  - **> 6 GHz:** 3 bits ( $b_5, b_4, b_3$ ) are carried explicitly in PBCH payload
  - **< 6 GHz:** No need for more bits (i.e. the 3 payload bits can be reused for other purposes)


# Minimum System Bandwidth

## Initial Access and Beam Management

- The PSS, SSS and PBCH transmission define the minimum component carrier bandwidth:
  - **< 6GHz**
    - **15 kHz** subcarrier spacing: 5 MHz
    - **30 kHz** subcarrier spacing: 10 MHz
      - Minimum bandwidth for LTE-NR coexistence
  - **> 6 GHz**
    - **120 kHz** subcarrier spacing: 50 MHz
    - **240 kHz** subcarrier spacing: 100 MHz
- The specification will fix a **single SCS for each frequency band**
  - With the exception of some bands below 6 GHz for the LTE-NR coexistence scenario

# PSS/SSS Definition

## Initial Access and Beam Management



- PSS/SSS sequence is mapped to consecutive 127 subcarriers
- Center frequency of PSS/SSS is aligned with center frequency of PBCH

# PBCH Definition


## Initial Access and Beam Management

- Same antenna port as PSS and SSS in the same SSB
- **Single antenna** port transmission scheme
- PBCH TTI: **80 ms**
- PBCH payload: **56 bits** (including CRC)
- PBCH channel coding scheme: **Polar Code**

# PBCH Resource Element Mapping

## Initial Access and Beam Management

- PBCH coded bits of the PBCH code block(s) are mapped across resource elements in PBCH
  - Two scrambling operations:
    - **1<sup>st</sup> scrambling**
      - Before CRC attachment
      - Initialization based on Cell ID
      - Sequence is partitioned in 4 non-overlapping portions
        - The portion is selected with the 2<sup>nd</sup> and 3<sup>rd</sup> LSB of SFN
    - **2<sup>nd</sup> scrambling**
      - After encoding
      - Initialization based on Cell ID
      - Sequence is partitioned in 4 or 8 non-overlapping portions
        - The portion is selected with the 2<sup>nd</sup> or 3<sup>rd</sup> LSBs of the SS-Block time index






# Random Access Preamble (PRACH)

## Initial Access and Beam Management

- PRACH sequence is Zadoff-Chu based
- Two different preamble lengths
  - **Long sequence** ( $L = 839$ )
    - Only for  $< 6$  GHz
    - Subcarrier spacing and bandwidth:
      - **1.25 kHz (1.25 MHz) and 5 kHz (5 MHz)**
  - **Short sequence** ( $L = 139$ )
    - Intended for  $> 6$  GHz (i.e. for beam-sweeping)
    - Can be used both below and above 6 GHz
    - Subcarrier spacing and bandwidth:
      - $< 6$  GHz: **15 kHz (2.5 MHz) and 30 kHz (5 MHz)**
      - $> 6$  GHz: **60 kHz (10 MHz) and 120 kHz (20 MHz)**

# PRACH Formats (Long Sequence)

## Initial Access and Beam Management




Format	Subcarrier Spacing	Bandwidth	$N_{\text{SEQ}}$	$T_{\text{SEQ}}$	$T_{\text{CP}}$	$T_{\text{GP}}$	Use Case
0	1.25 kHz	1.08 MHz	1	$24576 \cdot T_s$	$3168 \cdot T_s$	$2976 \cdot T_s$	LTE refarming
1	1.25 kHz	1.08 MHz	2	$24576 \cdot T_s$	$21024 \cdot T_s$	$21984 \cdot T_s$	Large cell
2	1.25 kHz	1.08 MHz	4	$24576 \cdot T_s$	$4688 \cdot T_s$	$29264 \cdot T_s$	Large cell
3	5 kHz	4.32 MHz	1	$24576 \cdot T_s$	$3168 \cdot T_s$	$2976 \cdot T_s$	High speed

# PRACH Formats (Short Sequence)

## Initial Access and Beam Management

- Common time structure for all short sequence formats:



# PRACH Formats (Short Sequence)

## Initial Access and Beam Management

– For 15 kHz subcarrier spacing:

Format	$N_{\text{SEQ}}$	$T_{\text{CP}}$	$T_{\text{SEQ}}$	$T_{\text{GP}}$	Use Case
<b>A</b>	0	1	$144 \cdot T_s$	$2048 \cdot T_s$	TA is already known or very small cell
	1	2	$288 \cdot T_s$		Small cell
	2	4	$576 \cdot T_s$		Normal cell
	3	6	$864 \cdot T_s$		Normal cell
<b>B</b>	1	2	$216 \cdot T_s$		Small cell
	2	4	$360 \cdot T_s$		Normal cell
	3	6	$504 \cdot T_s$		Normal cell
	4	12	$936 \cdot T_s$		Normal cell
<b>C</b>	0	1	$1240 \cdot T_s$		Normal cell
	1	2	$1384 \cdot T_s$		Normal cell
	2	4	$2048 \cdot T_s$		Normal cell

# Key Things to Learn...

## Initial Access and Beam Management

### – Beam-sweeping

- How does the UE identifies the best beam to receive from the gNB?
- How does the gNB identifies the best beam to receive from the UE?

### – Initial access

- How does beamforming affect the initial access procedure?
- Implications of beam-sweeping in the design of the initial access related signals
- Implications of the initial access design to NR-LTE coexistence

# Contents

Understanding the 5G NR Physical  
Layer

Page 62

- 3GPP NR Introduction & Roadmap
- Waveform, Numerology and Frame Structure
- Initial Access and Beam Management
- **Downlink and Uplink Channels**
- Bandwidth Parts
- Summary

# Key Things to Learn...

## Downlink and Uplink Channels

### – Channel Coding

- Which channel coding schemes will be used?
- Implications of the channel coding schemes to the processing chain

### – Downlink/Uplink Channels

- Channel state information report improvements
- How is the PDSCH/PUSCH design changed to achieve lower latency?
- How does URLLC traffic affect eMBB traffic?

### – MIMO

- What are the differences between sub-6 GHz and mmWave bands with respect to MIMO?

# Introduction to Downlink

## Downlink and Uplink Channels

– **Downlink** physical channels:

- Physical Broadcast channel (PBCH)
- Physical Downlink Control Channel (PDCCH)
- Physical Downlink Shared Channel (PDSCH)

– **Downlink** physical signals:

- Primary Synchronization Signal (PSS)
- Secondary Synchronization Signal (SSS)
- Channel State Information Reference Signal (CSI-RS)
- Tracking Reference Signal (TRS)

PBCH, PSS and SSS already covered as part of Initial Access



# PDCCH


## Downlink and Uplink Channels

- Carries **DCI**
- Modulation: **QPSK**
- RNTI is mask onto DCI CRC bits
- 1 PDCCH CCE = **6 REGs**
  - A REG is one PRB during one OFDM symbol
- **One-port transmit diversity** scheme with REG bundling per CCE (i.e. the same precoder is used for the REGs in a REG bundle)

# PDCCH CORESET

## Downlink and Uplink Channels

- A **control resource set** (CORESET) is defined as a set of REGs under a given numerology
- Configured by UE-specific higher-layer signaling:
  - Frequency-domain resources
  - Starting OFDM symbol (OFDM symbol #0, #1 or #2)
  - Time duration (maximum duration of 3 OFDM symbols)



# Group-Common PDCCH

## Downlink and Uplink Channels

- PDCCH intended for a group of UEs
- Use cases:
  - **Dynamic Slot Format Indication (SFI)**
    - Indicates slot related information for one or more slots from which the UE can derive at least which symbols in a slot are *Downlink*, *Uplink* and *Flexible*
    - The SFI carries an index to a UE-specific table (i.e. configured via RRC)
  - **Downlink Pre-Emption Indication (PI)**
    - Transmitted in different DCI than SFI
    - Whether a UE needs to monitor preemption indication is configured by RRC signaling

# PDSCH

## Downlink and Uplink Channels

- Carries user **data**
- Modulated symbols associated with a codeword mapped in the following order:
  - Across layers associated with the codeword
  - Across subcarriers
  - Across OFDM symbols (i.e. time)
- PDSCH is rate-matched around transmitted SSBs and PDCCH/CORESET
- Modulations: QPSK, 16QAM, 64QAM and 256QAM


# PDSCH DMRS

## Downlink and Uplink Channels

- Front-loaded DMRS symbols (can be either 1 or 2) are located at:
  - **Slot based (DMRS mapping type A):** Fixed OFDM symbol regardless of the PDSCH assignment
    - Configurable between  $l_0 = \{2, 3\}$
  - **Non-slot based (DMRS mapping type B):** First OFDM symbol assigned for PDSCH
    - i.e. Mini-slots
- Additional DMRS symbols can be configured (e.g. for high-speed scenarios)
  - Additional symbols are always present for broadcast/multicast PDSCH

# PDSCH Processing Chain

## Downlink and Uplink Channels



# PDSCH eMBB and URLLC Multiplexing


## Downlink and Uplink Channels

### – **For downlink:**

- Dynamic resources sharing between eMBB and low latency traffic is supported:
  - With pre-emption by scheduling the URLLC services on overlapping time/frequency resources
  - Without pre-emption by scheduling the eMBB and URLLC services on non-overlapping time/frequency resources
- Support indication of time and/or frequency region of impacted eMBB resources to respective eMBB UE(s)
  - Done through group-common PDCCH

# Downlink Pre-Emption Indication

## Downlink and Uplink Channels





# CSI-RS and CSI Reports

## Downlink and Uplink Channels

- Use cases:
  - CSI acquisition
  - Beam management
- Two types of CSI feedback:
  - **Type I: NORMAL**
    - Codebook-based PMI feedback with normal spatial resolution
  - **Type II: ENHANCED**
    - Explicit feedback and/or codebook-based feedback with higher spatial resolution
      - Category 1: Precoder feedback based on linear combination codebook
      - Category 2: Covariance matrix feedback
      - Category 3: Hybrid CSI feedback

**This feature in NR can outperform LTE under the same circumstances**

# TRS

## Downlink and Uplink Channels

- Use cases:
  - Fine time tracking
  - Fine frequency tracking
  - Path delay spread and Doppler spread
- TRS is UE-specifically managed
- A TRS burst consists of four OFDM symbols in two consecutive slots

# Introduction to Uplink

## Downlink and Uplink Channels

– **Uplink** physical channels:

- Physical Uplink Shared Channel (PUSCH)
- Physical Uplink Control Channel (PUCCH)
- Physical Random Access Channel (PRACH)

– **Uplink** physical signals:

- Sounding Reference Signal (SRS)

PRACH already covered as part of Initial Access

# PUSCH

## Downlink and Uplink Channels

- Carries user **data** and **UCI** (optional)
- Two waveforms:
  - **CP-OFDM**: intended for MIMO
  - **DFT-s-OFDM**: only used with single layer transmissions
- Modulated symbols associated with a codeword mapped in the following order:
  - Across layers associated with the codeword
  - Across subcarriers
  - Across OFDM symbols (i.e. time)
- Intra-slot frequency hopping is supported for DFT-s-OFDM

# PUSCH

## Downlink and Uplink Channels

### – Modulations:

- **CP-OFDM:** QPSK, 16QAM, 64QAM and 256QAM
- **DFT-s-OFDM:**  $\pi/2$ -BPSK, 16QAM, 64QAM and 256QAM

### – UL Transmission schemes:

- **Scheme 1:** Codebook-based
- **Scheme 2:** Non-codebook based for more than 2 ports

### – Uplink Transmission can be:

- **Grant-based** (i.e. Grant delivered using DCI)
- **Grant-free**
  - **Type 1:** Only based on RRC configuration without any L1 signaling
  - **Type 2:** Based on RRC configuration and L1 signaling for activation/deactivation



# PUSCH DMRS

## Downlink and Uplink Channels

- Difference depending on the waveform:
  - **CP-OFDM**
    - Sequence: Gold sequence (i.e. as in PDSCH)
  - **DFT-s-OFDM**
    - Sequence: Zadoff-Chu
- Front-loaded DMRS symbols (can be either 1 or 2) are located at first OFDM symbol assigned for PUSCH
  - Additional DMRS symbols can be configured (e.g. for high-speed scenarios)

# PUSCH Processing Chain

## Downlink and Uplink Channels



# PUCCH

## Downlink and Uplink Channels

- Carries **UCI**, **HARQ-ACK** and/or **SR**
- Two type of PUCCHs:
  - **Short PUCCH**
  - **Long PUCCH**

PUCCH Format	Length in OFDM Symbols	Number of Bits
0 (SHORT)	1-2	$\leq 2$
1 (LONG)	4-14	$\leq 2$
2 (SHORT)	1-2	$> 2$
3 (LONG)	4-14	$> 2, < N$
4 (LONG)	4-14	$> N$



# Short PUCCH

## Downlink and Uplink Channels



### – Format 0 ( $\leq 2$ bits):

- PUCCH is based on sequence selection with low PAPR
  - Sequence length: 12 RE
  - Information is delivered by transmitting different sequences/codes
- Can transmit HARQ-ACK and SR

$$y(n) = x_j(n)$$
$$j = \sum_{i=0}^{M_{bit}-1} b(i) \cdot 2^i$$

### – Format 2 ( $> 2$ bits):

- DMRS mapped on REs {1, 4, 7, 10} for each PRB
- DMRS sequence based on PUSCH
- Contiguous PRB allocation



# Long PUCCH


## Downlink and Uplink Channels

### – Format 1 ( $\leq 2$ bits):

- DMRS always occur in every other symbol in the long PUCCH
- BPSK and QPSK modulations
- Sequence length: 12 RE
- Modulated symbol is spread with a Zadoff-Chu sequence with OCC in the time domain

$$y(n) = d(0) \cdot r_{u,v}^{(\alpha)}(n)$$

$$z(m \cdot N_{seq}^{PUCCH} + n) = w_i(m) \cdot y(n)$$



# Long PUCCH

## Downlink and Uplink Channels

- **Format 3** ( $> 2$  bits,  $< N$  bits):
  - Still to be agreed
- **Format 4** ( $> N$  bits):
  - Still to be agreed
- Long PUCCH can be configured with intra-slot hopping
- Long PUCCH can be configured to span over multiple slots
  - In that case inter-slot hopping can be configured

# Channel Coding Schemes


## Downlink and Uplink Channels

- Channel coding for **eMBB**:
  - **LDPC** for eMBB physical data channels
  - **Polar Code** for eMBB physical control channels
- Channel coding for **PBCH**:
  - **Polar Code**
    - Same as for eMBB physical control channels
- Channel coding for other use cases (i.e. mMTC, URLLC):
  - Not in Rel-15 scope


# Transport Channel Coding Chains

## Downlink and Uplink Channels

DL-SCH




UL-SCH



# CBG-Based Retransmissions

## Downlink and Uplink Channels

- It is possible to make retransmissions with a codeblock granularity
- Information included in the DCI:
  - Which CBG(s) is/are (re)transmitted
  - Which CBG(s) is/are handled differently for soft-buffer/HARQ combining
    - **Combining**
      - If retransmission is caused by SNR, then combining of the soft-buffer will help improve decoding on retransmission
    - **Flushing**
      - If the retransmitted codeblock was affected by pre-emption the buffer content is not correct and it is better to flush it rather than combining



# HARQ Timing Definitions

## Downlink and Uplink Channels

- $K_0$ : Delay between DL grant and corresponding DL data (PDSCH) reception
- $K_1$ : Delay between DL data (PDSCH) reception and corresponding ACK/NACK transmission on UL
- $K_2$ : Delay between UL grant reception in DL and UL data (PUSCH) transmission
- $K_3$ : Delay between ACK/NACK reception in UL and corresponding retransmission of data (PDSCH) on DL
- $K_0$ ,  $K_1$  and  $K_2$  are indicated in the DCI
- If  $K_1 = 0$  ► **Self-contained slots** (not mandatory to UEs)

# MIMO

## Downlink and Uplink Channels

- NR supports the following number of codewords for DL and UL per UE:
  - For 1 to 4-layer transmission: **1 codeword**
  - For 5 to 8-layer transmission: **2 codewords**
- UEs are higher layer configured with 2 DMRS configurations for the front-loaded case in DL/UL CP-OFDM:
  - **Configuration 1:** Supports up to 8 ports (SU-MIMO)
    - One or two OFDM symbols
  - **Configuration 2:** Supports up to 12 ports (MU-MIMO)
    - One or two OFDM symbols



# MIMO at Below-6 GHz and mmWave

## Downlink and Uplink Channels

	< 6 GHz	mmWave
Deployment Scenario	Macro cells High user mobility	Small cells Low user mobility

# MIMO at Below-6 GHz and mmWave

## Downlink and Uplink Channels

	< 6 GHz	mmWave
<b>Deployment Scenario</b>	Macro cells High user mobility	Small cells Low user mobility
<b>MIMO Order</b>	Up to 8x8	Less MIMO order (typically 2x2)

# MIMO at Below-6 GHz and mmWave

## Downlink and Uplink Channels

	< 6 GHz	mmWave
<b>Deployment Scenario</b>	Macro cells High user mobility	Small cells Low user mobility
<b>MIMO Order</b>	Up to 8x8	Less MIMO order (typically 2x2)
<b>Number of Simultaneous Users</b>	Tens of users Large coverage area	A few users Small coverage area

# MIMO at Below-6 GHz and mmWave

## Downlink and Uplink Channels

	< 6 GHz	mmWave
<b>Deployment Scenario</b>	Macro cells High user mobility	Small cells Low user mobility
<b>MIMO Order</b>	Up to 8x8	Less MIMO order (typically 2x2)
<b>Number of Simultaneous Users</b>	Tens of users Large coverage area	A few users Small coverage area
<b>Main Benefit</b>	Spatial multiplexing	Beamforming for single user

# MIMO at Below-6 GHz and mmWave

## Downlink and Uplink Channels

	< 6 GHz	mmWave
<b>Deployment Scenario</b>	Macro cells High user mobility	Small cells Low user mobility
<b>MIMO Order</b>	Up to 8x8	Less MIMO order (typically 2x2)
<b>Number of Simultaneous Users</b>	Tens of users Large coverage area	A few users Small coverage area
<b>Main Benefit</b>	Spatial multiplexing	Beamforming for single user
<b>Channel Characteristics</b>	Rich multipath propagation	A few propagation paths

# MIMO at Below-6 GHz and mmWave

## Downlink and Uplink Channels

	< 6 GHz	mmWave
<b>Deployment Scenario</b>	Macro cells High user mobility	Small cells Low user mobility
<b>MIMO Order</b>	Up to 8x8	Less MIMO order (typically 2x2)
<b>Number of Simultaneous Users</b>	Tens of users Large coverage area	A few users Small coverage area
<b>Main Benefit</b>	Spatial multiplexing	Beamforming for single user
<b>Channel Characteristics</b>	Rich multipath propagation	A few propagation paths
<b>Spectral Efficiency</b>	High due to the spatial multiplexing	Low spectral efficiency (few users, high path loss)

# MIMO at Below-6 GHz and mmWave

## Downlink and Uplink Channels

	< 6 GHz	mmWave
<b>Deployment Scenario</b>	Macro cells High user mobility	Small cells Low user mobility
<b>MIMO Order</b>	Up to 8x8	Less MIMO order (typically 2x2)
<b>Number of Simultaneous Users</b>	Tens of users Large coverage area	A few users Small coverage area
<b>Main Benefit</b>	Spatial multiplexing	Beamforming for single user
<b>Channel Characteristics</b>	Rich multipath propagation	A few propagation paths
<b>Spectral Efficiency</b>	High due to the spatial multiplexing	Low spectral efficiency (few users, high path loss)
<b>Transceiver</b>	Digital transceiver	Hybrid

# Key Things to Learn...

## Downlink and Uplink Channels

### – Channel Coding

- Which channel coding schemes will be used?
- Implications of the channel coding schemes to the processing chain

### – Downlink/Uplink Channels

- Channel state information report improvements
- How is the PDSCH/PUSCH design changed to achieve lower latency?
- How does URLLC traffic affect eMBB traffic?

### – MIMO

- What are the differences between sub-6 GHz and mmWave bands with respect to MIMO?



# Contents

Understanding the 5G NR Physical  
Layer

Page 97

- 3GPP NR Introduction & Roadmap
- Waveform, Numerology and Frame Structure
- Initial Access and Beam Management
- Downlink and Uplink Channels
- **Bandwidth Parts**
- Summary

# Key Things to Learn...

## Bandwidth Parts

- **Bandwidth part definition**

- How are bandwidth parts configured?
- How are bandwidth parts activated/deactivated?

- **Motivation for the introduction of bandwidth parts**

- Why are bandwidth parts a great NR feature?
- Use cases for bandwidth parts

# Bandwidth Part Definition

## Bandwidth Parts

- A bandwidth part consists of a group of contiguous PRBs
  - The bandwidth part may or may not contain SS block
  - Reserved resources can be configured within the bandwidth part
  - Each bandwidth part (BWP) has its own numerology (i.e. cyclic prefix length and subcarrier spacing)
- An **initial BWP** is signaled by PBCH
  - It contains CORESET and PDSCH for RMSI

# Bandwidth Part Parameters

## Bandwidth Parts

- One or multiple bandwidth part configurations for each component carrier can be semi-statically signaled to a UE
  - **Only one BWP** in DL and one in UL **is active** at a given time instant
- Configuration parameters include:
  - **Numerology**: CP type, subcarrier spacing
  - **Frequency location**: the offset between BWP and a reference point is implicitly or explicitly indicated to UE based on common PRB index for a give numerology
  - **Bandwidth size**: in terms of PRBs
  - **CORESET**: required for each BWP configuration in case of single active DL bandwidth part for a given time instant

# Bandwidth Part Operation

## Bandwidth Parts

### – Definition of **active BWP**:


- A UE is only assumed to receive/transmit within active DL/UL bandwidth part using the associated numerology
- UE expects at least one DL bandwidth part and one UL bandwidth part being active
  - A UE can assume that PDSCH and corresponding PDCCH (PDCCH carrying scheduling assignment for the PDSCH) are transmitted within the same BWP

### – **BWP activation/deactivation**:

- Activation by dedicated RRC signaling
- Activation/deactivation by DCI with explicit indication
- Activation/deactivation by a timer for a UE to switch its active DL bandwidth part to a default DL bandwidth part

# Example of Bandwidth Part Operation


## Bandwidth Parts




# Bandwidth Part Use Cases

## Bandwidth Parts


### 1) Supporting reduced UE bandwidth capability



### 2) Supporting reduced UE energy consumption




### 3) Supporting FDM of different numerologies




# Bandwidth Part Use Cases

## Bandwidth Parts

### 4) Supporting non-contiguous spectrum



### 5) Supporting forward compatibility





# Key Things to Learn...

## Bandwidth Parts

- **Bandwidth part definition**

- How are bandwidth parts configured?
- How are bandwidth parts activated/deactivated?

- **Motivation for the introduction of bandwidth parts**

- Why are bandwidth parts a great NR feature?
- Use cases for bandwidth parts

# Contents

Understanding the 5G NR Physical  
Layer

Page 106

- 3GPP NR Introduction & Roadmap
- Waveform, Numerology and Frame Structure
- Initial Access and Beam Management
- Downlink and Uplink Channels
- Bandwidth Parts
- **Summary**

# Summary

- NR introduced on **Release-15**
  - **December'17** release:
    - Only for NSA
    - eMBB and low latency aspects of URLLC
    - Only essential features
  - **June'18** release:
    - Final Release-15 delivery
    - NSA and SA connectivity scenarios
    - Rest of features
- Study for **Release-16** to start on 2018
- **Future-proof and forward-compatible**

# LTE vs. NR Comparison

## Summary

	LTE	New Radio
<b>Maximum Bandwidth (per CC)</b>	20 MHz	50 MHz (@ 15 kHz), 100 MHz (@ 30 kHz), 200 MHz (@ 60 kHz), 400 MHz (@ 120 kHz)
<b>Maximum CCs</b>	5 (currently)	16 (allowed BW and CCs combinations TBD)
<b>Subcarrier Spacing</b>	15 kHz	$2^n \cdot 15$ kHz TDM and FDM multiplexing
<b>Waveform</b>	CP-OFDM for DL; SC-FDMA for UL	CP-OFDM for DL; CP-OFDM and DFT-s-OFDM for UL
<b>Maximum Number of Subcarriers</b>	1200	3300
<b>Subframe Length</b>	1 ms (moving to 0.5 ms)	1 ms
<b>Latency (Air Interface)</b>	10 ms (moving to 5 ms)	1 ms
<b>Slot Length</b>	7 symbols in 500 $\mu$ s	14 symbols (duration depends on subcarrier spacing) 2, 4 and 7 symbols for mini-slots
<b>Channel Coding</b>	Turbo Code (data); TBCC (control)	Polar Codes (control); LDPC (data)
<b>Initial Access</b>	No beamforming	Beamforming
<b>MIMO</b>	8x8	8x8
<b>Reference signals</b>	UE Specific DMRS and Cell Specific RS	Front-loaded DMRS (UE-specific)
<b>Duplexing</b>	FDD, Static TDD	FDD, Static TDD, Dynamic TDD

# NR Key Technologies

## Summary

### Waveforms and Frame Structure

Scalable Numerology

Numerology Multiplexing

Dynamic TDD

### Low Latency

Mini-Slots

CBG Retransmissions

Front-Loaded DMRS

### Millimeter Wave

Beam-Sweeping

Beam Management

Massive MIMO

### Future Proof – Forward Compatible

Bandwidth Parts

Reduced Always-On Signals

No Fixed Time Relationship Between Channels

# Links

## Summary

- 3GPP Webpage ([www.3gpp.org](http://www.3gpp.org))
- 3GPP RAN1 Documents ([www.3gpp.org/ftp/tsg\\_ran/WG1\\_RL1](http://www.3gpp.org/ftp/tsg_ran/WG1_RL1))
- The METIS 2020 Project ([www.metis2020.com](http://www.metis2020.com))
- The 3G4G Blog ([blog.3g4g.co.uk](http://blog.3g4g.co.uk))
- Keysight Solutions ([www.keysight.com/find/5G](http://www.keysight.com/find/5G))

